




HEWLETT  
PACKARD



2621A/P Interactive Terminal



owner's manual

## **Congratulations.....**

You have selected Hewlett-Packard's Model 2621 Interactive Terminal. The HP 2621 is a simple, efficient terminal designed to serve your requirements for the processing of alphabetic and/or numeric data.

This owner's manual is provided to acquaint you with the characteristics of this terminal and to aid you in using them to your advantage. Included in the manual are instructions for installing and using your terminal. In addition to installation and usage information, reference material is provided for including this terminal as an input/output device within a computer system environment.

For information regarding repair and functional operation, see the HP 2621 Interactive Terminal Service Manual, HP Part No. 02620-90002.

**HP Computer Museum**  
**[www.hpmuseum.net](http://www.hpmuseum.net)**

**For research and education purposes only.**

# CONTENTS

A Guide To Using This Manual ..... iii

## **Introducing The HP 2621** ..... 1-1

Display Screen ..... 1-2  
Display Memory ..... 1-2  
Keyboard ..... 1-2  
Function Keys ..... 1-2  
Configuration ..... 1-3  
Data Communications ..... 1-3  
Self-Test ..... 1-3

## **How To Get Started** ..... 2-1

Identifying Options and Accessories ..... 2-1  
Preparing Your Terminal For Use ..... 2-2  
Power Switch (On/Off) ..... 2-3  
    ON ..... 2-3  
    OFF ..... 2-3  
What To Do In Case Of Difficulty ..... 2-3

## **The Terminal's Display Characteristics** ..... 3-1

Screen ..... 3-1  
Memory ..... 3-2  
Display Enhancement ..... 3-3

## **The Terminal's Keyboard** ..... 4-1

Character Set Group ..... 4-1  
Numeric Pad Group ..... 4-3  
    NUM Key Unshifted Mode ..... 4-3  
    NUM Key Shifted Mode ..... 4-3  
Function Key Group ..... 4-4  
    Function Key Unshifted Mode ..... 4-4  
    Labels Key ..... 4-7  
        Screen Labels ..... 4-7  
        Labels Key, Unshifted ..... 4-8  
        Labels Key, Shifted ..... 4-8  
        Labels Key, Control Shifted ..... 4-8  
    Function Key Shifted Mode ..... 4-9  
        Configuration Function Set ..... 4-12  
        Printer Control Function Set ..... 4-12



TAB and Margin Control Function Set ..... 4-12  
Edit Control Function Set ..... 4-13

## **Using The Terminal As An Input/Output Device** ..... 5-1

Configuration Function Keys ..... 5-2  
    Baud Rate Configuration ..... 5-5  
    Parity Configuration ..... 5-5  
    Duplex Configuration ..... 5-5  
    Strap Configuration ..... 5-6  
    Handshake Configuration ..... 5-10  
    Hz Configuration ..... 5-11  
    Start Column Configuration ..... 5-11  
    Return Key Configuration ..... 5-11  
Terminating the Configuration Mode ..... 5-11  
Selecting The Remote Operating Mode ..... 5-12  
Modem Considerations ..... 5-12  
Sending Data To The Computer ..... 5-12  
Receiving Data From The Computer ..... 5-14  
Escape Code Sequences ..... 5-14

## **The HP 2621P** ..... 6-1

Options and Accessories ..... 6-1  
Thermal Printer Paper ..... 6-2  
    Paper Loading ..... 6-2  
Printer Control Functions ..... 6-3  
Printer Control Escape Sequences ..... 6-6

## **Preventive Maintenance** ..... 7-1

Cleaning The Display and Keyboard ..... 7-1  
Battery Maintenance ..... 7-1

## **Diagnosing Problems** ..... 8-1

Resetting the Terminal ..... 8-3

## **HP ASCII-coded Character Set** ..... A-1

## **Cable Connector Pin Assignments** ..... B-1

## **Primary Status** ..... C-1

## **Cursor Sensing** ..... D-1

## **Terms Used In This Manual** ..... Glossary-1

## **Index** ..... I-1

## Figures

Figure 2-1.	Identification Label, Rear Panel	2-1
Figure 2-2.	Power Switch and Connector Positions, Rear Panel	2-2
Figure 2-3.	Initial Screen Display	2-3
Figure 4-1.	Keyboard Character Set Group	4-1
Figure 4-2.	Keyboard Numeric Pad Group	4-3
Figure 4-3.	Keyboard Function Key Group	4-4
Figure 4-4.	Screen Labels Structure	4-7
Figure 5-1.	DC1/DC2 Handshake Protocol	5-7
Figure 6-1.	Printer Mechanism	6-2
Figure 6-2.	Printer Test Display	6-5
Figure 7-1.	Battery Location, Rear Panel	7-1
Figure 7-2.	Battery Support	7-3
Figure 8-1.	Self-Test Screen Display	8-1

## Tables

Table 2-1.	HP 2621A Options	2-1
Table 2-2.	HP 2621A Accessories	2-1
Table 5-1.	Strapping Configuration	5-6
Table 5-2.	DC1/DC2 Handshake Protocol Strapping Effects	5-9
Table 5-3.	Data Communications Handshake Configuration	5-10
Table 5-4.	Escape Sequences, Cursor and Screen Control	5-14
Table 5-5.	Escape Sequences, Terminal Control	5-14
Table 5-6.	Escape Sequences, TAB and Margin Control	5-15
Table 5-7.	Escape Sequences, Edit Control	5-15
Table 5-8.	Escape Sequences, Miscellaneous Control	5-16
Table 5-9a.	Escape Sequences, Cursor Sensing	5-16
Table 5-9b.	Escape Sequences, Cursor Address Control	5-17
Table 5-10.	Escape Sequences, Display Enhancement Control	5-18
Table 5-11.	Escape Sequences, Screen Labels Control	5-18
Table 5-12.	Escape Code Sequences Transmitted by the HP 2621	5-19
Table 5-13.	ASCII-coded Control Codes	5-20
Table 6-1.	HP 2621P Options	6-1
Table 6-2.	HP 2621P Accessories	6-1
Table 6-3.	HP 2621P Escape Sequences, Printer Control	6-6
Table 8-1.	Diagnostic Error Messages	8-1
Table C-1.	Status Byte Interpretation	C-1

## A Guide to Using This Manual

This owner's manual is written to introduce you to the HP 2621A and 2621P Interactive Terminals. The HP 2621A is the basic terminal while the HP 2621P provides a self-contained thermal printer together with the basic terminal.

Within this manual, the term HP 2621 is used to reference features and capabilities applicable to either version. The term HP 2621A or HP 2621P is used to reference features and capabilities unique to either the A version or the P version, respectively.

Detailed information about specific features is included so that you may use this manual as a reference guide to operating the terminal. An index of terms and phrases is included at the back of the manual to assist you in quickly locating reference material.

This owner's manual includes the following sections:

**Section I - Introducing the HP 2621.** This section is a general description of the terminal and briefly lists its features and capabilities.

**Section II - How to Get Started.** Information is given in this section about how you can identify the options and accessories delivered with your terminal. In addition to this information, you are instructed about how to prepare your terminal for use.

**Section III - The Terminal's Display Characteristics.** This section contains a complete description of the display screen and display memory. Included is information about the initial state of the display after the main power switch is turned on, screen and memory organization, and cursor positioning.

**Section IV - The Terminal's Keyboard.** A description of the keyboard is provided in this section. Examples of keyboard interaction with the terminal's display are included.

**Section V - Using the Terminal as an Input/Output Device.** This section describes the data communication capabilities of the HP 2621. Included is information about the terminal's configuration, operating modes, and transmission of data between the HP 2621 and an external data processing device.

**Section VI - The HP 2621P.** This section describes the HP 2621P Interactive Terminal with self-contained thermal printer. A complete description of operating procedures together with reference material is included.

**Section VII - Preventive Maintenance.** This section contains information about the care and cleaning of your terminal to keep it in the best operating condition.

**Section VIII - Diagnosing Problems.** Problem conditions and the messages associated with these conditions are discussed in this section. In addition to this information, this section includes a description of the self-test feature, recovery (resetting the terminal) in case of an error, and information about where to get help if you have difficulty solving a problem.

**Appendix Section -** This section contains a reference table in Appendix A that includes the ASCII-coded character set, and control codes and escape sequence codes. Appendix B contains tables that list cabling assignments. Primary status information is presented in Appendix C and Cursor Sensing is described in Appendix D.



# Introducing the HP 2621

# Section I

The HP 2621 Interactive Terminal is designed to provide you with a simple, efficient character-mode terminal device. This terminal offers many powerful features that are easy to use.

Among the features offered by the HP 2621 are:

## Display Memory and Screen

- Bright, Clear Screen Display
- 24 Line by 80 Character Display Area
- Uppercase and Lowercase Character Set
- Displayable Control Code Characters
- Character-by-Character Underlining
- Cursor Position Relocation
- 48 Line by 80 Character Display Memory (Two Pages)
- Roll, Home-up, and Home-down Display Control

## Keyboard

- 68 Key Typewriter-style Keyboard Layout
- Embedded Calculator-style Numeric Key Pad
- Eight Variable Function Keys
- Labels Key

## Function Keys

- Redefinable Configuration
- Self-test
- Clear Line
- Clear Display
- Printer Output Control (HP 2621P Only)
- Display Function Code Enable/Disable
- Tabulation and Margin Control
- Text Editing Control
- Transmit Pre-defined Escape Sequences

## Configuration

- Screen Displayable Configuration Data
- Redefinable Configuration via Function Keys
- Data Transmission Baud Rate Control
- Data Parity Control
- Duplex Control
- Strapping Control
- Communications Handshake Control
- User-definable RETURN Key
- User-definable Transmission Start Column
- Configuration Memory Protection

## Data Communications

- Data Transfer Rate up to 9600 Baud
- Character or Line Mode Transfers
- Support of EIA RS232C or CCITT V.24 Interface
- Full Duplex Data Transmission





## Display Screen

The HP 2621 Interactive Terminal has a screen with a 6 X 8 inch viewing area capable of displaying up to 1,920 characters in 24 lines of 80 character positions. Each character is formed by a 7 x 9 dot matrix within a 9 x 15 dot cell. This permits the precise formation of complex character symbols with ample separation between adjacent characters, both vertically and horizontally. The combination of these features gives you a bright, easy-to-read display.

Refer to Section III for a detailed description of the display screen.

## Display Memory

Your terminal's display memory can store up to 3,840 characters (48 lines of 80 character positions). A "page" of data is the maximum number of lines that can be displayed on the screen at one time (24 lines). Thus, you can store up to two pages of data in display memory. You can examine any portion of text within display memory by using the home-up, home-down, or roll Function keys on your keyboard.

A detailed description of display memory is contained in Section III.

## Keyboard

The HP 2621 keyboard is a separate unit that is linked to the display portion of the terminal via a flexible cable. The keyboard layout is similar to that used for standard office typewriters. It has 68 keys that include eight Function keys, and a Labels key. The remaining keys support the ASCII-coded character set. A numeric key pad similar to that used for calculators is embedded within the alphanumeric keys. Included within the keyboard unit is a speaker used to sound the terminal's bell tone.

Refer to Section IV for a detailed description of the keyboard.

## Function Keys

The Function keys are the eight light-colored keys located across the top of the keyboard and the Labels key (an unmarked light-colored key located to the right of the keyboard). These keys provide you with access to several sets of functions. Similar to the other keys on the keyboard, the Function keys are used either unshifted or shifted.

Unshifted, the keys perform cursor and screen control functions that are labeled directly on the key caps.

Shifted, these keys perform the functions indicated by a screen label associated with each key. The screen labels are displayed in inverse video across the bottom of the screen (row 25). The labels are selected by using the Labels key. Some of the screen labeled Function keys are transition keys that result in a branch to a new set of labels. For example, the `[config]` and `[edit]` Function keys.

See Section IV for a detailed description of the Function keys.

## Configuration

The HP 2621 provides you with the ability to change the terminal's configuration directly from the keyboard using a set of Function keys. You can cause the terminal's current configuration to be displayed on the screen in a coded format and then make changes to the configuration simply by pressing the appropriate Function key. The portion of memory used to store this configuration data is nonvolatile. A battery is used to protect this portion of memory whenever the main power source should be intentionally or accidentally shut off.

Section V contains detailed information about the configuration of your terminal.

## Data Communications

You can transfer data to and from a host computer in Character mode (character-by-character) using the terminal as a completely interactive device. In addition to Character mode, you may select Line mode operation (transmit data to the computer a line at a time). In Line mode, you can compose a line of data, then verify and correct the data before you transmit it to the computer.

The terminal operates at a data transfer rate of up to 9600 baud and offers asynchronous point-to-point data communications using the EIA RS232C and CCITT V.24 communications interface specifications.

Connection to the computer is direct or through a modem. In addition to these features, the HP 2621P provides an integral thermal line printer which can be used to produce a permanent copy of your data communications transactions.

Section V contains detailed information about data communications.

## Self-Test

This terminal is engineered for high reliability, ease of testing, and, if required, rapid repair. By using the Test function, you get a GO/NO GO indication of the terminal's operating condition. See Section VIII for information about the terminal's Self-test function.



## How To Get Started

## Section II

### Identifying Options and Accessories

Any options you request when you order your terminal are delivered installed within the terminal. Accessories, such as data communication cables, are delivered with the terminal, usually in the same carton but packaged separately. Upon delivery of your terminal, verify that the options and/or accessories you ordered are included in the shipment received.

An identification label is located on the rear panel of your terminal (see Figure 2-1). The first section of this label states the power requirements of the terminal. The next section states the model number and the serial number. The third section lists any options included with the terminal.

Table 2-1 is a list of options available for the HP 2621A Interactive Terminal (see Section VI for HP 2621P options).

Table 2-2 is a list of accessories available for the HP 2621A Interactive Terminal (see Section VI for HP 2621P accessories).




Figure 2-1. HP 2621 Identification Label, Rear Panel

When communicating with Hewlett-Packard regarding your terminal, specify the model, serial, and option numbers to ensure accurate identification by Hewlett-Packard. A list of Hewlett-Packard Sales and Service Offices is included at the back of this manual.

#### NOTE

If your terminal is already installed, you can ignore the following material and proceed to "Power Switch (ON/OFF)".

Table 2-1. HP 2621A Options

Option No.	Description
013	50Hz, 240V, 0.3A, 75W Power
014	60Hz, 100V, 0.6A, 60W Power
015	50Hz, 220V, 0.4A, 75W Power
016	50Hz, 100V, 0.6A, 60W Power

Table 2-2 HP 2621A Accessories

Accessory No.	Description
13222N	U.S.A. Modem Cable (Male Connector)
13222M	European Modem Cable (Male Connector)
13222C	RS232C Cable (Female Connector)
13222W	HP 300 Cable (Female Connector)
13222Y	Three Wire Cable (Male Connector)
13265A	300 Baud Modem
13266A	Current Loop Converter


## Preparing Your Terminal for Use

This terminal is designed to operate in a wide range of environments. It is self-contained and provides easy access to the operator controls so that normal installation does not require that you open the unit.

### CAUTION

The terminal should be opened only by a qualified service person. Please refer to the HP 2621 Service Manual, HP Part No. 02620-90002.

To install your terminal, complete the following steps:



AIR FLOW

Step 1. Place the terminal on any sturdy, convenient surface such as a desk, table, or stand designed for such a purpose. Avoid plush or spongy surfaces that might restrict the flow of air through the vents in the base of the terminal. For example, do not use a typewriter pad beneath the terminal.

Step 2. Connect and secure the keyboard cable hood connector to the socket connector labeled KYBD on the terminal's rear panel (see Figure 2-2).

Step 3. This step is required to connect the terminal to an external data processing device such as a computer. Connect and secure the data communications cable hood connector to the socket connector labeled DATA COM on the terminal's rear panel. The cable hood connector must be securely held in place by the wire clamps provided with the socket connector.

Connect the other end of this cable to the appropriate external device.

Step 4. Set the main power switch on the terminal's rear panel (see Figure 2-2) to the OFF position.

Connect the power cord to the connector located just below the main power switch.

Step 5. ENSURE THAT THE VOLTAGE TO BE SUPPLIED MATCHES YOUR TERMINAL'S POWER REQUIREMENTS (see the power requirements label on the rear panel of the terminal).

Plug the 3-prong power connector into the outlet for your main power source.

### CAUTION

For your safety, a 3-prong grounded power outlet always must be used.




Figure 2-2 HP 2621 Power Switch and Connector Positions, Rear Panel

## Power Switch (ON/OFF)

### ON

Step 1. When the installation of your terminal is completed, set the main power switch on the rear panel (see Figure 2-2) to the ON position.

After approximately 15 seconds, the terminal is ready to use. Figure 2-3 illustrates the condition of the display screen as it appears following the initial application of power to the terminal.

As shown in Figure 2-3, when the terminal is ready to use, the cursor is displayed in screen column 1, row 1. In addition to the cursor, the first level of function key labels is displayed across the bottom of the screen.

The battery that protects nonvolatile memory may be accidentally jarred loose during shipment or unpacking. In this case, the terminal comes up initially in configuration mode when power is supplied. If this occurs, ensure that the battery pack is securely seated (see Section VII for instructions about removing and replacing the battery pack).




Figure 2-3. HP 2621 Initial Screen Display

Step 2. (Optional) Try using the Self-test function to see the result. Press and hold down **SHIFT** while you press the function key associated with the screen label TEST (that is, key **↵**). A pattern of ASCII characters is written to the screen. This pattern should be similar to the test pattern shown in Section VIII if your terminal is operating properly.

### OFF

To shut off your terminal, simply set the main power switch to the OFF position.

#### NOTE

If you intend to use the terminal interactively as an input/output device for a computer, you must configure the terminal to match the requirements of the computer. Detailed information about configuring the terminal is presented in Section V.


## What To Do In Case of Difficulty

If the key or function you try does not work properly, or if an error message appears on the screen, refer to Section VIII. A list of messages and their meaning is given there. In addition to the list of messages, Section VIII contains information about error recovery, testing the terminal, and where to get service assistance should you require it.

Each time you switch the main power ON, it is possible that the terminal will start up either in Configuration mode or in "continuous" Self-test mode.

If the terminal starts up in Configuration mode (that is, configuration data and function key labels are displayed on the screen), it is likely that the memory-protect mechanism for nonvolatile memory failed while the main power was off. Check that the battery is functioning properly (see Section VII for instructions).

If the terminal starts up with the Self-test repeating continuously, simply reset the terminal (hold down **SHIFT** and **CTRL** while pressing **BREAK**). This action halts execution of continuous Self-test.




## The Terminal's Display Characteristics

The display portion of your terminal consists of the display screen (where data appears as alphanumeric and special control characters), and display memory (where the displayable data is stored).

### Screen

The display screen is capable of showing up to 24 contiguous lines of display memory data. For the HP 2621, these 24 lines are considered to be one page of data.

The screen actually provides 25 rows of 80 character positions each for the display. Rows 1 through 24 are used to display the content of display memory. Row 25, at the bottom of the screen, is used to display the currently active set of function key labels, a current cursor position column indicator, and any error messages that may be generated.







## The Terminal's Display Characteristics

### Memory

Display Memory can accommodate up to 48 lines of data (two pages). Each line has 80 character positions.

When you enter lines of data into memory, each line appears in its proper line position on the display screen until you have filled one page (24 lines). At this point, display memory rolling begins. When you enter line 25, the first line in Page 1 is rolled off the top of the display screen (it still exists within memory) and line 25 appears at the bottom of your screen. You can enter up to 48 lines into memory and examine them on the screen by using the Roll Function keys. Once you exceed 48 lines, the line first entered (at the "top" of display memory) is discarded to make room for the new line (at the "bottom" of display memory).

Note that if you fill 48 lines of memory with data and press  (home cursor down), you will lose the first line of data in memory because the home down operation positions the cursor to a blank line following the last data line in memory. One line is deleted from the top of memory to accomplish the home down operation.



## Display Enhancement

You can enhance the display of data by placing an underline in any character position on your screen. You accomplish this by defining an enhanced field within a display line. Once you define the beginning of an enhanced field, the display enhancement remains in effect until the end of the current line or until you define the end of the enhanced field, whichever occurs first. A field consists of one or more character positions in any display line.

To define an enhanced field, position the cursor to the column where you want the field to begin, and then enter the following escape code key sequence:

```
esc & d A      (the last or terminating
                character may be any up-
                percase character from
                the letter set A through
                O).
```

The cursor marks the beginning of the enhanced field. Characters entered subsequent to this column position appear underlined on the screen until the end of the line or until you terminate the enhanced field which ever occurs first.

To terminate the enhanced field, enter the following escape code key sequence:

```
esc & d e
```

When you insert or delete a character in an enhanced field, the result is the same whether the underline enhancement is enabled or disabled. For insert or delete operations, an underline character is inserted into or deleted from any enhanced field. When you replace a character, the result depends upon whether the display enhancement is enabled or disabled. The display enhancement must be enabled to replace any character with an underlined character.

Note that the underline enhancement differs from the UNDRLINE function (see "Edit Control Function Set" in Section IV).

The underline Enhancement causes any character entered to appear underlined. The UNDRLINE function places an underline beneath any existing character.

### Exercise

Make sure that the terminal is in local mode (REMOTE disabled). Then, display data on the screen and edit it. For example, sit at the keyboard and enter your name. Notice that the cursor moves across the screen character—by—character as you type. This action shows you where the next display character will appear when you press a key.

```
Alexander Hamilton_
```

**Changing A Character.** To change a character displayed on the screen to another character, position the cursor under the character to be changed (using **↑**, **←**, **→**, **↓** keys). Now press the desired character key. The original character is replaced by the new character entered, both on the screen and in display memory.



# The Terminal's Keyboard

Before learning how to transfer data, you should become familiar with the terminal's keyboard. This simple, compact keyboard consists of the following functional groups:

- Character Set Group. The layout of these keys is similar to a standard typewriter keyboard. In addition to the alphanumeric character keys, this group includes typical data terminal keys such as **BREAK**, **CTRL**, **ENTER**, and so forth.
- Numeric Pad Group. This group is a calculator-type numeric key pad that is embedded into the character set keys. You may use this pad for entering large amounts of numeric data such as that required for financial reporting.
- Function Key Group. This group of keys is used to access screen and cursor control, and special functions that are available in the HP 2621.

## Character Set Group

The alphabetic, numeric, symbolic, keyboard control, and data transfer keys are located in the Character Set Group. This is the largest group of keys. The character set is made up of 128 ASCII-coded characters. This includes the uppercase and lowercase alphabetic characters, numeric characters, punctuation and commercial symbols and control codes. The keyboard can generate the entire ASCII character code set (see Appendix A). Figure 4-1 shows the Character Set Group.

The standard character symbols are indicated on the key caps. The **SHIFT** key selects the uppercase or shifted characters. The **BACK SPACE** and **RETURN** keys are used in the same manner as those same keys on a typewriter. The **RETURN** key can be configured to transmit a two-character string each time it is pressed (See Section V).




Figure 4-1. HP 2621 Keyboard Character Set Group

## The Terminal's Keyboard

The **TAB** key is used to generate a move to a TAB stop position within the current row or to the next or previous row if no TAB stop exists in the current row. Used by itself, tabular moves may be performed to the right along the row. Used in combination with the **SHIFT** key, tabular moves may be performed to the left along the row. The TAB stop positions are set via a Function key (see "Function Key Group") or by an escape code sequence.

When you enter **TAB** (TAB right), the cursor skips forward to the next tabulation stop to the right of the current cursor position, or to the default TAB stop at the left margin of the next row if no stops exist in the current row.

When you enter **SHIFT** and **TAB** (TAB left), the cursor skips backward to the next tabulation stop to the left of the current cursor position, or to the first TAB stop encountered in the previous row if no stops exist in the current row.

A Power Off followed by a Power On (or holding down **CTRL** and **SHIFT** while pressing **BREAK**) resets the terminal to default conditions with a TAB stop at the left margin (in this case, column 1).

The **CAPS** key is a toggle switch that changes state each time you press it. When the terminal is generating lowercase alphabetic characters, press the **CAPS** key once to cause a shift to uppercase. Only the alphabetic characters A through Z are affected. Press it again to return to lowercase. Note that the **SHIFT** key remains active even when you have enabled the **CAPS** key. That is, if you have enabled the **CAPS** key, pressing the **SHIFT** key causes a shift to lowercase for as long as the **SHIFT** key is held down. The action of this key differs from that of the Caps Lock Function key (see Section V). A Power Off followed by Power On or holding down **CTRL** and **SHIFT** while pressing **BREAK** resets the terminal to default conditions with the **CAPS** key disabled.

THE **DEL** key has two purposes. Used by itself, it generates the ASCII escape character. Used in combination with the **SHIFT** key, it generates the ASCII delete character.

The **CTRL** key is used in combination with other keys to generate control sequences.

The **ENTER** key is used to initiate a line data transfer via the data communications interface within the terminal. For Line mode and Modify mode, the data transmitted via the **ENTER** key is appended with the same string configured into the **RETURN** key (see Section V). The **ENTER** key is ignored in Local mode (the REMOTE function disabled).

The **BREAK** key is used to interrupt data communications between the terminal and an external host computer. To reset the terminal to the initial Power On state, press and hold **CTRL** and **SHIFT** and then press the **BREAK** key. When REMOTE is enabled, pressing this key has no effect on the Data Communications line. The **BREAK** key is ignored in Local mode (the REMOTE function disabled).

Note that the use of the space bar on this terminal is normally destructive. A blank space is placed in the current character position (marked by the cursor) whenever you press the space bar.

### Exercise

Make sure the terminal is in Local mode (REMOTE disabled). Then, type in a few lines of text to get used to the keyboard. This part of the terminal works much like a typewriter. Note that you can use the backspace key to overwrite and change characters on the screen.

## Numeric Pad Group

This group of keys supplements the standard keyboard numeric keys. The numeric pad consists of 12 keys that are embedded into the Character Set Group, and a **NUM** key used to enable or disable the numeric pad. Figure 4-2 shows the location of the keys in the Numeric Pad Group.

The numeric pad includes the characters 0 through 9, decimal point (period), and comma. These keys are arranged in a format similar to that used for calculators. The numeric pad character symbols are imprinted on the key caps. The characters 0 through 6 appear in the lower left corner of the alphabetic character keys M, J, K, L, U, I, and O, respectively. The remaining numeric pad characters (7 through 9, decimal point, and comma) make use of those same characters from the Character Set Group.

Note that although use of the **NUM** key enables the Numeric Pad Group of keys, all of the other keys on the keyboard remain active and, if pressed, generate a character.

The **NUM** key has both an unshifted and shifted mode, as follows:

### **NUM** Key Unshifted Mode

When used by itself (unshifted), the **NUM** key enables the Numeric Pad Group of keys. Press **NUM** and hold it down for as long as you want access to the numeric pad. Release **NUM** to return to the standard character set.

### **NUM** Key Shifted Mode

When the **NUM** key is pressed in combination with the **SHIFT** key, access to the Numeric Pad Group is "locked" into the enabled state. When you have finished using the numeric pad and wish to return to the standard character set, simply press and release the **NUM** key to disable the pad.




Figure 4-2. HP 2621 Keyboard Numeric Pad Group

## Function Key Group

The Function Key Group consists of eight Function keys located across the top of the keyboard, and a Labels key located at the right edge of the character set group. Figure 4-3 shows the Function Key Group.

### Function Key Unshifted Mode

When these keys are used by themselves (unshifted mode) they cause execution of the cursor or text control function imprinted on the key cap. The unshifted mode functions are:












Figure 4-3. HP 2621 Keyboard Function Key Group

Key	Function
	Home Cursor Up — Positions the cursor to the top left corner of the display screen (row 1, left margin) and rolls the text in display memory down as far as possible so that the first line of text in memory appears in row 1 of the screen.
	Home Cursor Down — Positions the cursor to the bottom left corner of the display screen (row 24, left margin) and rolls the text in display memory up as far as possible so that the last line of text in memory plus one blank line appears at the bottom of the screen. If there are fewer than 24 lines of text in display memory, the cursor is positioned to the left margin of a blank line following the last screen row containing text. In the home down position, the cursor is always in a blank screen row.


Key	Function
	<p>Roll Text Up — Each time this key is pressed, the text in display memory is rolled upward one row on the screen. The top row of text is rolled off the screen but is not destroyed. If you hold this key down, text continues to roll upward until the last line of text in memory appears on the screen, at which time the rolling action stops. Normally, the rolling action stops whenever there is no additional data to display.</p>
	<p>Roll Text Down — Each time this key is pressed, the text in display memory is rolled downward one row on the screen. The bottom row of text may be rolled off the screen but is not destroyed. If you hold this key down, text continues to roll downward until the first line of text in memory appears on the screen, at which time the rolling action stops. Normally, the rolling action stops whenever there is no additional data to display.</p>
	<p>Move Cursor Up — Each time this key is pressed, the cursor is moved upward one row in the current column position. If you hold the key down, upward movement continues row-by-row. When the cursor is in screen row 1, any text in memory is rolled down one line. This action continues as long as the key is held down until the first line of text in memory is reached.</p>



## The Terminal's Keyboard

Key	Function
	<p>Move Cursor Left — Each time this key is pressed, the cursor is moved one column to the left in the current screen row. If you hold the key down, the cursor continues to move left. When the cursor is in column 1 of the row, it will wrap around to column 80 of the preceding row. When the cursor is in column 1 of row 1, pressing this key causes the text in display memory to be rolled down one line and the cursor moves to column 80 of the new line. This action continues as long as the key is held down until column 1 of the first line of text in display memory is reached.</p>
	<p>Move Cursor Right — Each time this key is pressed, the cursor is moved one column to the right in the current screen row. If you hold the key down, the cursor continues to move right. When the cursor is in column 80 of the row, it will wrap around to column 1 of the succeeding row. When the cursor is in column 80 of row 24, pressing this key causes the text in memory to be rolled up one line and the cursor moves to column 1 of the new line. This action continues as long as the key is held down until column 80 of the last line of text in display memory is reached.</p>
	<p>Move Cursor Down — Each time this key is pressed, the cursor is moved downward one row in the current column position. If you hold the key down, downward movement continues row-by-row. When the cursor is in screen row 24, any text in display memory is rolled up one line. This action continues as long as the key is held down until the last line of text in memory is reached.</p>


**Labels Key**

This key is located to the right of the character set group and is the only unmarked key on the keyboard (see Figure 4-3). The  key is used to manipulate the screen display of the Function labels.

**Screen Labels**

There are several levels of screen displayed function labels. The initial display is a primary set of screen labels. The structure of the screen labels function set is shown in Figure 4-4.

**NOTE**

To return to the primary set of labels from any other sets, press the  key.




Figure 4-4. HP 2621 Screen Labels Structure

## The Terminal's Keyboard

The **ESC** key is used by itself (unshifted), in combination with the **SHIFT** key (shifted), or in combination with the **CTRL** and **SHIFT** keys (control shifted) to obtain various results, as explained in the following paragraphs.

### **ESC** Key, Unshifted

Usually, you use the **ESC** key to return to the primary set of screen labels from one of the subsets. You also can turn on the display of screen labels when it has been shut off.

When either of these conditions exists (the screen labels display is a subset such as config, tab/margn, or edit, or the screen labels display has been shut off), press the **ESC** key by itself to cause the primary set of labels to return to the screen. For results when the f1—f8 subset is displayed, see the following section.

### **ESC** Key, Shifted

You use the **ESC** key in conjunction with the **SHIFT** key to cause the display of the f1—f8 screen labels:

**f1** **f2** **f3** **f4**

When the primary set of screen labels, or any subset of screen labels (except the config subset) is displayed, press and hold down the **SHIFT** key and then press the **ESC** key to cause the display of the f1—f8 screen labels subset.

To terminate the f1—f8 function subset, simply press the **ESC** key by itself. Control returns to the set of screen labels (either primary or a subset) from which you requested the f1—f8 screen labels.

For example, if you were using the TAB and margin control functions and had the tab/margn screen labels displayed when you pressed the **SHIFT** and **ESC** keys, the tab/mrgn screen labels are replaced by the f1—f8 screen labels. Now, when you press the **ESC** key by itself, the screen labels display returns to the tab/mrgn screen labels. You must press the **ESC** key once more (unshifted) to get to the primary set of screen labels.

**f5** **f6** **f7** **f8**

### Labels Key, Control Shifted

To shut off the display of the screen labels, press and hold down the **CTRL** and **SHIFT** keys and then press the **ESC** key. The display of the screen labels is shut off until you press the **ESC** key (or shifted **ESC** key) once again.

The screen labels display line includes an "active modem" indicator asterisk and a cursor position column indicator. These indicators are shut off whenever the screen labels are shut off. See "Function Labels, Shifted Mode" for a description of the indicators. If you are using the terminal to communicate with a computer via a modem and the "active modem" indicator is required by your facility, do not shut off the screen labels.

## Function Key Shifted Mode

When the function keys are used in combination with the **SHIFT** key (shifted mode), they cause execution of the functions named by the function labels that are displayed at the bottom of your screen.

The primary Function labels appear as follows:

```
config  TEST  CLR LINE CLR DSPY  a nn  printer  DSPY FN  tab/mrgn  edit
```






- a* An asterisk is displayed in this position if the Data Set Ready control line (RS232C CC line or CCITT V.24 107 line) is high (true). This indicator disappears from the display if the Data Set Ready control line goes low (false), or if the screen labels display is shut off (control shifted Labels key).




Normally, this indicator is used when your terminal is connected to a computer via a modem. The indicator signals that the modem line is active. Do not shut off the screen labels display if your facility requires the use of the active modem indicator.

- nn* A number appears in this position that identifies the current column position of the cursor (in the range 1–80). This column number is incremented or decremented each time the cursor is moved to a new position on the screen.

The shifted mode functions are described beginning on the following page:

## The Terminal's Keyboard

Function Label	Key Stroke	Function
[config]	Shifted 	Set the terminal into Configuration mode: The current configuration is displayed on the screen together with a set of configuration function key labels that you may use to manipulate the terminal's configuration. The configuration data requires three lines of display memory. When memory is full (48 lines of data), you will lose data from memory upon requesting Configuration mode. Section V contains details about the configuration of the terminal.
[TEST]	Shifted 	Perform a diagnostic test of the terminal: check ROM, Video RAM, Program RAM, Keyboard Chip, then display the full character set and the status bytes. If an error condition is encountered, an appropriate message is displayed. Section VIII contains a description of the Test function.
[CLR LINE]	Shifted 	Clear Line — this function clears (erases) the content of the current line from the character marked by the cursor through the last character in the line. Move the cursor to the character position where you want the line deletion to begin and press the shifted Function key associated with this label.
[CLR DSPY]	Shifted 	Clear Display — this function clears (erases) the content of display memory from the character marked by the cursor through the last character in memory. Move the cursor to the character position where you want the memory deletion to begin and press the shifted Function key associated with this label.
[printer]	Shifted 	Applicable only to the HP 2621P Interactive Terminal. See Section VI. This label is blank in an HP 2621A.

Function Label	Key Stroke	Function
[DSPY FN]	Shifted 	<p>Cause terminal control function codes, such as escape sequences, to be displayed symbolically on the screen rather than being executed by the terminal. An asterisk appears on the screen immediately to the right of this label when this function is enabled (for example, [DSPY FN*]).</p> <p>When Display Functions is enabled in Local operating mode, all characters are displayed. The Return character (CR) is displayed and a Return/Linefeed (CR/LF) is executed.</p> <p>In Remote operating mode, the Null and Delete characters are used for padding. They are not displayed. If the ENQ/ACK handshake is enabled (See Configuraiton, Section V), the ENQ character is executed but not displayed. If the ENQ/ACK handshake is disabled, ENQ is not executed but is displayed.</p> <p>To terminate the display of function codes, press this key again. The asterisk disappears from the label and function codes are no longer displayed on the screen.</p>
[tab/mrgn]	Shifted 	<p>Display a set of function key labels that you may use to set TAB stop positions, clear any single TAB stop position, or clear all TAB stop positions. You may also define the position of the left and right margins of the display screen, and clear these margins.</p>
[edit]	Shifted 	<p>Display a set of function key labels that you may use to perform editing operations upon text in display memory. Editing operations provided include: Modify, underline, clear line or display, insert or delete line, and insert or delete character.</p>

## The Terminal's Keyboard

### Configuration Function Set

When you request Configuration mode (press **SHIFT** together with the Function key labeled [config]), you are able to examine and change the internal configuration of your terminal. The process of reconfiguration is described in Section V.







### Printer Control Function Set

The printer functions apply only to the HP 2621P. These functions are described in Section VI.

### TAB and Margin Control Function Set

When you request TAB and Margin Control (press **SHIFT** together with the Function key labeled [tab/mrgn]), a new set of Function labels appears on your screen, as follows:

**[SET TAB] [CLR TAB] [CLR TABS] [L MARGIN] [R MARGIN] [CLR MRGN]**


Function Label	Key Stroke	Function
[SET TAB]	Shifted 	Set TAB Stop — this function sets a tabulation stop at the current position of the cursor. Move the cursor to the column where you want a TAB stop and press the shifted Function key associated with this label.
[CLR TAB]	Shifted 	Clear TAB Stop — this function clears (erases) any tabulation stop at the current position of the cursor. Position the cursor to the column where you want to remove a TAB stop and press the shifted Function key associated with this label. Note that the default TAB stop at the left margin can be cleared using this function. The TAB key is ignored when no TAB stops are defined.
[CLR TABS]	Shifted 	Clear All TAB Stops — this function clears (erases) all existing tabulation stops. Simply press the shifted Function key associated with this label. Following execution of this function, a default TAB stop is set at the left margin.
[L MARGIN]	Shifted 	Set Left Margin — this function sets the left text margin at the current position of the cursor. Move the cursor to the column where you want the left margin and press the shifted Function key associated with this label. A default TAB stop is set at the left margin whenever this function is executed.
[R MARGIN]	Shifted 	Set Right Margin — this function sets the right text margin at the current position of the cursor. Move the cursor to the column where you want the right margin and press the shifted Function key associated with this label. It is illegal to set the right margin to the left of the left margin. If you attempt to do this, the terminal ignores your request and sounds a bell tone.
[CLR MRGN]	Shifted 	Clear Margins — this function clears (erases) any left and right margin set between column 2 and 79 inclusive. The left margin is reset at column 1 and the right margin is reset at column 80. A default TAB stop is set at the left margin (in this case, column 1).

### Edit Control Function Set

The edit control functions allow you to perform various editing operations upon text in display memory. When you request Edit Control (press **SHIFT** together with the Function key labeled [Edit]), a new set of Function labels appear on the screen, as follows:










**MODIFY** **UNDRLINE** **CLR LINE** **CLR DSPY** **INS LINE** **DEL LINE** **INS CHR** **DEL CHAR**

Function Label	Key Stroke	Function
[MODIFY*]	Shifted 	<p>Modify Text – this function enables Modify mode while you are interacting with a host computer. For example, if you are in Character mode and transmit an erroneous command string to the host computer and receive an error message in response, you can enable Modify mode, correct the error in the command string on the screen, and retransmit the command without having to retype the entire string. To enable Modify mode, press the shifted Function key associated with this label. An asterisk is displayed within the label to indicate that the Modify mode is in the enabled state. Move the cursor to the line you want to change and use the Edit Functions to make the desired changes. When the line is changed to what you want, press <b>ENTER</b> or <b>RETURN</b> to transmit the changed line to the host computer. The use of the <b>ENTER</b> or <b>RETURN</b> key executes Modify mode. The current line (marked by the cursor) is transmitted to the computer and the asterisk is removed from the [MODIFY*] screen label.</p> <p>To disable modify mode (before you press either <b>ENTER</b> or <b>RETURN</b>), press the shifted function key associated with the [MODIFY*] screen label. The asterisk is removed from the label and Modify mode is disabled.</p> <p>The amount of data retransmitted is a function of the Line mode transmission rules. See "Sending Data To The Computer" in Section V for a discussion of Line mode data transmission.</p>



## The Terminal's Keyboard

Function Label	Key Stroke	Function
[UNDRLINE]	SHIFTED 	<p>Display Underline — this function adds an underline character at the current cursor position. Each time the [UNDRLINE] Function key is pressed an underline character is added to the current character. If you hold this key down the underline repeats along the line until you release the Function key. Note that this underline function differs from the ASCII-coded underline character.</p>
[CLR LINE]	Shifted 	<p>Clear Line — this function clears (erases) the content of the current line from the character marked by the cursor through the last character in the line. Move the cursor to the character position where you want the line deletion to begin and press the shifted Function key associated with this label.</p>
[CLR DSPY]	Shifted 	<p>Clear Display — this function clears (erases) the content of display memory from the character marked by the cursor through the last character in memory. Move the cursor to the character position where you want the memory deletion to begin and press the shifted Function key associated with this label.</p>
[INS LINE]	Shifted 	<p>Insert Line — this function inserts a blank line into display memory immediately preceding the line marked by the cursor. Move the cursor to the line before which you want to insert a line and press the shifted Function key associated with this label. A new blank line is inserted into memory and the cursor position remains unchanged (it remains in the same row and column).</p> <p>When memory is full (48 lines of data) and the cursor is at row 1, an insert request deletes a line from the bottom of memory to make room for the line to be inserted. When memory is full and the cursor is at any row other than 1, an insert request deletes a line from the top of memory.</p>
[DEL LINE]	Shifted 	<p>Delete Line — this function deletes an entire line at the current cursor position. Move the cursor to any character position within the line you want deleted and press the shifted Function key associated with this label. The entire line is deleted from display memory. The cursor position is unchanged (it remains in the same row and column).</p>

Function Label	Key Stroke	Function
[INS CHR]	Shifted 	<p>Insert Character — this function enables the Insert Character mode. When enabled, any character that you enter is inserted into display memory in the position immediately preceding the cursor. Move the cursor to the character position at which you want to insert one or more characters and press the shifted Function key associated with this label. An asterisk is displayed within the label to indicate that the Insert Character mode is enabled. Then, insert new characters. While inserting characters, any existing characters are shifted to the right one character position within the same line for each new character entered.</p> <p>Any characters shifted beyond the right margin setting are lost. No wraparound occurs.</p> <p>To disable Insert Character mode, simply press the shifted Function key associated with this label. The asterisk is removed from the label and you cannot insert new characters. Any characters entered when Insert Character mode is disabled overwrite existing characters in the line.</p>
[DEL CHAR]	Shifted 	<p>Delete Character — this function deletes one character marked by the cursor. Move the cursor to the character you want deleted and press the shifted Function key associated with this label. The character is erased from memory. Remaining characters within the same line are shifted to the left one character position for each character deleted.</p>



## Using the Terminal as an Input/Output Device

## Section V

The HP 2621 Interactive Terminal can be connected, either directly or through a modem, to an external data processing device such as a computer.

You may be required to select specific characteristics that define the terminal operation before you can use it as a data communications device. This set up procedure is called "configuring" the terminal.

For the HP 2621, configuration parameters are maintained within programmable fields that are displayable on the screen. Included among these fields are:

- Values that define the terminal's data transfer baud rate.
- Keywords that define the type of parity generated by the terminal and the duplex setting of the terminal.
- Single-character mnemonics that define the data handling straps and the type of data communications handshake.
- Values that define the frequency rate for your local A.C. electric power and the starting column position for the transmission of data across the data communications line.

- A two-character redefinable string associated with the **RETURN** and **ENTER** keys.

You use the cursor left or right **←**, or **→** keys to position the cursor for modification of the desired parameter.

You may use the TAB right or left **TAB→**, or **TAB←** key to position the cursor to the beginning of any displayed field in the configuration data.

The configuration function descriptions follow:

You use the **[config]** function key to enter configuration mode and display the configuration parameters on the screen. When requested, these parameters are displayed together with a set of function key labels with which you may change the parametric values. Using the keys associated with these labels, you configure the terminal to match your Local mode requirements or the Remote mode requirements of an external computer system.

## Using the Terminal as an Input/Output Device

The initial HP 2621 configuration data is displayed on the screen in the following format:

<u>Baud Rate</u>	<u>Parity</u>	<u>Duplex</u>	<u>Straps</u>	<u>Handshake</u>	<u>Hz</u>	<u>Start Col</u>	<u>Return</u>
2400	NONE(O)	FULL	bcgHxz	Etx	60	1	(↵)


Language   **NEXT**   **PREVIOUS**   **MODEM OFF**

**REMOTE**   **CAPS LK**   **LN MODE**   **AUTO LF**

Note that the configuration data uses three lines of display memory. Thus, if memory is full and you request the configuration data, you may lose up to three lines from display memory.







When you are in Configuration mode and make changes to the displayed configuration fields, these changes do not become effective until you terminate the Configuration mode.

### Configuration Function Keys




The configuration function "exit" terminates Configuration mode. You may also press the  key to terminate Configuration mode. In either case, the configuration data and screen labels disappear from the screen and are replaced by the content of display memory and the primary set of screen labels.

The NEXT and PREVIOUS functions are used to manipulate the displayed configuration data.

The remaining functions define conditions such as Modem Disconnect, REMOTE mode enable/disable, uppercase character (CAPS) lock/unlock (teletypewriter simulation), Line mode enable/disable, and automatic linefeed enable/disable.









Function Label	Key Stroke	Function
[exit]	Shifted 	This function terminates Configuration mode. The screen returns to the screen conditions that existed before you requested configuration mode. You also may terminate Configuration mode by pressing the  key.
[NEXT]	Shifted 	The NEXT function sets the current configuration parameter (the cursor marks the current parameter) to the next available value. For the straps and for handshake, NEXT simply changes the state of the parameter from lowercase to uppercase, or vice versa. For Baud Rate, Parity, Duplex, Hz, and Start Col, the next available value replaces the current value each time you execute NEXT. The RETURN field is not affected by the NEXT function.
[PREVIOUS]	Shifted 	The PREVIOUS function sets the current configuration parameter (the cursor marks the current parameter) to the previous available value. For the straps and for handshake, PREVIOUS changes the state of the parameter from lowercase to uppercase, and vice versa. For Baud Rate, Parity, Duplex, Hz, and Start Col, the previous available value replaces the current value each time you execute the PREVIOUS function. The RETURN field is not affected by the PREVIOUS function.
[MODEM OFF]	Shifted 	Modem Disconnect — This function directs the terminal to “hang-up” the modem. The action resulting from pressing the function key associated with this label occurs immediately. The cursor disappears from the screen for approximately three seconds.
[REMOTE]	Shifted 	This function enables the connection to a remote computer via the data communication interface. An asterisk appears in the label when this function is enabled (for example, [REMOTE*]). To disable this mode (that is, to allow Local mode) press the function key associated with this label once again.

## Using the Terminal as an Input/Output Device

Function Label	Key Stroke	Function
[CAPS LK]	Shifted 	<p>This function causes the terminal's alphabetic keys to be locked into uppercase characters. Specifically, when Caps Lock is enabled, the terminal generates the uppercase characters for the set of characters a through z. The characters ` and ~ are ignored. (Refer to the ASCII-coded Character Set in Appendix A.) An asterisk appears in the label when this function is enabled (for example, [CAPS LK*]).</p> <p>When Caps Lock is disabled, the complete ASCII Character Set (128 characters) is generated by the terminal. For remote operation, the HP 2621 always accepts the complete 128 characters whether Caps Lock is enabled or disabled.</p>
[LN MODE]	Shifted 	<p>This function enables Line Mode. When Line Mode is enabled, data entered into display memory appears on the screen but is not transmitted across the data communications link until after the <b>ENTER</b> or <b>RETURN</b> key is pressed and the host computer has responded. An asterisk appears in the label when this function is enabled (for example, [LN MODE*]).</p> <p>In Line mode, the amount of data transmitted is determined as follows: If you have created the line to be transmitted using the keyboard, data is transmitted from the point where you started typing data. If the remote computer created the line to be transmitted (and you have not typed anything into the line) data is transmitted from the point defined by the Start Col field in Configuration mode. Trailing blanks are suppressed. If you have typed data into a computer-generated line of data, transmission begins at the point where you started typing.</p> <p>When this function is disabled, the terminal operates in Character Mode. Each character entered is transmitted immediately across the data communications link when the character's key is pressed.</p>
[AUTO LF]	Shifted 	<p>This function enables Automatic Linefeed. When enabled, a Linefeed is generated automatically each time the <b>RETURN</b> or <b>ENTER</b> key is pressed. This function should be enabled when you operate the terminal in local mode and should be disabled when you operate the terminal in remote mode, depending on the requirements of the host computer. An asterisk appears in the label when Automatic Linefeed is enabled (for example, [AUTO LF*]).</p>

## Baud Rate Configuration

The speed at which data transfers occur between the terminal and the host computer is determined by the value set into the Baud Rate parameter field. The available Baud Rate values are EXT., 110, 150, 200, 300, 600, 1200, 1800, 2400, 3600, 4800, and 9600. The value you select must match the capability of the host computer or that of the modem link between the terminal and computer. The defaulted baud rate value is 2400.









To change the Baud Rate value, use the cursor left  or cursor right  key to position the cursor beneath the first character of the current Baud Rate value on the screen. You also may use  or  to move the cursor to this field. Then execute the NEXT or PREVIOUS function (  and  or  and  ) until the appropriate value is displayed.

## Parity Configuration

The type of parity generated for each data byte is determined by the value set into the Parity parameter field. The available parity types are NONE(0), NONE(1), EVEN, and ODD. The type selected must match the requirements of the host computer. The defaulted parity is NONE(0).

The available parity types are:

NONE(0)	No parity is generated; eighth bit is always 0.
NONE(1)	No parity is generated; eighth bit is always 1.
EVEN	Even parity is generated; eighth bit is parity result.
ODD	Odd parity is generated; eighth bit is parity result.









To change the Parity value, use the cursor left  or cursor right  key to position the cursor beneath the first character of the current Parity value on the screen. You also may use  or  to move the cursor to this field. Then, execute the NEXT or PREVIOUS function (  and  or  and  ) until the appropriate value is displayed.

## Duplex Configuration

The type of echo duplex for data communications transmission can be determined by the keyword set into the Duplex parameter field. The available duplex types are FULL and HALF. The default type is FULL Duplex.

In Character mode, FULL duplex indicates that the terminal transmits a character to the computer and the computer should provide the echo to the display screen.

HALF duplex indicates that the terminal both transmits a character to the computer and echoes that character locally to the display screen.

To change the Duplex keyword, use the cursor left  or cursor right  key to position the cursor beneath the first character of the current Duplex keyword on the screen. You also may use  or  to move the cursor to this field. Then, execute the NEXT or PREVIOUS function (  and  or  and  ).



## Strap Configuration

Each strap is represented on the screen by a single alphabetic character. You enable or disable a strap by changing the state of the displayed character from lowercase to uppercase, or vice versa. Table 5-1 lists the straps and their condition when either lowercase or uppercase. A description of each strap follows Table 5-1.











When the configuration parameters are displayed, you use the cursor left  or cursor right  key to move the cursor to a position beneath the character representing the strap you want to change. You may use  or  to move the cursor to this field. When the cursor is positioned correctly, the state of the strap character can be changed by executing either the NEXT or PREVIOUS function; that is,  and  or  and .

Table 5-1. HP 2621 Strapping Configuration

Strap	Closed	Open	Default
Space Overwrite (SPOW) Latch	b (disabled)	B (enabled)	disabled
Wraparound Cursor, End-of-Line	c (enabled)	C (disabled)	enabled
Short Transfer Trigger Handshake (Block Transfer Handshake)	g (enabled)	G (disabled)*	enabled
Long Transfer Warning Handshake (Inhibit DC2)	h (enabled)	H (disabled)	enabled
Data Speed Select	x (disabled)	X (enabled)	disabled
Parity Check	z (enabled)	Z (disabled)	enabled

\* Although the Short Transfer Trigger Handshake is disabled, transfer conditions become dependent on the state of the Long Transfer Warning Handshake strap. For further information, see the description for these straps, below.

**Space Overwrite (SPOW) Latch.** When this strap is enabled, the SPOW latch can be turned on by a Return character (CR), and turned off by , a Linefeed, or . When the SPOW latch is on, the space bar causes the cursor to move to the right along the current line without overwriting existing characters. When the SPOW latch is off, the space bar causes an overwrite of blank (space) characters as the cursor moves along the current line.

When this strap is disabled (the defaulted state), the SPOW latch is not accessible.

**Wraparound Cursor, End-Of-Line.** When enabled (the defaulted state), this strap causes the cursor to wrap around to the beginning of the next line on the screen whenever the right margin of any line is exceeded. The terminal generates a Return and a Linefeed character to accomplish this.

When this strap is disabled, no Return or Linefeed character is generated at the end of a line. The cursor remains in, and overwrites the content of the right margin.

**Short Transfer Trigger Handshake (Block Transfer Handshake). Long Transfer Warning Handshake (Inhibit DC2).** The HP 2621 provides three kinds of data transfer operations that are meaningful in Remote mode only; Long Transfer in Line mode, Long Transfer in Character Mode, and Short Transfer.

#### Long Transfer, Line Mode

A data transfer operation initiated via the **ENTER** or **RETURN** key while the terminal's Line mode or Modify function is enabled.

#### Long Transfer, Character Mode

A data transfer operation initiated via the **ENTER** or **RETURN** key while the terminal's Line mode or Modify function is disabled.

#### Short Transfer

A data transfer operation involving:

1. Terminal Status
2. f1 through f8 functions
3. Completion Status Indicator (S, F, or U) following a remote print operation request via escape code sequence (HP 2621P only).
4. Cursor Sensing

If more than one transfer request is pending simultaneously, the execution priority is:

1. Status Requests
2. Cursor Sense Requests
3. f1-f8 Function Requests
4. **ENTER** or **RETURN** Key Line Transfer Requests
5. Completion Status Responses

The complete DC1/DC2 handshake protocol consists of a "trigger" signal (DC1) sent from the host computer to inform the terminal that a data transfer is possible. In response, the terminal sends a "warning" signal (DC2) to the host computer indicating that the data to be transferred is ready. The host computer sends another trigger signal (DC1) to enable the transfer. Figure 5-1 illustrates the handshake protocol.





Figure 5-1. DC1/DC2 Handshake Protocol


## Using the Terminal as an Input/Output Device

Depending on the state of the g and h straps, one of three subsets of the handshake protocol shown in Figure 5-1 is used by the terminal, as follows:


### TYPE 1 (No Handshake)



### TYPE 2 (DC1 Trigger Handshake)



### TYPE 3 (DC1/DC2/DC1 Warning Handshake)



The effect of the various g and h strap states is shown in Table 5-2.

Table 5-2. DC1/DC2 Handshake Protocol Strapping Effects

Strap State	Transfer Category		
	Long (Line Mode)	Short	Long (Char Mode)
g,h	TYPE 3	TYPE 2	TYPE 1
g,H (default)	TYPE 1	TYPE 2	TYPE 1
G,h	TYPE 3	TYPE 3	TYPE 3
G,H	TYPE 1	TYPE 1	TYPE 1

**Data Speed Select.** This strap allows the operation of modems that support dual speed data transmission. When this strap is enabled, the data speed signal (RS232C CH line or CCITT V.24 111 line) is in the High (on) state.

When disabled (the defaulted state), the data speed signal (RS232C CH line or CCITT V.24 111 line) is in the Low (off) state.

**Parity Check.** When the Parity Check strap is enabled (the defaulted state), a parity check for even or odd parity is performed by the terminal upon received data.







When this strap is disabled, no parity check is performed.

Note that parity is never checked for received data if the terminal is not generating parity, i.e., is configured for either NONE(0) or NONE(1) parity.

## Handshake Configuration

Table 5-3. Data Communications Handshake Configuration

Each handshake type is represented on the screen by a single alphabetic character. You enable or disable the type of handshake by changing the state of the displayed character from lowercase to uppercase, or vice versa. Table 5-3 lists the handshake types and their condition when either lowercase or uppercase. A description of each handshake type follows Table 5-3.

When the configuration parameters are displayed, you use the cursor left  or cursor right  key to move the cursor to a position beneath the character representing the handshake you want to change. You may use  or  to move the cursor to this field. When the cursor is positioned correctly, press and hold down  while you press . This executes the NEXT function which results in a change of state for the handshake character. Either the NEXT or PREVIOUS function may be used to change a character's state.

**ENQ/ACK Handshake.** This type of handshake may be used to ensure that the terminal has an empty input buffer before the host computer transmits more data. When this strap is enabled (the defaulted

Handshake	Closed	Open
ENQ/ACK Handshake	e (disabled)	E (enabled)
Transmit Handshake	t (disabled)	T (enabled)
XON/XOFF Handshake	x (disabled)	X (enabled)

state), an acknowledge signal (ACK) is transmitted by the terminal each time an enquiry signal (ENQ) is encountered from the host computer. Any data contained in the buffer is processed before the ACK signal is transmitted. The buffer size is 128 characters. You should transmit an ENQ from the computer following 120 characters (maximum).

When this strap is disabled, any enquiry signal (ENQ) encountered from the host computer is treated by the terminal as a normal data character. No acknowledge signal (ACK) is generated.

**Transmit Handshake.** When this handshake type is enabled, the host computer can transmit a "busy" signal across the Clear to Send (RS232C CB or CCITT V.24 106) or Received Line Signal Detector (RS232C CF or CCITT V.24 109) line to temporarily stop the transmission of data from the terminal (temporarily set the signal to the false state).

When this handshake type is disabled (the defaulted state), data transmission continues uninterrupted by the computer.

**XON/XOFF Handshake.** This handshake protocol allows the terminal to signal the host computer to stop transmitting data and, subsequently, to resume transmitting data as the input buffer fills and empties.

When this strap is enabled, the input buffer fills to within approximately 16 bytes of its capacity. At this point, the terminal sends a Transmit Off (XOFF) signal to cause the computer to stop sending data. When the buffer has emptied below one-fourth of its capacity, the terminal sends a Transmit On (XON) signal which causes the computer to resume sending data. This process is repeated until the current data transfer operation is completed.

When this handshake type is disabled (the defaulted state), no XON/XOFF handshake occurs between the terminal and the computer.

Note that the XON signal is represented by a DC1 (CTRL Q) character transmission. The XOFF signal is represented by a DC3 (CTRL S) character transmission.

### Hz Configuration

The value set for this strap must match the frequency of your local A.C. power (that is, the frequency on your power line). For an area with a 60-cycle power frequency (such as the U.S.A. or Canada), set this value to 60 (the defaulted state). For Europe and elsewhere with 50-cycle power frequency, set this value to 50.

Setting this strap merely changes the refresh rate for screen data. It does not change or affect the type of input power supplied to the terminal.

For information concerning input power requirements, consult the HP 2621 Service Manual, HP Part No. 02620-90002.

To change the state of the Hz Configuration, use the cursor control keys **←** or **→** to position the cursor at the first character of this field. You also may use **TAB→** or **TAB←** to move the cursor to this field. Press **SHIFT** and **↙** or **SHIFT** and **ROLL↑** to change the state within the Hz field. Either the NEXT or PREVIOUS function may be used to change the frequency value from 60 to 50, and vice versa.

### Start Column Configuration

You may specify a column number from which data transmission is to begin on the screen. Any characters to the left of the starting column are ignored when the **ENTER** or **RETURN** key is pressed. This allows you to retransmit a line without having to physically remove the computer's prompt character. For example, if the computer issues a 1-character prompt in response to your entries, you can specify a starting column of 2. Subsequent entry lines are transmitted from column 2 to the end of the line.

This parameter is overridden by the logical start-of-text pointer maintained by the terminal. See "Sending Data to the Computer" for a description of the logical start-of-text pointer.

The defaulted starting column is 1. To change this value, use the cursor left **←** or cursor right **→** key to position the cursor to the first position within the Start Col field. You also may use **TAB→** or **TAB←** to move the cursor to this field. Then, use the NEXT or PREVIOUS Function key to increment or decrement the starting column value (press **SHIFT** and **↘**, or **SHIFT** and **ROLL↓**).

### Return Key Configuration

You can specify one or two characters that will be transmitted each time the **RETURN** or **ENTER** key is pressed. Any ASCII character is legal, however, these are usually control codes that you wish to pass to the host computer. See Appendix A for a table of legal ASCII characters.

Note that the **RETURN** and **ENTER** key perform the same transmit operation only in Line and Modify mode. Their operations differ in Character mode.

To specify RETURN key characters, use the cursor left **←** or cursor right **→** key to move the cursor to the first character position in the RETURN parameter field. You may use **TAB→** or **TAB←** to move the cursor to this field. Enter the desired character or characters from the keyboard. The default value is [CR ].

### Terminating the Configuration Mode

When you are satisfied with the configuration data on the screen, you terminate the Configuration Mode by executing the exit function ( **SHIFT** and **↘** ), or by pressing the **Key**. The configuration data is stored in nonvolatile memory, protected from destruction by a battery should the main power source be interrupted for any reason.

## Selecting The Remote Operating Mode

Before the terminal can send and receive data via the data communications interface, you must enable remote operation. You accomplish this by enabling the REMOTE function. Press **SHIFT** and **↵** keys to obtain the Configuration screen labels. The labels appear in the following format:

**exit** **NEXT** **PREVIOUS** **MODEM OFF**

**REMOTE** **CAPS LK** **LN MODE** **AUTO LF**

To execute the REMOTE function, press and hold down **SHIFT** while you press **↵**.

An asterisk appears in the REMOTE function label to indicate that the function is enabled. For example, **REMOTE\***.

To disable Remote mode, press Shifted **↵** once more. The asterisk disappears from the label and Local mode is in effect.

## Modem Considerations

If you are communicating with the host computer through a modem, it may be necessary for you to turn on a modem power switch or make modem parity setting changes. The modem's baud rate and parity settings should be the same as those configured in the terminal.

The HP 2621 supports the Bell 103A or equivalent type of modem.

Whenever the modem line is active, an asterisk appears between the fourth and fifth screen label at the bottom of the screen. If your facility requires the display of this "active modem" indicator, do not shut off the screen labels display.

## Sending Data To The Computer

You enter the data to be sent to the host computer into display memory from the terminal's keyboard. If your terminal is configured for Character mode, the data is transmitted character-by-character as you type it.

If your terminal is configured for Line mode, you type a single line and use the **ENTER** or **RETURN** key to transmit the data a line at a time.

Line mode allows you to enter into memory an entire line of up to 80 characters. The data that you type into the line is not transmitted to the computer until you press either **ENTER** or **RETURN**. The line appears on the screen and you can make changes to the displayed data at any time before you press **ENTER** or **RETURN**.

When you enter data the terminal remembers, for each line, which character was the first character that you entered and sets a logical start-of-text pointer. The pointer is stored with the data line in display memory and is retained if you access that line later.

To set a logical start-of-text pointer, the following conditions must be true:

- The terminal must be on-line (in remote mode).
- The first character entered on a line must be an alphanumeric character, a space, or a backspace. (The cursor control keys have no affect.)
- The line in which you are entering data must be the bottom (last) line in display memory.

Example:

Assume that the computer prompts you with a colon (:) on the terminal and that you enter a BUILD command to this prompt:

```
: BUILD TF;REC=128,1,F,BINARY;NOCCTL;DEV=DISC;CODE=0;DISC=1023,8,1
└── Computer Prompt ───┬── Your Response
```

The logical start-of-text pointer for this line (at the bottom of memory) does not exist until you enter the B in the BUILD command, at which time the pointer is set to column 2.

Even though the logical start-of-text pointer is used in character mode, it only affects the Line mode, Modify mode, and **ENTER** operations. If the line has no logical start-of-text pointer, the Configuration Start Column value is used to determine the starting point of the data transmitted.

If you are in character mode, there may be times you will find yourself transmitting a command string to the host computer and receive an error message in response. To correct this command string without retyping the whole line again, you can simply enable the Modify mode.

Modify mode permits you to switch temporarily to Line mode, select any line of display memory, edit that line, and transmit it.

Example:

Assume you entered a BUILD command, pressed **RETURN** and the system came back with an error message.

```
: BUILD TF;REC=128,1,F,BINARY;NOCCTL;DEV=DISC;CODE=0;DISC=1023,8,1
      ^
EXPECTED "ASCII" OR "BINARY". (CIERR 274)
```

To correct this statement, simply enter Modify mode and position the cursor to the appropriate line and character on the screen. Retype BINARY and press **ENTER** or **RETURN**. The BUILD command is transmitted to the computer, and there was no need to retype the whole line.

To free the start-of-text pointer, simply home the cursor above the line you want to begin the deletion and clear display. This will remove the pointer from all the lines below the character marked by the cursor through the last character in memory.



## Receiving Data From The Computer

No special action is required to receive data from the host computer other than having the REMOTE function enabled. Data is displayed on the screen as it is received from the computer.

It may be necessary to configure for a specific type of handshake when you transmit control codes, escape sequences, or are using the HP 2621P printer.

## Escape Code Sequences

The HP 2621 recognizes a set of escape code sequences that can be transmitted from a host computer. These sequences are used to control cursor and screen display, the terminal, margin and tabulation stop settings, editing, cursor addressing, display enhancement, cursor sensing, and so forth.

In addition to the escape code sequences recognized upon receipt from a host computer, you can transmit some escape code sequences from the terminal to a host computer via the Function keys. To access these codes, press and hold down **SHIFT**, and then press the **■** key. The following Function labels are displayed across the bottom of the screen:

**f1** **f2** **f3** **f4** **f5** **f6** **f7** **f8**

See Table 5-12 for escape sequence function definitions.

The terminal also recognizes and acts upon a set of ASCII-coded control codes transmitted from a host computer. The escape code sequences and control codes recognized by the terminal are listed and defined in Tables 5-4 through 5-13.

Table 5-4. Escape Sequences, Cursor and Screen Control

Function	Code	Description
Cursor Up	esc A	Move cursor up by one row.
Cursor Down	esc B	Move cursor down by one row.
Cursor Right	esc C	Move cursor right by one column.
Cursor Left	esc D	Move cursor left by one column.
Home Down	esc F	Cursor Home Down.
Home Up	esc H	Cursor Home Up.
	esc h	
Roll Up	esc S	Scroll display up by one line.
Roll Down	esc T	Scroll display down by one line.

Table 5-6. Escape Sequences, TAB and Margin Control

Function	Code	Description
Set TAB Stop	esc 1	Set a tabulation stop at current cursor position.
Clear TAB Stop	esc 2	Delete a tabulation stop at current cursor position.
Clear All TAB Stops	esc 3	Delete all tabulation stops.
Set Left Margin	esc 4	Set left margin at current cursor position.
Set Right Margin	esc 5	Set right margin at current cursor position.

Table 5-5. Escape Sequences, Terminal Control

Function	Code	Description
Reset Terminal	esc E	Set terminal to power ON state.
Test Terminal	esc z	Self-test, terminal.
Display Functions On	esc Y	Disable execution of any control functions, but display their code; display asterisk in screen label ( <code>(DSPY FN*)</code> ).
Display Functions Off	esc Z	Enable execution of any control functions; do not display their code; remove asterisk from screen label ( <code>(DSPY FN)</code> ).

Table 5-7. Escape Sequences, Edit Control

Function	Code	Description
Clear Line	esc K	Delete current line from current cursor position to end-of-line.
Clear Display	esc J	Clear display memory from current cursor position to end-of-memory.
Insert Line	esc L	Insert blank line at current cursor position.
Delete Line	esc M	Delete entire line at current cursor position.
Insert Character On	esc Q	Enable Insert Character Function; display asterisk in screen label; subsequent character-entry inserts a character into line at current cursor position.
Insert Character Off	esc R	Disable Insert Character Function; remove asterisk from screen label.
Delete Character	esc P	Delete character at current character position.



Table 5-8. Escape Sequences, Miscellaneous Control

Code	Description
esc @	Delay; generate a one second pause within the terminal.
esc ^	Primary status request; generate the terminal's primary status bytes and transmit them to the requesting computer. See Appendix C for information about the terminal's Primary status.
esc d	Enable Line Transfer (ENTER key function).
esc f	Modem Disconnect; Set CD signal (RS232C) or 108.2 signal (CCITT V.24) on modem line low for 3 seconds.
esc i	Backtab; move cursor left to TAB stop position.

Table 5-9a. Escape Sequences, Cursor Sensing

Function	Code	Description
Absolute Cursor Sense	esc a	Obtain absolute column and row location of cursor within display memory.
Relative Cursor Sense	esc `	Obtain column and row location of cursor relative to the beginning of the currently displayed screen page.

**NOTES:**

- 1) Generally, actual cursor positional values are referenced in the following notation:
  - screen column positions-1 through 80
  - screen row positions-1 through 24
  - memory row positions-1 through 48
  
- 2) For cursor sensing and addressing, the positional values are referenced in the following notation:
  - screen column positions-0 through 79
  - screen row positions-0 through 23
  - memory row positions-0 through 47

Table 5-9b. Escape Sequences, Cursor Address Control

Note that the base sequence is `esc & a`

Code	Description
<code>esc &amp; a</code> <i>memory row number r</i> <i>column number C</i>	Absolute Memory Addressing; move cursor to any displayable position by using absolute memory coordinates. The range of <i>memory row number</i> is 0-47. The range of <i>column number</i> is 0-79.
<code>esc &amp; a</code> <i>screen row number y</i> <i>column number C</i>	Absolute Screen Addressing; move cursor to any position currently displayed on the screen by using screen relative coordinates. The range of <i>screen row number</i> is 0-23. The range of <i>column number</i> is 0-79.
<code>esc &amp; a +/-</code> <i>memory row number r</i> <i>column number C</i>	Relative Memory Addressing; move cursor to any displayable position by using memory coordinates relative to the current cursor position (+ or - memory row; + or - column).
<code>esc &amp; a +/-</code> <i>screen row number y</i> <i>+/- column number C</i>	Relative Screen Addressing; move cursor to any position currently displayed on the screen by using screen coordinates relative to the current cursor position (+ or - screen row; + or - column number).

These sequences always must be terminated with an uppercase character (rather than a lowercase character) to inform the terminal that the sequence has ended. For example, in the sequence `esc & a 12r 45C`, the uppercase C character is the sequence terminator.

## Using the Terminal as an Input/Output Device

Table 5-10. Escape Sequences, Display Enhancement Control

Note that the base sequence is `esc & d`

Code	Description
<code>esc &amp; d A through O</code>	Enable Underline Function; subsequent character entries include underline on display screen.
<code>esc &amp; d @</code>	Disable Underline Function.

Table 5-11. Escape Sequences, Screen Labels Control

Note that the base sequence is `esc & j`

Function	Code	Description
Clear Labels	<code>esc &amp; j @</code>	Clear Screen Labels. Turn off display of screen labels.
Display Labels	<code>esc &amp; j A</code>	Display Primary Screen Labels. Turn on display of first level of screen labels.
Display f1 - f8 Labels	<code>esc &amp; j B</code>	Display Function Keys f1 through f8. Turn on display of f1-f8 screen labels.

Table 5-12. Escape Code Sequences Transmitted by the HP 2621

Code	Description	
esc\ 7-byte status data  S, F, or U	<p>Primary Status Response; When an esc ^ sequence is received, the terminal generates this 7-byte status response and transmits it to the requesting computer.</p> <p>HP 2621P Only; device completion response transmitted following any printer control escape sequence, esc X p . . . . . The terminal responds with S to indicate that the print operation was successful; F to indicate failure; or U to indicate user interference (for example, the RETURN key was held down preventing completion of the print operation).</p>	
Function	Code	Description
Transmit Key [+1]	esc p	Transmit esc p sequence to computer.
Transmit Key [+2]	esc q	Transmit esc q sequence to computer.
Transmit Key [+3]	esc r	Transmit esc r sequence to computer.
Transmit Key [+4]	esc s	Transmit esc s sequence to computer.
Transmit Key [+5]	esc t	Transmit esc t sequence to computer.
Transmit Key [+6]	esc u	Transmit esc u sequence to computer.
Transmit Key [+7]	esc v	Transmit esc v sequence to computer.
Transmit Key [+8]	esc w	Transmit esc w sequence to computer.

Note that the terminating character for each code transmitted is the string configured into the **RETURN** key together with a line-feed character if automatic linefeed is enabled. The transmission occurs under control of the g and h strap state for a Short Transfer Trigger Handshake (Block Transfer Handshake); see Section V.

Table 5-13. ASCII-Coded Control Codes


ASCII Code		Code Definition	Key Sequence	Display Character
(hexadecimal)	(decimal)			
07	7	Bell	G <sup>c</sup>	␣
08	8	BACKSPACE	H <sup>c</sup>	␣
09	9	Horizontal TAB	I <sup>c</sup>	␣
0A	10	Linefeed	J <sup>c</sup>	L <sub>F</sub>
0D	13	RETURN	M <sup>c</sup>	␣
05	5	ENQ — Enquiry; if ENQ/ACK handshake is enabled, terminal responds with 006 (ACK Acknowledge).	E <sup>c</sup>	␣
0C	12	Form Feed to printer (HP 2621P only); if Report Mode is enabled, printer skips to top of new page. If Report Mode is disabled, Form Feed code is ignored.	L <sup>c</sup>	r <sub>F</sub>
11	17	DC1; depending on which type of DC1/DC2 handshake protocol is enabled, the terminal responds with data, DC2, or nothing.	Q <sup>c</sup>	␣ <sub>1</sub>
1B	27	ESC; signals start of an escape sequence.	E <sup>c</sup>	␣

## The HP 2621P

## Section VI

This section describes the features offered by the HP 2621P Interactive Terminal. The HP 2621P provides all of the features described in the preceding sections of this manual, plus an integral thermal printer mechanism.

A set of screen labeled printer control functions is available with which you can control the form and content of printer output data. In addition to the control functions, the HP 2621P supports a set of printer control escape sequences. You may use these escape sequences to programmatically control the form and content of printer output data from an external computer.



### Identifying Options and Accessories

The options and accessories you requested are delivered with your terminal. When you receive the terminal make sure that all of the items that were ordered are present. Tables 6-1 and 6-2 list the options and accessories available for the HP 2621P Interactive Terminal.

When communicating with Hewlett-Packard regarding your terminal, specify the model, serial, and option numbers to ensure accurate identification by Hewlett-Packard. A list of Hewlett-Packard Sales and Service Offices is included at the back of this manual.

Table 6-1. HP 2621P Options

Option No.	Description
015	50 Hz, 230V Power
016	50 Hz, 115V Power

Table 6-2. HP 2621P Accessories

Accessory No.	Description
13222N	U.S.A. Modem Cable (Male Connector)
13222M	European Modem Cable (Male Connector)
13222C	RS232C Cable (Female Connector)
13222W	HP 300 Cable (Female Connector)
13222Y	Three Wire Cable (Male Connector)
13265A	300 Baud Modem
13266A	Current Loop Converter



## Thermal Printer Paper

The HP 2621P mechanism uses a thermal printing paper produced specifically for use by this product. Printer paper can be purchased through your local HP Sales and Service Office using the following nomenclature and part number:

1 Box (24 rolls) Thermal Paper, HP Part No. 92160A (blue) or 92160B (black).

It is recommended that you always use this HP Thermal Paper in your terminal. If you have an HP Warranty and Service Contract, you must use HP Thermal Paper to maintain a valid contract. HP Warranty and Service Contracts are available through your local HP Sales and Service Office.

### Paper Loading

The print mechanism is shown in Figure 6-1.




Figure 6-1. Printer Mechanism

To load a roll of Thermal Paper into the printer, refer to Figure 6-1 and use the following instructions:

1. Lift the top cover of the printer mechanism. An illustration of the correct paper position and flow is embossed on the underside of this cover.
2. Press the latch (Figure 6-1) toward the front of the terminal to release the latching frame. Lift the hinged latching frame to its forward position.
3. Remove any paper remaining in the printer.
4. The center paper core is held in place by a metal rod inserted through the center of the core. Grasp the core and lift forward and upward along the guide slots to remove the paper core and rod.
5. Remove the rod from the old core and insert the rod through the core of a new roll of paper.
6. The Thermal Paper is coated with print material on one side and must be inserted into the printer correctly to produce the print image. The paper must feed toward the front of the terminal from the underside of the paper roll (see the embossed illustration on the top cover).

7. Place the ends of the metal rod into the guide slots on either side of the print mechanism and press downward and then toward the back of the terminal until the rod snaps into place.
8. Feed the leading edge of the paper through the latching frame (between the latching frame and the clear plastic guide window). Be careful not to sharply strike the print head because damage may result.
9. Each new roll of paper has a glue spot near the leading edge of the roll that holds the paper roll intact. You should not allow the print head to pass over this glue spot during print operations.
10. Feed approximately 12 inches of paper through the latching frame so that the glue spot is beyond (outside) the print head and guide window.
11. Lower the latching frame without locking it into place.  
  
Align the sides of the paper with the guide lines embossed on each side of the guide window.
12. **IMPORTANT!** Press down the latch until it locks into place with an audible click sound.
13. Tear off excess paper using the edge of the guide window as a cutting edge.
14. Close the top cover securely.











Note that if subsequent print operations appear normal except that no print image appears, the paper may have been inserted backwards. An image can be printed only on one side of the paper.

## Printer Control Functions

The printer control functions allow you to copy data from display memory to the internal line printer. When you request printer control functions (press **SHIFT** together with the Function key labeled [printer]), a new set of screen labels appear, as follows:

**REPORT** **PRT TEST** **LOG BTM** **LOG TOP**

**PAPER** **COPY ALL** **COPYPAGE** **COPYLINE**

Function Label	Key Stroke	Function
[REPORT]	Shifted 	Enable REPORT print mode; display an asterisk in label. For example, [REPORT *]. Subsequent print operations are in paged format, i.e., print 60 lines, skip 3 lines, print a tic mark for a page break, skip 3 lines, then print 60 lines, and so forth. To disable REPORT print mode, press the Shifted Function key once more.
	Control Shifted 	Enable Metric REPORT mode; press and hold down the <b>CTRL</b> and <b>SHIFT</b> keys while you press  . An asterisk is displayed in the REPORT label. For example, [REPORT *]. Subsequent print operations are in metric paged format; that is, print 64 lines, skip 3 lines, print a tic mark for a page break, skip 3 lines, then print 64 lines, and so forth. To disable Metric REPORT print mode, press either the Shifted Function key or Control Shifted Function key once more.
[PRT TEST]	Shifted 	Printer Test; execute test of internal printer mechanism. Display test pattern on printer.
[LOG BTM]	Shifted 	Enable Logging from Bottom of Memory; display asterisk in label. For example, [LOG BTM*]. Current line entry is copied to the printer upon the cursor leaving this line.
[LOG TOP]	Shifted 	Enable Logging from Top of Memory; display asterisk in label. For example [LOG TOP*]. Subsequent line that rolls off top of memory is copied to printer.
[PAPER]	Shifted 	Paper advance on Printer; move printer paper up one line.
[COPY ALL]	Shifted 	Copy all data from memory to printer (from current line position marked by cursor to end-of-memory).
[COPYPAGE]	Shifted 	Copy all data on screen to printer (from current line position marked by cursor to end-of-screen).
[COPYLINE]	Shifted 	Copy current line on screen (marked by cursor) to printer.

The control code for a Form Feed produces various results depending on the conditions existing when a Form Feed is encountered. If **REPORT** mode is disabled, Form Feed is ignored.

If **REPORT** mode is enabled, and **LOG TOP** and **LOG BTM** are disabled, Form Feed results in a top-of-page operation on the printer (skip to new page and print tic mark).

If **REPORT** mode is enabled, and **LOG TOP** is enabled, Form Feed results in completion of logging from the screen to the printer, a top-of-page operation on the printer (skip to new page and print tic mark), and a top-of-page operation on the screen (home up, clear display).

If **REPORT** mode is enabled, and **LOG BTM** is enabled, Form Feed results in a top-of-page operation on the printer (skip to new page and print tic mark), and a top-of-page operation on the screen (home up, clear display).

The cursor does not leave its current position when either **LOG TOP** or **LOG BTM** are enabled and a **COPY ALL**, **COPY PAGE**, or **COPY LINE** operation is requested. The copy operation is performed and the cursor remains stationary.

Control codes for operations such as Form Feed and Escape that are displayed on the screen are transferred to the printer during logging or copy operations. However, displayed control codes for Carriage Return and Linefeed are not transferred from the screen to the printer. Instead, a period character is substituted for the Carriage Return and Linefeed during the print operation.




Figure 6-2. Printer Test Display

## Printer Control Escape Sequences

Note that for each printer control sequence (`esc & p . . . .`) received from a host computer, the terminal generates a device completion status response character to inform the computer of the final disposition of the requested print operation. An S is returned to indicate successful completion, F to indicate a failed completion, or U to indicate that the user interfered with the completion of the requested operation (for example, the **RETURN** key was held down which prevented the operation from being completed).

Table 6-3. HP 2621P Escape Sequences, Printer Control

Function	Code	Description
Copy All Memory	esc 0	Position the cursor to the left margin of first line of memory data and copy all of memory to printer.
Log Data From Memory Bottom	esc & p 11 C	Enable data logging from the bottom of memory (print the current entry line).
Log Data From Memory Top	esc & p 12 C	Enable data logging from the top of memory (print line as it rolls off top of memory).
Log Data Function Off	esc & p 13 C	Disable data logging (top or bottom, whichever is enabled).
Copy All Memory	esc & p M	Print all data in memory from current line (marked by cursor) to end of memory.
Copy One Page	esc & p F	Print all data on screen from current line (marked by cursor) to end of screen.
Copy One Line	esc & p B	Print current line (marked by cursor).

## Preventive Maintenance

## Section VII

### Cleaning the Screen and Keyboard

The display screen and the keyboard should be cleaned regularly to remove dust and grease. First, lightly dust the entire terminal using a damp, lint-free cloth or paper towel. The cloth or paper towel should be damp enough to pick up any dust, but should not be wet. Avoid wiping dust or lint into the key area of the keyboard.

Greasy smudges and fingerprints can be removed using most conventional spray cleaners. Avoid spraying between the keys.

DO NOT use petroleum-based cleaners such as lighter fluid, or cleaners containing benzene, trichlorethylene, ammonia, dilute ammonia, or acetone because the terminal's plastic surfaces may be damaged.

### Battery Maintenance

The nonvolatile portion of memory that contains the terminal's configuration data is protected against destruction by a battery that is located just above the rear panel of your terminal. Figure 7-1 shows the rear panel and the location of the battery.




Figure 7-1. HP 2621 Battery Location, Rear Panel

## Preventive Maintenance

There is no care or maintenance required for the battery. The battery should be replaced with a new battery every 12 months. A new battery can be obtained through commercial sources. Request a Mallory Battery, Type TR133. In addition to commercial sources, you can order batteries through your local HP Sales and Service Office using the following nomenclature and number:

HP 2621A/P Battery, HP Part No. 1420-0259

You may want to record the Configuration data on paper before removing the old battery in case the Configuration data in the terminal's memory should be destroyed while the battery is not in place. You can use the following form to record the Configuration data:

Date battery replaced (Month, Day, Year): _____							
BAUD RATE (circle one):	EXT. 110 150 200 300 600 1200 1800 2400 3600 4800 9600						
PARITY (circle one):	NONE(0) NONE(1) EVEN ODD						
DUPLEX (circle one):	FULL HALF						
STRAPS (record state - uppercase or lowercase - in box): b c g h x z							
<table border="1"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table>							
HANDSHAKE (record state - uppercase or lowercase - in box): e t x							
<table border="1"><tr><td> </td><td> </td><td> </td></tr></table>							
HZ (circle one):	60 50						
START COL (record starting column number in box):	<table border="1"><tr><td> </td></tr></table>						
RETURN (record state in blank space):	[ CR ]						

To replace the battery:

1. Use your thumb and index finger to grasp the battery support at points A and B (see Figure 7-2).
2. Squeeze the tabs at points A and B toward the center of the battery support with enough pressure to disengage the flanges that hold the battery support in place.
3. Gently pull the support downward until it is completely free of the terminal housing.
4. Remove the old battery from the support.
5. Insert a new battery making sure that the positive end of the battery matches the positive end of the support (+ to + and - to -).
6. Reinsert the battery support into the terminal. A slotted guide along one side of the battery support ensures that the battery support is inserted correctly. The slotted guide must be facing away from the terminal case when you reinsert the support.




Figure 7-2. HP 2621 Battery Support





## Diagnosing Problems

## Section VIII

Press [SHIFT] together with the [TEST] Function key to perform a diagnostic test of the terminal. The test checks ROM, Video RAM, Program RAM, and the keyboard processor chip. In addition to these checks, a list of the full character set is displayed on the screen followed by a list of the terminals status bytes. Figure 8-1 shows the Self-test screen display. Appendix C defines the terminal's Primary status data.

If an error condition is encountered, an appropriate error message is displayed across the bottom of the screen (line 25). Table 8-1 contains a list of the error messages that may be generated as a result of test execution.

A diagnostic test of the terminal's data communication transmit, receive, and control lines can be performed under specific conditions. The data communications self-test is executed when you press both [CTRL] and [SHIFT] together with the [TEST] Function key. During the data communications test, signals are generated and transmitted from the terminal which must be "looped back" to the terminal to check the functioning of the data and control lines. This loop-back can be either a connector hood assembly or a modem interface that has an integral loop-back mode.

Detailed information about performing the data communications self-test and an interpretation of any resultant message is contained in the HP 2621 Service Manual, HP Part No. 02620-90002.




Figure 8-1. Self-Test Screen Display

Table 8-1. HP 2621 Diagnostic Error Messages

Message	Meaning	Action
PROGRAM RAM? <i>n1</i>	Error condition encountered in the Program RAM indicated by the value of <i>n1</i> which is in the range 0 through 1.	Contact a qualified service person (see the HP 2621 Interactive Terminal Service Manual).
DISPLAY RAM? <i>n2</i>	Error condition encountered in the Display RAM indicated by the value of <i>n2</i> which is in the range 0 through 7.	Contact a qualified service person (see the HP 2621 Interactive Terminal Service Manual).
ROM? <i>n3</i>	Error condition encountered in the ROM indicated by the value of <i>n3</i> which is in the range 0 through 1.	Contact a qualified service person (see the HP 2621 Interactive Terminal Service Manual).
KYBD CHIP?	Error condition encountered in the Keyboard Chip.	Contact a qualified service person (see the HP 2621 Interactive Terminal Service Manual).
PRINTER?	Error condition encountered in the printer mechanism.	Check to ensure that the latch or top cover is securely closed; check that the printer has a supply of paper.
PRINTER CHIP?	Error encountered in the printer chip.	Contact a qualified service person (see the HP 2621 Interactive Terminal Service Manual).

The following is a list of possible problem conditions that might occur together with suggested action for correcting the problem condition.

Problem	Action
<p>1. When you turn on the Main Power Switch, the terminal comes up in Configuration mode.</p>	<p>This indicates a possible problem with the memory—protect battery. Check to make sure that the battery is installed properly (+ to + and securely seated). If this action does not correct the problem, replace the battery.</p>
<p>2. When you turn on the Main Power Switch, the terminal comes up with Self-test running continuously.</p>	<p>Press and hold down <b>CTRL</b> and <b>SHIFT</b> while you press the <b>BREAK</b> key to reset the terminal.</p>
<p>3. When you press a character key on the keyboard and nothing appears on the screen.</p>	<p>This indicates that the terminal may have Remote mode enabled. Enter the Configuration mode to make sure that Remote mode is disabled.</p>
<p>4. In Remote Mode, the DEL character appears on the screen.</p>	<p>This indicates that there may be a Data Communications error, or a buffer overflow condition.</p>

## Resetting the Terminal

You reset the terminal by pressing and holding down the **CTRL** and **SHIFT** keys while you press the **BREAK** key. The result of this action is a reset to the initial Power On state. The Configuration parameters and screen labeled functions are not affected because they are protected from change within nonvolatile memory. The following default conditions do occur when the terminal is reset:

- CAPS Lock — disabled
- NUM Key — disabled
- TAB Stops — cleared except for left margin (column 1)
- Left Margin — set to column 1
- Right Margin — set to column 80
- DSPY FN — disabled
- MODIFY — disabled
- INS CHAR — disabled
- REPORT (HP 2621P only) — disabled
- LOG BTM (HP 2621P only) — disabled
- LOG TOP (HP 2621P only) — disabled




# Hewlett-Packard ASCII-coded Character Set

# Appendix A

BIT 7 4321	CONTROL (CNTL) CHARACTERS				DISPLAYABLE CHARACTERS			
	0 0	0 1	1 0	1 1	0 0	0 1	1 0	1 1
0000	@ NUL	P DLE	SP 0	@ P \ p				
0001	A S <sub>H</sub>	Q D <sub>1</sub>	I 1	A Q a q				
0010	B S <sub>X</sub>	R D <sub>2</sub>	" 2	B R b r				
0011	C E <sub>X</sub>	S D <sub>3</sub>	# 3	C S c s				
0100	D F <sub>T</sub>	T D <sub>4</sub>	S 4	D T d t				
0101	E E <sub>O</sub>	U N <sub>K</sub>	% 5	E U e u				
0110	F A <sub>K</sub>	V S <sub>V</sub>	& 6	F V f v				
0111	G W	W E <sub>B</sub>	' 7	G W g w				
1000	H B <sub>S</sub>	X C <sub>N</sub>	( 8	H X h x				
1001	I H <sub>T</sub>	Y E <sub>M</sub>	) 9	I Y i y				
1010	J L <sub>F</sub>	Z S <sub>B</sub>	* : J Z j z					
1011	K V <sub>T</sub>	ESC E <sub>C</sub>	+ ; K [ k {					
1100	L F <sub>F</sub>	FS F <sub>S</sub>	< , L \   !					
1101	M C <sub>R</sub>	GS G <sub>S</sub>	- = M   m					
1110	N S <sub>O</sub>	RS R <sub>S</sub>	. > N ^ n ~					
1111	O S <sub>I</sub>	US U <sub>S</sub>	/ ? O - o DEL					

- ␣ — ACKNOWLEDGE
- ␣ — BELL
- ␣ — BACKSPACE
- ␣ — CANCEL LINE
- ␣ — CARRIAGE RETURN
- ␣ — DATA LINK ESCAPE
- ␣ — DEVICE CONTROL 1
- ␣ — DEVICE CONTROL 2
- ␣ — DEVICE CONTROL 3
- ␣ — DEVICE CONTROL 4
- ␣ — DELETE
- ␣ — END OF MEDIUM
- ␣ — ENQUIRY
- ␣ — END OF TRANSMISSION
- ␣ — ESCAPE
- ␣ — END OF BLOCK
- ␣ — END OF TEXT
- ␣ — FORM FEED
- ␣ — FILE SEPARATOR
- ␣ — GROUP SEPARATOR
- ␣ — HORIZONTAL TAB
- ␣ — LINE FEED
- ␣ — NEGATIVE ACKNOWLEDGE
- ␣ — RECORD SEPARATOR
- ␣ — SHIFT IN
- ␣ — SHIFT OUT
- ␣ — SPACE
- ␣ — START OF HEADING
- ␣ — START OF TEXT
- ␣ — SYNCHRONOUS IDLE
- ␣ — UNIT SEPARATOR
- ␣ — VERTICAL TAB

Control Character Legend:



BIT 7 4321	ESCAPE SENT FIRST					
	0 1	0 1	1 0	1 0	1 1	1 1
0000	SP ① PRINT ALL	0 DELAY 1 SEC	@ DELETE CHAR	P RELATIVE CURSOR SENSE	Ⓝ f <sub>1</sub>	p
0001	I SET TAB	1 CURSOR UP	A INSERT CHAR ON	Q ABSOLUTE CURSOR SENSE	a f <sub>2</sub>	q
0010	" CLEAR TAB	2 CURSOR DOWN	B INSERT CHAR OFF	R	b f <sub>3</sub>	r
0011	# CLEAR ALL TABS	3 CURSOR RIGHT	C ROLL UP	S	c f <sub>4</sub>	s
0100	S SET LEFT MARGIN	4 CURSOR LEFT	D ROLL DOWN	T ENTER	d f <sub>5</sub>	t
0101	% SET RIGHT MARGIN	5 RESET TERMINAL	E	U	e f <sub>6</sub>	u
0110	& PARA METER SEQUENCE	6 CURSOR HOME DOWN	F	V MODEM DIS CONNECT	f f <sub>7</sub>	v
0111	' CURSOR RETURN	7 HOME CURSOR	G	W HOME CURSOR	g f <sub>8</sub>	w
1000	{	8	H	X	h	x
1001	}	9	I	Y	i	y
1010	*	:	J	Z	j	z
1011	+	;	K	[	k	{
1100	,	<	L	\		!
1101	-	=	M		m	
1110	.	>	N	^	n	~
1111	/	?	O	-	o	DEL

# Hewlett-Packard ASCII-coded Character Set

## NOTES:

1. The  $\text{Esc}$  & parameter sequences are:

### Memory and Screen Addressing

$\text{Esc} \& a$ <i>memory row number r column number C</i>	Absolute Memory Addressing
$\text{Esc} \& A$ <i>screen row number y column number C</i>	Absolute Screen Addressing
$\text{Esc} \& a$ $\pm$ <i>memory row number r column number C</i>	Relative Memory Addressing
$\text{Esc} \& A$ $\pm$ <i>screen row number y <math>\pm</math> column number C</i>	Relative Screen Addressing

### Display Enhancement

$\text{Esc} \& d$ A through D	Enable Enhancement
$\text{Esc} \& d$ ●	Disable Enhancement

### Screen Labels Control

$\text{Esc} \& j$ @	Clear Screen Labels
$\text{Esc} \& j$ A	Display Screen Labels
$\text{Esc} \& j$ B	Display f1 — f8 Screen Labels

### Printer Control (HP 2621P Only)

$\text{Esc} \& p$ 11 C	LOG BTM On
$\text{Esc} \& p$ 12 C	LOG TOP On
$\text{Esc} \& p$ 13 C	LOG BTM/LOG TOP Off
$\text{Esc} \& p$ M	Copy All Memory
$\text{Esc} \& p$ B	Copy Current Line
$\text{Esc} \& p$ F	Copy Current Page

2. In REMOTE Mode, upon receipt of  $\text{Esc} \& ^$ , the terminal responds with:  
 $\text{Esc} \backslash$  *terminal primary status bytes* (see Appendix C)
3. These escape sequences ( $\text{Esc} p$  through  $\text{Esc} w$ ) are transmit sequences only.
4. In REMOTE Mode, upon receipt of  $\text{Esc} \backslash$ , the terminal responds with:  
 $\text{Esc} \& a$  *column number c screen row Y*
5. In REMOTE Mode, upon receipt of  $\text{Esc} a$ , the terminal responds with:  
 $\text{Esc} \& a$  *column number c memory row R*

### Note

If  $\text{Esc}$  space through  $\text{Esc} /$  is sent to the terminal, the keyboard will be locked until a capital letter (A-Z) is received as data communications input.

Escape sequences that are not used by the terminal are ignored. However, they still must be terminated by a capital letter (A-Z) before the terminal can return to normal operation.

# Cable Connector Pin Assignments

# Appendix B

HP 13222N U.S.A. Modem Cable Connector Pin Assignments

50-Pin Terminal Connector Pin Number	RS232C/CCITT V.24 Code Description	25-Pin Modem Connector Pin Number
7	DA/113 Transmit Signal Element Timing	24
9	CE/125 Ring Indicator	22
12	BA/103 Transmitted Data (Data Out)	2
13	CA/105 Request To Send	4
14	CD/108.2 Data Terminal Ready	20
15	SCA/120 Secondary Request To Send	11
24	AA/- Protective Ground	1
40	CH/111 Data Signal Rate Selector	23
41	DB/114 Transmission Signal Element Timing	15
42	BB/104 Received Data (Data In)	3
43	DD/115 Receiver Signal Element Timing	17
44	CB/106 Clear To Send	5
45	CC/107 Data Set Ready	6
46	CF/109 Received Line Signal Detector	8
47	SCF/122 Secondary Received Line Signal Detector	12
48	AB/102 Signal Ground (Common Return)	7



## Cable Connector Pin Assignments

### HP 13222M European Modem Cable Connector Pin Assignments

50-Pin Terminal Connector Pin Number	RS232C/CCITT V.24 Code Description	25-Pin Modem Connector Pin Number
7	DA/113 Transmit Signal Element Timing	24
9	CE/125 Ring Indicator	22
12	BA/103 Transmitted Data (Data Out)	2
13	CA/105 Request To Send	4
14	CD/108.2 Data Terminal Ready	20
15	SCA/120 Secondary Request To Send	19
24	AA/- Protective Ground	1
40	CH/111 Data Signal Rate Selector	23
41	DB/114 Transmission Signal Element Timing	15
42	BB/104 Received Data (Data In)	3
43	DD/115 Receiver Signal Element Timing	17
44	CB/106 Clear To Send	5
45	CC/107 Data Set Ready	6
46	CF/109 Received Line Signal Detector	8
47	SCF/122 Secondary Received Line Signal Detector	12
48	AB/102 Signal Ground (Common Return)	7

## Cable Connector Pin Assignments

### HP 13222C RS232 Data Comm Cable Connector Pin Assignments

50-Pin Terminal Connector Pin Number	RS232C/CCITT V.24 Code Descrip- tion	25-Pin RS 232 Connector Pin Number
12	BA/ 103 Transmitted Data (Data Out)	2
13	CA/ 105 Request To Send	4
14	CD/ 108.2 Data Terminal Ready	20
15	SCA/ 120 Secondary Request To Send	11 (USA), 19 Eu- rope
24	AA/ - Protective Ground	1
34	x16 Clock In	25
42	BB/ 104 Received Data (Data In)	3
44	CB/ 106 Clear To Send	5
46	CF/ 109 Received Line Signal Detec- tor	8
47	SCF/ 122 Secondary Received Line Signal Detector	12
48	AB/ 102 Signal Ground (Common Re- turn)	7
49	x8 Clock Out	16
50	x16 Clock Out	24

100



## Terminal Status

### Primary Status

The primary status of the terminal is shown as the last data item whenever the terminal self-test function is executed. In addition to obtaining a display of primary status using self-test, you may request the primary status programmatically by sending the status request escape sequence (`esc ^`) from a computer to your terminal.

Upon receipt of the status request escape sequence, the terminal responds with an `esc \` followed by seven status bytes represented in ASCII character notation and a terminator. The terminator included in the response is usually a Return character but its value depends on the content of the configuration data Return field and the state of the automatic linefeed function.

The primary status bytes provide information about the terminal's current status, i.e., display memory size, strap states, keyboard interface configuration, and terminal error

conditions. The seven status bytes are referred to as byte 0 through byte 6 and are displayed as seven ASCII characters. For example:

4088020  
↑           ↑  
byte 0     byte 6




The status data is contained in the lower four bits of each byte. The upper four bits are set so that the entire byte represents an ASCII character. Thus, each status byte is interpreted as one ASCII character. These characters are defined in Table C-1.

Table C-1. Status Byte Interpretation

ASCII Character	Binary Value	ASCII Character	Binary Value
0	0011 0000	8	0011 1000
1	0011 0001	9	0011 1001
2	0011 0010	:	0011 1010
3	0011 0011	::	0011 1011
4	0011 0100	<	0011 1100
5	0011 0101	=	0011 1101
6	0011 0110	>	0011 1110
7	0011 0111	?	0011 1111

## Terminal Status

Figure C-1 shows an example of a typical status request and response interchange between a computer and a terminal.



BYTE	ASCII	BINARY	STATUS
0	4	0011 0100	4,096 bytes of display memory
1	0	0011 0000	Space overwrite latch disabled, strap b Cursor wraparound enabled, strap c
2	8	0011 1000	Short transfer handshake disabled, strap g Long transfer handshake enabled, strap H
3	8	0011 1000	CAPS LK disabled LN MODE disabled AUTO LF disabled
4	0	0011 0000	No Cursor Sense Pending No Function key transfer pending No ENTER key transfer pending
5	2	0011 0010	No data communication errors Last Self-Test successful
6	0	0011 0000	No device completion pending

Figure C-1. Example: Typical Terminal Status

Figure C-2 is an illustration of the binary characteristics of each byte together with an interpretation of its meaning in the terminal's status response.




Figure C-2. Primary Status Byte Characteristics



## Cursor Sensing

You can obtain the current position of the screen cursor via an escape sequence. You may issue a request either for the absolute position of the cursor in display memory, or for the cursor position relative to the beginning of the current screen page. The terminal's response to these requests is a Short Transfer Trigger Handshake and is affected by the setting of the `g` and `h` straps (see Strap Configuration in Section V).

### NOTES:

- 1) Generally, actual cursor positional values are referenced in the following notation:
  - screen column positions–1 through 80
  - screen row positions–1 through 24
  - memory row positions–1 through 48
- 2) For cursor sensing and addressing, the positional values are referenced in the following notation:
  - screen column positions–0 through 79
  - screen row positions–0 through 23
  - memory row positions–0 through 47

### Absolute Cursor Sensing

You determine the absolute position of the cursor within display memory by issuing the following escape sequence:

```
esc a
```

In response to this request, the terminal generates an `esc & a` followed by numeric values that specify the column and row number at which the cursor currently resides within display memory.

For example, assume that the cursor resides at column 20, memory row 40.

You cause the following escape sequence to be issued from the computer:

```
esc a
```

The terminal responds with:

```
esc & a 019c 039R
```

You use this response to determine the absolute position of the cursor, where `019c` represents physical column 20 and `039R` represents physical memory row 40.

## Appendix D

### Relative Cursor Sensing

You determine the position of the cursor relative to the beginning of the currently displayed screen page by issuing the following escape sequence:

```
esc `
```

In response to this request, the terminal generates an `esc & a` followed by numeric values that specify the column number and the row number at which the cursor resides relative to screen row 0.

For example, assume that the cursor resides at column 20, memory row 40, and screen row 0 is at memory row 35.

You cause the following escape sequence to be issued from the computer:

```
esc `
```

The terminal responds with:

```
esc & a 019c 005Y
```

You use this response to determine the position of the cursor relative to the beginning of the currently displayed screen page, where `019c` represents physical column 20 and `005Y` represents physical screen row 6.





## Terms Used in This Manual

A glossary of terms pertinent to the HP 2621 Interactive Terminal is given in the following table. Being familiar with these terms and their definitions will help you to understand the descriptive material in this manual.

Column	A single character position within a row or line of data on the display screen. Beginning with the first character position at the left side of your display screen, the columns are numbered from 1 through 80.
Configuration Data	Your HP 2621 has no hardware straps or switches for data transmission baud rate and parity values. Instead, this information is stored in nonvolatile memory as part of your terminal's configuration. You may redefine the configuration data via function keys.
Cursor	The cursor acts as a pointer for subsequent character—entry action. The cursor is a blinking underline that appears on the display screen to show you where the next character or space will occur. You can control cursor movement via cursor positioning keys, or escape sequence codes.
Data Communication	The means by which your terminal handles the transfer of data between itself and an external data processing device, such as a computer. The HP 2621 supports asynchronous point-to-point data communication.

Data Transfer Operation

The process of transferring data from one device to another. For example, the transfer of data from the display screen (or display memory) to a remote computer, or to a peripheral device such as a line printer.

Display Memory

The random access display memory (RAM) portion of your terminal in which the results of your keyboard or data transfer operations are stored. The display memory stores up to 48 text lines of 80 character positions per line.

Display Screen

The cathode ray tube (CRT) screen portion of your terminal upon which the results of your keyboard or data transfer operations are displayed. The display screen format is 25 rows of 80 character positions per row. Text from the display memory appears in screen rows 1 through 24. Row 25 is used to display the current function key labels and error messages.

Function Keys

A set of nine light-colored keys on your keyboard that cause execution of special functions such as cursor and text control, terminal control, and so forth. Eight of the function keys are located across the top of your keyboard. The remaining key (the Labels key) is located to the right of the character keys. The Labels key cap is unmarked. It is the only blank key cap on the keyboard.

Home Cursor	<p>The cursor has two home positions; the left margin setting of the first row of display memory data (home cursor up), and the left margin setting of the blank line following the last row of display memory data (home cursor down). These home positions are obtained via cursor control function keys, or escape sequence codes.</p>	Numeric Pad	<p>A calculator-type numeric key pad is incorporated into the ASCII-character keyboard. This pad is useful for entering large amounts of numeric data. The numeric pad is accessed via the <b>NUM</b> key.</p>
Labels Key	<p>This is the function key located to the right of the character keys. The Labels key is used to select various screen labeled functions which you can access via the function keys.</p>	Page	<p>The 24 lines of data (including blank lines) that can be displayed on your terminal's screen at any given time.</p>
Line	<p>A string of from 0 through 80 characters appearing on your display screen and/or stored in display memory. A zero-length line is displayed as a blank line on the screen. The terms line and row are synonymous. Generally, line is used in reference to data in display memory while row is used for data displayed on the screen. See "Display Memory".</p>	Parity	<p>Parity refers to a check bit that is added as the high bit of each byte as it is transmitted and checked for the correct value as it is received over the data communications line.</p>
Local Operation	<p>The off-line operation of your terminal. That is, without the aid of an external data processing device such as a computer.</p>	Remote Operation	<p>The on-line operation of your terminal; that is, using the terminal while actively connected to an external data processing device such as a computer.</p>
Nonvolatile Memory	<p>The portion of memory that contains your terminal's configuration data (strapping, baud rate, and parity) is protected from destruction by a battery. If the terminal's main power source is interrupted for any reason, the data in this portion of memory remains intact.</p>	Row	<p>A single horizontal line on the display screen capable of containing a line of data from display memory. There are 25 rows on your terminal's screen. The first 24 rows are used for displaying text from display memory. Row 25 is used to display function key labels, the active modem indicator, current column position pointer, and error messages. The terms row and line are synonymous. Generally, row is used in reference to data displayed on the screen while line is used for data in display memory. See "Display Screen".</p>

# INDEX

- a guide to using the manual . . . . . iii
- accessories, HP 2621P . . . . . 2-1
  - HP 2621P . . . . . 6-1
- active modem, indicator . . . . . 4-9
- air flow . . . . . 2-2
- ASCII-coded character set, HP . . . . . A-1
- ASCII-coded control codes . . . . . 5-20
- AUTO LF function . . . . . 5-4
- automatic linefeed function . . . . . 5-4
  
- battery, location . . . . . 7-1
  - maintenance . . . . . 7-1
  - ordering . . . . . 7-1
  - replacement . . . . . 7-3
  - support . . . . . 7-3
- baud rate configuration . . . . . 5-5
- block transfer handshake . . . . . 5-7
- bottom, memory . . . . . 3-2
  
- cable connector, pin assignments . . . . . B-1
- CAPS LK function . . . . . 5-4
- changing a character . . . . . 3-3
- character mode, defined . . . . . 1-3
  - long transfer . . . . . 5-7
- character set group, introduction . . . . . 4-1
- characteristics, terminal . . . . . 3-1
- cleaning, keyboard . . . . . 7-1
  - screen . . . . . 7-1
- clear display function . . . . . 4-10, 4-14
- clear line function . . . . . 4-10, 4-14
- clear margins function . . . . . 4-12
- clear tab function . . . . . 4-12
  
- clear tabs function . . . . . 4-12
- CLR DSPY function . . . . . 4-10, 4-14
- CLR LINE function . . . . . 4-10, 4-14
- CLR MARGIN function . . . . . 4-12
- CLR TAB function . . . . . 4-12
- CLR TABS function . . . . . 4-12
- column position indicator . . . . . 4-9
- config function . . . . . 4-10
- configuration function . . . . . 4-10
- configuration function keys, description . . . . . 5-2
- configuration function labels set . . . . . 4-12
- configuration mode, termination . . . . . 5-11
- configuration screen labels . . . . . 4-7
- configuration, handshake . . . . . 5-10
  - introduction . . . . . 1-3
  - strapping . . . . . 5-6
- configuring your terminal . . . . . 5-1
- connector locations . . . . . 2-2
- control codes, ASCII-coded . . . . . 5-20
- control functions, printer . . . . . 6-3
- COPY ALL function . . . . . 6-4
- COPYLINE function . . . . . 6-4
- COPYPAGE function . . . . . 6-4
- cursor address control,
  - escape sequences . . . . . 5-17
- cursor control labels . . . . . 4-7
- cursor control, escape sequences . . . . . 5-14
- cursor, down . . . . . 4-6
  - home down . . . . . 4-4
  - home up . . . . . 4-4
  - left . . . . . 4-6
  - right . . . . . 4-6
  - up . . . . . 4-5
- cursor sensing . . . . . 5-14, 5-17, D-1
  
- data communications connector, location . . . . . 2-2
- data communications, introduction . . . . . 1-3
- data speed select . . . . . 5-9
- data transmission from a computer . . . . . 5-14
- data transmission to a computer . . . . . 5-12
- DC1 trigger handshake . . . . . 5-8
- DC1/DC2 handshake protocol . . . . . 5-7
- DC1/DC2/DC1 warning handshake . . . . . 5-8
- DEL CHAR function . . . . . 4-15
- DEL LINE function . . . . . 4-14
- delete character function . . . . . 4-15
- delete line function . . . . . 4-14
- diagnosing problems . . . . . 8-1
- diagnostic error messages . . . . . 8-2
- display characteristics . . . . . 3-1
- display enhancement . . . . . 3-3
- display enhancement control,
  - escape sequences . . . . . 5-18
- display functions function . . . . . 4-10
- display memory . . . . . 1-2
- display screen . . . . . 1-2
- DSPY FN function . . . . . 4-11
- duplex configuration . . . . . 5-5
  
- edit control function label set . . . . . 4-13
- edit control, escape sequences . . . . . 5-15
- edit function . . . . . 4-10, 4-11
- editing screen labels . . . . . 4-7
- enhanced field, define . . . . . 3-3
  - terminate . . . . . 3-3
- enhancement, display . . . . . 3-3
- ENQ/ACK handshake . . . . . 5-10
- error messages, diagnostic . . . . . 8-2

escape code sequences, introduction	5-14	in case of difficulty	2-3	maintenance, battery	7-1
<b>escape sequences transmitted by</b>		<b>indicator, active modem</b>	<b>4-9</b>	<b>preventive</b>	<b>7-1</b>
the terminal	5-19	column position	4-9	margin control function labels set	4-12
<b>escape sequences,</b>		<b>inhibit DC2</b>	<b>5-7</b>	margin control, escape sequences	5-15
cursor address control	5-17	<b>INS CHA function</b>	<b>4-15</b>	memory, bottom	3-2
cursor control	5-15	INS LINE function	4-14	characteristics	3-2
display enhancement control	5-18	insert character function	4-15	page	1-2, 3-2
edit control	5-15	insert line function	4-14	top	3-2
margin control	5-15			display	1-2
miscellaneous control	5-16			miscellaneous control, escape sequences	5-16
printer control	6-6			modem considerations	5-12
screen control	5-15			modem off function	5-3
screen labels control	5-18	key, labels	4-7	modem, active indicator	4-9
tab control	5-15	keyboard connector, location	2-2	MODIFY function	4-13
terminal control	5-15	keyboard, cleaning	7-1	MODM OFF function	5-3
EXIT function	5-3	description	4-1	move cursor down	4-6
		introduction	1-2	move cursor left	4-6
				move cursor right	4-6
				move cursor up	4-5
f1 — f8 screen labels	4-7				
function key group, description	4-4	L MARGIN function	4-12	NEXT function	5-3
introduction	4-1	labels key	4-7	NUM key, description	4-3
function key, shifted	4-9	labels key, control shifted	4-8	shifted	4-3
unshifted	4-4	shifted	4-8	unshifted	4-3
function keys, introduction	1-2	unshifted	4-8	numeric pad group, description	4-3
		labels, cursor control	4-7	introduction	4-1
handshake configuration	5-10	screen	4-7		
handshake protocol strapping effects	5-9	screen control	4-7	options, HP 2621A	2-1
handshake, ENQ/ACK	5-10	left margin function	4-12	HP 2621P	6-1
transmit	5-10	line mode function	5-4		
XON/XOFF	5-10	line mode, defined	1-3	page, memory	1-2
home cursor down	4-4	long transfer	5-7	PAPER function	6-4
home cursor up	4-4	LN MODE function	5-4	paper, printer	6-2
HP 2621, introduction	1-1	loading, printer paper	6-2	parity check	5-9
HP 2621A, accessories	2-1	LOG BTM function	6-4	parity configuration	5-5
options	2-1	LOG TOP function	6-4	pin assignments, cable connector	B-1
HP 2621P, accessories	6-1	logical start-of-text	5-13	power cord connector, location	2-2
introduction	6-1	long transfer, character mode	5-7	pointer, logical start-of-text	5-13
options	6-1	line mode	5-7		
Hz configuration	5-11				

power switch, location .....	2-2
off .....	2-3
on .....	2-3
preparing your terminal for use .....	2-2
preventive maintenance .....	7-1
PREVIOUS function .....	5-3

## primary screen labels ..... 4-1

primary status, screen display .....	8-1, C-1
printer control function labels set .....	6-3
printer control functions .....	6-3
printer control, escape sequences .....	6-6
printer function .....	4-10
printer mechanism .....	6-2
printer screen labels .....	4-7
printer test, display .....	6-5
function .....	6-4
problems, diagnosing .....	8-1
what to do .....	2-3
protocol, DC1/DC2 handshake .....	5-7
handshake strapping .....	5-9
PRT TEST function .....	6-4

R MARGIN function .....	4-12
receiving data from a computer .....	5-14
REMOTE function .....	5-3
remote operating mode selection .....	5-12
replacing a character .....	3-3
replacing the battery .....	7-3
REPORT function .....	6-4
report mode .....	6-5

resetting the terminal .....	8-3
return key configuration .....	5-11
right margin function .....	4-12
roll text down .....	4-5
roll text up .....	4-5

## screen characteristics ..... 3-1

screen control labels .....	4-7
screen control, escape sequences .....	5-15
screen labels control, escape sequences .....	5-18
screen labels, configuration .....	4-7
editing .....	4-7
f1 — f8 .....	4-7
introduction .....	4-7
primary .....	4-7
printer .....	4-7
structure .....	4-7
tab/margin .....	4-7
screen, cleaning .....	7-1
display .....	1-2
selecting remote operating mode .....	5-12
self-test, introduction .....	1-3
screen display .....	8-1
sending data to a computer .....	5-12
SET TAB function .....	4-12
short transfer trigger handshake .....	5-7
space overwrite (SPOW) latch .....	5-6
start column configuration .....	5-11
start-of-text, logical .....	5-13
status, terminal .....	C-1
strap configuration .....	5-6

tab control function labels set .....	4-12
tab control, escape sequences .....	5-15
tab/mrgn function .....	4-10, 4-11
tab/margin screen labels .....	4-7
terminal control, escape sequences .....	5-15
terminal preparation .....	2-2

## terminal reset ..... 8-3

terminal status .....	C-1
terminating configuration mode .....	5-11
terms used in the manual .....	Glossary-1
TEST function .....	4-10
text, roll down .....	4-5
text, roll up .....	4-5
thermal printer paper, description .....	6-2
loading .....	6-2
ordering .....	6-2
top, memory .....	3-2
transfer warning handshake .....	5-7
transmit handshake .....	5-10
underline, enhancement .....	3-3
UNDRLINE function .....	4-14
wraparound cursor, end-of-line .....	5-6
XON/XOFF handshake .....	5-10



2621 A/P Owner's Manual

Part No. 02620-90001 Printed: 6/80

Your Comments, Please . . . . .

Your comments assist us in improving the usefulness of our publications. Comments are an important part of the inputs used in preparing updates to manuals.

Please complete the questionnaire, fold it up and return it to us. Feel free to mark more than one box to a question and to make any additional comments. If you prefer not to give us your name just leave the last part, name and address, blank. All comments and suggestions become the property of HP.

*Thank you for your help.*

1. Did you have any difficulty in understanding or applying the material presented in this manual?

None  Minimal Difficulty  Difficulty  Considerable Difficulty

If so:

a. What were the "difficult" areas?

Indexing?  Depth of coverage?  Examples?  
 Organization?  Omitted information?  Other (Please explain)

b. How could we clarify these areas? \_\_\_\_\_

2. What errors or misleading information have you found in the manual? (Please give page numbers.) \_\_\_\_\_

3. What was your level of programming knowledge before you started using this manual?

None  Beginner  Intermediate  Expert

4. What is your major application of the terminal?

Business Administration  Interfacing  Medicine  
 General Computation  Education  What kind?  
 Engineering  Data Entry  Other  
What kind?  Control

5. What best describes how you use the terminal?

Run programs written by others  Do applications programming  Hobbyist  
 Write simple programs  Write complex programs  Other  
 Do simple calculations

6. General Comments: \_\_\_\_\_

Name: \_\_\_\_\_

Address: \_\_\_\_\_

*Thank you for your help. No postage necessary if mailed in the U.S.A.*






**BUSINESS REPLY MAIL**  
FIRST CLASS PERMIT NO. 506 CUPERTINO, CA., U.S.A.

POSTAGE WILL BE PAID BY ADDRESSEE

**Hewlett-Packard**  
**Attn: Ed Hayes**  
**974 Arques Avenue**  
**Sunnyvale, California USA 94086**

NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



**SALES & SERVICE OFFICES**

**AFRICA, ASIA, AUSTRALIA**

**ANGOLA**

Teletra  
Empresa Técnica de Equipamentos  
Ectricos, S.A.R.L.  
R. Barbosa Rodrigues, 42-1<sup>o</sup>DT.  
Caixa Postal, 6487  
**Luanda**  
Tel: 355156  
Cable: TELECTRA Luanda

**AUSTRALIA**

Hewlett-Packard Australia  
Pty Ltd.  
31-41 Joseph Street  
**Blackburn**, Victoria 3130  
P.O. Box 36  
**Donsdale East**, Victoria 3109  
Tel: 896351  
Telex: 31-024  
Cable: HEWPARD Melbourne

**Hewlett-Packard Australia**

Pty Ltd.  
31 Bridge Street  
**Pymble**  
New South Wales, 2073  
Tel: 4495566  
Telex: 21561  
Cable: HEWPARD Sydney  
Hewlett-Packard Australia  
Pty Ltd.  
153 Greenhill Road  
**Parkside**, S.A., 5063  
Tel: 2725911  
Telex: 82536  
Cable: HEWPARD Adelaide  
Hewlett-Packard Australia  
Pty Ltd.

141irling Highway  
**Nedlands**, W.A. 6009  
Tel: 3865455  
Telex: 93859  
Cable: HEWPARD Perth

**Hewlett-Packard Australia**

Pty Ltd.  
121 Wollongong Street  
**Fyshwick**, A.C.T. 2609  
Tel: 804244  
Telex: 62650  
Cable: HEWPARD Canberra  
Hewlett-Packard Australia  
Pty Ltd.

5th Floor  
Teachers Union Building  
495-499 Boundary Street  
**Spring Hill**, Queensland 4000  
Tel: 2291544  
Cable: HEWPARD Brisbane

**BANGLADESH**

The General Electric Co. of Bangladesh Ltd.  
Magnet House 72  
Ditkusha Commercial Area  
**Mitkhil**, Dacca 2  
Tel: 252415, 252419  
Telex: 724  
Cable: GECDAC Dacca

**ETHIOPIA**

Abdel Abdulmakki  
P.O. Box 2635  
**Addis Ababa**  
Tel: 11 93 40  
GUM  
Medical Only  
Guam Medical Supply, Inc.  
Suite C, Airport Plaza  
P.O. Box 8947  
**Tamuning** 96911  
Tel: 646-4513  
Cable: EARMED Guam

**HONG KONG**

Schmitt & Co. (Hong Kong) Ltd  
Wing On Centre, 28th Floor  
Connaught Road, C.  
**Hong Kong**  
Tel: 5-455644  
Telex: 74766 SCHMC HK

**INDIA**

Blue Star Ltd.  
234 Kodambakkam High Road  
**Madras** 600 034  
Tel: 82056  
Telex: 041-379  
Cable: BLUESTAR  
Blue Star Ltd.  
234 Kodambakkam High Road  
**Madras** 600 034  
Tel: 82056  
Telex: 041-379  
Cable: BLUESTAR

**JAKARTA**

BHCA Indonesia P.T.  
P.O. Box 4961kt  
Jin Abdul Muis 62  
**Jakarta**  
Prabadevi  
Jambashi 400 025  
Tel: 45 76 87  
Telex: 011-4093  
Cable: FROSTBLUE

**PRABHDEVI**

Blue Star Ltd.  
Bang Box House  
Prabadevi  
**Bombay** 400 025  
Tel: 45 73 01  
Telex: 011-3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Bhavdeep  
Stadium Road  
**Ahmedabad** 380 014  
Tel: 42980  
Telex: 231-0131  
Cable: BLUEFROST

**Blue Star Ltd.**

7th & 8th Floor  
**New Delhi** 110 024  
Tel: 534770 & 535166  
Telex: 031-2483  
Cable: BLUESTAR

Blue Star Ltd.  
Blue Star House  
11/11A Magarath Road  
**Bangalore** 560 025  
Tel: 55668  
Telex: 043-430  
Cable: BLUESTAR  
Blue Star Ltd.  
Meakshi Mandiram  
xxx/1678 Mahatma Gandhi Rd.  
**Cochin** 582 016  
Tel: 32068-32181-32282  
Telex: 0885-514  
Cable: BLUESTAR

Mito Mitsui Building  
105, 1-chome, San-no-maru  
**Mito**, Ibaragi 310  
Tel: 0292-25-7470  
Yokogawa-Hewlett-Packard Ltd.  
Mito Mitsui Building  
105, 1-chome, San-no-maru  
**Mito**, Ibaragi 310  
Tel: 0462-24-0452

Yokogawa-Hewlett-Packard Ltd.  
Kumagaya Asahi  
Hachiumi Building  
4th Floor  
3-4 Tsukuba  
**Kumagaya**, Saitama 360  
Tel: 0465-24-6533

**KENYA**  
Advanced Communications Ltd.  
P.O. Box 30070  
**Nairobi**  
Tel: 331955  
Telex: 22639  
Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 19012  
**Nairobi** Airport  
**Nairobi**  
Tel: 356055-56  
Telex: 22201/22301  
Cable: INTAERIO Nairobi

Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 95221  
**Mombasa**

**KOREA**  
Samsung Electronics Co., Ltd.  
15th Floor, Daeyoung Bldg.,  
25-5, 1-KA  
Chong Moo-Ro, Chung-Ku,  
**Seoul**  
Tel: 2231 6811, 778-3401-2/3,4  
Telex: 22575

Yokogawa-Hewlett-Packard Ltd.  
Onno Bldg., 4th Floor  
4-20, Nishinakajima 5-chome  
Yodogawa-ku, Osaka-shi  
**Osaka** 532  
Tel: 06-334-6021  
Telex: 523-3624  
Yokogawa-Hewlett-Packard Ltd.  
29-21, Takaido-Higashi 3-chome  
Suginami-ku, Tokyo 168  
Tel: 03-331-5111  
Telex: 232-2024 YHP-Tokyo  
Cable: YHPMARKET TOK 23 724

Yokogawa-Hewlett-Packard Ltd.  
Nakamo Building  
24 Kami Sasajima-cho  
Nakamura-ku, **Nagoya**, 450  
Tel: 052 571-5171  
Yokogawa-Hewlett-Packard Ltd.  
Tanigawa Building  
2-24-1 Tsuruya-cho  
Kanagawa-ku  
**Yokohama**, 221  
Tel: 045-312-1252  
Telex: 383-3204 YHP YDK

Yokogawa-Hewlett-Packard Ltd.  
Mito Mitsui Building  
105, 1-chome, San-no-maru  
**Mito**, Ibaragi 310  
Tel: 0292-25-7470  
Yokogawa-Hewlett-Packard Ltd.  
Imoue Building  
1348-3, Asahi-cho, 1-chome  
**Atsugi**, Kanagawa 243  
Tel: 0462-24-0452

Yokogawa-Hewlett-Packard Ltd.  
Kumagaya Asahi  
Hachiumi Building  
4th Floor  
3-4 Tsukuba  
**Kumagaya**, Saitama 360  
Tel: 0465-24-6533

Advanced Communications Ltd.  
P.O. Box 30070  
**Nairobi**  
Tel: 331955  
Telex: 22639  
Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 19012  
**Nairobi** Airport  
**Nairobi**  
Tel: 356055-56  
Telex: 22201/22301  
Cable: INTAERIO Nairobi

Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 95221  
**Mombasa**

**KOREA**  
Samsung Electronics Co., Ltd.  
15th Floor, Daeyoung Bldg.,  
25-5, 1-KA  
Chong Moo-Ro, Chung-Ku,  
**Seoul**  
Tel: 2231 6811, 778-3401-2/3,4  
Telex: 22575

**MALAYSIA**  
Hewlett-Packard Sales SDN BHD  
Suite 2, 21/22  
Jalan Ampang  
Bangunan Angkasa Raya  
**Kuala Lumpur**  
Tel: 23320/27491

Protal Engineering  
P.O. Box 917  
Lot 259, Satok Road  
Kuching, **Sarawak**  
Tel: 53344  
Cable: PROTELENG  
**MOZAMBIQUE**  
A N Goncalves, Ltd.  
162, 1<sup>o</sup> Apt., 14 Av. D. Luis  
Caixa Postal 107  
**Maputo**  
Tel: 27091, 27114  
Telex: 6-203 NEGON Mo  
Cable: NEGON

**NEW GUINEA**  
Hewlett-Packard Australia  
Pty Ltd.  
Development Bank Building  
Ground Floor  
Ward Strip  
**Port Moresby**, Paupua  
Tel: 258933

**NEW ZEALAND**  
Hewlett-Packard (N.Z.) Ltd.  
4112 Cruckshank Street  
Kilbirnie, Wellington 3  
P.O. Box 9443  
Courtney Place  
**Wellington**  
Tel: 877-199  
Cable: HEWPACK Wellington  
Hewlett-Packard (N.Z.) Ltd.  
Pakuranga Professional Centre  
267 Pakuranga Highway  
Box 51092  
**Pakuranga**  
Tel: 569-651  
Cable: HEWPACK Auckland  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
Scientific Division  
79 Canton Gore Road, **Newmarket**  
P.O. Box 1234  
**Auckland**  
Tel: 75-289  
Cable: DENTAL Auckland  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
Norrie and Parumoana Streets  
**Porirua**  
Tel: 75-098  
Tel: 3858  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
P.O. Box 809  
239 Stanmore Road  
**Christchurch**  
Tel: 892-019  
Cable: DENTAL Christchurch  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
303 Great King Street  
**Dunedin**  
Tel: 86-817  
Cable: HEWPACK Dunedin

**NIGERIA**  
The Electronics  
Instrumentations Ltd  
N6B-770 Oyo Road  
Oluseun House  
P.M.B. 5402  
**Ibadan**  
Tel: 461577  
Telex: 31231 TEIL NG  
Cable: THETEL Ibadan  
The Electronics Instrumenta-  
tions Ltd.  
144 Agege Motor Road, Mushin  
P.O. Box 6645  
**Lagos**  
Cable: THETEL Lagos

**PAKISTAN**  
Mushko & Company Ltd.  
Qosman Chambers  
Abdullah Haroon Road  
**Karachi-3**  
Tel: 511027, 512927  
Tel: 289  
Cable: COOPERATOR Karachi  
Mushko & Company, Ltd.  
38B, Satellite Town  
**Rawalpindi**  
Tel: 41524  
Cable: FEMUS Rawalpindi

**PHILIPPINES**  
The Online Advanced  
Systems Corporation  
Rico House  
Amorsolo cor. Herrera Str.  
Legaspi Village, **Makati**  
P.O. Box 1510  
**Metro Manila**  
Tel: 85-35-81, 85-34-91, 85-32-21  
Telex: 3274 ONLINE

**RHODESIA**  
Field Technical Sales  
45 Union Road North  
P.O. Box 3458  
**Salisbury**  
Tel: 705231 (5 lines)  
Telex: HK 4122

**SINGAPORE**  
Hewlett-Packard Singapore  
Tel: 42461  
1150 Depot Road  
Alexandra P.O. Box 58  
**Singapore 4**  
Tel: 270-2355  
Telex: HPSG RS 21486  
Cable: HEWPACK Singapore

**SOUTH AFRICA**  
Hewlett-Packard South Africa  
(Pty.) Ltd.  
Private Bag Wendywood,  
Sandton, Transvaal, 2144  
Hewlett-Packard Centre  
Daphne Street, Wendywood,  
**Sandton**, 2144  
Tel: 802-1040-6  
Telex: 84781  
Cable: HEWPACK Johannesburg

**Hewlett-Packard South Africa**

(Pty.) Ltd.  
P.O. Box 120  
Howard Place, Cape Province, 7450  
Pine Park Centre, Forest Drive,  
**Pinelands**, Cape Province, 7405  
Tel: 53-7955 thsu 9  
Telex: 57-0006

**SRI LANKA**

Metropolitan Agencies Ltd.  
209-9 Union Place  
**Colombo 2**  
Tel: 35947  
Cable: METRETOLD CE  
Cable: METRETOLD

**SUDAN**

Ridwan Trade  
P.O. Box 921  
**Khartoum**  
Tel: 44048  
Telex: 375  
**TAIWAN**  
Hewlett-Packard Far East Ltd.  
Tawai Branch  
39 Chung Hsiao West Road  
Section 1, 7th Floor  
**Taipei**  
Tel: 3819160-9, 3141010  
Cable: HEWPACK TAIPEI  
Hewlett-Packard Far East Ltd.  
Taiwan Branch  
68-2, Chung Cheng 3rd. Road  
**Kaohsiung**  
tel: 071 242318-Kaohsiung

Analytical/Medical Only  
San Kwang Instruments Co., Ltd.  
20 Yung Siu Road  
**Taipei**  
Tel: 3615446-9 (4 lines)  
Cable: 22864 SANKWANG  
Cable: SANKWANG Taipei

**TANZANIA**  
Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 861  
**Dar es Salaam**  
Tel: 1251 Ext. 265  
Telex: 41030

**THAILAND**  
UNIMESA Co. Ltd  
Eicom Research Building  
2538 Sukumvit Ave.  
**Bangkok, Bangkok**  
Tel: 3832387, 3830338  
Cable: UNIMESA Bangkok

**UGANDA**  
Medical Only  
International Aeradio (E.A.) Ltd.  
P.O. Box 2577  
**Kampala**  
Tel: 54388  
Cable: INTAERIO Kampala

**ZAMBIA**  
R.J. Tibury (Zambia) Ltd.  
P.O. Box 2792  
**Lusaka**  
Tel: 273783  
Cable: RAJTYATE, Lusaka

**OTHER AREAS NOT LISTED, CONTACT:**

Hewlett-Packard International

3200 Hillway Ave.  
Palo Alto, California 94304  
Tel: (415) 856-1501  
TWX: 910-373-1267  
Cable: HEWPACK Palo Alto  
Tel: 034-8300, 034-8493

## CANADA

### ALBERTA

Hewlett-Packard (Canada) Ltd.  
11620A - 168th Street  
Edmonton T5M 3T9  
Tel: (403) 452-3670  
TWX: 610-831-2431

Hewlett-Packard (Canada) Ltd.  
210, 7220 Fisher St. S.E.

Calgary T2H 2H8  
Tel: (403) 253-2713  
Twx: 610-821-6141

### BRITISH COLUMBIA

Hewlett-Packard (Canada) Ltd.  
10691 Shellbridge Way

Richmond V6X 2W7  
Tel: (604) 270-2277  
TWX: 610-925-5059

### MANITOBA

Hewlett-Packard (Canada) Ltd.  
360-550 Century St.

Winnipeg R3H 0Y1  
Tel: (204) 786-6701  
TWX: 610-671-3531

### NOVA SCOTIA

Hewlett-Packard (Canada) Ltd.  
900 Windmill Road

Dartmouth B3B 1L1  
Tel: (902) 469-7820  
TWX: 610-271-4482

### ONTARIO

Hewlett-Packard (Canada) Ltd.  
1020 Morrison Dr.

Ottawa K2H 8K7  
Tel: (613) 820-6483  
TWX: 610-563-1636

Hewlett-Packard (Canada) Ltd.  
6877 Goreway Drive  
Mississauga L4V 1M8

Tel: (416) 678-9430  
TWX: 610-492-4246

Hewlett-Packard (Canada) Ltd.

552 Newbold Street  
London N6E 2S5  
Tel: (519) 686-9181

### QUEBEC

Hewlett-Packard (Canada) Ltd.  
275 Hymus Blvd.

Pointe Claire H9R 1G7

Tel: (514) 697-4232  
TWX: 610-422-3022  
TLX: 05-821-521 HPCL

### FOR CANADIAN AREAS NOT LISTED:

Contact Hewlett-Packard (Canada)

Ltd. in Mississauga.

## CENTRAL AND SOUTH AMERICA

### ARGENTINA

Hewlett-Packard Argentina

S.A.  
Av. Leandro N. Alem 822 - 12°  
1001 Buenos Aires  
Tel: 31-8063.4.5.6  
Telex: 122443 AR CIGY  
Cable: HEWPACKARG

Biotron S.A. C.I. y M.

Bolivar 177  
1066 Buenos Aires  
Tel: 30-4846, 34-9356, 34-0460,  
33-2863

Telex: 011-7595

Cable: Biotron Baries

BOLIVIA

Casa Kavlin S.A.

Calle Potosí 1130

P.O. Box 500

La Paz

Tel: 41530, 53221

Telex: CWC BX 5298, ITT 3560082

Cable: KAVLIN

BRAZIL

Hewlett-Packard do Brasil

L. e. C. Ltda.

Alameda Rio Negro, 750

Alphaville

06400 Barueri SP

Tel: 429-3222

Cable: HEWPACK Sao Paulo

Hewlett-Packard do Brasil

L. e. C. Ltda.

Rua Padre Chagas, 32

90000-Porto Alegre-RS

Tel: (0512) 22-2998, 22-5621

Cable: HEWPACK Porto Alegre

Hewlett-Packard do Brasil

L. e. C. Ltda.

Av. Epitacio Pessoa, 4664

Lagoa

20000-Rio de Janeiro-RJ

Tel:

Telex: 021-21905 HPBR-BR

Cable: HEWPACK

Rio de Janeiro

CHILE

Jorge Calcagni y Cia. Ltda.

Vicuna Mackenna 3, Ofic. 1204

Casilla 16475

Correo 9, Santiago

Tel: 34152

Telex: JCALCAGNI

### COLOMBIA

Instrumentación

Henrik A. Langebaek & Kier S. A.

Carrera 7 No. 48-75

Apartado Aéreo 6287

Bogotá, D. E.

Tel: 269-8877

Cable: 44400

Telex: AARIS Bogotá

Instrumentación

H. A. Langebaek & Kier S. A.

Carrera 53 No. 49-A-31

Apartado 54098

Medellin

Tel: 304475

COSTA RICA

Científica Costarricense S. A.

Avenida 2, Calle 5

San Pedro de Montes de Oca

Apartado 10159

San Jose

Tel: 24-38-20, 24-08-19

Telex: 2367 GALGUR CR

Cable: GALGUR

### ECUADOR

Computadoras y Equipos

Eléctricos del Ecuador

P.O. Box 6423 CCI

Eloy Alfaro No. 1824, 3° Piso

Quito

Tel: 453 482

Telex: 2548 CYEDE ED

Cable: CYEDE-Quito

Medical Only

Hospitalaria S. A.

Casilla 3590

Robles 625

Quito

Tel: 545-250

Cable: HOSPITALAR-Quito

EL SALVADOR

IPESA

Bulevar de los Heroes 11-48

San Salvador

Tel: 252787

GUATEMALA

IPESA

Avenida Reforma 3-48,

Zona 9

Guatemala City

Tel: 318627, 314786, 66471-5, ext. 9

Telex: 4192 Teletro Gu

### MEXICO

Hewlett-Packard Mexicana,

S. A. de C. V.

Av. Periferico Sur No. 6501

Tepepan, Xochimilco

México 23, D. F.

Tel: 905-676-4600

Telex: 017-74-507

Hewlett-Packard Mexicana,

S. A. de C. V.

Ave. Constituidn No. 2184

Monterrey, N. L.

Tel: 48-71-32, 48-71-64

Telex: 038-410

NICARAGUA

Roberto Terán G.

Apartado Postal 689

Edificio Terán

Managua

Tel: 25114, 23412, 23454, 22400

Cable: ROTERAN Managua

PANAMA

Eléctrico Balboa, S. A.

Aparatado 4929

Panama 5

Calle Samuel Lewis

Edificio "A", No. 2

Ciudad de Panama

Tel: 64-2700

Telex: 3483103 Curundo,

Canal Zone

Cable: ELECTRON Panama

### PERU

Compañía Electro Médica S. A.

Los Flamencos 145

San Isidro Casilla 1030

Lima 1

Tel: 41-4325

Telex: Pub. Booth 25424 SISIDRO

Cable: LEMED Lima

SURINAME

Surlet Radio Holland N.V.

Grote Hofstr. 3-5

P.O. Box 155

Paramaribo

Tel: 72118, 77880

Cable: Surlet

TRINIDAD & TOBAGO

CARTEL

Caribbean Telecoms Ltd.

P.O. Box 732

69 Frederick Street

Port-of-Spain

Tel: 62-53068

URUGUAY

Pablo Ferrando S. A. C. I.

Avenida Italia 2877

Casilla de Correo 370

Montevideo

Tel: 40-3102

Telex: 702 Public Booth Para

Pablo Ferrando

Cable: RADIUM Montevideo

### VENEZUELA

Hewlett-Packard de Venezuela

C. A.

P.O. Box 50933

Caracas 105

Los Ruices Norte

3a Transversal

Edificio Segre

Caracas 107

Tel: 239-4133 (20 lines)

Telex: 25146 HEWPACK

Cable: HEWPACK Caracas

### FOR AREAS NOT LISTED, CONTACT:

Hewlett-Packard

Inter-Americas

3200 Holloway Ave

Palo Alto, California 94304

Tel: (415) 856-1501

TWX: 910-373-1260

Cable: HEWPACK Palo Alto

Telex: 034-8300, 034-8493

# EUROPE, NORTH AFRICA AND MIDDLE EAST

**AUSTRIA**  
Hewlett-Packard Ges m b H  
Händelsried 52  
P.O. Box 7  
A-1205 Vienna  
Tel: 351621-27  
Cable: HEWPAK Vienna  
Telex: 75923 hewpak a

**BAHRAIN**  
Medical Only  
Wael Pharmacy  
P.O. Box 648  
Bahrain  
Tel: 54866 56123  
Telex: 8050 WAEI GJ  
Cable: WAEI PHARM  
Analytical Only  
Al Hamidiya Trading  
and Contracting  
P.O. Box 20074  
Manama  
Tel: 259978 259958  
Telex: 8895 KALDIA GJ

**BELGIUM**  
Hewlett-Packard Benelux  
S.A. N.V.  
Avenue du Col-Vert, 1  
(Groenraaijan)  
B-1170 Brussels  
Tel: 0(2)1660 50 50  
Cable: PALOBN Brussels  
Telex: 23-434 paloben br

**CYPRUS**  
Kyronicos  
15 Gregorios Xenopoulos Street  
P.O. Box 1152  
Nicosia  
Tel: 45628 29  
Cable: Kyronicos Pandhios  
Telex: 3018

**CZECHOSLOVAKIA**  
Vývojová a Provozní Zakladna  
Výzkumných Ústavů v Bečovicích  
CSSR 2609  
Běchovice u Prahy  
Tel: 89 83 41  
Telex: 12133  
Institute of Medical Biomics  
Výzkumný Ústav Lékařské Biologie  
Jedlová 6  
CS 58345  
Bratislava-Kramere  
Tel: 4251  
Telex: 93229

**DDR**  
Entwicklungslabor der TU Dresden  
Forschungsinstitut Meinsberg  
DDR-7305  
Weidheim/Meinsberg  
Tel: 37 867  
Telex: 518741  
Export Contact AG Zuerich  
Quethen Fangleth  
Schlegelstrasse 15  
1040 Berlin  
Tel: 42-74-12  
Telex: 111889

**DENMARK**  
Hewlett-Packard A/S  
Dalavej 52  
DK-3460 Birkeroed  
Tel: 021 81 96 40  
Cable: HEWPAK A/S  
Telex: 37409 hps dk  
Hewlett-Packard A/S  
Navnvej 1  
DK-8600 Silkeborg  
Tel: 081 82 71 96  
Telex: 37409 hps dk  
Cable: HEWPAK A/S

**EGYPT**  
International Engineering Associates  
24 Hussein Hegazi Street  
Kasr el-Aim  
Cairo  
Tel: 23 829  
Telex: 93830  
Cable: INTENGASSO  
SAMITRO  
Sams Amm Trading Office  
18 Abdel Aziz Gwash  
Abdine-Cairo  
Tel: 24932  
Cable: SAMITRO CAIRO

**FINLAND**  
Hewlett-Packard Oy  
Nahkuruntie 5  
P.O. Box 6  
SF-00211 Helsinki 21  
Tel: (80) 6923631

**FRANCE**  
Hewlett-Packard France  
Avenue des Tropiques  
Les Pôles Poste No 6  
Boite Postale No 6  
91401 Orsay-Cedex  
Tel: (1) 807 78 45  
TWX 600048F

Hewlett-Packard France  
Chemins des Moulins  
B.P. 162  
69130 Ecully  
Tel: (78) 33 81 25  
TWX 310617F

Hewlett-Packard France  
Périmètre de la Capitale  
31081 Toulouse-La Mirail  
Tel: (63) 40 11 12  
TWX 510987F

Hewlett-Packard France  
Le Logiques  
Bureau de vente de Marseilles  
Place Rodée de Vitteville  
0300 Aix-en-Provence  
Tel: (42) 59 41 02

Hewlett-Packard France  
2 Allée de la Bourgne  
35100 Rennes  
Tel: (99) 51 42 44  
TWX 740912F

Hewlett-Packard France  
18, rue du Canal de la Marne  
67300 Schiltigheim  
Tel: 88 83 08 10  
TWX 880141F

Hewlett-Packard France  
Immeuble pérorite  
Rue van Gogh  
98620 Villeneuve D'Ascq  
Tel: (20) 91 41 25  
TWX 160124F

Hewlett-Packard France  
Bureau de Vente  
Centre d'Affaires Paris-Nord  
Bâtiment Ampère  
Rue S. Barbès  
B.P. 300  
93153 Le Blanc Mesnil Cedex  
Tel: 01 1931 88 50

Hewlett-Packard France  
Av. du Pdt. Kennedy  
33700 Mérignac  
Tel: 56 197 22 69  
Hewlett-Packard France  
"France-Envy" Immeuble Lorame  
Bois de France  
11035 Evry-Cedex  
Tel: D77 96 60

Hewlett-Packard France  
60, Rue de Metz  
57130 Jouv aux Arches  
Tel: 87 69 45 32

**GERMAN FEDERAL REPUBLIC**  
Hewlett-Packard GmbH  
Vertriebszentrale Frankfurt  
Bernier Strasse 117  
Postfach 560 140  
D-6000 Frankfurt 56  
Tel: (0611) 50-04  
Cable: HEWPAKCSA Frankfurt  
Telex: 04 13249 hpffm d  
Hewlett-Packard GmbH  
Technisches Büro Böblingen  
Hertenberger Strasse 110  
D-7030 Böblingen Württemberg  
Tel: (0703) 867-1  
Cable: HEWPAKCS6 Böblingen  
Telex: 07265739 bbn  
Hewlett-Packard GmbH  
Technisches Büro Düsseldorf  
Emanuel-Lützeler-Str. (Geestern)  
D-4000 Düsseldorf  
Tel: (0211) 59711  
Technisches Büro München  
Hewlett-Packard GmbH  
Technisches Büro Hamburg  
Wendensstrasse 23  
D-2000 Hamburg 3  
Tel: (40) 24 13 93

Cable: HEWPAKCSA Hamburg  
Telex: 21 63 032 hpffm d  
Hewlett-Packard GmbH  
Technisches Büro Hannover  
Am Grossmarkt 6  
D-3000 Hannover 91  
Tel: (0511) 46 80 01  
Telex: 092 3259

Hewlett-Packard GmbH  
Technisches Büro Nürnberg  
Neumeynerstrasse 30  
D-85000 Nürnberg  
Tel: (0911) 56 30 83  
Telex: 0623 860

Hewlett-Packard GmbH  
Technisches Büro München  
B.P. 162  
D-8021 Taufkirchen  
Tel: (089) 6117-1

Hewlett-Packard GmbH  
Technisches Büro Berlin  
Kastanienstr. 4  
D-1000 Berlin 30  
Tel: (30) 24 90 86  
Telex: 018 3405 hpfnm d

**GREECE**  
Kostas Karayannis  
8 Omirou Street  
Athens 133  
Tel: 32 303332/37 37  
Analytical Only  
INTECO  
D. Papathanassiou & Co  
17 Miami Street  
Athens 103  
Tel: 5522 915 6221 989  
Telex: 21 5329 INTE GR

Cable: INTERNUKA  
Medical Only  
Technomed Hellas Ltd  
52 Skoufa Street  
Athens 135  
Tel: 3626 972

**HUNGARY**  
MTA  
Muszerügyi és Mérési Technikai  
Szolgálat  
Hewlett-Packard Service  
Lenin Krt. 67, P.O. Box 241  
1391 Budapest VI  
Tel: 42 03 38  
Telex: 22 51 14

**ICELAND**  
Medical Only  
Elding Trading Company Inc  
Hafnarholv - Tyggvagnin  
P.O. Box 893  
5 Reykjavik  
Tel: 1 58 201 63 03  
Cable: ELDING Reykjavik

**IRAN**  
Hewlett-Packard Iran Ltd  
No 13 Fourteenth St  
Mir Ebad Avenue  
P.O. Box 412419  
Tehran  
Tel: 851082-5  
Telex: 213405 hewp ir

**IRELAND**  
Hewlett-Packard Ltd  
King Street Lane  
Winnereah, Wokingham  
Berks. RG11 5AR  
GB-England  
Tel: (0474) 78 47 74  
Telex: 847178

Cable: Hewpe London  
Hewlett-Packard Ltd  
Industrial Estate  
Long Mile Road  
Dublin 12, Eire  
Tel: 01 514322  
Telex: 30439

Medical Only  
Cardiac Services (Ireland) Ltd  
Economic Road  
Artane  
Dublin 5, Eire  
Tel: 01 315820  
Medical Only  
Cardiac Services Co  
95A Franghy Rd. South  
Dublin 11, Eire  
GB-Northern Ireland

**ITALY**  
Hewlett-Packard Italiana S.p.A.  
Via G. Di Vittorio, 9  
20063 Cernusco  
Sul Naviglio (Mi)  
Tel: (2) 90569  
Telex: 311946 HEWPAKIT

Hewlett-Packard Italiana S.p.A.  
Via Turazza, 14  
35100 Padova  
Tel: 49 164488  
Telex: 41612 HEWPAKIT  
Hewlett-Packard Italiana S.p.A.  
Via G. Armellini 10  
I-00143 Roma  
Tel: 06 54 69 91  
Telex: 61514  
Cable: HEWPAKIT Roma

Hewlett-Packard Italiana S.p.A.  
Corso Giovanni Lanza 94  
I-10133 Torino  
Tel: (011) 882245.659308

Medical Calculators Only  
Hewlett-Packard Italiana S.p.A.  
Via Principe Nicola 43 G.C.  
95126 Catania  
Tel: (095) 37 05 04

Hewlett-Packard Italiana S.p.A.  
Via Nuova San Rosa  
Capomonte 624  
I-80131 Napoli  
Tel: (081) 7913544  
Hewlett-Packard Italiana S.p.A.  
Via 17 Marzo Street  
I-40137 Bologna  
Tel: (051) 307887300040

**JORDAN**  
Moussher Cousins Co  
P.O. Box 138  
Amman  
Tel: 24007-39907  
Telex: SABCO JO 1456  
Cable: WHPACKCSA

**KUWAIT**  
Al-Khaldiya Trading & Contracting  
P.O. Box 636-Safat  
Kuwait  
Tel: 42 491041 1726

**LUXEMBURG**  
Hewlett-Packard Benelux  
S.A. N.V.  
Avenue du Col-Vert, 1  
(Groenraaijan)  
B-1170 Brussels  
Tel: 0(2)1662 22 40  
Cable: PALOBN Brussels  
Telex: 23 434

**MOROCCO**  
Dohaa  
81 rue Karatch  
Casablanca  
Tel: 304 82  
Telex: 230512282  
Cable: MATERIO  
Gerep  
3, rue d'Agadir  
Casablanca  
Tel: 272093-5  
Telex: 23739

Cable: GEREP-CASA  
Cogedr  
31 rue Omar Sbaoui  
Casablanca  
Tel: 27 65 40  
Telex: 21737/23003  
Cable: CODEGOR

**NETHERLANDS**  
Hewlett-Packard Benelux N.V.  
Van Heverweg  
Boedhartaan 121  
P.O. Box 667  
NL-Amstelveen 1134  
Tel: (01) 514322  
Tel: (20) 47 20 21

**NORWAY**  
Hewlett-Packard Norge AS  
Kinnore Road  
Østerdalen 18  
P.O. Box 34  
Telex: 085 865 533 hpnd d  
Medical Only  
Tel: (021) 1771 80  
Telex: 16621 npnas n  
Hewlett-Packard Norge AS  
Bellevue 3110 Østoy  
5000 Bergen

**POLAND**  
Biuro Informacji Technicznej  
WIA G. Di Vittorio, 9  
ul. Sławk, 5 5P  
00-950 Warszawa  
Tel: 33 25 88 69 67 43  
Telex: 311 24 53 hewa pl

**PORTUGAL**  
Unipam  
Biuro Obsluzi Technicznej  
01-447 Warszawa  
Tel: 49 164488  
ul. Nowelska 5  
Poland  
Zaklady Naprawcze Sprzetu  
Medycznego  
Plac Komuny Paryskiej 6  
90-007 Lodz  
Tel: 334 411 337-83  
Telex: 868981

**PORTUGAL**  
Telectra-Empresa Técnica de  
Equipamentos Eléctricos S a r l  
Rua Rodrigo da Fonseca 103  
P.O. Box 2531  
Lisbon  
Tel: (18) 86 60 72  
Cable: ELECTRA Lisbon  
Telex: 12598

Medical only  
Mundinter  
Intercambio Mundial de Comercio S.A.  
P.O. Box 2761  
Avenida Antonio Augusto  
de Aguiar 138  
P. Lisbon  
Tel: (19) 531 21 317  
Telex: 16691 munter p  
Cable: INTERCAMBIO Lisbon

**QATAR**  
Nasser Trading & Contracting  
P.O. Box 1563  
Doha  
Tel: 22170  
Cable: 4439 NASSER  
Cable: NASSER

**ROMANIA**  
Hewlett-Packard Reprezentanta  
Bd. N. Balcescu 16  
Bucuresti  
Tel: 15 80 2313 88 85  
Telex: 10440  
I. I. R. U.  
Intraprinderea Pentru  
Intretinere  
Si Reparatii Utilajelor de Calcul  
B-dul Prof. Omilme Pompei 6  
Bucuresti-Sectorul 2  
Tel: 88-20-60, 88-24-40, 88-67-95  
Telex: 118

**SAUDI ARABIA**  
Modern Electronic  
Establishment (Branch)  
P.O. Box 2728  
Riyadh  
Tel: 62596 66232  
Modern Electronic  
Establishment (Branch)  
P.O. Box 193  
Al-Khobar  
Tel: 44678-44813

**SPAIN**  
Hewlett-Packard Española, S.A.  
Calle Arce 3  
E-Madrid 16  
Tel: (1) 458 26 00 (10 lines)  
Telex: 235 15 hpe  
Hewlett-Packard Española S.A.  
Colonia Miraserra  
Edificio Judan  
% Costa Brava, 13  
Tel: 0211771 80

Hewlett-Packard Española, S.A.  
Miansesado 21-23  
E-Barcelona 11  
Tel: G1 203 6200 (5 lines)

Hewlett-Packard Española, S.A.  
Av. Ramón y Cajal  
1  
E-Madrid 5  
Tel: 4276 0326  
planta 9  
S-Vendilla 5  
Tel: 64 44 54 58

Hewlett-Packard Española S.A.  
Edificio Alba 11 7-8  
E-Bilbao 1  
Tel: 23 83 0623 82 06  
Hewlett-Packard Española S.A.  
C/Ramón Gordillo 1  
Poland  
E-Valencia-10  
Tel: 96 361 13.54.061 13 58

**SWEDEN**  
Hewlett-Packard Sverige AB  
Engneshävsgraven 3, Fack  
S-161 Bromma 20  
Tel: 081 730 05 50  
Telex: 10721  
Cable: MEASUREMENTS  
Stockholm  
Hewlett-Packard Sverige AB  
Fridtjofsgatan 30  
S-421 32 Vastra Frölunda  
Tel: 031 149 09 50  
Telex: 10721 va Bromma office

**SWITZERLAND**  
Hewlett-Packard (Schweiz) AG  
Zürcherstrasse 20  
P.O. Box 301  
CH-8652 Schlieren-Zürich  
Tel: (01) 7305240  
Telex: 53933 hpag ch  
Cable: HPAG CH  
Hewlett-Packard (Schweiz) AG  
Château Bloc 19  
CH-1219 Le Lignon-Geneva  
Tel: 0221 96 03 28  
Telex: 53933 hpag ch  
Cable: HEWPAKCSA Geneva

**SYRIA**  
General Electronic Inc.  
Nuri Basha Abnal Ebn Kays Street  
P.O. Box 5781  
Damascus  
Tel: 33 24 87  
Telex: 11215 ITRIKAL  
Cable: ELECTROBOR DAMASCUS  
Medical/Personal Calculator only  
Sawan & Co  
P.O. Box 2308  
Damascus  
Tel: 16 367-19 697-14 268  
Telex: 4252 31111  
Suleiman Hial El Miami  
P.O. Box 2528  
Mamoun Bitar Street, 56-58  
Damascus-11 46 63

**TUNISIA**  
Tunisie Electronique  
31 Avenue de la Liberté  
Tunis  
Tel: 280 144  
Cable: 40035  
Cable: ELECTA JEDDAH  
Modern Electronic  
Establishment (Branch)  
P.O. Box 2728  
Riyadh  
Tel: 62596 66232  
Modern Electronic  
Establishment (Branch)  
P.O. Box 193  
Al-Khobar  
Tel: 44678-44813

**TURKEY**  
TEKNİM Company Ltd  
Riza Şah Penhri  
Cadden No  
Kavaklıdere Ankara  
Tel: 275800  
Tel: 42155  
Teknım Com. Ltd  
Taksim Cad. 55/12  
Beşiktaş, İstanbul  
Tel: 613 540  
Telex: 23540  
Medical only  
E.M.A.  
Mühendislik Kolektif Şirketi  
Medina Etilim Sokak 41/6  
Yüksel Caddesi  
Ankara  
Tel: 27 75 22  
Cable: EMA TRAE/Ankara

Analytical only  
Yılmaz Özyürek  
E-Bacalhoga 11  
Muştafa Cad 16/6  
Kızılay

**Ankara**  
Tel: 25 03 09 - 17 80 26  
Telex: 4276 0326 TR  
Cable: ÖZYUREK ANKARA  
Tel: 64 44 54 58

**UNITED ARAB EMIRATES**  
Emirat Ltd. (Head Office)  
P.O. Box 1641  
Sharjah  
Tel: 061-584213  
Telex: 8136  
Emirat Ltd. (Branch Office)  
P.O. Box 2711  
Ahu Dhabi  
Tel: 313370

**UNITED KINGDOM**  
Hewlett-Packard Ltd  
King Street Lane  
Winnereah, Wokingham  
Berks RG11 5AR  
Tel: 0734 784774  
Telex: 847178 9

Hewlett-Packard Ltd  
Trafalgar House  
Navigation Road  
Aldreot, 10721 va Bromma office  
Cheshire WA14 1NU  
Tel: (061) 928 6422  
Telex: 880686

Hewlett-Packard Ltd  
Lygon Court  
Hereford Rise  
Oudley Road  
Hilsea  
West Midlands B62 8SD  
Tel: 01520 9911  
Telex: 330105  
Hewlett-Packard Ltd  
Wedge House  
799 London Road  
Merton, Greater Heath  
Surrey CR4 6XL  
Tel: (01) 8640103  
Telex: 940625

Hewlett-Packard Ltd  
10, Wesley St  
Castleford  
York WF10 1AE  
Tel: (017) 150016  
Telex: 557355  
Hewlett-Packard Ltd  
1, Wallace Way  
Hitchin  
Hertfordshire, SG4 0SE  
Tel: (0452) 31111  
Telex: 82 59 81

**USSR**  
Hewlett-Packard  
Representative Office USSR  
Petrovskiy Boulevard 4/17-kv 12  
Moscow 101000  
Tel: 294 20 24  
Telex: 7925 hewpak su

**YUGOSLAVIA**  
Iskra-Standard Hewlett-Packard  
Mladostovca 38 VII  
61000 Ljubljana  
Tel: 31 58 79 92 16 74

**SOCIETAL COUNTRIES**  
LEFT SHOWING PLEASE  
CONTACT  
Hewlett-Packard Ges m b H  
Händelsried 52  
P.O. Box 7  
A-1205 Vienna, Austria  
Tel: 0(222) 35 16 21 to 27

**MEDITERRANEAN AND MIDDLE EAST COUNTRIES**  
NOT SHOWING PLEASE CONTACT:  
Hewlett-Packard S.A.  
Mediterranean and Middle  
East Operations  
35, Kolokotroni Street  
Plata Kefallionu  
GR-Missia, Athens, Greece  
Tel: 8080337/259 429

**FOR OTHER AREAS**  
NOT LISTED CONTACT  
Hewlett-Packard S.A.  
7, rue de lausanne  
P.O. Box  
CH-1212 Meyrin 2 - Geneva  
Tel: 022 12 70 00

# UNITED STATES

## ALABAMA

P. O. Box 4207  
8290 Whitesburg Dr.  
Huntsville 35802  
Tel: (205) 881-4591  
8933 E. Roebuck Blvd  
Birmingham 35206  
Tel: (205) 836-2202/2

## ARIZONA

2336 E. Magnolia St  
Phoenix 85034  
Tel: (602) 244-1361  
2424 East Aragon Rd  
Tucson 85706  
Tel: (602) 889-4661

## ARKANSAS

Medical Service Only  
P. O. Box 5646  
Brady Station  
Little Rock 72215  
Tel: (501) 376-1844

## CALIFORNIA

1579 W. Shaw Ave.  
Fresno 93771  
Tel: (209) 224-0582  
1430 East Orangeflorpe Ave.  
Fullerton 92631  
Tel: (714) 870-1000  
3939 Lankershim Boulevard  
North Hollywood 91604  
Tel: (213) 877-1282  
TWX 910-499-2671  
5400 West Rosecrans Blvd  
P. O. Box 92105  
World Way Postal Center  
Los Angeles 90009  
Tel: (213) 776-7500  
TWX 910-325-6606  
\*Los Angeles  
Tel: (213) 776-7500  
3003 Scott Boulevard  
Santa Clara 95050  
Tel: (408) 988-7000  
\*Ridgecrest  
Tel: (714) 446-6165  
646 W. North Market Blvd  
Sacramento 95834  
Tel: (916) 929-7222

9606 Aero Drive  
P. O. Box 23333  
San Diego 92123  
Tel: (714) 279-3200  
\*Tarzana  
Tel: (213) 705-3344

## COLORADO

5600 DTC Parkway  
Englewood 80110  
Tel: (303) 771-3455

## CONNECTICUT

12 Luntar Drive  
New Haven 06525  
Tel: (203) 389-6551  
TWX 710-465-2029

## FLORIDA

P. D. Box 24210  
2727 N.W. 62nd Street  
Ft. Lauderdale 33309  
Tel: (305) 973-2600  
4428 Emerson Street  
Unit 103  
Jacksonville 32207  
Tel: (904) 725-6333  
P. O. Box 13910  
6177 Lake Elinor Dr  
Orlando 32809  
Tel: (305) 859-2900  
P. O. Box 12826  
Suite 5, Bldg. 1  
Office Park North  
Pensacola 32575  
Tel: (904) 476-8422

## GEORGIA

P. O. Box 105005  
450 Interstate North Parkway  
Atlanta 30348  
Tel: (404) 955-1500  
Medical Service Only  
\*Augusta 30903  
Tel: (404) 736-0592  
P. O. Box 2103  
1172 N. Davis Drive  
Warner Robins 31098  
Tel: (812) 922-9449  
HAWAII  
2875 So. King Street  
Honolulu 96826  
Tel: (808) 955-4455

## ILLINOIS

5201 Tollview Dr.  
Rolling Meadows 60008  
Tel: (312) 755-9800  
TWX 910-687-2260

## INDIANA

7301 North Shadeland Ave.  
Indianapolis 46250  
Tel: (317) 842-1000  
TWX 810-260-1797

## IOWA

2415 Heinz Road  
Iowa City 52240  
Tel: (319) 338-9466

## KENTUCKY

Medical Only  
3901 Atkinson Dr.  
Suite 407 Atkinson Square  
Louisville 40218  
Tel: (502) 456-1573

## LOUISIANA

P. O. Box 1449  
3229-39 Williams Boulevard  
Kenner 70063  
Tel: (504) 443-6201

## MARYLAND

7121 Standard Drive  
Parkway Industrial Center  
Hanover 21076  
Tel: (301) 796-7700  
TWX 710-862-1943  
2 Choke Cherry Road  
Rockville 20850  
Tel: (301) 948-6370  
Tel: (301) 542-1384

## MASSACHUSETTS

32 Hartwell Ave.  
Lexington 02173  
Tel: (617) 861-4980  
TWX 710-326-8904

## MICHIGAN

23855 Research Drive  
Farmington Hills 48024  
Tel: (313) 476-6400  
724 West Centre Ave  
Kalamazoo 49002  
Tel: (606) 323-8362

## MINNESOTA

2400 N. Prior Ave.  
St. Paul 55113  
Tel: (612) 636-0700

## MISSISSIPPI

322 N. Mart Plaza  
Jackson 39206  
Tel: (601) 982-9363

## MISSOURI

11131 Colorado Ave.  
Kansas City 64137  
Tel: (816) 763-8000  
TWX 910-771-2087  
1024 Executive Parkway  
St. Louis 63141  
Tel: (314) 878-0200

## NEBRASKA

Medical Only  
7101 Mercy Road  
Suite 401  
Omaha 68106  
Tel: (402) 392-0948

## NEVADA

\*Las Vegas  
Tel: (702) 736-6610

## NEW JERSEY

W. 120 Century Rd  
Paramus 07652  
Tel: (201) 265-5000  
TWX 710-990-4951  
Crystal Brook Professional  
Building, Route 35  
Eatontown 07724  
Tel: (201) 542-1384

## NEW MEXICO

P. O. Box 11634  
Station E  
11300 Lomas Blvd. N. E.  
Albuquerque 87123  
Tel: (505) 292-1330  
TWX 910-989-1185  
156 Wyatt Drive  
Las Cruces 89001  
Tel: (505) 526-2484  
TWX 910-9983-0550

## NEW YORK

6 Automation Lane  
Computer Park  
Albany 12205  
Tel: (518) 458-1550  
TWX 710-444-4961  
650 Perinton Hill Office Park  
Fairport 14450  
Tel: (716) 223-9950  
TWX 510-253-0092  
No. 1 Pennsylvania Plaza  
55th floor  
34th Street & 8th Avenue  
New York 10001  
Tel: (212) 971-0800

## NEW YORK

5856 East Molloy Road  
Syracuse 13211  
Tel: (315) 455-2486  
1 Crossways Park West  
Woodbury 11797  
Tel: (516) 921-0300

## NORTH CAROLINA

Greensboro 27405  
Tel: (919) 852-1800

## OHIO

Medical Computer Only  
Bldg. 300  
1313 E. Kemper Rd  
Cincinnati 45426  
Tel: (513) 671-7400  
16500 Sprague Road  
Cleveland 44130  
Tel: (216) 243-7300  
TWX 810-423-9430  
330 Progress Rd  
Dayton 45449  
Tel: (513) 859-8202

## OKLAHOMA

1041 Kingsmill Parkway  
Columbus 43229  
Tel: (614) 436-1041  
6301 N. Meridian Avenue  
Oklahoma City 73112  
Tel: (405) 721-0200  
9920 E. 42nd Street  
Suite 121  
Tulsa 74145

## OREGON

17890 SW Lower Boones  
Ferry road  
Tualatin 97062  
Tel: (503) 620-3350

## PENNSYLVANIA

111 Zeta Drive  
Pittsburgh 15238  
Tel: (412) 782-0400  
1021 8th Avenue  
King of Prussia Industrial Park  
King of Prussia 19406  
Tel: (215) 265-7000  
Tel: (610) 860-2670

## PUERTO RICO

Hewlett-Packard Inter-Americas  
Puerto Rico Branch Office  
Calle 272  
Edif. 203 Urg. Country Club  
Carolina 00924  
Tel: (809) 762-7255  
Telex: 345 0514

## SOUTH CAROLINA

P. O. Box 6442  
6941-O N. Trenholm Road  
Columbia 29260  
Tel: (803) 782-6493

## TENNESSEE

8914 Kingston Pike  
Knoxville 37922  
Tel: (615) 523-0522

## TEXAS

3027 Vanguard Dr.  
Director's Plaza  
Memphis 38131  
Tel: (901) 346-6370

## \*Nashville

Medical Service only  
Tel: (615) 244-5448  
4171 North Mesa  
Suite C110  
El Paso 79902  
Tel: (915) 533-3555  
P. O. Box 1270  
201 E. Arapahoe Rd.  
Richardson 75080  
Tel: (214) 231-6101

P. O. Box 42816  
10535 Harwin Dr  
Houston 77036  
Tel: (713) 776-6400

## \*Lubbock

Medical Service only  
Tel: (806) 799-4472  
205 Billy Mitchell Road  
San Antonio 78226  
Tel: (512) 434-8241

## UTAH

2160 South 3270 West Street  
Salt Lake City 84119  
Tel: (801) 972-4711

## VIRGINIA

P. O. Box 12778  
Norfolk 23502  
Tel: (804) 460-2671

## P. O. Box 9669

2914 Hungary Springs Road  
Richmond 23228  
Tel: (804) 285-3431

## WASHINGTON

Bellefield Office Pk.  
1203-114th Ave. S. E.  
Bellevue 98004  
Tel: (206) 454-3971

## P. O. Box 4010

Spokane 99202  
Tel: (509) 535-0864

## \*WEST VIRGINIA

Medical Analytical Only  
Charleston  
Tel: (304) 345-1640

## WISCONSIN

9004 West Lincoln Ave.  
West Allis 53227  
Tel: (414) 541-0550

## FOR U.S. AREAS NOT LISTED:

Contact the regional office  
nearest you: Atlanta, Georgia...  
North Hollywood, California...  
Rockville, Maryland... Rolling Meadows,  
Illinois. Their complete  
addresses are listed above.

\*Service Only 2/79

