



HP 3000/930 and 9000/840S Computer Systems

CE Handbook



19483 Pruneridge Avenue, Cupertino 95014-9974

Part No. 09740-90023

Printed in U.S.A. 12/87

FOR USA ONLY

FEDERAL COMMUNICATION COMMISSION RADIO
FREQUENCY INTERFERENCE STATEMENT

The United States Federal Communications Commission (in 47CFR Subpart J, of Part 15) has specified that the following notice be brought to the attention of the users of this product:

"Warning: This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested for compliance with the limits for Class A computing devices pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference."

FOR JAPAN ONLY

この装置は、第一種情報装置(商工業地域において使用されるべき情報装置)で商工業地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会(VCCI)基準に適合しております。

従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains propriety information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company.

UNIX is a trademark of AT&T Laboratories in the USA and other countries.

Copyright (c) 1986-1987 by HEWLETT-PACKARD COMPANY

HP Computer Museum
www.hpmuseum.net

For research and education purposes only.

PRINTING HISTORY

New editions are complete revisions of the manual. Update packages, which are issued between editions, contain additional and replacement pages to be merged into the manual by the customer. The dates on the title page change only when a new edition or a new update is published. No information is incorporated into a reprinting unless it appears as a prior update; the edition does not change when an update is incorporated.

The software code printed alongside the date indicates the version level of the software product at the time the manual or update was issued. Many product updates and fixes do not require manual changes and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one to one correspondence between product updates and manual updates.

First Edition Nov 1986
Second Edition Apr 1987
Third Edition Aug 1987
Fourth Edition Dec 1987

LIST OF EFFECTIVE PAGES

The List of Effective Pages gives the date of the most recent version of each page in the manual. To verify that your manual contains the most current information, check the dates printed at the bottom of each page with those listed below. The date on the bottom of each page reflects the edition or subsequent update in which that page was printed.

| Effective Pages | Date |
|-----------------|----------|
| all | Dec 1987 |

CONTENTS

| | Page |
|---|------|
| PREFACE | |
| Reference Documents | xii |
| Section 1 | |
| PRODUCT INFORMATION | |
| System Specifications | 1-7 |
| Central Processing Unit (CPU) | 1-7 |
| System Monitor Card | 1-7 |
| System Capacity | 1-8 |
| System Color Code Organization | 1-8 |
| System Orientation | 1-9 |
| System Status Display Panels | 1-14 |
| Power Distribution System | 1-16 |
| Section 2 | |
| ENVIRONMENTAL/INSTALLATION/ PREVENTIVE MAINTENANCE | |
| SPU Specifications | 2-2 |
| Expansion Bay Specifications | 2-4 |
| Installation | 2-6 |
| Hardware Installation Checklist | 2-6 |
| Operating System Installation | 2-6 |
| Device Adapters | 2-4 |
| Preventive Maintenance | 2-7 |
| Section 3 | |
| CONFIGURATION | |
| CPU Card Cage Configuration Assignment | 3-6 |
| CIO Card Cage Configuration Assignment | 3-7 |
| Memory Card Cage Configuration Assignment | 3-9 |
| Midbus Card Cage Configuration Assignment | 3-10 |
| Expansion Bay Configuration Assignment | 3-11 |
| Configuration Switch Definitions | 3-15 |
| Selftest Configuration Switch Definitions | 3-15 |
| System Console Configuration | 3-16 |
| MPE-XL/HP-UX System Console | 3-16 |
| Access Port Configuration | 3-16 |
| Power Distribution Chart | 3-17 |
| Expansion Bay Power Distribution Chart | 3-19 |
| Section 4 | |
| TROUBLESHOOTING | |
| System Display Status Codes | 4-8 |

CONTENTS (continued)

| | Page |
|--|------|
| HPMC Error List | 4-8 |
| Selftest Error Messages | 4-11 |
| Multiplexed Display Error Codes | 4-37 |
| System Display Codes | 4-37 |
| HP-UX System Display Codes | 4-37 |
| MPE-XL System Display Codes | 4-38 |
| SPU Troubleshooting | 4-41 |
| Minimum Hardware Configuration | 4-41 |
| Troubleshooting Procedures | 4-42 |
| DC Power Supply Check | 4-43 |
| Power Fail Check | 4-43 |
| PDU Strapping Verification | 4-44 |
| Power Supply Troubleshooting | 4-45 |
| Selftest Switch Settings | 4-49 |
| Selftest as a Troubleshooting Tool | 4-56 |
| Access Port Selftest and Troubleshooting | 4-63 |
| System Console Selftest | 4-63 |
| AP Frontplane Selftest | 4-63 |
| Remote Maintenance | 4-67 |
| PDC Boot Error Codes | 4-72 |

Section 5 DIAGNOSTICS

| | |
|--|------|
| HP 9740A SPU Selftest | 5-2 |
| Selftest Display | 5-2 |
| Diagnostic/Utility Orientation | 5-3 |
| Diagnostic User Interface (DUI) | 5-6 |
| Mini-Operating Instructions | 5-6 |
| CS/80 Disc Diagnostic (CS80DIAG) | 5-8 |
| Mini-Operating Instructions | 5-8 |
| Flex Disc Diagnostic (FLEXDIAG) | 5-10 |
| Mini-Operating Instructions | 5-10 |
| HP7974A/7978A/B Magnetic Tape Drive Diagnostic(DIAG7478) | 5-11 |
| Mini-Operating Instructions | 5-11 |
| Ciper Line Printer Diagnostic (CIPERLPD) | 5-13 |
| Mini-Operating Instructions | 5-13 |
| Page Printer Diagnostic (PPDIAG) | 5-14 |
| Mini-Operating Instructions | 5-14 |
| AFI Device Adapter Diagnostic (AFIDAD) | 5-15 |
| Mini-Operating Instructions | 5-15 |
| HP-IB Device Adapter Diagnostic (HPIBDIAG) | 5-16 |
| Mini-Operating Instructions | 5-16 |
| HP-FL Device Adapter Diagnostic(HPFLDIAG) | 5-17 |
| Mini-Operating Instructions | 5-17 |
| Memory Array Diagnostic (MAD) | 5-18 |
| Mini-Operating Instructions | 5-18 |

CONTENTS (continued)

| | Page |
|---|------|
| Six-Channel MUX Diagnostic (MUXDIAG) | 5-19 |
| Minimum Configuration | 5-19 |
| Mini-Operating Instructions | 5-19 |
| Local Area Network Device Adapter Diagnostic (LANDAD) | 5-21 |
| Mini-Operating Instructions | 5-21 |
| I/O Test Tool (IOTT) | 5-23 |
| Mini-Operating Instructions | 5-23 |
| COMMAND SUMMARY | 5-23 |
| Control Commands (CC) | 5-23 |
| User Program File Commands (UPFC) | 5-24 |
| Program Editing Commands (PEC) | 5-24 |
| Miscellaneous Commands (MC) | 5-24 |
| INSTRUCTION SUMMARY | 5-24 |
| Test Environment Instructions (TEI) | 5-24 |
| Buffer Manipulation Instructions (BMI) | 5-25 |
| Predefined I/O Request Instructions (PIORI) | 5-25 |
| HP-IB Device Adapter Program Instructions (HPIBPI) | 5-25 |
| HP-CIO DMA Chain Instructions (HPCIOI) | 5-26 |
| PROGRAM STATEMENT SUMMARY | 5-26 |
| CIO Channel Adapter Diagnostic (CADIAG) | 5-27 |
| Mini-Operating Instructions | 5-27 |
| HP98720A Graphics Processor Diagnostic (GP3DDIAG) | 5-28 |
| Mini-Operating Instructions | 5-28 |
| System and Memory Log Analysis Tool (LOGTOOL) | 5-29 |
| Mini-Operating Instructions | 5-29 |
| System Map (SYSMAP) | 5-30 |
| Mini-Operating Instructions | 5-30 |
| HP-UX Logging Facility | 5-31 |
| Mini-Operating Instructions | 5-31 |
| MPE-XL Online Diagnostic Installer (DIAGINST) | 5-32 |
| Mini-Operating Instructions | 5-32 |
| MPE-XL Online Diagnostic Subsystem Implementation | 5-33 |
| Implementation Dependent Information | 5-33 |
| MPE-XL Specific Diagnostic Procedures/Features | 5-33 |
| HP-UX Online Diagnostic Implementation | 5-34 |
| Implementation Dependent Information | 5-34 |
| HP-UX Specific Diagnostic Procedures/Features | 5-34 |
| HP-UX Support Tape | 5-35 |
| Booting Up | 5-35 |
| Support Tape Main/Utilities Menus | 5-36 |

**Section 6
ADJUSTMENTS**

| | |
|---|-----|
| Power Supply Removal/Replacement - Power Supply #1 | 6-2 |
| Power Supply Removal/Replacement - Power Supplies #2 and #3 | 6-4 |

CONTENTS (continued)

| | Page |
|--|------|
| Section 7 | |
| PERIPHERALS | |
| Supported Peripheral Devices | 7-2 |
| General Information | 7-2 |
| MPE-XL/HP-UX Default Device Configuration | 7-2 |
| Distributed Terminal Device(DTC) | 7-4 |
| | |
| Section 8 | |
| REPLACEABLE PARTS | |
| Replaceable Parts Catalog | 8-7 |
| | |
| Section 9 | |
| DIAGRAMS | |
| Overall Block Diagram - 9740 CPU | 9-3 |
| Series 800 Model 840 Block Diagram | 9-5 |
| Series 900 Model 930 Block Diagram | 9-7 |
| AC Power Distribution System | 9-9 |
| DC Power Distribution System | 9-10 |
| Expansion Bay/Module Block Diagram | 9-11 |
| Expansion Bay Power Distribution System | 9-12 |
| Cache Unit (CA+) Block Diagram | 9-13 |
| Execution Unit (EU+) Block Diagram | 9-14 |
| Floating Point Unit (FP) Block Diagram | 9-15 |
| Power Supply Block Diagram | 9-16 |
| System Monitor Block Diagram | 9-17 |
| Front Panel Indicators | 9-18 |
| Display Power Table | 9-19 |
| Instructional Unit(IU) Block Diagram | 9-20 |
| Register File Unit (RF) Block Diagram | 9-21 |
| Translation Lookaside Buffer (TL+) Block Diagram | 9-22 |
| HP 9000 Series 800 Model 840 Front/Rear Cabinet PCAs | 9-23 |
| HP 3000 Series 900 Model 930 Front/Rear Cabinet PCAs | 9-24 |
| System Monitor Card Backplane Connectors | 9-25 |
| Row C Connector Definition for Processor Board (CIO slot 12) | 9-26 |
| System Monitor Card Front Panel Connectors | 9-27 |
| | |
| Section 10 | |
| REFERENCE | 10-1 |
| | |
| Section 11 | |
| SERVICE NOTES | |
| Notes | 11-1 |
| Notes | 11-2 |
| Notes | 11-3 |
| Notes | 11-4 |
| Notes | 11-5 |
| Notes | 11-6 |

FIGURES AND TABLES

| LIST OF FIGURES | Page |
|---|------|
| HP 3000/930 Functional Diagram | 1-3 |
| HP 9000/840S Functional Diagram | 1-5 |
| Cabinet, Front View (Door and Card Cage Covers Removed) | 1-9 |
| Cabinet, Rear View (Door and Card Cage Covers Removed) | 1-10 |
| SPU and Expansion Bay, Front View | 1-11 |
| SPU and Expansion Bay, Rear View | 1-12 |
| DTC(Rear View)with Cable Management Racks | 1-13 |
| External and Internal System Status Display Panels | 1-14 |
| Expansion Bay External Display Panel | 1-15 |
| Expansion Bay Internal Display Panel | 1-15 |
| HP 3000/930 and HP 9000/840S DC Power Distribution System | 1-16 |
| HP 3000/930 and HP 9000/840S AC Power Distribution System | 1-17 |
| Expansion Bay Power Distribution Diagram | 1-18 |
| System Card Cage Location | 3-5 |
| CPU Card Slot Assignments | 3-6 |
| Channel I/O Card Slot Assignments for HP-UX Configuration | 3-8 |
| Memory Array and Memory Controller Slot Assignments | 3-9 |
| Midbus Card Slot Assignments | 3-10 |
| HP-UX Expansion Bay Configuration Example | 3-13 |
| MPE-XL Expansion Bay Configuration Example | 3-14 |
| Power Distribution Matrix for Card Slots | 3-18 |
| External and Internal System Status Display Panels | 4-2 |
| Expansion Bay Module System Status Display Panels | 4-5 |
| Hexidecimal Display Panel | 4-8 |
| PDU Transformer Strapping Diagram | 4-45 |
| System Monitor Test Points | 4-46 |
| Power System Troubleshooting Flowchart 1 | 4-50 |
| Power System Troubleshooting Flowchart 2 | 4-51 |
| Power System Troubleshooting Flowchart 3 | 4-52 |
| Power System Troubleshooting Flowchart 4 | 4-53 |
| Power System Troubleshooting Flowchart 5 | 4-54 |
| Power System Troubleshooting Flowchart 6 | 4-55 |
| Selftest Operation Flowchart 1 | 4-56 |
| Selftest Operation Flowchart 2 | 4-57 |
| Selftest Operation Flowchart 3 | 4-58 |
| Selftest Operation Flowchart 4 | 4-59 |
| HPMC Troubleshooting Flowchart 1 | 4-60 |
| HPMC Troubleshooting Flowchart 2 | 4-61 |
| HPMC Troubleshooting Flowchart 3 | 4-62 |
| AP Frontplane Layout | 4-64 |
| AP Cable Testhood Diagram | 4-69 |
| Remote Maintenance Cable Configuration Diagram | 4-70 |
| AP Card Block Diagram | 4-71 |
| Location of Power Supplies | 6-3 |
| DTC Internal Protective Plate(Front View) | 7-5 |
| DTC Internal Protective Plate(Rear View) | 7-6 |
| SPU, Front View | 8-3 |
| SPU, Rear View | 8-5 |

FIGURES AND TABLES (continued)

| LIST OF TABLES | Page |
|--|------|
| CPU Specifications | 1-7 |
| System Monitor Specifications | 1-7 |
| CPU and Mid-Bus Card Cage Capacity | 1-8 |
| Channel I/O Card Cage Capacity | 1-8 |
| System Color Code | 1-9 |
| SPU Specifications | 2-2 |
| Expansion Bay Specifications | 2-4 |
| Preventive Maintenance Schedule | 2-7 |
| Minimum Hardware Configuration (All Systems) | 3-2 |
| Maximum Peripheral Devices for System Configuration | 3-3 |
| System Card Cage Configuration | 3-4 |
| Configuration Switch Definitions (HP 27110B/HP 27113A) | 3-15 |
| External System Control Panel | 4-3 |
| Internal System Control Panel | 4-4 |
| Expansion Module Internal Display Panel | 4-6 |
| Expansion Module External Display Panel | 4-7 |
| Class Error Descriptions | 4-9 |
| Selftest Error Codes | 4-10 |
| Minimum Hardware Configuration | 4-41 |
| Power Supply Voltage/Signal Test Points | 4-47 |
| Power Supply Voltage/Signal Test Table | 4-48 |
| Selftest Switch Settings | 4-49 |
| Selftest Results | 4-66 |
| AP Commands for Remote Maintenance | 4-68 |
| Supported Diagnostic Programs | 5-4 |
| Supported Subsystem Utilities | 5-5 |
| MPE-XL Default Device Configuration | 7-2 |
| HP-UX Default Device Configuration | 7-3 |
| Exchange Parts | 8-7 |
| Non-Exchange Parts (1 of 2) | 8-8 |
| Non-Exchange Parts (2 of 2) | 8-9 |
| CIO Expansion Bay/Module, Replaceable Parts (1 of 2) | 8-10 |
| CIO Expansion Bay/Module, Replaceable Parts (2 of 2) | 8-11 |
| ASCII Code Table | 10-1 |

PREFACE

The Customer Engineer Handbook is a reference guide for the Customer Engineer (CE). It provides specifications, procedures, replaceable parts list, troubleshooting data, and applicable reference information. This handbook is divided into sections to logically arrange data into subject groups.

The Product Information section contains functional block diagrams (HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S), system specifications, system orientation, control panel information, and power system information.

The Environmental, Installation, and Preventive Maintenance (PM) section provides reference to applicable manuals for installation procedures, as well as describes environmental requirements and preventive maintenance procedures.

The Configuration section provides hardware data required to operate a standard configuration of the HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S Computer Systems.

The Troubleshooting section contains information on LED status indicators, Expansion Bay Module LED status indicators, system display status codes, error descriptions, flowcharts for SPU troubleshooting and selftest as a troubleshooting tool. Information on Access Port troubleshooting and Remote Maintenance is also included.

The Diagnostic Section provides information pertaining to the diagnostics used for the HP-UX and MPE-XL operating systems. Reference material for detailed diagnostic procedures is also provided.

The Adjustments section contains procedures required to remove/replace the system power supply.

The Peripherals section contains default device configuration information supported on the HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S Computer Systems.

The Replaceable Parts section contains a Replaceable Parts Catalog that provides illustrations and parts lists to assist with parts replacement procedure.

The Diagrams section contains selected hardware drawings to aid the CE in isolating system faults.

The Reference section contains conversion charts and acronyms to aid the CE in troubleshooting.

The Service Note section is a depository for special procedures and troubleshooting data developed in the field.

The information which refers specifically to HP-UX or MPE-XL is cited, all other information applies to both.

REFERENCE DOCUMENTS

The hardware documentation supporting the HP 3000/930 and HP 9000/840S Computer Systems is listed below. Reference these manuals when additional information is required.

Hardware Support Manual, Part Number 09740-90011.

Site Preparation and Requirements Guide, Part Number 09740-90018.

Installation and Configuration Guide, Part Number 09740-90019.

Online Diagnostics Subsystem Manual, Part Number 09740-90020.

Online Diagnostics Subsystem Utilities Manual, Part Number 09740-90021.

System Support Log, Part Number 09740-90013.

HP Precision Architecture and Instruction Reference Manual, Part Number 09740-90014.

Precision Architecture Procedure Calling Conventions Reference Manual, Part Number 09740-90015.

HP 19744A Add-on Channel Installation Guide, Part Number 19744-90001.

HP 19748A Add-on Memory Installation and Configuration Guide, Part Number 19748-90001.

HP 19749A Cable Management System Installation Guide, Part Number 19749-90001.

Interface and Networking Cards Manual, Part Number 09740-64011.

Peripherals and Accessories Manual, Part Number 09740-90012.

HP 9000/840S System Administrators Manual, Part Number 92453-90004.

HP 7937 Operating and Installation Manual, Part Number 07937-90902.

HP 7936/37 Hardware Support Manual, Part Number 07937-90903.

HP 27111A Fiber Optic Link Interface for the Channel I/O Bus Installation and Service Manual, Part Number 27111-90001.

Expansion Bay/Module Support Manual, Part Number 32480-90001.

Expansion Bay/Module Installation and Configuration Guide, Part Number 32480-90003.

PRODUCT INFORMATION

SECTION

1

This section provides an overview for the HP 3000/930 and 9000/840S computer systems functional block diagrams, system specifications, system orientation, and system status display panel information.

| | |
|--|------|
| System Specifications | 1-7 |
| Central Processing Unit (CPU) | 1-7 |
| System Monitor Card | 1-7 |
| System Capacity | 1-8 |
| System Color Code Organization | 1-8 |
| System Orientation | 1-9 |
| System Status Display Panels | 1-14 |
| Power Distribution System | 1-16 |



Series 900 Model 930 Block Diagram




Figure 1-1. HP 3000/930 Functional Diagram

Series 800 Model 840 Block Diagram




Figure 1-2. HP 9000/840 Functional Diagram Page 1-5

SYSTEM SPECIFICATIONS

HP Precision Architecture Computer Systems share a common architecture and instruction set. The instruction set is hardwired to speed up instruction decoding operations. See Figures 1-1 and 1-2 for the HP 3000/930 and HP 9000/840S functional block diagrams. The processor uses a TTL processing unit technology. The following is a listing of general System Processor Unit (SPU) specifications.

Central Processing Unit (CPU)

Table 1-1. CPU Specifications

| | |
|---|---|
| Word Length | 32 bits |
| Virtual Memory Address Space | 48 bits |
| Physical Memory Address Space | 27 bits (128 Mbytes) |
| Instruction Set (with Floating Point Coprocessor) | 127 instructions (167 instructions) |
| Cycle Time | 125 nanoseconds |
| Mid-Bus Bandwidth | 32 Mb per second (raw) 15 - 20 Mb per second (typical) |

System Monitor Card

Table 1-2. System Monitor Specifications

| | |
|------------------------------|----------|
| Lithium Battery Service Life | 10 years |
|------------------------------|----------|

System Capacity

Table 1-3. CPU and Mid-Bus Card Cage Capacity

| | |
|--|--------|
| Processor Boards (RF, EU+, IU, TLB, CA+) | 5 |
| Coprocessor Boards | 2 |
| CIO Channel Adapter (two cards per channel) (See NOTE) | 3 sets |
| Mid-Bus Cards (See NOTE) | 5 |
| Memory Boards (3 Memory Controllers and 3 Memory Arrays) | 6 |

NOTE

The total sum of the CIO Channel Adapter Cards (with two cards per channel) plus general purpose Mid-Bus Cards in the CPU Card Cage cannot be greater than seven cards.

Table 1-4. Channel I/O Card Cage Capacity

| | |
|--|----|
| CIO Cards | 12 |
| Access Port (dedicated slot) - Console Attachment Board #1 | 1 |
| Channel Buffer Card (CIB Attachment Board) | 1 |

System Color Code Organization

Table 1-5. System Color Code

| Functional Area (Card Slot Qty.) | Color Code |
|----------------------------------|------------|
| CIO (14) | Orange |
| Mid-Bus (7) | Blue |
| Memory (6) | Pink |
| CPU (7) | Purple |
| System Monitor Module | Mustard |
| Power Supply Module - 3 ea. | White |

SYSTEM ORIENTATION

Provided in Figure 1-3 and 1-4 are front and rear views of the SPU. Figure 1-5, 1-6, and 1-7 are views of the Expansion Bay.






Figure 1-3. Cabinet, Front View (Door and Card Cage Covers Removed)




LG200012_011a

Figure 1-4. Cabinet, Rear View (Door and Card Cage Covers Removed)




LG200050_001

Figure 1-5. SPU and Expansion Bay, Front View



LQ200050_002

Figure 1-6. SPU and Expansion Bay, Rear View



LG200050_004

Figure 1-7. DTC (Rear View) with Cable Management Racks

SYSTEM STATUS DISPLAY PANELS

The external and internal system status display panels are illustrated in Figure 1-8. Refer to Troubleshooting in Section 4 for Indicator/Status description information.






Figure 1-8. External and Internal System Status Display Panels



LG200005_005


Figure 1-9. Expansion Bay External Display Panel



LG200005_004


Figure 1-10. Expansion Bay Internal Display Panel

POWER DISTRIBUTION SYSTEM



LG200012_015


Figure 1-11. HP 3000/930 and HP 9000/840S DC Power Distribution System



LG200012_016

Figure 1-12. HP 3000/930 and HP 9000/840S AC Power Distribution System

Product Information



LG200005_012

Figure 1-13. Expansion Bay Power Distribution Diagram

ENVIRONMENTAL/INSTALLATION/ PREVENTIVE MAINTENANCE

SECTION

2

This section contains information on environmental specifications, installation, and preventive maintenance.

| | |
|---|-----|
| SPU Specifications | 2-2 |
| Expansion Bay Specifications | 2-4 |
| Installation | 2-6 |
| Hardware Installation Checklist | 2-6 |
| Operating System Installation | 2-6 |
| Device Adapters | 2-6 |
| Preventive Maintenance | 2-7 |



SPU SPECIFICATIONS

Table 2-1. SPU Specifications

| Description | Specification | |
|--------------------------------|--|--|
| | 3000/930 SPU Only | 9000/840S SPU Only |
| Operating temperature | 0 to 55 degrees C | 0 to 55 degrees C |
| Storage temperature | -40 to 70 degrees C | -40 to 70 degrees C |
| Operating temp rate of change | 0.3 degrees C/min. 20 degrees C/hr. | 0.3 degrees C/min. 20 degrees C/hr. |
| Recommended operating temp | 20-30 degrees C (68-86 degrees F) | 20-30 degrees C (68-86 degrees F) |
| Operating humidity | 5 to 95% RH @ 40 degrees C | 5 to 95% RH @ 40 degrees C |
| Non-operating humidity | 90% RH @ 65 degrees C | 90% RH @ 65 degrees C |
| Humidity condensation recovery | 15 minutes | 15 minutes |
| Altitude, operating | 15,000 ft temp derated -1.1 deg C/1000 ft, above 7000 ft | 15,000 ft temp derated -1.1 deg C/1000 ft, above 7000 ft |
| Altitude, non-operating | 50,000 ft. | 50,000 ft. |
| Nominal AC line input | 200, 208, 220, 230 or 240VAC (single phase) | 200, 208, 220, 230 or 240VAC (single phase) |
| Operating tolerance range | + 15% of selected nominal input voltage | + 15% of selected nominal input voltage |
| Input frequency | 50 to 60Hz (-5% to +10%, 47.5 to 66Hz) | 50 to 60Hz (-5% to +10%, 47.5 to 66Hz) |
| Max steady state current | 13A | 13A |
| Surge Current | 110A max | 110A max |
| Power dissipation | 2000 Watts | 1685 Watts (2000 Watts with Expansion Bay) |
| Power factor | 0.7 | 0.7 |
| Max heat dissipation | 6900 BTU/hr. | 5745 BTU/hr. (6900 BTU/hr. with Expansion Bay) |

Table 2-1. SPU Specifications (Cont.)

| Description | Specification | |
|--|---|---|
| | 3000/930 SPU Only | 9000/840S SPU Only |
| Min battery backup power | 15 minutes (SPU only, no backup on the expansion bay) | 15 minutes |
| Power fail carry through | one cycle minimum | one cycle minimum |
| Power line transients | IEEE 587, category B | IEEE 587, category B |
| Total harmonic distortion | < 10% | < 10% |
| Magnetic emissions operating non-operating | < 5 gauss p-p < 5.25 milligauss at 4.6 meters | < 5 gauss p-p < 5.25 milligauss at 4.6 meters |
| Magnetic field immunity | 1 gauss | 1 gauss |
| ESD immunity | 0 to 15KV, no effect; 15 to 25KV, no hardware failures | 0 to 15KV, no effect; 15 to 25KV, no hardware failures |
| Electric field immunity radiated: 10Khz to 1GHz 146Hz to 174MHz and 406Hz to 512MHz | 5V/m 10V/m | 5V/m 10V/m |
| Electric field immunity conducted: 30Hz to 400Mhz | 3V rms | 3V rms |
| Physical dimensions | height: 1 meter (39 in.) width: 1.2 meters (46.8 in.) * depth: 0.8 meters (31.2 in.) weight: 574 lbs. (261 kg) * | height: 1 meter (39 in.) width: 0.6 meters (23.4 in.) depth: 0.8 meters (31.2 in.) weight: 357 lbs. (162 kg) |
| Safety | UL listed, CSA certified compliant to IEC 380, 435 | UL listed, CSA certified compliant to IEC 380, 435 |
| Electromagnetic Interference | Complies with FCC rules for Class A computing device. FTZ licensed to VDE level A. VCCI registered. | Complies with FCC rules for Class A computing device. FTZ licensed to VDE level A. VCCI registered. |
| Acoustics | 6.6 Bels (A) sound power | 6.6 Bels (A) sound power |

Table 2-2. Expansion Bay Specifications

The HP 19746B Expansion Bay/Module configures to the 9000/840S computer. It consists of the HP 19746A Expansion Module which is contained within the HP 19747A Expansion Bay.

The Expansion Bay/Module that configures to the 3000/930 computer consists of the HP 19746A Expansion Module and the HP 2345A Distributed Terminal Controller (DTC) which are both contained within the HP 19747B Expansion Bay.

The specifications listed in Table 2-2 are for the HP 19746A Expansion Module. Refer to the DTC documentation to obtain the DTC specifications.

HP 19746A Expansion Module Specifications

| PARAMETERS | SPECIFICATIONS |
|------------------------------|---|
| Shock Requirements: | |
| End use handling: | 4 inch free fall drop (45 degrees each edge) |
| Transportation: | 1/2 sine drop |
| Susceptability Requirements: | |
| Electrostatic Discharge | 0 to 15 KV no effect 15 to 25 KV no damage |
| Input power Requirements: | |
| Voltage | 168 to 280 VAC |
| Frequency: | 47 to 67 Hz |
| Current: | 1.3 Amps maximum |
| Power Consumption: | 330 Watts maximum |
| Display Requirements: | |
| Voltage | +5VS |
| Current: | 200ma |
| Power: | 1 Watt |
| Height: | 11 inches (268 mm) |
| Width: | 17 inches (425 mm) |
| Depth: | 20 inches (500 mm) |
| Weight: | 31 pounds (14 kg) |
| Expansion Bay Cabinet: | |
| Height: | 39 inches (1000 mm) |
| Width: | 23.4 inches (600 mm) |
| Depth: | 31.2 inches (800 mm) |
| Weight: | 33 pounds (15 kg) |

Table 2-2. Expansion Bay Specifications (Cont.)

| PARAMETERS | SPECIFICATIONS |
|--|--|
| Ambient Temperature Requirements: Operating: Maximum operating rate of change: Non-operating: | 0 to 55 degrees C 20 degrees C per hour -40 to +70 degrees C |
| Humidity Requirements: Operating: Non-operating: (24 hours with no visible effect) | 5 to 95% relative humidity at 40 degrees C 90% relative humidity at 65 degrees C |
| Altitude Requirements: Maximum operating: Maximum non-operating: | 15,000 feet (derate maximum temperature by - 1.1 degrees C per 1000 feet above 7,500 feet) 50,000 feet |
| Vibration Requirements: | |
| Sinusoidal Sweep: | 5 to 5000 Hz at 0.5 g RMS |
| Sinusoidal dwell: | 0.5 g RMS for 5 minutes at the four lowest resonant frequencies |
| Random operational: | 5 Hz, 0.002 g per Hz 5 - 15 Hz, -1.5 dB per octave 15 Hz, 0.0015 g per Hz 15 - 170 Hz, -6.0 dB per octave 170 - 350 Hz, 0.00013 g per Hz 350 - 500 Hz, -6.0 dB per octave 500 Hz, 0.000067 dB per octave |
| Random non-operational: | 5 - 100 Hz, 0.015 g per Hz 100 - 137 Hz, -6.0 dB per octave 137 - 350 Hz, 0.0008 g per Hz 350 - 500 Hz, -6.0 dB per octave 500 Hz, 0.0039 g per Hz |

INSTALLATION

System installation procedures for the CE are not provided in this manual due to their level of detail. Refer to the Installation and Configuration Guide, P/N 09740-90019, for installation procedures which apply to the Hardware Installation Checklist provided below. For installation procedures regarding the Expansion Bay/Module, refer to the Expansion Bay Installation and Configuration Guide. P/N 32480-90003.

Hardware Installation Checklist

- Install I/O Extender Bay (Optional).
- Install Floating Point Coprocessor (Optional).
- Install System Cables.
- Install System Console.
- Install Disc Drive.
- Install Peripheral Devices.
- Check Power Supply Voltages.
- Run Computer Selftest.
- Backup System.
- Run System Verification.
- Check Power Fail Recovery System.

Operating System Installation

The SPU is ready for installation of the operating system software after the system hardware has been installed. During installation, the eight dip switches (labeled Diagnostic Switch) that are located on the front of the System Monitor Module (see Figure 4-10) are in the CLOSED (toggled left) position. For installation of MPE-XL, refer to System Administrator Series; System Startup and Shutdown Manual, P/N 32650-90034. Installation of HP-UX is found in the System Administrator Manual, P/N 92433-90004.

Device Adapters

Device adapters provide an interface between peripheral devices and the CIO bus. The supported device adapters are:

- HP 27113A Commercial HP-IB Device Adapter.
- HP 27110B Technical HP-IB Card.
- HP 27112A General Purpose I/O (GPIO) Card.
- OEM Programmable Serial Interface Card.
- Programmable Serial Interface, Remote Job Entry.
- HP 27140A Six-Channel Multiplexer for terminals.
- HP 27125A (IEEE 802.3) Local Area Network Interface Card (LANIC).
- HP 27114A Asynchronous FIFO Interface (AFI) Card.
- HP 27111A Fiber Optic Link Interface (HP-FL) Card.

Refer to Table 3-4 in the Configuration Section for HP 27110B/27113A switch configurations.

PREVENTIVE MAINTENANCE

Preventive Maintenance (PM) is performed periodically to ensure the system will operate continuously without failures. Refer to the Hardware Support Manual (P/N 09740-90011) for detailed procedure information concerning Preventive Maintenance (Chapter 4) or Removal and Replacement (Chapter 6). For preventative Maintenance regarding the Expansion Bay, refer to the Expansion Bay/Module Hardware Support Manual.

The following maintenance schedule is recommended for sustained performance of the computer system.

| |
|-------------|
| NOTE |
|-------------|

Before maintenance on the system is started, verify that the System Operator has backed-up all files, users are logged off, and an operating system shutdown was performed before powering down system.

Table 2-3. Preventive Maintenance Schedule

| SCHEDULE ASSEMBLY | EVERY 12 MONTHS |
|---|---|
| Fans (4) (P/N 3160-0478) | Check fan operation, replace as necessary. |
| Air Filter (P/N 3150-0504) | Replace. |
| System Control Panel LEDs | Press and hold RESET button on System Control Panel. Observe all LEDs are ON. If any LEDs are not ON, replace System Control Panel Display Card. |
| DC Power Supply | Verify voltages at System Monitor Card test points. Refer to Table 4-8 (Troubleshooting, Section 4). Replace power supply if not within normal specification. |
| Backup Battery - lead acid (P/N 09740-60007) | Test power fail and replace battery as necessary. |
| System Monitor Module Batteries (2) - lithium (P/N 1420-0341) | Test both batteries and replace as necessary. |
| Memory | Check single bit errors |

WARNING

Observe all **WARNING - HAZARDOUS VOLTAGE** labels. Hazardous voltages are present inside the computer mainframe. Refer to **Hardware Support Manual (P/N 09740-90011)** for detailed information on handling assemblies.

CONFIGURATION

SECTION

3

This section provides hardware data required to operate a standard configuration of the HP 3000/930 and 9000/840S Computer Systems.

| | |
|---|------|
| CPU Card Cage Configuration Assignment | 3-6 |
| CIO Card Cage Configuration Assignment. | 3-7 |
| Memory Card Cage Configuration Assignment. | 3-9 |
| Midbus Card Cage Configuration Assignment | 3-10 |
| Expansion Bay Configuration Examples | 3-11 |
| Configuration Switch Definitions | 3-15 |
| Selftest Configuration Switch Definitions | 3-15 |
| System Console Configuration | 3-16 |
| MPE-XL/HP-UX System Console. | 3-16 |
| Access Port Configuration. | 3-16 |
| Power Distribution Chart | 3-17 |
| Expansion Bay Power Distribution Chart | 3-19 |



Configuration

The minimum hardware configuration that is required to support the HP 3000/930 (MPE-XL) or HP 9000/840S (HP-UX) Computer Systems is provided in Table 3-1 and Table 4-7.

Table 3-1. Minimum Hardware Configuration (All Systems)

| Quantity (MPE-XL) | Quantity (HP-UX) | HP Product# | Description |
|-------------------|------------------|-------------|---|
| 1 | 1 | 9740A | SPU (HP-UX is HP Product # 9741A) |
| 1 | 1 | 19742A | Floating Point Coprocessor (optional) |
| 2 | 1 | 19744A | Channel Set (3 cards each set) |
| 1 | X | 19746A | Expansion Module |
| 1 | X | 19747A | Expansion Bay |
| 4 | 1 | 19748A | 8M Byte Memory |
| 1 | 1 | 30192A | Access Port |
| X | X | I/O Cards | CIO Interface Cards (Quantity to support peripherals) |

The minimum peripheral hardware needed to support either an MPE-XL or HP-UX operating system is:

- One CS80 Disc Drive (HP 7935).
- One System Console (HP 2392A).
- One Mag Tape (HP 7978).
- One Line Printer (HP 2563/2566) - optional.

The maximum number of peripheral hardware devices allowed for system configuration of the MPE-XL or HP-UX operating system is listed in Table 3-2. For specific default device configuration information, refer to Tables 7-1 and 7-2 in Section 7.

Table 3-2. Maximum Peripheral Devices for System Configuration

| Peripheral Device | Maximum Quantity (MPE-XL) | Maximum Quantity (HP-UX) |
|--|---------------------------|--------------------------|
| Devices allowed on HP-IB device adapter. | *6 | 6 |
| HP-IB device adapter allowed on one channel adapter. | 4 | 4 |
| LAN cards allowed on channel adapter. | 2 | 1 |
| LAN cards allowed per system. | 2 | 1 |
| Disc drives allowed on one HP-IB device adapter. | 4 | 4 |
| Disc spindles allowed per system. | 24 | 8 |
| Line printers allowed per system. | 8 | 3 |
| Page printers allowed per system. | 4 | - |
| Total printers allowed per system. | 12 | 3 |
| Tape drives allowed per system. | 8 | 5 |
| DTCs allowed per system. | 16 | n/a |
| Port muxes (6) allowed per system. | **1 | 6 |
| Channel adapter sets allowed per system. | 3 | 1 |

* Maximum of 4 disc drives per HP-IB adapter

** 1 mux port active only for system console


Table 3-3. System Card Cage Configuration

| SLOT# | CARD CAGE | BOARD NAME |
|----------------------------|-----------|--|
| -- CPU Card Cage -- | | |
| 1 | CPU | Register File (RF) unit |
| 2 | CPU | Floating Point Coprocessor (C1) |
| 3 | CPU | Reserved for Coprocessor |
| 4 | CPU | Execution Unit (EU) |
| 5 | CPU | Instruction Unit (IU) |
| 6 | CPU | Translation Lookaside Buffer (TL) Unit |
| 7 | CPU | Cache (CA) Unit |
| -- Midbus/Memory Module -- | | |
| 1 | Midbus | Channel Adapter CIO - C2 |
| 2 | Midbus | Channel Adapter Midbus - C1 |
| 3 | Midbus | Empty (HP-UX); Channel Adapter CIO - C2 (MPE-XL) |
| 4 | Midbus | Empty (HP-UX); Channel Adapter Midbus - C1 MPE-XL) |
| 5 | Midbus | Open for Add-On Channel Installation |
| 6 | Midbus | Open for Add-On Channel Installation |
| 7 | Midbus | Empty |
| **8 | Memory | Memory Array (MA) - 5Mb |
| **9 | Memory | Memory Controller (MC) - 3Mb |
| **A | Memory | Memory Array (MA) - 5Mb |
| **B | Memory | Memory Controller (MC) - 3Mb |
| **C | Memory | Memory Array (MA) - 5Mb |
| **D | Memory | Memory Controller (MC) - 3Mb |
| -- CIO Card Cage -- | | |
| *0-11 | CIO CC | CIO Device Adapters (up to 12, maximum) |
| 12 | CIO CC | Access Port (AP) Card |
| 13 | CIO CC | CIO Buffer Card |

* Lower slot numbers have higher priority. Use these lower numbered slots for high speed peripheral devices. HP-FL cards should be installed in the highest priority slots.

** Any combination of card sets can be supported as long as the largest memory card sets are sorted from the higher number slots down. (If an 8Mb and 32Mb are mixed, then the 32Mb should go in the higher numbered slot.)

LQ200012_005d




LQ200004_031b

Figure 3-1. System Card Cage Location

CPU Card Cage Configuration Assignment

Each Central Processor Unit (CPU) Card has an assigned slot location in the CPU Card Cage. The CPU Card Cage is located between the power supplies (behind a cover plate), inside the front door of the computer cabinet. Refer to Table 3-3 for CPU card slot definitions.



LQ200002_005

Figure 3-2. CPU Card Slot Assignments

CIO Card Cage Configuration Assignment

Each peripheral device in the system is connected to the computer through a Channel I/O (CIO) card, installed in the CIO Card Cage. The two CIO Card Cages (one upper and one lower) are located to the left of the Midbus (inside the rear door of the computer cabinet). (See Figure 3-1.)

A standard MPE-XL operating system includes two channel adapter sets, with a third channel adapter set available as an option. The standard HP-UX operating system consists of one channel adapter set, with two more channel adapter sets available for an optional Expansion Bay. To facilitate maximum system hardware requirements, there are some device adapter cards that are required to be installed in specific CIO card slots. If the system has an Expansion Bay, the required cards must be installed in the main SPU bay. They must NOT be installed in the Expansion Bay. The CIO service priority system is the same for each channel adapter: the service priority of a particular device adapter is determined exclusively by its CIO slot assignment (lower CIO slot assignments have higher service priority). Refer to Section 9 for the overall front/rear cabinet PCAs configuration diagrams of the HP 3000/930 and 9000/840S Computer Systems.

REQUIRED CARDS AND CIO SLOTS

MPE-XL


- CIO slot #0, HP-IB for the System Disc
- CIO slot #1, MUX (6 port) for the System Console
- CIO slot #4, LANIC for the DTC
- CIO slot #12, Access Port Device Adapter
- CIO slot #13, first CIO Buffer Card
- Expansion Bay CIO slot #B1, second CIO Buffer Card, configure 2x8 or 1x16
- Expansion Bay CIO slot #4, Mag Tape & Printer

HP-UX

- CIO slot #0, HP-IB/HP-FL* for the System Disc
- CIO slot #1, MUX (6 port) for the System Console
- CIO slot #2, HP-IB/HP-FL* for the Mag Tape
- CIO slot #7, HP-IB/HP-FL* for printer
- CIO slot #12, Access Port Device Adapter
- CIO slot #13, CIO Buffer Card

* HP-FL cards should be installed in the highest priority slots (lowest slot numbers).

Configuration



LG200002_006b

Figure 3-3. Channel I/O Card Slot Assignments for HP-UX Configuration
 (See Figure 3-7 for MPE-XL Configuration)



Memory Card Cage Configuration Assignment

Memory configuration consists of combinations of 3 Mbyte Memory Controller (MC) Cards and 5 Mbyte Memory Array (MA) Cards, and 12 Mbyte Memory Controller Cards and 20 Mbyte Memory Array cards. All are installed in the Memory Card Cage, located to the right of the Midbus, inside the rear door of the computer cabinet. Any combination of card sets can be supported as long as the largest memory card sets are sorted from the highest numbered slots down. (If an 8MB and 32 MB are mixed, the 32 MB should go in the highest numbered slot.) See Figure 3-1 for card cage location and Figure 3-4 for slot assignments.

Support of the MPE-XL System Software:


- Minimum memory required is 32 Mbytes.
- Maximum memory allowed is 96 Mbytes.

Support of the HP-UX System Software:

- Minimum memory required is 8 Mbytes.
- Maximum memory allowed is 96 Mbytes.

NOTE

Supported memory configurations are 8, 16, 24, 32, 64, and 96 Mbytes.




LQ20002_007

Figure 3-4. Memory Array and Memory Controller Slot Assignments

Midbus Card Cage Configuration Assignment

Midbus configuration consists of a Channel Adapter CIO (CA CIO) Card and a Channel Adapter Midbus (CA MID) Card. These two cards interface with each other inside the Midbus Card Cage, located to the left of the Memory Card Cage. (See Figure 3-1 for card cage location and Figure 3-5 for slot assignments.) Both cards then interface with the CIO Buffer Card (CA BC), located in the CIO Card Cage. (See Figure 3-3.) The three cards form the SPU Channel Adapter that interface the Midbus to the CIO bus.

Standard configuration (higher slot assignment has higher service priority) for MPE-XL is two Channel Adapter sets; standard configuration for HP-UX is one Channel Adapter set. HP-UX also has the option of adding two more Channel Adapter sets to accommodate the Expansion Bay. The Expansion Bay can be configured as one 16-slot card cage with a second Channel Adapter set, or two 8-slot card cages with a second and third Channel Adapter set. The second and third CIO Buffer Cards are located in the Expansion Bay CIO Card Cages.



LG200012_012

Figure 3-5. Midbus Card Slot Assignments

Expansion Bay Configuration (HP-UX)

The HP-UX system (3000/840S) will support an optional Expansion Bay containing an Expansion Module that accommodates another CIO card cage. The Expansion Module can be configured as one 16-slot CIO card cage or two 8-slot CIO card cages. For additional information regarding the Expansion Bay, refer to the Expansion Bay Installation and Configuration Guide (32480-90003).

Figure 3-6, Expansion Bay Configuration Example, shows how the CIO slots might be configured to support the 16-slot configuration or the two 8-slot configurations.

16-Slot Installation Example

1. The 16-slot module has two Channel Adapters, one for the main bay and one for the Expansion Bay. Each Channel Adapter is a three-card set consisting of a Channel Adapter CIO card, a Channel Adapter Mid-Bus card, and a Channel Buffer card. To configure the Expansion Bay to operate as one 16-slot module, insert the configuration card in slot A2 of the Expansion Module backplane. The second CIO Buffer card is inserted in Expansion Module slot B1, while the second Channel Adapter CIO card and Channel Adapter Mid-Bus card are inserted in Mid-Bus card cage slots 3 and 4.
2. Install the system disc, 6 port Mux, mag tape, and printer device adapters in the main bay CIO slots 0, 1, and 2, respectively. These assignments are mandatory for the first power up and operating system download. After the initial download, the printer and mag tape (slot 2) position can be changed with the UXGEN utility.
3. The 16-slot module example has 16 discs (including the system disc) requiring four device adapters to connect the system. One of these device adapters is assigned to the next available CIO slot (6) in the main bay. The other two have been assigned to the highest priority slots (0 and 1) in the Expansion Module. This enables the high speed disc memory load to be evenly distributed between the two Channel Adapters.
4. The two tape drives and two printers can all operate off one device adapter, which should be inserted in CIO slot 2 of the main CIO bay.
5. The LAN device adapter for the terminals is inserted in the Expansion Module to evenly balance the load.

Two 8-Slot Installation Example

1. The two 8-slot module has three Channel Adapters. One Channel Adapter is for the main bay, and the other two Channel Adapters are for the Expansion Module. To configure the Expansion Bay to operate as two 8-slot modules, insert the configuration card in slot A1. The second and third CIO Buffer cards are inserted in slots B1 and B2. The second and third Channel Adapter CIO cards and Channel Adapter Mid-Bus cards are inserted in the Mid-Bus card cage slots 3-6.
2. The system disc, 6 port Mux, and tape/printer device adapters have been assigned to the main bay CIO slots 0, 1, and 2, respectively. These assignments are mandatory (without regard to the number of channel adapters employed) for the first power up and operating system download. After the initial download, the printer and mag tape (slot 2) position can be changed with the UXGEN utility.


Configuration

3. The two 8-slot installation example has 24 discs (including the system disc). One of these is assigned to the next available CIO slot (6) in the main bay along with the required system disc in slot #1. The other four have been divided evenly between the highest priority slots (0 and 1) in each of the 8-slot busses. This enables the high speed disc memory load to be evenly distributed across the three Channel Adapters.
4. The four tape drives and six printers have been assigned a higher priority than any of the terminals (in this installation), so they are divided evenly between the tape/printer device adapter inserted in CIO slot 2 in the main bay and a second in CIO slot 2 in the Expansion Module.
5. Two Lan device adapters are now required, one to support the terminals and a second to handle the network devices. They are split between the two CIO devices in the Expansion Module to balance the traffic load. This creates an unavoidable load imbalance in CIO 2; however, imbalance here or on CIO 3 is preferable to overloading the main bay.

Expansion Bay Configuration (MPE-XL)

The MPE-XL system (3000/930) is shipped with an Expansion Bay containing an Expansion Module configured as one 16-slot CIO card cage. It can also be configured as two 8-slot card cages. For additional information regarding the Expansion Bay, refer to the Expansion Bay Installation and Configuration Guide (32480-90003).


The MPE-XL Configuration Example (Figure 3-7), shows how the CIO slots are configured to support the 16-slot configuration and the two 8-slot configuration.



LQ200002_014b

Figure 3-6. HP-UX Expansion Bay Configuration Example

Configuration



LG200002_014a

Figure 3-7. MPE-XL Expansion Bay Configuration Example

Configuration Switch Definitions

The HP 27110B and HP 27113A device adapters use specific switch settings. These definitions are represented in Table 3-4.

Table 3-4. Configuration Switch Definitions (HP 27110B/27113A)

| SWITCH | FUNCTION | SETTINGS | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--|------|------|------|------|------------|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|------|----|----|----|----|----|------|------------|
| S(8) | Not Used | | | | | | | | | | | | | | | | | | | | | | | | | |
| S(7) | Data Setting Time Selection | UP =Medium/Slow-Speed DOWN =High-Speed | | | | | | | | | | | | | | | | | | | | | | | | |
| S(6) | System Controller Selection | UP =System Controller DOWN =Not System Controller | | | | | | | | | | | | | | | | | | | | | | | | |
| S(10-S(5)) | HP-IB Address Selection (When not the Controller-In-Charge) | S(5) =MSB S(10) =LSB UP =Logic One = Open DOWN =Logic Zero = Closed | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>The factory settings for the configuration switches are as follows:</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td>S(1)</td> <td>S(2)</td> <td>S(3)</td> <td>S(4)</td> <td>S(5)</td> <td>S(6)</td> <td>S(7)</td> <td>S(8)</td> </tr> <tr> <td>---</td> <td>---</td> <td>---</td> <td>---</td> <td>---</td> <td>---</td> <td>---</td> <td>---</td> </tr> <tr> <td>DOWN</td> <td>UP</td> <td>UP</td> <td>UP</td> <td>UP</td> <td>UP</td> <td>DOWN</td> <td>Don't Care</td> </tr> </table> | | | S(1) | S(2) | S(3) | S(4) | S(5) | S(6) | S(7) | S(8) | --- | --- | --- | --- | --- | --- | --- | --- | DOWN | UP | UP | UP | UP | UP | DOWN | Don't Care |
| S(1) | S(2) | S(3) | S(4) | S(5) | S(6) | S(7) | S(8) | | | | | | | | | | | | | | | | | | | |
| --- | --- | --- | --- | --- | --- | --- | --- | | | | | | | | | | | | | | | | | | | |
| DOWN | UP | UP | UP | UP | UP | DOWN | Don't Care | | | | | | | | | | | | | | | | | | | |

Selftest Configuration Switch Definitions

Eight Dip switches located on the front of the System Monitor Module control the execution of selftest. Normal position for all switches is the CLOSED position. See Figure 4-5 for illustration of the System Monitor Module and refer to Table 4-10 for definitions of switch settings in the OPEN position.

Configuration

System Console Configuration

The configuration for the System Console and Remote Console is the same for both MPE-XL and HP-UX. The datacomm and terminal configuration parameters can be set to any value and do not affect the operation of the Access Port Card or the system. The menus are as follows:

DATACOMM CONFIGURATION MENU:

```
Parity/Databits = none/8
Chk Parity = NO
EnqAck = YES
CS (CB) Xmit = NO
RecvPace = Xon/Xoff
XmitPace = Xon/Xoff
```

TERMINAL CONFIGURATION MENU:

```
Local/Echo = OFF
SPOW(B) = NO
Line/Page(D) = LINE (necessary during control mode.)
ReturnDef = <CR>
```

MPE-XL/HP-UX System Console

The System Console is configured into the default configuration files supplied with the operating system. The System Console is connected to Port 0 of the Mux (6 port) card, located in slot #1 of the CIO bus. The connection of the System Console is through the SPU RS-232C Junction Panel, labeled, "Console Terminal" to the Mux (6 port) card via the split cable. The MPE-XL and HP-UX default device configuration information can be found in Peripherals, Section 7. Normal Access Port configuration and troubleshooting procedures can be found in Troubleshooting, Section 4.

Access Port Configuration

Any terminal connected to the computer system through the Access Port (AP) card must be configured into the default configuration files supplied with the operating system, in the same manner as the System Console. The MPE-XL and HP-UX default device configuration information can be found in Peripherals, Section 7.

POWER DISTRIBUTION CHART**POWER SUPPLY #1**

+5V Mid-bus slots 3-13
 +12V Mid-bus slots 3-13, C2, SM
 -12V Mid-bus slots 3-13, C1, C2, SM
 +28V Not Used
 25KHz Not Used

PFW- Power Fail Warning Status Signal
 PON+ Power On Status Signal

POWER SUPPLY #2

+5V RF, EU+, C1, IU, TLB, CA+
 +12V Not Used
 -12V Not Used
 +28V SM (+5VS1)
 25KHz Not used

PFW- Power Fail Warning Status Signal
 PON+ Power On Status Signal

POWER SUPPLY #3

+5V Mid-bus slots 1-2, CIO slots 0-13
 +12V Mid-bus slots 1-2, CIO slots 0-13
 -12V Mid-bus slots 1-2, CIO slots 0-13
 +28V SM (+5VS2)
 25KHz Not Used

PFW- Power Fail Warning Status Signal
 PON+ Power On Status Signal

A separate +5S (+5 secondary) voltage is provided from a regulator on the System Monitor Module used to sustain memory.

A power distribution matrix for card slots of the HP 3000/930 and HP 9000/840S Computer Systems is illustrated in Figure 3-8. The PDU Transformer Strapping diagram is shown in Figure 4-4. See Figure 4-5 for the System Monitor test points, if applicable.

Configuration

| | POWER SUPPLY 1 | POWER SUPPLY 2 | POWER SUPPLY 3 | SYSTEM MONITOR CARD | INTERNAL BATTERY | EXTERNAL BATTERY |
|-------------|--|-------------------------|--------------------------|------------------------------|---------------------|---------------------|
| +5 VOLTS | MID-BUS SLOTS 3-13 | RF, C1, EU, IU, TLB, CA | MID-BUS 1 and 2 CIO 0-13 | | | |
| +5S * VOLTS | | | | CIO 12, CA, IU, MID-BUS 8-13 | | |
| +10 VOLTS | | | | | SYSTEM MONITOR CARD | |
| +12 VOLTS | MID-BUS 3-13, C2, SYSTEM MONITOR | | MID-BUS 1 and 2 CIO 0-13 | | | SYSTEM MONITOR CARD |
| -12 VOLTS | MID-BUS 3-13, C1 (FPP), C2, SYSTEM MONITOR | | MID-BUS 1 and 2 CIO 0-13 | | | |
| +28 VOLTS | | SYSTEM MONITOR CARD | SYSTEM MONITOR CARD | | | |

* 5 VOLTS, SECONDARY IS GENERATED BY THE SYSTEM MONITOR CARD.

Figure 3-8. Power Distribution Matrix for Card Slots

EXPANSION BAY POWER DISTRIBUTION CHART**POWER SUPPLY (300 W)**

| | |
|----------|--|
| +5V(DC) | To Backplane, SM/Configuration Card, Int./Ext. Display Panels, Device Adapters |
| +12V(DC) | To Backplane, Device Adapters |
| -12V(DC) | To Backplane, Device Adapters |
| AC+ | To Backplane, Device Adapters |
| AC- | To Backplane, Device Adapters |
| PPON+ | Primary Power On Status Signal |
| PFW- | Power Fail Warning Status Signal |

Facility Power to three Distributed Terminal Controllers (DTCs).

Refer to Diagrams, Section 9 for illustrations of the Expansion Bay/Module Block Diagram and the Expansion Bay Power Distribution System. Refer to Expansion Bay Configuration, Section 3, for configuration examples.

TROUBLESHOOTING

SECTION

4

This section contains troubleshooting data that is designed to assist the CE with repair and diagnostic functions associated with the HP 3000/930 and 9000/840S Computer Systems.

| | |
|--|------|
| System Display Status Codes | 4-8 |
| HPMC Error List | 4-8 |
| Selftest Error Messages | 4-11 |
| Multiplexed Error Display Codes | 4-37 |
| System Display Codes | 4-37 |
| HP-UX System Display Codes | 4-38 |
| MPE-XL System Display Codes | 4-38 |
| SPU Troubleshooting | 4-41 |
| Minimum Hardware Configuration | 4-41 |
| Troubleshooting Procedures | 4-42 |
| DC Power Supply Check | 4-43 |
| Power Fail Check | 4-43 |
| PDU Strapping Verification | 4-44 |
| Power Supply Troubleshooting | 4-45 |
| Selftest Switch Settings | 4-49 |
| Selftest as a Troubleshooting Tool | 4-56 |
| Access Port Selftest and Troubleshooting | 4-63 |
| System Console Selftest | 4-63 |
| AP Frontplane Selftest | 4-63 |
| Remote Maintenance | 4-67 |
| PDC Boot Error Codes | 4-72 |






Figure 4-1. External and Internal System Status Display Panels

NOTE

Tables 4-1 and 4-2 provide LED status information to be used as an aid for troubleshooting.

Table 4-1. External System Control Panel

| Indicator | Status |
|-----------------------|---|
| RUN (LED is Green) | <p><u>All of the following:</u></p> <ul style="list-style-type: none"> • Selftest passed. • ISL Program Module (OS, DIAG, or UTIL) is loaded. • Power supplies are within voltage specification. • Battery backup is charged. • Temperature is normal. • Battery charging (Green and Yellow LEDs light simultaneously). |
| CHECK (LED is Yellow) | <p><u>One or more of the following:</u></p> <ul style="list-style-type: none"> • Selftest in progress. • Initialization in progress. • Software initiated shutdown. • Non-fatal error has occurred in selftest. • Battery backup is charging. • System temperature is marginal. • Battery charging (Green and Yellow LEDs light simultaneously). |
| FAULT (LED is Red) | <p><u>One or more of the following:</u></p> <ul style="list-style-type: none"> • Selftest in progress. • Initialization in progress. • Fatal error. • One or more power supplies out of voltage spec. • Battery backup in use. • Overtemp. System about to shutdown. |
| REMOTE ENABLED (On) | <p>System "open" to remote access. (AP Link enabled.)</p> |
| CONSOLE ENABLED (On) | <p>System "open" to System Console access. See CONSOLE button on Internal Control Panel. (Mechanical Enable.)</p> |

NOTE

The red FAULT LED on the External Display will light whenever any red LED on the Internal Display is lighted. The yellow CHECK LED on the External Display lights whenever a yellow LED on the Internal Display is lighted. The green RUN LED on the External Display will light when all green LEDs on the Internal Display are lighted. The one exception is that

Troubleshooting

during battery backup, the green RUN LED and the yellow CHECK LED will light simultaneously as the battery is charging. The red FAULT LED will light when the battery is discharging. At system shutdown, all lights are OFF.

Table 4-2. Internal System Control Panel

| Indicator | Status |
|----------------|---|
| TEMPERATURE | Green - Temperature within normal specification. Yellow - System temperature is marginal. Red - Overtemp. |
| DC POWER | Green - Power supplies within normal voltage specification. Red - One or more power supplies out of voltage specification. |
| BATTERY BACKUP | Yellow - Battery backup is charging. Red - Battery backup in use. |
| SELF TEST | Green - Selftest passed. Yellow - Selftest in progress. - Non-fatal error has occurred in Selftest. - Initialization is in progress. - Software initiated shutdown. Red - Selftest in progress. - Initialization in progress. |




Figure 4-2. Expansion Bay Module System Status Display Panels

NOTE

The LEDs located in the first column of the internal/external display panels are always color coded Green, second column LEDs are color coded Yellow, and the third column LEDs are always color coded Red.

NOTE

Tables 4-3 and 4-4 provide indicator/status information for the Expansion Bay Module internal/external system status display panels.

Table 4-3. Expansion Module Internal Display Panel

| Indicator | Status |
|---------------|---|
| TEMPERATURE | Green LED - System temperature is normal. Yellow LED - System temperature is marginal. Red LED - Overtemp. System shutdown. |
| DC POWER | Green LED - System temperature is normal. Red LED - Overtemp. System shutdown (either manually or automatically). - DC Power out of spec. |
| CONFIGURATION | 1/16 (Green LED) - System Monitor/Configuration Card inserted (Slot A2). 2/8 (Split Green LED) - System Monitor/Configuration Card inserted (Slot A1). |

NOTE

The System Monitor/Configuration Card inserted in Slot A2 defines the backplane as being a single 16-slot bus; the System Monitor/Configuration Card inserted in Slot A1 defines the backplane as being two, mutually independent 8-slot busses.

Table 4-4. Expansion Module External Display Panel

| Indicator | Status |
|---|--|
| RUN (Green LED) (EXP 1 and EXP 2) | <ul style="list-style-type: none"> • Power supply voltages within normal specification. • Temperature inside module is normal. |
| CHECK (Yellow LED) (EXP 1 and EXP 2) | <ul style="list-style-type: none"> • Temperature inside module is high. • System operable, but cooling system needs checking. |
| FAULT (Red LED) (EXP 1 and EXP 2) | <ul style="list-style-type: none"> • Overtemp. System shutdown (either manually or automatically). • One or more power supplies not within normal voltage specification. |

NOTE

The External Display Panel is split in two horizontally, providing status indications for a single installed Expansion Module (EXP 1) and also for a second module (EXP 2), as applicable. The row of indicators associated with EXP 2 will remain off at all times if the second module is not present in the cabinet.



SYSTEM DISPLAY STATUS CODES

Tables 4-5 and 4-6 provide the detailed format of the hexadecimal display panel shown in Figure 4-3. High Priority Machine Checks may be associated with any of these class errors. For detailed descriptions on all error numbers generated by selftest, PDC/IODC, and ISL refer to Selftest Error Messages in this section.




Figure 4-3. Hexadecimal Display Panel

HPMC Error List

The twelve types of High Priority Machine Checks (HPMCs) are described below. These are the detailed errors from the hexadecimal display. See Figures 4-16 thru 4-18 for flowcharts that describe how to troubleshoot them. The HPMC error list is also included in Selftest Error Messages in this section.

1. XXF1 - Instruction TLB parity error.
2. XXF2 - Data TLB parity error.
3. XXF3 - Midbus address parity error / No slave response.
4. XXF4 - Midbus read data parity error.
5. XXF5 - Multiple bit memory read error.
6. XXF6 - Midbus write data parity error.
7. XXF7 - Midbus CMD or EIR data parity error / Midbus timeout.
8. XXF8 - Cache tag parity error.
9. XXF9 - D cache read parity error.
10. XXFA - Floating Point Instruction parity error.
11. XXFB - Instruction parity error.
12. XXFC through FF - Undefined HPMC.

(XX represents the first two symbols of an error message.)

Table 4-5. Class Error Descriptions

| Class Errors | Description of Error Condition |
|---------------------|---|
| 0XXX | Catastrophic Failure. |
| 1XXX | Processor Hardware Failure. |
| 2XXX | Cache (CA+) or Translation Lookaside Buffer (TLB) Hardware Failure. |
| 3XXX | Processor Dependent Hardware/System Monitor Failure. |
| 4XXX | Coprocessor Hardware Failure. |
| 5XXX | Bus Protocol Error. |
| 6XXX | Reserved. |
| 7XXX | Memory Hardware Failure. |
| 8XXX | I/O Hardware Failure. |
| 9XXX | Console Device Failure. |
| AXXX | Boot Device Failure. |
| BXXX | Operating System Software. |
| CXXX | Initialization Failure. |
| EXXX | OS or Environmental Warning. |
| FXXX | Run Time Messages. |

Table 4-6. Selftest Error Codes

| Class Error# | Slot # with Detailed Error | Description | Action |
|--------------|----------------------------|--|-----------------------|
| 1 | 11XX | Processor Failure - RF Unit. | Replace Faulty Board. |
| 1 | 14XX | Processor Failure - E Unit. | Replace Faulty Board. |
| 1 | 15XX | Processor Failure - I Unit. | Replace Faulty Board. |
| 2 | 26XX | TLB/CA Failure - TLB Unit. | Replace Faulty Board. |
| 2 | 27XX | TLB/CA Failure - Cache Board. | Replace Faulty Board. |
| 3 | 30XX | Processor Dependent Hardware Failure (System Monitor Card Failure 30). | Replace Faulty Board. |
| 4 | 4ZXX* | Coprocessor Failure. | Replace Faulty Board. |
| 5 | 5ZXX* | Bus Protocol Failure. | Replace Faulty Board. |
| 6 | 6XXX* | Architecturally Reserved. | Replace Faulty Board. |
| 7 | 7ZXX* | Memory Hardware Failure. | Replace Faulty Board. |
| 8 | 8ZXX* | I/O Channel Adapter Test. | Replace Faulty Board. |
| | XXF0-XXFF | HPMC Console Device Path Test. Boot Device Path Test. | Replace Faulty Board. |
| 9 | 9ZXX* | Operating System Failure. | Replace Faulty Board. |
| A | AZXX* | Initialization: Power Fail. | Replace Faulty Board. |
| B | BZXX* | Initialization: Transfer of Control. | Replace Faulty Board. |
| C | CAXX | Initialization: Initial System Load Code. | Replace Faulty Board. |
| C | CBXX | Loader Error: Parallel Card. | Replace Faulty Board. |
| C | CEXX | | Replace Faulty Board. |
| C | OSXX | | Replace Faulty Board. |

* Z = Slot dependent value.

** See HPMC Error Messages in Chapter 8 of the Hardware Support Manual, P/N 09740-90011.

NOTE

The detailed error code is reflected by the last two digits on the System Display Panel. Detailed error descriptions are provided in this section.

SELFTEST ERROR MESSAGES

The following list contains the detailed error numbers generated by selftest, PDC/IODC, and ISL program code. (** signifies the same error number is repeated.)

1. Class **ERROR 1**: Processor failure; Register File, error code = 11XX

| Error Numbers | Description of error condition |
|-------------------|--|
| 1100 | Undefined error occurred at start of test of this board. |
| 1101 ** ** | Failure while testing GR's 1, 2, and 31. Second possible cause of error is E__unit. Third possible cause of error is I__unit. |
| 1102 ** ** | Failure while testing general registers. Second possible cause of error is E__unit. Third possible cause of error is I__unit. |
| 1103 ** ** | Failure while testing RC, or EIEM. Second possible cause of error is E__unit. Third possible cause of error is I__unit. |
| 1104 ** ** | Failure while testing temporary control registers. Second possible cause of error is E__unit. Third possible cause of error is I__unit. |
| 1105 and 1106 | Reserved. |
| 1107 | Crosstalk between general registers. |
| 1108 | Crosstalk between general registers and the temporary registers. |
| 1109 | Reserved. |
| 110A | X and B bus bypass testing. |
| 110B | GR0 bypassed. |
| 110C | GR0 bypassed on a nullify. |
| 110D | Failure while verifying trap with Interval Timer. |
| 110E through 110F | Reserved. |
| 1110 ** ** | Interval Timer does not get incremented. Second possible cause of error is I__unit. Third possible cause of error is E__unit. |
| 1111 ** ** | Interval Timer does not cause trap. (Cannot force external interrupt trap.) Second possible cause of error is I__unit. Third possible cause of error is TLB. |

Troubleshooting

| | |
|-------------------|---|
| 1112 | Recovery Counter doesn't cause trap. |
| ** | Second possible cause of error is l_unit. |
| ** | Third possible cause of error is TLB. |
| 1113 through 1114 | Reserved. |
| 1115 | Load to general register zero modified that register. |
| 1116 | Nullified instruction stored to register file. |
| 1117 | Failure while verifying address calculation for load word and modify (LDWM). |
| 1118 | Failure while verifying address calculation for load word indexed and modify (LDWX, M). |
| 1119 | Failure while verifying address calculation for load byte indexed and modify (LDBX, U, M). |
| 111A | Failure while verifying address calculation for load half word indexed and modify (LDHX, U, M). |
| 111B | Failure while verifying address calculation for load word indexed and modify (LDWX, U, M). |
| 111C through 111F | Reserved. |
| 1120 | Failure while verifying operation of Register File interlocks. |
| 1121 | Failure while verifying address calculation for load word and modify after (LDW, MA). |
| 1122 | Failure while verifying address calculation for load word and modify before (LDW, MB). |
| 1123 | Failure while verifying operation of move to Control register (MTCTL) after load word (LDW). |
| 1124 through 1129 | Reserved. |
| 112A | Nullified instruction after data trap stored to Register File. |
| 112B | Failure while verifying address calculation of load and modify which cause data trap. |
| 112C | Failure while verifying ripple through the counters of recovery counter. |
| 112D | Could not force overflow trap. |
| 112E | Failure while verifying back up operation on recovery counter. |

| | |
|-------------------|---|
| 112F | Failure while verifying late nullify on recovery counter. |
| 1131 | Unexpected recovery counter trap was taken. |
| ** | Second possible cause of error is I_unit. |
| ** | Third possible cause of error is TLB taken. |
| 1132 | Unexpected external interrupt trap was taken. |
| ** | Second possible cause of error is I_unit. |
| ** | Third possible cause of error is TLB. |
| 1140 | Failure while testing EIR register with zero. |
| 1141 | Failure while verifying value of GR1 after ADDIL instruction. |
| 1142 | Failure while verifying calculation of return address with BLE instruction. |
| 1143 | Register File does not zero unused portion of target register for LDH instruction. |
| 1144 | Register File does not zero unused portion of target register for LDB instruction. |
| 1145 | Cannot distinguish between different bank of general registers. |
| 1146 | Failure while verifying Recovery Counter operation (RC cannot count up). |
| 1147 | Failure while verifying Recovery Counter operation with nullify instruction. |
| 1148 | Failure while verifying Recovery Counter operation with late nullify instruction. |
| 1149 | Failure while verifying Recovery Counter operation with late nullify instruction caused by data trap. |
| 114A | Failure while verifying Recovery Counter trap. |
| 114B | Failure while verifying operation of Recovery Counter trap immediately after data trap. |
| 114C | Cannot verify External Interrupt Enable Mask. |
| 114D | Cannot verify External Interrupt Request Register. |
| 114E | Failure while verifying operation of External Interrupt. |
| 114F | Cannot verify current privilege level after execution of gate way instruction. |
| 1150 | Failure while verifying timing on RF board. |
| 1151 | Failure while verifying EIRR with HPMC (EIRR bit get set on HPMC). |
| 11F0 through 11FE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

Troubleshooting

2. Class ERROR 1: Processor failure; Execution unit, error code = 14XX

| Error Numbers | Description of error condition |
|-------------------|---|
| 1400 | Undefined error occurred at start of test of this board. |
| 1401 | Data path through barrel shifter. |
| 1402 | Shift by 0, 1, 2, 4, 6, 8, 16, or 31 bits failed. |
| 1403 | Pattern test of 3/4 bit hardware boundaries failed. |
| 1404 | Pre-shift by 0 for MOVB failed. |
| 1405 | Extract sign/unsigned failed for some bit field. |
| 1406 | Failure of timing critical path of instruction mix MTCTL & VEXTRS. |
| 1407 | Failure while verifying shift amount register. |
| 1408 and 1409 | Reserved. |
| 140A | Arithmetic/Logical conditions failed. |
| 140B | Failure while testing unit conditions. |
| 140C | Failure while testing Extract/Logical conditions. |
| 140D ** | Failure while testing PSW C/B bit. Second possible cause of error is Register File. |
| 140E through 140F | Reserved. |
| 1410 | Failure while verifying condition on shift and add. |
| 1411 | Cannot verify shift one and add. |
| 1412 | Cannot verify shift two and add. |
| 1413 | Cannot verify shift three and add. |
| 1414 | Failure while verifying load byte short with odd. index |
| 1415 | Failure while verifying operation of PSWs C/B bits with Decimal Correct (DCOR) instruction. |
| 1416 | Failure while verifying PSWs C/B bit with logical shift operation (C/B gets updated). |
| 1417 | Cannot verify operation of logical add. |
| 1418 | Failure while verifying PSWs C/B bit with logical add operation (C/B gets updated). |

| | |
|-------------------|---|
| 1419 | Addition of two negative numbers caused overflow trap. |
| 1420 | Failure while verifying overflow conditions with logical ADD instruction. |
| 1421 | Failure while verifying overflow conditions with EXTRU logical instruction. |
| 1422 | Failure while verifying operation of extract signed instruction. |
| 141A | Cannot verify addition of two negative numbers. |
| 141B through 141F | Reserved. |
| 14F0 through 14FE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

3. Class **ERROR 1**: Processor failure; Instruction unit, error code = 15XX

| Error Numbers | Description of error condition |
|---------------|---|
| 1500 | Undefined error occurred at start of test of this board. |
| 1501 | Condition branch test failed. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1502 | Condition add with no overflow failed. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1503 | Odd condition failed. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1504 | Test unit true condition failed. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1505 | Test ext/dep true condition failed. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1506 and 1507 | Reserved. |
| 1508 | Branch and Link instruction cannot calculate return address. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |
| 1509 | Branch and Vector instruction cannot return to the given address. |
| ** | Second possible cause of error is E__unit. |
| ** | Third possible cause of error is Register File. |

Troubleshooting

| | |
|-------------------|--|
| 150A ** ** | Failure while verifying System mask portion of PSW. Second possible cause of error is E__unit. Third possible cause of error is Register File. |
| 150B ** | Failure while verifying Co_Processor Configuration register. Second possible cause of error is E__unit. |
| 150C ** | Failure while verifying Interruption Vector Address or PC Offset Queue. Second possible cause of error is E__unit. |
| 150D ** | Failure while verifying Interruption Processor Status word. Second possible cause of error is E__unit. |
| 510E ** | Failure while verifying operation of PCOQ. (cannot verify functionality of PSWs Q bit). Second possible cause of error is TLB. |
| 150F ** | I__unit cannot force trap. Second possible cause of error is Register File. |
| 1510 through 1515 | Reserved. |
| 1516 | PCOQ does not hold correct address after trap. |
| 15117 | IPSW does not get value of PSW after trap. |
| 1518 | IIR does not get value of instruction which cause trap. |
| 1519 | Failure while verifying forced Break Instruction trap. |
| 1520 | Failure while verifying forced Illegal Instruction trap. |
| 1521 | Failure while verifying forced Over Flow trap. |
| 1522 | Failure while verifying forced Conditional trap. |
| 1523 | Failure while verifying forced Branch Taken trap (cannot verify functionality of PSW'S T bit). |
| 1524 | Cannot verify functionality of PSWs B bit |
| 1525 | Cannot enable High Priority Machine Check with PSWs M bit. |
| 1526 | Cannot disable High Priority Machine Check with PSWs M bit. |
| 1527 | Cannot verify change of privilege with Branch External (BE) instruction. |
| 1528 | Cannot verify change of privilege with Branch and Link External (BLE) instruction. |
| 1529 | Cannot verify change of privilege with Branch Vector (BV) instruction. |

| | |
|-------------------|--|
| 152A | Failure while verifying functionality of Privilege Register trap. |
| 152B | Failure while verifying functionality of Privilege Operation trap. |
| 152C | Failure while verifying functionality of Lower Privilege Transfer trap. |
| 152D | Failure while verifying functionality of Higher Privilege Transfer trap. |
| 152C through 152F | Reserved. |
| 1531 | Unexpected High Priority Machine Check trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1532 | Unexpected low parity machine check trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1533 | Unexpected illegal instruction trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1534 | Unexpected break instruction trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1535 | Unexpected privileged operation trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1536 | Unexpected privileged register trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1537 | Unexpected overflow trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1538 | Unexpected condition trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 1539 | Unexpected assist emulation trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 153A | Unexpected privilege transfer trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |
| 153B | Unexpected low privilege transfer trap was taken. |
| ** | Second possible cause of error is Register File. |
| ** | Third possible cause of error is TLB. |

Troubleshooting

| | |
|-------------------|--|
| 153C ** ** | Unexpected Taken Branch Trap was taken. Second possible cause of error is Register File. Third possible cause of error is TLB. |
| 153D ** ** | Un-implemented trap was taken. Second possible cause of error is Register File. Third possible cause of error is TLB. |
| 1540 1541 | Failure while verifying TOC/soft reset. Unexpected HPMC was found during forced TOC/soft reset. |
| 1542 | Could not verify PCQ front after RFI with Q bit off. |
| 1543 | Could not verify Assist Emulation trap (or could not verify bit zero of CCR). |
| 1544 | Could not verify Co_Processor Configuration Register by forcing Assist Emulation trap. |
| 1545 | Could not verify overflow trap with ADDIO instruction. |
| 1546 | Unexpected overflow trap was taken when it should not. |
| 1547 | Could not verify index other than zero with BLR instruction. |
| 1548 | Could not verify index other than zero with BV instruction. |
| 1549 | Could not verify System Mask (of PSW) with MTSM instruction. |
| 154A through 154D | Reserved. |
| 154E | Could not verify functionality of PSWs N bit (N bit does not get set for nullified instruction when taken branch trap is taken). |
| 154F | Could not verify functionality of PSWs N bit (When N bit is set RFI target does not get nullified). |
| 1550 | Reserved. |
| 1551 | Could not verify functionality of PSWs X bit (Cannot prevent Data memory break trap by setting X bit). |
| 1552 | Failure while verifying PSWs V bit (could not verify remainder of divide step). |
| 1553 | Failure while verifying PSWs C bit. |
| 1554 | Failure while verifying IPSW in virtual mode. |
| 1555 | Failure while verifying PCQ in high virtual address. |
| 1556 | Failure while verifying small displacement in high virtual address. |
| 1557 | Failure while verifying PSW when HPMC was forced by TLB parity error. |

- 1558 Could not force HPMC in virtual mode.
- 1559 Failure while verifying IPSW in virtual mode.
- 15F0 through 15FE High Priority Machine Check (Refer to list 19 for detailed error messages.)

4. Class ERROR 2: Translation Lookaside Buffer/Cache failure; (TLB), error code = 26XX

| Error Numbers | Description of error condition |
|----------------------|---|
| 2600 | Undefined error occurred at start of test of this board. |
| 2601 | Failure while verifying Read and Write operation on Space registers via Space ID. |
| 2602 | Failure while verifying Read and Write operation on Space registers via MTSP. |
| 2603 | Reserved. |
| 2604 | Failure while verifying Read or Write access to a page with proper protection and access right. |
| ** | Second possible cause of error is Cache. |
| 2605 | Failure while verifying operation of Write Disable bit. |
| ** | Second possible cause of error is Cache. |
| 2606 | Failure while verifying operation of Public Access. |
| ** | Second possible cause of error is Cache. |
| 2607 | Failure while verifying operation of PSW P__bit. |
| ** | Second possible cause of error is Cache. |
| ** | Third possible cause of error is I__unit. |
| 2608 | Failure while verifying operation of Data TLB miss. trap |
| ** | Second possible cause of error is I__unit. |
| 2609 | Failure while verifying operation of Non__Access Data TLB miss trap. |
| ** | Second possible cause of error is I__unit. |
| 260A | Failure while verifying operation of Debug trap. |
| ** | Second possible cause of error is I__unit. |
| 260B | Failure while verifying operation of Dirty bit trap. |
| ** | Second possible cause of error is I__unit. |
| 260C | Failure while verifying operation of Virtual I/O trap. |
| ** | Second possible cause of error is I__unit P. |
| 260D | Failure while verifying Physical Page Number Rams. |

Troubleshooting

| | |
|-------------------|--|
| 260E through 260F | Reserved. |
| 2610 ** | Lower privilege trap not taken. Second possible cause of error is I__unit. |
| 2611 | Failure while verifying data path through PIDs. |
| 2612 | Failure while verifying data path through PCSQ. |
| 2613 | Second possible cause of error is Cache. |
| 2614 ** | Failure while verifying Physical Address Generation or Physical Page Number Ram. Second possible cause of error is Cache. |
| 2615 ** | Failure while verifying Read and Write with virtual address. Second possible cause of error is Cache. |
| 2616 ** ** | Gate way instruction does not promote privilege to zero in a real mode. Second possible cause of error is I__unit. Third possible cause of error is Register File. |
| 2617 | Reserved. |
| 2618 ** ** | Failure while verifying privilege level generation with gate way instruction for page types 2 or 3. Second possible cause of error is I__unit. Third possible cause of error is Register File. |
| 2619 ** ** | Failure while verifying privilege level generation with gate way instruction for page types 4, 5, 6, or 7 Second possible cause of error is I__unit. Third possible cause of error is Register File. |
| 261A ** ** | Gate way instruction does not promote privilege to zero in a virtual mode. Second possible cause of error is I__unit. Third possible cause of error is Register File. |
| 261B ** | Failure while verifying execution of gate way instruction in delay slot of branch (No trap was generated.) Second possible cause of error is I__unit. |
| 261C ** | Failure while verifying generation of Data Memory Protection trap. Second possible cause of error is I__unit P. |
| 261D ** | Failure while verifying generation of Instruction Memory Protection trap. Second possible cause of error is I__unit. |
| 261E through 261F | Reserved. |
| 2620 | Failure while verifying operation of ISR. |
| 2621 | Failure while verifying operation of IOR. |



| | |
|---------------|--|
| 2622 | Failure while verifying Parity generator and parity checking on D_TLB physical page Number RAMs. |
| ** | Second possible cause of error is I__unit. |
| 2623 | Failure while verifying parity generator and parity checking on I_TLB Physical Page Number RAMs. |
| ** | Second possible cause of error is I__unit. |
| 2624 and 2625 | Reserved. |
| 2626 | Failure while verifying memory protection trap with byte access. |
| 2627 | Failure while verifying memory protection trap with half word access. |
| 2628 | Failure while verifying memory protection trap with word access. |
| 2629 | Failure while verifying Instruction TLB miss fault. |
| 262A | Could not force data TLB miss fault. |
| 262B | Cannot verify Protection ID, Access ID. |
| 262C | Cannot verify Public Pages. |
| 262D | Cannot distinguish between I__CA and D__CA via diagnostic register |
| 262E | Failure while verifying two cycle opcode instruction (Cannot verify TLB FREZ). |
| 262F | Reserved. |
| 2640 | Cannot verify TLB indexing through its rams. |
| 2631 | Unexpected instruction TLB miss fault was taken. |
| ** | Second possible cause of error is I__unit. |
| 2632 | Unexpected instruction memory protection trap was taken. |
| ** | Second possible cause of error is I__unit. |
| 2633 | Unexpected data TLB miss trap was taken. |
| ** | Second possible cause of error is I__unit. |
| 2634 | Unexpected non__access instruction TLB miss trap was taken. |
| ** | Second possible cause of error is I__unit. |
| 2635 | Unexpected non__access data TLB miss trap was taken. |
| ** | Second possible cause of error is I__unit. |
| 2636 | Unexpected data memory protection trap was taken. |
| ** | Second possible cause of error is I__unit. |
| 2637 | Unexpected data memory break trap was taken. |
| ** | Second possible cause of error is I__unit. |

Troubleshooting

- 2638 Unexpected TLB dirty bit fault was taken.
** Second possible cause of error is I__unit.
- 2639 Unexpected virtual device reference trap was taken.
** Second possible cause of error is I__unit
- 26F0 through 26FE High Priority Machine Check (Refer to list 19 for detailed error messages.)

5. Class ERROR 2: Translation Lookaside Buffer/Cache failure; (Cache), error code = 27XX

| Error Numbers | Description of error condition |
|------------------|--|
| 2700 | Undefined error occurred at start of test of this board. |
| 2701 | Failure while verifying Read/Write protocol in the first and last set of D__cache RAM. |
| 2702 | Reserved. |
| 2703 ** ** | Failure while verifying Read or Write operation (address test) on Data Cache. Second possible cause of error is memory. Third possible cause of error is TLB. |
| 2704 ** | Failure while verifying Read or Write operation (data path test) on Data Cache. Second possible cause of error is memory. |
| 2705 ** ** | Failure while verifying half word or byte operation on D__Cache. Second possible cause of error is Register File. Third possible cause of error is memory. |
| 2706 ** | D__Cache cannot set EIR bits. Second possible cause of error is Register File. |
| 2707 ** ** | Failure while verifying operation of D__Cache Dirty bit, MISS, or flush. Second possible cause of error is Register File. Third possible cause of error is memory. |
| 2708 ** | Failure while verifying operation of D__Cache load word with clean miss. Second possible cause of error is memory. |
| 2709 | Reserved. |
| 270A ** | Failure while verifying parity error generator on byte zero. Second possible cause of error is memory. |
| 270B ** | Failure while verifying parity error generator on byte 1. Second possible cause of error is memory. |
| 270C ** | Failure while verifying Parity error generator on byte 2. Second possible cause of error is memory. |

| | |
|-------------------|---|
| 270D ** | Failure while verifying parity error generator on byte 3. Second possible cause of error is memory. |
| 270E | Reserved. |
| 270F | Stuck bit on CA diagnostic register. |
| 2710 ** | Failure while verifying data path on the Instruction Cache. Second possible cause of error is E unit. |
| 2711 through 2714 | Reserved. |
| 2715 ** | Size of I__CA and D__CA do not match (Check revision of E unit). Second possible cause of error is E unit. |
| 2716 | Cache line gets updated on data TLB MISS fault. |
| 2717 | Memory line get updated on data TLB MISS fault. |
| 2718 | Failure while verifying byte transaction with data cache MISS. |
| 2719 | Failure while verifying half word transaction with data cache MISS. |
| 271A | Failure while verifying parity checking/generator with EIRR/CMD. |
| 271B | Cache line gets updated on TLB data trap. |
| 271C | Memory gets updated on TLB data trap. |
| 1E and 1F | Reserved. |
| 2720 | Failure while verifying Cache tag parity error. |
| 2721 | Failure while verifying EIRR/CMD with its address. |
| 2722 | Failure while verifying soft reset with its address. |
| 2723 | Failure while verifying operation of LDCWS instruction. |
| 2724 | Failure while verifying semaphore in load word and clear. |
| 2725 | Failure while verifying operation of Cache MISS. |
| 2726 | Failure while verifying operation of Cache FREZ. |
| 27F0 through 27FE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

Troubleshooting

6. Class **ERROR 3**: Processor Dependent Hardware failure; error code = 3ZXX, Z = Slot Dependent Value (System Monitor Card 30)

| Error Numbers | Description of error condition |
|----------------------|--|
| 3Z00 | Undefined error occurred at start of test of this board. |
| 3Z01 | Data error while verifying byte 30 of NVM |
| 3Z02 | GR0 was found to be not zero in Transfer of Control (TOC). |
| 3Z03 ** | Invalid return address for Transfer of Control (TOC). Second possible cause of error is memory. |
| 3Z04 through 3Z06 | Reserved. |
| 3Z07 | Could not read PDC PROM, no PDC PROM installed. |
| 3Z08 | Could not find second part of selftest in PDC PROM, no PROM installed. |
| 3Z09 | Could not find PDC code in PDC PROM check PDC PROM. |
| 3Z0A | Cannot initialize memory with Switch 3 Open. |
| 3Z0B | GR0 was found to be not zero at TOC or HPMC save state routine. |
| 3Z0C | Undefined error message was found for HPMC in HPMC save state routine. |
| 3Z0D | Could not verify Checksum while down loading code from E_PROM on System Monitor Card. |
| 3Z0E | Selftest completed with WARNING. |
| 3Z0F | Selftest completed successfully. |
| 3Z10 through 3Z20 | Reserved. |
| 3Z21 | Warning: Failure while verifying stable storage. |
| 3Z22 | Warning: Failure while reading from stable storage. |
| 3Z23 through 3Z27 | Reserved for PDC/IODC code. |
| 3Z28 | Warning: Failure while reading from time of day clock. |
| 3ZF0 through 3ZFE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

7. Class **ERROR 4**: Co__Processor failure; error code = 4ZXX, Z = Slot Dependent value.

| Error Numbers | Description of error condition |
|---------------|---|
| 4Z00 | Possible problem with FP.DMAWR+, FP.STATUS+, FP.ABORT+, FP.FRINH, C.MSR.CLK+, C.8MHZB-, C2.CPLD.VLD-, or any of UIW+[0:31]. A number of other problems are possible since this error code indicates that the coprocessor is frozen. |
| 4Z01 | Undefined. |
| 4Z02 | A single load followed by a single store with no intervening I-cache miss is executed. This checks FP.RREG.2B-, C.RREG.CLK+, FP.DMAWR+, FP.LSFREEZE+, FP.XREG.2B-, C.XREG.CLK+, FP.IFRZ+, and C1.CPIFREEZE-. |
| 4Z03 | A double load is done followed by a double store, checking to see that the lower word returns correctly. This tests FP.DMALO+ and FP.RAMADR+[7]. |
| 4Z04 | A floating point operation is executed followed by a sufficient number of non-floating point instructions insure that the floating point operation is to completed. A single precision store is then performed to check the result. This tests FP.NFLOP+, the FLOP state, FP.MMB.DLY+, FP.FIR.CLK.4B-, FP.MAPEN+, the FIR register, and part U0504 (the mapper ROM), as well as logic controlling the math chips and microcode exception conditions. This code also occurs with a number of other problems. |
| 4Z05 | A floating point compare operation that sets the C-bit is executed. This is followed by an FTEST instruction that checks whether the C-bit has indeed been set. This tests FP.FREEZE.X+, C2.CP1.NULL-, FP.FBUSY+, FP.FINHIBIT-, and FP.TINHIBIT- as well as compare logic. |
| 4Z06 | A load of the status register is attempted from an I/O address. This should abort. This tests FP.ABORT+, FP.BAILOUT+, FP.STATUS+, and LSPH (internal to PAL). |
| 4Z07 | A coprocessor load is executed immediately followed by a floating point operation that uses the load data. This tests FP.LSBUSY+ and FP.LSB.DLY (internal to PAL). |
| 4Z08 | A floating point operation that causes a trapping exception is executed immediately followed by a coprocessor store with t-register conflict. The store should be delayed until the trap completes and thus should reflect the result of the trap. This tests FP.FRZTRP.C+, the t comparator, FP.CONFLICT.2B+, FP.CONFLICT+, FP.NIR-[22], FP.TVLD-, C2.TRAPASSIST1-, FP.TINHIBIT-, and FP.TRAP.X+ as well as microcode exception conditions. |
| 4Z09 | An unanticipated trap occurs possibly caused by failure of the r1 comparator or trap logic. |

Troubleshooting

| | |
|------|--|
| 4Z0A | Bit-14 in GR[28] is set. An invalid operand is put in a given register and a floating point operation is attempted with r2 set to that register. This operation is immediately followed by a coprocessor load of a valid operand to r2. The test then checks bit 14 in GR[28]; it should be clear. The attempted operation results in an exception trap if the load is delayed by the r2 conflict comparator properly, and the trap handler clears GR[28]. This test therefore checks the r2 conflict comparator for proper operation. |
| 4Z0B | A coprocessor load of a non-zero number to FPR[0] (the status register) is executed. Then a floating point operation with FPR[0] (zero for floating point operations) as an operand is executed. This test then ascertains that the floating point operation reflects an operand of zero. This checks FP.LSIR+[1] and FP.RAMADR+[1]. |
| 4Z0C | A floating point compare instruction that generates an exception is executed. This is followed immediately by a coprocessor load that has a destination field identical to the condition field in the compare instruction. This is followed immediately by a coprocessor double store of FPR[0]. The double store should find the T-bit set since the load should be completed by the time that the compare determines that a trap is necessary. If the load is frozen (an error), the trap will occur clearing the T-bit before the load. This tests FP.TVLD-. |
| 4Z0D | A floating point operation with a zero t-field is executed followed by a coprocessor store of the status register. The status register is checked to assure that it has not been affected by the floating point operation. This tests FP.TOK- and FP.RAMADR+[0]. |
| 4Z0E | A coprocessor load to a reserved register is attempted. This should cause a reserved operation trap. This tests FP.RESERVED+. |
| 4Z0F | A coprocessor load from an I/O address is attempted. This load should abort. This tests FP.STATUS+ and FP.ABORT+. |
| 4Z31 | Test results in unexpected assist exception trap, which could be caused by a number of problems in the system, possibly resulting from a test of the conflict comparator. In this test a floating point operation is executed immediately followed by a coprocessor load with an r1 conflict, i.e. a load the destination field of which is the same as the r1 field of the floating point operation. The result of the floating point operation is checked to ascertain that it reflects the original r1 data. This tests the function of the r1 comparator. This error code can also reflect a malfunction of one or more of the math chips. |
| 4Z42 | Test of ALUZERO condition fails. |
| 4Z43 | Test of ALUZERO condition fails. |
| 4Z44 | Test of ALUSIGN condition fails. |
| 4Z45 | Test of XOR in ALU fails. |

| | |
|------|---|
| 4Z46 | Test of AND in ALU fails. |
| 4Z47 | Test of OR in ALU fails. |
| 4Z48 | Test of load to status register fails. |
| 4Z49 | Test of instruction register fails. |
| 4Z62 | Failure of multiply chip U2302 detected. |
| 4Z64 | Failure of add chip U2104 detected. |
| 4Z65 | Failure of divide chip U2305 detected. |
| 4Z80 | Failure in nullify generation circuitry detected. |
| 4Z86 | Possible failure of RAM6, U1101 detected by microcode. |
| 4Z90 | Possible failure of RAM7, U1301 detected by microcode. |
| 4Z91 | Possible failure of RAM2, U1302 detected by microcode. |
| 4Z92 | Possible failure of RAM3, U1303 detected by microcode. |
| 4Z95 | Possible failure of RAM5, U1401 detected by microcode. |
| 4Z96 | Possible failure of RAM1, U1402 detected by microcode. |
| 4Z97 | Possible failure of RAM4, U1403 detected by microcode. |
| 4Z98 | Possible failure of RAM0, U1404 detected by microcode. |
| 4ZC0 | Possible failure of RAM0, U1404 detected by macrocode. |
| 4ZC1 | Possible failure of RAM1, U1402 detected by macrocode. |
| 4ZC2 | Possible failure of RAM2, U1302 detected by macrocode. |
| 4ZC3 | Possible failure of RAM3, U1303 detected by macrocode. |
| 4ZC4 | Possible failure of RAM4, U1403 detected by macrocode. |
| 4ZC5 | Possible failure of RAM5, U1401 detected by macrocode. |
| 4ZC6 | Possible failure of RAM6, U1101 detected by macrocode. |
| 4ZC7 | Possible failure of RAM7, U1301 detected by macrocode. |
| 4ZCA | Error detected during a series of arbitrary microcoded calculations. Possible cause: mapper PROM or math chips. |
| 4ZCC | Error detected which slows the execution of the Floating Point Unit. |

Troubleshooting

4ZF0 through 4ZFE High Priority Machine Check (Refer to list 19 for detailed error messages.)

8. Class ERROR 5: Bus Protocol failure; error code = SZXX, Z = Slot dependent value.

| Error Numbers | Description of error condition |
|---------------|---|
| SZ00 | Undefined error occurred at the start of this test. |

9. Class ERROR 6: Architecturally Reserved (6XXX)

10. Class ERROR 7: Memory failure; error code = 7ZXX, Z = Slot Dependent value.

| Error Numbers | Description of error condition |
|-------------------|---|
| 7Z00 | Undefined error occurred at start of test of this board. |
| 7Z01 | Stuck bit in I/O status register or couldn't find four contiguous words without single bit error within the first 256Kb. |
| 7Z02 ** ** | Failure while verifying memory with its address. Second possible cause of error is Cache. Third possible cause of error is TLB. |
| 7Z03 ** ** | Failure while pattern testing memory. Second possible cause of error is Cache. Third possible cause of error is TLB. |
| 7Z04 ** | Multiple bit flag was set with single bit error. Second possible cause of error is Cache. |
| 7Z05 ** | Multiple bit flag does not get set with multiple bit error. Second possible cause of error is Cache. |
| 7Z06 ** | MC cannot calculate address of faulty memory. Second possible cause of error is Cache. |
| 7Z07 ** | Single bit error was found. Second possible cause of error is Cache. |
| 7Z08 through 7Z09 | Reserved. |
| 7Z0A ** | Parity checking/generator not working. Second possible cause of error is Cache. |
| 7Z0B ** | Failure while verifying Read and Write protocol. Second possible cause of error is Cache. |
| 7Z0C ** | Failure while verifying Read and Clear protocol. Second possible cause of error is Cache. |

| | |
|-------------------|---|
| 7Z0D through 7Z0F | Reserved. |
| 7Z10 | Undefined type of memory controller was found. |
| 7Z11 | 32Mb memory controller must be installed first, HOLE is not allowed in the memory. |
| 7Z12 | Last 32Mb memory controller does not have memory array. |
| 7Z13 | Last 8Mb (3Mb MC & 5Mb MA) memory controller does not have memory array installed. |
| 7Z2F ** | During memory initialization no memory board was found. Second possible cause of error is Cache. |
| 7Z50 | During initialization no memory controller was found in slot 13. |
| 7Z51 through 5F | Reserved for initialization. |
| 7ZF0 through 7ZFE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

NOTE

Memory test takes approximately 1.5 seconds per Megabyte of memory.

11. Class ERROR 8: I/O Channel Adapter Test; error code = 8ZXX, Z = Slot Dependent value

| Error Number | Description of error condition |
|---------------------|---|
| 8Z00 | Undefined error occurred at start of test of this board. |
| 8Z01 | Cannot enable Soft Physical Address (cannot set the SSET bit). |
| 8Z02 | Cannot disable Soft Physical Address (cannot reset the SSET bit to zero). |
| 8Z03 | Cannot verify memory with its address. |
| 8Z04 | Cannot verify memory with sliding ones. |
| 8Z05 | Cannot verify memory with sliding zeros. |
| 8Z06 | Cannot verify memory with all zeros. |
| 8Z07 | Failure while pattern testing EIEM register. |
| 8Z08 | Cannot set Interrupt register to zero. |
| 8Z09 | Failure while pattern-testing Interrupt register. |

Troubleshooting

| | |
|-------------------|---|
| 8Z0A | Failure while pattern testing Chain_Ram_Base register |
| 8Z0B | Failure while pattern testing Mask register. |
| 8Z0C and 8Z0D | Reserved. |
| 8Z0E | Failure while pattern testing Reset Address register. |
| 8Z0F | Failure while pattern testing Reset Data register. |
| 8Z10 | Reset does not clear SPA. |
| 8Z11 | No installed CIO card was found, or none of CIO cards pass Selftest and ready for command. |
| 8Z12 | Stop Command does not set the RDY bit. |
| 8Z13 | Chain Command does not clear RDY bit. |
| 8Z14 | Cannot get interrupt at end of DMA (Appropriate bit in sub_mask register does not get reset). |
| 8Z15 | DMA does not transfer any data. |
| 8Z16 | RDY bit does not get set at end of DMA. |
| 8Z17 | Wrong status was returned from CIO card after disconnecting subchannel. |
| 8Z18 | Undefined error was found with CIO card (RFC, PST, PRE or LEV did not match). |
| 8Z19 | Reserved. |
| 8Z1A | Data write error on HP-IB loopback (status error). |
| 8Z17 through 8Z10 | Reserved. |
| 8Z1A | Data write status error was reported on HP-IB loopback test. |
| 8Z1B | HP-IB card does not get ready for command. |
| 8Z1C | Undefined status error was reported on HP-IB loopback test. |
| 8Z1D | Data error on HP-IB loopback test. |
| 18ZE | Channel does not request attention after disconnecting subchannel. |
| 8Z1F | Reserved. |
| 8Z20 | Cannot verify link to previous link status block. |
| 8Z21 | Status error while verifying link status quad (reserved for now). |

| | |
|-------------------|---|
| 8Z22 | Cannot verify link to last data quad. |
| 8Z23 | Cannot verify counter within the DMA chain quad. |
| 8Z24 | Reserved. |
| 8Z25 | Failure while verifying operation of channel with semaphore set to zero. |
| 8Z26 | Undefined error, could not find any installed memory board. |
| 8Z27 | Failure while verifying operation of channel with semaphore set to one after being zero for a while. |
| 8Z28 | Failure while verifying parity checking operation. |
| 8Z29 | Failure while verifying functionality of ME bit on channel adapter status register for data parity errors. Channel does not set ME bit on data parity errors. |
| 8Z2A | Channel cannot identify a data parity error (wrong MSTAT on data parity error). |
| 8Z2B | Failure while verifying functionality of ME bit on channel adapter status register for address parity errors. Channel does not set ME bit on address parity errors. |
| 8Z2C | Channel cannot identify an address parity error (wrong MSTAT on address parity error) |
| 8Z2D through 8Z2E | Reserved. |
| 8Z2F | No midbus I/O card was found. |
| 8Z30 through 8Z3F | Reserved for unexpected trap errors. |
| 8Z40 | Channel cannot finish log channel transaction (no interrupt at end of log channel transaction) |
| 8Z41 | Log channel status error. Transaction requires device adapter to be system controller and it is not. Check HP-IB card switch setting. |
| 8Z42 | Undefined log channel status error. |
| 8Z43 | Bad status was returned at end of HP-IB loopback test with log channel. |
| 8Z43 | Bad status was returned from HP-IB loopback test at the end of log channel. |
| 8Z44 | Subchannel does not come ready after log channel operation. |
| 8Z45 | Subchannel does not come ready after attention request enable followed by attention request operation. |

Troubleshooting

| | |
|-------------------|---|
| 8Z46 | Wrong status was return from I/O card after ARQ. |
| 8Z47 | Correct bit does not get set in ARQ register. |
| 8Z48 | ARQ bit was found to be set before ARQ test (unknown error). |
| 8Z49 | Subchannel does not request attention after enabling attention request and request attention (write control of ARE and ARG). |
| 8Z4A through 8Z4E | Reserved. |
| 8Z4F | Warning: Channel cannot complete its test without HP-IB card |
| 8ZF0 through 8ZFE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

NOTE

Channel Adapter is about a 5 second duration.

12. Class ERROR 9: Console path test; error code = 9XXX. This error is a multiplexed error, refer to table 4-5 for a definition.

| Error Numbers | Description of error condition |
|---------------|--|
| 01WX 9YZZ | Console path related error or CIO error. W = CIO slot number. X = device address (always 0 for console). Y = CIO channel Mid-bus slot number. ZZ = IODC driver error code (00 - 7F). |
| 0100 9Y80 | IODC load from CIO channel in console path fail. Y = CIO channel Mid-bus slot number. |
| 0100 9Y88 | (Fault) No working console found, autoboot disabled. Y = CIO channel Mid-bus slot number. |
| 01C0 9YZZ | (WARNING) Access Port selftest failure. Y = CIO channel Mid-bus slot number. ZZ = Access Port selftest code (00 - 7F). |
| 01C0 9YF0 | (WARNING) Access Port read of hex display failed. Y = CIO channel Mid-bus slot number. |
| 01C0 9YFF | (WARNING) no Access Port found. Y = CIO channel Mid-bus slot number. |

13. Class ERROR A: Boot path test; error code = AXXX. This error is a multiplexed error, refer to table 4-5 for a definition.

| Error Numbers | Description of error condition |
|---------------|---|
| 01WX AYZZ | Boot path related error and/or CIO error. W = CIO slot number. X = Device address (always 0 for console). Y = CIO Channel Mid-bus slot number. ZZ = IODC driver error code (00 - 7F). |
| 0100 AY80 | (WARNING) IODC load from CIO channel in boot path failed. |
| 01WX AYF0 | (WARNING) LIF volume label error (media may have been improperly initialized). |
| 01WX AYF8 | IPL checksum failed. |

14. Class ERROR CX: Boot path display code; error/information code = CXXX.

| Error Numbers | Description of error condition |
|---------------|--|
| C20X | Informational: First memory controller initialization. X = 1st memory controller Mid-bus slot number. |
| C201 | (Fault) No memory controller found. |
| C40X | Informational: Primary console path initialization. X = CIO Channel Mid-bus slot number. |
| C54X | Informational: Primary boot path initialization. X = CIO Channel Mid-bus slot number. |
| C58X | Informational: Primary boot path I/O. X = CIO Channel Mid-bus slot number. |
| C5FF | Informational: Launch IPL that was read from primary boot path. X = CIO Channel Mid-bus slot number. |
| C60X | Informational: Alternate (hard wired) console path initialization. X = CIO Channel Mid-bus slot number. |
| C74X | Informational: Alternate boot path initialization. X = CIO Channel Mid-bus slot number. |
| C78X | Informational: Alternate boot path I/O. X = CIO Channel Mid-bus slot number. |
| C7FF | Informational: Launch IPL that was read from alternate boot path. X = CIO Channel Mid-bus slot number. |

Troubleshooting

15. Class **ERROR CA**: Initialization; Power Fail, error code = CAXX

| Error Numbers | Description of error condition |
|-------------------|---|
| CAF0 through CAFE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

16. Class **ERROR CB**: initialization; Transfer of control, error code = CBXX

| Error Numbers | Description of error condition |
|-------------------|---|
| CB01 | GR0 was not zero. |
| CBF0 through CBF6 | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

17. Class **ERROR CE**: Initialization; ISL Code, error/information code = CEXX

| Error Number | Description of error condition |
|--------------|--|
| CE00 | ISL is executing. |
| CE01 | ISL is autobooting from the autoexecute file. |
| CE02 | Cannot find an autoexecute file. Autoboot abort. |
| CE03 | No system console found, ISL can only autoboot. |
| CE05 | Directory size is too big, ISL reads only 2K bytes. |
| CE06 | Autoexecute file in inconsistent. Autoboot aborted. |
| CE07 | Utility file header inconsistent. SOM values invalid. |
| CE08 | Autoexecute file input string exceeds 2048 characters. Autoboot aborted. |
| CE09 | ISL command or utility name exceeds 10 characters. |
| CE0F | ISL has transferred control to utility. |
| CE10 | Error detected in reading volume label - FATAL! |
| CE11 | Error detected in reading directory - FATAL! |
| CE12 | Error reading auto-file goes interactive. |
| CE13 | Error reading from system console. |
| CE14 | Error writing to system console. |
| CE15 | Not an ISL command or utility in ISL directory. |

| | |
|-------------------|---|
| CE16 | System ID was not Precision Architecture ID. |
| CE17 | Error reading in SOM header. |
| CE18 | Bad magic number in SOM header. |
| CE19 | Utility would overlay ISL in memory. |
| CE1A | Utility needs more memory than is configured. |
| CE1B | Error in reading utility into memory. |
| CE1C | Checksum was not correct after reading utility into memory. |
| CE1D | User input or autoboot input greater than 2Kb. |
| CE1E | Unknown or NULL boot device class. |
| CE21 | Destination address is invalid. |
| CE22 | Error calling PDC__cache entry. |
| CE23 | Error reading IO DC__entry__init to memory. |
| CE24 | Error in IO DC__entry__init for console. |
| CE25 | Error in IO DC__entry__init for boot device. |
| CE26 | Bad aux__id in SOM auxiliary header. |
| CE27 | Utility file type not an IPL file type. |
| CEFO through CEFE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

FFFF NO ERROR--Utility launched.

18. Loader ERROR: Parallel Card; error code = 005X

| Error Numbers | Description of error condition |
|----------------------|---|
| 005B | Leftover word in parallel card buffer when it should have been empty. |
| 005C | Word alignment problem in command address. |
| 005D | Unknown hardware problem in parallel card. |
| 005E | Unrecognized command. |
| 005F | Parallel card in bad state. |
| 00F0 through 00FE | High Priority Machine Check (Refer to list 19 for detailed error messages.) |

Troubleshooting

19. High Priority Machine Check - detailed error messages; (error codes = XXF0 through XXFF)

| Error Numbers | Description of error condition |
|-------------------|---|
| XXF1 | Instruction TLB parity error (I-Unit). |
| XXF2 | Data TLB parity error (I-Unit). |
| XXF3 | Mid-bus address parity error or no slave response. The cache is the master and either the slave detects bad parity on the address cycle or a slave never responds to the address (does not assert word_slave). |
| XXF4 | Mid-bus read data parity error. The cache is the master and is performing a read transaction and detects bad parity from the slave. |
| XXF5 | Multiple bit Read error. The cache is the master and is performing a Read transaction and the slave pulls error. This is a possible multiple bit memory error, or a slave checking its own data and finding a parity error. |
| XXF6 | Mid-bus Write data parity error. The cache is the master and is performing a Write transaction and the slave detects bad parity and pulls error. |
| XXF7 | Mid-bus CMD/EIR data parity error/Mid-bus timeout. The cache is the slave and detects bad parity on a WRITE 4 to its command register or EIR register; or the cache detects a Mid-bus timeout error. A timeout error is one of the following: <ul style="list-style-type: none">- cache detects master asserted for 8 cycles without an address valid cycle- master asserted for 60 cycles.- read_write asserted for 60 cycles. |
| XXF8 | Cache tag parity error. |
| XXF9 | Data cache Read parity error (RAMs internal to cache, not on Mid-bus). |
| XXFA | Floating Point HPMC. |
| XXFB | Instruction parity error (I-Unit). |
| XXFC through XXFF | Undefined HPMC. |

NOTE

This is an attempt to further define HPMCs. Its accuracy is not guaranteed. If more than one error occurred, only the smallest error number is displayed (if error F4 and F7 occurred, only F4 is displayed on Hex display).

HP-UX System Display Codes

| Error Numbers | Description of error conditions |
|---------------|---|
| B00X | System Panic. |
| B000 | Panic Begun. |
| B009 | Panic dump completed (discs not fully synchronized). |
| B00A | Panic dump completed (discs fully synchronized). |
| FXFF | System Running. An F in the first, third, and fourth digits implies the system is running normally. The X, second digit, is updated every 5 seconds with the length of the run queue at that time (an instantaneous reading, NOT an average). Loads higher than 9, display as an A. The Range is 0 to 100%, in increments of 10%. |

MPE-XL System Display Codes

When the system halts, the reason for the halt can be seen on the SPU Control Panel Status Display (refer to the Hex display in Figure 4-3). The first number is the source of the halt call, and following it are numbers of the form **Onxx** where **n** is a number that starts at 1 and increments. The reason can be interpreted by stringing the **xx** values together to form a number. When the monitor is the source of the halt, the first number is B000 (System Abort uses B007).

Examples:


B000 Monitor Halt 00F3 (same as selftest XXF3)
 01F3
 DNZZ

B000 Monitor Halt 008F (data page fault without RDB, MPE-XL not ready.)
 018F
 DNZZ


B007 SYSTEM ABORT 0003
 0103
 DNZZ

B007 SYSTEM__ABORT 0315 (Hex)
 0103
 0215
 DNZZ
 DEAD


Multiplexed Display, first number displayed:



Following numbers displayed:



Last number displayed:



Troubleshooting

| Error Numbers | Description of error condition |
|-------------------|---|
| 0001 through 0019 | The breaker handler to (RDB) was re-entered. The last two digits are the hex number from Section 5 of the processor ACD. |
| 0020 | A breaker 0 instruction was encountered without RDB. |
| 0021 | An unknown HPMC happened. |
| 0022 | A non-recoverable LPMC happened. |
| 0028 | Reinit__idoc failed to read entry__init. |
| 0029 | Reinit__idoc failed to read entry__io |
| 0030 | Image larger than first memory controller. |
| 003E | a non-recoverable branch taken or break trap occurred. |
| 003F | A bad instruction was received from RDB. |
| 0040 | A configured module was lost on power fail. |
| 0041 | A bus converter was lost on power fail. |
| 0042 | A bus converter was added on power fail. |
| 0043 | Memory was added on power fail. |
| 0044 | A module was added on power fail which generated an address conflict. |
| 0045 | Memory selftest failed in map__system__state. |
| 0046 through 004E | Error on call to entry__init in reinit__IODC (Error return number is 0050). |
| 005B through 005F | The parallel card driver (RDB communications) encountered something it didn't like. |
| 0066 through 006E | Error on call to entry__io in CONSOLE__READ or CONSOLE__WRITE (error return number is 0050). |
| 0080 through 0099 | A trap which neither RDB or MPE-XL was prepared for occurred. Number 0800 is the hex trap number from Section 5 of the processor ACD. |
| 00F1 | Non-recoverable instruction TLB error. |
| 00F2 | Non-recoverable data TLB error. |
| 00F3 | Non-recoverable bus address error. |
| 00F4 | Non-recoverable bus error on I/O space read. |
| 00F5 | Non-recoverable bus error on memory read or write. |
| 00F6 | Non-recoverable bus error on I/O space write. |
| 00F7 | Non-recoverable bus error with processor slave. |
| 00F8 | Non-recoverable cache tag error. |
| 00F9 | Non-recoverable data cache error. |
| 00FA | Non-recoverable assist coprocessor error. |
| 00FB | Non-recoverable instruction cache error. |

SPU TROUBLESHOOTING

The repair strategy of the System Processing Unit (SPU) is to identify and replace any failed Field Replaceable Unit (FRU). In most cases the FRU will be a Printed Circuit Assembly (PCA).

Minimum Hardware Configuration

To troubleshoot the SPU, the following minimum hardware configuration is required:

- CPU (IU, EU, RF, CA, TLB).
- At least one Memory Controller (MC).
- Mid-bus.
- Channel Adapter.
- CIO Bus.
- Verified Power System.
- System Control Panel.
- System Monitor.
- Access Port (AP) card and MUX (6-port) card connected to System Console through an RS-232C junction panel.
- System Disc Drive connected to CIO Bus through an HP-IB card.
- Magtape drive connected to CIO Bus through an HP-IB card.

Table 4-7. Minimum Hardware Configuration (9000/840S)

| QTY | Product number | Description |
|-----|----------------------------|--------------------------------|
| 1 | 9740A | SPU |
| 1 | 19748A | 8 MB Memory |
| 1 | 19744 | Channel set (3 cards each set) |
| 1 | 30192A | Access port |
| 1 | 19742A | Floating point coprocessor |
| 2 | 27110B | HP-IB device adapters * |
| 1 | 27140A | Console mux |
| 1 | 2392A | Console term |
| 1 | 7914, 7933 7935 or 7937 | Disc drive |
| 1 | 9144, 7974 or 7978 | Tape drive ** |

* If using a 7914A with a built in cartridge tape using a single controller, only 1 27110B device adapter is required.

** A tape drive is not required if using a 7914 with integrated cartridge tape.

Troubleshooting

Troubleshooting Procedures

Observe for proper operation of the following SPU hardware, firmware, and software elements:

- AC and DC power supply and distribution.
- Selftest operation.
- Access port operation.
- Initial System Load (ISL) prompt appearance.
- Operating System boot.
- Online diagnostic subsystem operation.

When a malfunction is encountered, replace the assembly indicated in the test procedures and SPU Internal Control Panel selftest code legend. Refer to Chapter 8 in the Hardware Support Manual, P/N 09740-90011 for additional information.

Computer malfunctions can be isolated to the assembly level by performing the following tests:

1. DC power supply check.
2. Selftest (refer to Table 4-6, Selftest Error Messages, and Section 5. For additional information, refer to Chapter 8 in the Hardware Support Manual, P/N 09740-90011).
3. Diagnostics (refer to Section 5 or the Online Diagnostics Subsystem Manual, P/N 09740-90020 for more detailed information).

DC Power Supply Check

Verify the power supply voltages by performing the following procedure. The voltage checks must be made with all plug-in cards installed in the computer.

WARNING

Hazardous voltages are present. Observe all warning labels on equipment to ensure safety of personnel. All maintenance/repair work must be done by qualified personnel.

The following is a procedure for checking power supply voltages:

1. Verify that the Main Power Breaker is OFF.
2. Connect power cord to a power outlet having the electrical characteristics specified on the rear of the computer.
3. Turn the Main Power Breaker to ON.
4. Verify that voltages and signals found at the test points on the System Monitor Module (see Figure 4-5) are as listed in Table 4-8 by using a digital voltmeter.
5. Replace power supply if the computer does not pass the DC Power Supply Check. Refer to Section 6 in this manual or the Hardware Support Manual, P/N 09740-90011, for removal/replacement procedures.

Power Fail Check

Check the power fail recovery system as follows:

1. Verify the computer is on and the operating system is functioning properly.
2. Press battery backup test switch, ensuring that the LED is lighted (located on the System Status Display Panel in the front of cabinet).
3. Turn OFF the Main Power Breaker, located on the rear of the cabinet.
4. Open the front door, ensuring the Battery Backup LED is still lighted.
5. Measure battery voltage by using the +10BATTERY and GND test points (See Figure 4-5). If voltage measures less than 9.5 volts after approximately 5 minutes, replace the backup battery by referring to Chapter 6 in the Hardware Support Manual, P/N 09740-90011.
6. Turn ON the Main Power Breaker.
7. Turn OFF the battery backup switch.

Troubleshooting

CAUTION

Ensure the battery backup switch is used for testing only. Leaving the switch on will cause the battery to discharge.

8. Ensure the system runs selftest and boots correctly.

PDU Strapping Verification

While performing power verification, the PDU strapping is verified by removing the power cord cover and unplugging the power cord for the fan tray (see Figure 6-1 for location). Measure for the nominal AC source voltage of 230V AC (+/- 5%). This AC voltage must be the same nominal range as the source voltage at the wall outlet (nominal 200V - 240V AC). If the voltage is not within the desired range, re-strap the PDU to accommodate the source voltage. See Figure 4-4 for verification of the PDU strapping.




Figure 4-4. PDU Transformer Strapping Diagram

NOTE

The PDU is strapped, RED jumper from 4 to 5, BLACK to 6, and WHITE to 1, at the factory.

POWER SUPPLY TROUBLESHOOTING

Power supply troubleshooting consists of removal and replacement. The two procedures (one for Power Supply #1 and another for Power Supply #2 and #3) are found in Section 6 .

Power supply and distribution problems that do occur can be checked for proper operation by following the Troubleshooting Flowcharts (see Figures 4-6 thru 4-11).




Figure 4-5. System Monitor Test Points

Table 4-8. Power Supply Voltage/Signal Test Points

| Voltage Status | Maximum Ripple (Volt) | Test Signal | DC Voltage Specification |
|---------------------------------|----------------------------------|---|---|
| Power Supply | | PON1, PON2, PON3 MB.PFW, MB.PON | 2.4V min. (logic 1) 2.4V min. (logic 1) |
| Lithium Battery | | +3V1, +3V2 | 2.5V minimum |
| Power Supplies (3) | 0.12V 0.12V 0.30V 0.10V | -12V PS1, -12V PS3 +12V PS1, +12V PS3 +28V PS2, +28V PS3 +5V PS1, +5V PS2, +5V PS3 | -10.56V to -13.44V 10.80V to 13.20V 22.4V to 33.6V 4.8V to 5.25V |
| Internal Battery | | +10V BATT | 8.4V to 11.90V |
| Secondary Power (Mid-bus slots) | 0.1V | +5VS1, +5VS2 (SM) | 4.8V to 5.25V |
| Ground | | Ground | |

NOTE

The above power supply test points are located on the System Monitor Card, P/N 09740-60905 (or 09740-69595, Exchange).

Troubleshooting

Table 4-9. Power Supply Voltage/Signal Test Table

| SM Test Point | DC Volt Spec | Max Ripple (volt) |
|---------------|------------------------|-------------------|
| PON1 | 2.4V min. (logic high) | |
| PON2 | 2.4V min. (logic high) | |
| PON3 | 2.4V min. (logic high) | |
| MB.PON | 2.4V min. (logic high) | |
| MB.PFW | 2.4V min. (logic high) | |
| +3V1 | 2.5V min. | |
| +3V2 | 2.5V min. | |
| -12VPS1 | -10.56V to -13.44V | 0.12V |
| +12VPS1 | 10.80V to 13.20V | 0.12V |
| +12VPS3 | 10.80V to 13.20V | 0.12V |
| -12VPS3 | -10.56V to -13.44V | 0.12V |
| +10BATTERY | 8.4V to 11.90V | |
| +5VPS1 | 4.8V to 5.25V | 0.10V |
| +5VPS2 | 4.8V to 5.25V | 0.10V |
| +5VPS3 | 4.8V to 5.25V | 0.10V |
| +5VS1 | 4.8V to 5.25V | 0.10V |
| +5VS2 | 4.8V to 5.25V | 0.10V |
| +28VPS3 | 22.4V to 33.6V | 0.3V |
| +28VPS2 | 22.4V to 33.6V | 0.3V |

If any of the DC voltages are out of specification, refer to the Hardware Support Manual for the appropriate troubleshooting or replacement procedure.

Selftest Switch Settings

Eight Dip switches (labeled Diagnostic Switch) located on the front of the System Monitor Module (see Figure 4-5) control the execution of selftest. Normal position for all switches is the CLOSED position.

Table 4-10. Selftest Switch Settings

| SWITCH NUMBER | CLOSED POSITION | OPEN POSITION |
|---------------|-----------------|--|
| 1 | Normal | Toggle switch to bypass error and execute the remainder of selftest; to boot system. |
| 2 | Normal | Continuous loop on selftest. |
| 3 | Normal | Soft Reset or Transfer of Control (TOC). |
| 4 | Normal | Detect single bit errors on memory. |
| 5 | Normal | Selftest will continue on nonfatal errors. Bypass I/O errors. |
| 6 | Normal | Reserved for future use. |
| 7 | Normal | Displays test sequence flow on the System Console. |
| 8 | Normal | Reserved for future use. |






Figure 4-6. Power System Troubleshooting Flowchart 1



LQ200004_034

Figure 4-7. Power System Troubleshooting Flowchart 2



LQ200004_035

Figure 4-8. Power System Troubleshooting Flowchart 3






Figure 4-9. Power System Troubleshooting Flowchart 4



LQ200004_037

Figure 4-10. Power System Troubleshooting Flowchart 5




LG200004_038

Figure 4-11. Power System Troubleshooting Flowchart 6


Selftest as a Troubleshooting Tool

The following flowcharts (Figures 4-12 thru 4-18) illustrate how to use Selftest as a troubleshooting tool. Figures 4-12 thru 4-15 reference selftest operation and Figures 4-16 thru 4-18 reference HPMC troubleshooting.



LG200004_039

Figure 4-12. Selftest Operation Flowchart 1



LG200004_040

Figure 4-13. Selftest Operation Flowchart 2






Figure 4-14. Selftest Operation Flowchart 3



LQ200004_042b

Figure 4-15. Selftest Operation Flowchart 4



LG200004_043a

Figure 4-16. HPMC Troubleshooting Flowchart 1





Figure 4-17. HPMC Troubleshooting Flowchart 2



LG200004_045

Figure 4-18. HPMC Troubleshooting Flowchart 3

ACCESS PORT SELFTEST AND TROUBLESHOOTING

Access Port (AP) Selftest checks the AP hardware with its associated cabling and connections. There are two primary ways of running AP selftest for troubleshooting purposes:

- Use the System Console.
- Use the frontplane of the AP PCA.

Additional information on AP Cable Test Hoods, verification of cable connections, and AP Selftest messages can be found in Chapter 8 of the Hardware Support Manual, P/N 09740-90011.

System Console Selftest

Invoke AP Selftest from the Access Port's command interpreter (CI) and use the following command:

```
CM> TA
```

Execution of AP Selftest through the AP CI is a full selftest. Results and test progress are printed on banners on the console display. Subtest codes appear successively on the ST_START_BANNER. If the test passes, the banner displays:

```
AP SELFTEST PASSED.
```

If the test fails, the banner displays:

```
AP SELFTEST FAILED SUBTEST XX (APERR 05).
```

XX is the code of the subtest that detected the failure. Refer to Table 4-9 to interpret any observed subtest results. Information for troubleshooting by port designation (see Figure 4-18) is found in Chapter 8 of the Hardware Support Manual, P/N 09740-90011.

AP Frontplane Selftest

The AP Selftest can be executed from the AP frontplane. This execution can be used when the System Console is not working well enough to report results of the test. The following is used in the execution of the AP Frontplane Selftest (see Figure 4-19 for the AP frontplane layout):

- A pushbutton switch (Selftest button).
- A display of eight LEDs.
- A test point pin labeled "LOOP".

Execution of the AP Frontplane Selftest is performed as follows:

1. The frontplane selftest button on the AP can be pressed (then released) at any time. The subtest codes are executed sequentially and displayed on the AP frontplane LEDs. When test hoods are present, they also are detected along with the associated circuitry.

Troubleshooting

2. The frontplane LEDs represent selftest in the following manner (TEST 0 and ST LED are the two upper LEDs that are not used as part of the Selftest display):
 - TEST 0 represents the LED Test. LEDs illuminate and extinguish.
 - ST LED represents selftest display mode and should be lit during Selftest execution.
 - LED 1, 2, 4, 8, 16, 32, and 64 display the number of the subtest being sequentially executed.
3. Selftest stops execution whenever a fault is discovered. The code of the failed subtest is displayed for 20 seconds. During this time, the CE should do the following:
 - a. Copy the decimal values visible on the illuminated LEDs.
 - b. Add decimal values together to get number of the subtest that failed.
 - c. Refer to Table 4-9 to interpret test results.

When selftest passes, the ST LED is lit and all the numbered LEDs are OFF. (This display lasts for only five seconds.)




Figure 4-19. AP Frontplane Layout

4. If an intermittent failure is suspected, press and hold the Selftest button down so the AP Selftest can execute continuously until the fault is encountered. When the failed subtest code appears, release the button and continue with the previous troubleshooting procedure.
5. Test looping with the use of the LOOP PIN and an oscilloscope is used to locate intermittent faults and time critical faults. The CE does the following:
 - a. Ground the LOOP PIN, then press and hold the Selftest button down.
 - b. Observe the displayed timing as the test continuously loops over the executed subtest that is failing.
 - c. Release the Selftest button for Selftest to execute to completion.

Troubleshooting

Table 4-11. Selftest Results

| Subtest # | Subtest Name | PON_ST | Button_ST | CI_ST | | S0_ST | DP_ST | IDLE_ST |
|-----------|----------------|--------|-----------|-------|----|-------|-------|---------|
| | | | | T0 | T1 | | | |
| 00 | LEDTEST | X | X | X | X | X | X | |
| 01 | Z80TEST1 | X | X | X | X | X | X | X |
| 02 | Z80TEST2 | X | X | X | X | X | X | X |
| 03 | ROMTEST | X | X | X | X | X | X | X |
| 04 | RAMTEST | X | X | X | X | X | X | X |
| 05 | Z80TEST3 | X | X | X | X | X | X | |
| 06 | RAMALIAS | X | X | X | X | X | X | |
| 07 | NVMTEST | X | X | X | X | X | X | X |
| 08 | CTRL1 | X | X | X | X | X | X | |
| 09 | CIO_TIMER | X | X | X | X | X | X | |
| 10 | FPRÉG | X | X | X | X | X | X | |
| 11 | S0LOOP | X | X | X | X | X | X | |
| 12 | T0LOOP | X | X | X | X | X | X | |
| 13 | DPLOOP | X | X | X | X | X | X | |
| 14 | ST_CONFIG | X | X | X | X | X | X | |
| 15 | SESS_INDCATR | FPH | FPH | | | | FPH | |
| 16 | T1_CONN | X | X | X | X | X | X | |
| 17 | Y_T1LOOP_IDLE | X | X | X | | X | X | |
| 18 | S1_HOOD_ORNC | X | X | X | | X | X | |
| 19 | CONSLOE | X | X | X | X | X | X | |
| 20 | FPLOOP_TEST_S0 | FPH | FPH | | | | FPH | |
| 21 | T1LOOP | X | X | X | X | X | X | |
| 22 | FPLOOP_TEST_T1 | FPH | FPH | | | | FPH | |
| 23 | NFPTEST_T1 | FPH | FPH | | | | FPH | |
| 24 | NFTTEST_T1 | FPH | FPH | | | | FPH | |
| 25 | D_CONLOOP_T1 | T1H | T1H | T1H | | T1H | T1H | |
| 26 | TERM_TEST_T1 | | X | X | X | X | X | |
| 27 | FPLOOPTESTS1 | FPH | FPH | | | | FPH | |
| 28 | NFPTEST_S1 | FPH | FPH | | | | FPH | |
| 29 | NFSTEST_S1 | FPH | FPH | | | | FPH | |
| 30 | D_CONLOOP_S1 | S1H | S1H | S1H | | S1H | S1H | |

LQ20004_060

- X: The subtest is executed.
- FPH: The subtest is executed only if there is a hood on front plane.
- T1H: The subtest is executed only if there is a hood on port T1.
(T1 is the Remote Support modem port.)
- S1H: The subtest is executed only if there are hoods on ports T1 and S1.
(T1 is the Remote Support modem port and S1 is the Session port.)



REMOTE MAINTENANCE

Remote support capability for the HP 3000/930 and HP 9000/840 Computer Systems is provided through the Access Port (AP) in conjunction with the modem connection at the system site.

NOTE

The term REMOTE refers to a console terminal (HP 2392A) connected to a computer system via a modem (not located at the system site). LOCAL refers to the console terminal located at the system site.

The following installation must apply to ensure remote maintenance contact:


- Access Port (AP) Card, P/N 5061-2537, is installed in slot C of the lower CIO Card Cage. (See Figure 3-3.)
- Cables are properly installed. (See Figures 4-20 and 4-21.)
- System Console is correctly configured for remote maintenance.

Validate the configuration of the remote support port by performing the following steps:

1. Open the front cabinet door.
2. Press the CONSOLE button (located on the Internal System Status Display Panel) if the CONSOLE ENABLED LED (located on the External System Status Display Panel) is not lighted. (See Figure 4-1 for illustrations.)
3. Press CNTL and B on the System Console simultaneously for the System Console to access the AP Control Mode.
4. Ensure that the CM> prompt is displayed on the System Console. The user softkey area should now display remote status and SPU status display hex codes.
5. Enter the valid AP command (refer to Table 4-12) at the CM> prompt. Table 4-12 lists the valid Access Port commands used for Remote Maintenance. Refer to Chapter 8 of the Hardware Support Manual, P/N 09740-90011, for detailed command syntax information.


Table 4-12. AP Commands for Remote Maintenance

| COMMAND | DESCRIPTION |
|------------|--|
| he or Help | To list valid commands for the Access Port. |
| ca | To configure or validate the configuration of the remote support port. |
| er | To enable remote access. |
| dr | To disable remote access. (Pressing the CONSOLE button on the Internal Display Panel also disables remote access.) |
| p | To alter ram or eeprom on card. Eeprom is protected by check sum bytes. |
| pam | To alter ram or eeprom on card. Eeprom is protected by check sum bytes. |
| pdm | Allows user to display rom, ram, and eeprom. |
| pdd | Allows user to display I/O control and data bytes. |
| pad | To alter I/O control and data bytes. |



LG200004_068

Figure 4-20. AP Cable Testhood Diagram



LG200012_019

Figure 4-21. Remote Maintenance Cable Configuration Diagram




Figure 4-22. AP Card Block Diagram

PDS BOOT ERROR CODES

IODC Status

A. MAIN ERROR CODES

PARAMETER RELATED ERRORS

| | | |
|--|-----|-----------|
| unsupported device adapter..... | -2 | FFFF FFFE |
| Unsupported device..... | -3 | FFFF FFFD |
| Unsupported unit..... | -4 | FFFF FFFC |
| Unsupported data transfer size..... | -5 | FFFF FFFB |
| Invalid slot..... | -8 | FFFF FFF8 |
| Invalid HPIB address or Port number..... | -9 | FFFF FFF7 |
| Invalid Unit..... | -10 | FFFF FFF6 |
| Invalid Volume..... | -11 | FFFF FFF5 |

HPA AND CHANNEL ERRORS

| | | |
|---|-----|-----------|
| CIO Channel not ready (io_status.ry = 0)..... | -17 | FFFF FFBF |
|---|-----|-----------|

SUBCHANNEL ERRORS

| | | |
|---|-----|-----------|
| Subchannel not ready(subch_status.rdy=0)..... | -32 | FFFF FFE0 |
|---|-----|-----------|

DEVICE ADAPTER ERRORS

| | | |
|--|-----|-----------|
| Device adapter not ready (sense.rfc =0)..... | -66 | FFFF FFBE |
| Device adapter selftest failed (sense.pst =0)..... | -67 | FFFF FFBD |

DEVICE ADAPTER LEVEL TRANSACTION ERRORS

| | | |
|---|------|-----------|
| IDY error..... | -128 | FFFF FF80 |
| HPIB initialize error..... | -192 | FFFF FF40 |
| HPIB data loopback error..... | -256 | FFFF FF00 |
| HPIB configuration error..... | -320 | FFFF FE00 |
| HPIB amigo identify error..... | -384 | FFFF FE80 |
| 6_port mux io error..... | -448 | FFFF FE40 |
| 6_port mux read status error..... | -512 | FFFF FE00 |
| 6_port mux device controlled Xon/Xoff enabled error.. | -576 | FFFF FDC0 |
| 6_port mux forced transmit error..... | -640 | FFFF FD80 |

TAPE DRIVE DEVICE LEVEL TRANSACTION ERRORS

| | | |
|--|-------|-----------|
| Device adapter program download error..... | -1088 | FFFF FBC0 |
| Selected device clear to tape drive error..... | -1152 | FFFF FB80 |
| Tape drive write loopback data error..... | -1216 | FFFF FB40 |
| Tape drive loopback error..... | -1280 | FFFF FB00 |
| Tape drive rewind error..... | -1344 | FFFF FAC0 |
| Tape drive io error..... | -1408 | FFFF FA80 |

CS80 DEVICE LEVEL TRANSACTION ERRORS

| | | |
|---|-------|-----------|
| Selected device clear to CS80 device error..... | -2112 | FFFF F7C0 |
| Read loopback to CS80 device error..... | -2176 | FFFF F780 |
| CS80 io error..... | -2240 | FFFF F740 |
| CS80 describe error..... | -2304 | FFFF F700 |

IODC Status (Cont.)

ALINK-AMUX ERRORS

| | | | |
|------------------------------------|-------|------|------|
| Global status error..... | -4096 | FFFF | F000 |
| Device identify error..... | -4160 | FFFF | EFC0 |
| Configure error..... | -4224 | FFFF | EF80 |
| Reset error..... | -4288 | FFFF | EF40 |
| CLOOP error..... | -4352 | FFFF | EF00 |
| DLOOP error..... | -4416 | FFFF | EEO0 |
| ACS80 IO error..... | -5120 | FFFF | EC00 |
| ACS80 extended describe error..... | -5184 | FFFF | EBC0 |

B. SECONDARY ERROR CODES

In order to provide more information, IODC may add one of the following error codes to a main error code:

DMA TRANSACTION ERRORS

| | | | |
|---|-----|------|------|
| DMA timeout..... | -1 | FFFF | FFFF |
| DMA abort error..... | -2 | FFFF | FFFF |
| DMA residue <>0 in last transaction of chain..... | -8 | FFFF | FFF8 |
| DMA residue <>0 in 2nd to last transaction of chain.. | -9 | FFFF | FFF7 |
| DMA residue <>0 in 3rd to last transaction of chain.. | -10 | FFFF | FFF6 |
| DMA residue <>0 in 4th to last transaction of chain.. | -11 | FFFF | FFF5 |
| DMA residue <>0 in 5th to last transaction of chain.. | -12 | FFFF | FFF4 |
| DMA residue <>0 in 6th to last transaction of chain.. | -13 | FFFF | FFF3 |
| DMA residue <>0 in 7th to last transaction of chain.. | -14 | FFFF | FFF2 |
| DMA residue <>0 in 8th to last transaction of chain.. | -15 | FFFF | FFF1 |

CIO TRANSACTION STATUS ERRORS

| | | | |
|--|-----|------|------|
| Data error..... | -48 | FFFF | FFD0 |
| TSTAT error..... | -49 | FFFF | FFCF |
| CS80 QSTAT error..... | -50 | FFFF | FFCE |
| Tape drive device adapter program HSTAT error..... | -51 | FFFF | FFCD |

(DSC = Disconnect Subchannel)

IODC Status (Cont.)


| IODC STATUS | | HPIB CS80 DEVICE | |
|-------------|--------------------|------------------|----------------|
| (Hex) | | | (Dec) |
| 0 | IODC Status | | 0 |
| 1 | | Sense | 1 |
| 2 | Sub-Channel Status | | 2 |
| 3 | C.A. IO_Status | | 3 |
| 4 | (Reserved) | | 4 |
| . | | | . |
| 7 | Tstat | Qstat | Identification |
| 8 | Reject | | Fault |
| 9 | Access | | Information |
| A | P1 | P2 | P3 P4 |
| B | P5 | P6 | P7 P8 |
| C | P9 | P10 | |
| D | (Reserved) | | 13 |
| . | | | . |
| . | | | . |
| F | | | 15 |

LG200012_020

| IODC STATUS | | HPIB 7974/78/79/80 TAPE | |
|-------------|--------------------|-------------------------|----------|
| (Hex) | | | (Dec) |
| 0 | IODC Status | | 0 |
| 1 | | Sense | 1 |
| 2 | Sub-Channel Status | | 2 |
| 3 | C.A. IO_Status | | 3 |
| 4 | (Reserved) | | 4 |
| . | | | . |
| 7 | Tstat | Qstat | DSJ 0X00 |
| 8 | S1 | S2 | S3 S4 |
| 9 | S5 | S6 | |
| A | (Reserved) | | 10 |
| . | | | . |
| . | | | . |
| F | | | 15 |

LG200012_021

Subchannel Status Register



The sub channel Status register contains the last error detected on this sub channel (SSTAT), the sub channel Ready bit, and the number of the Log channel (if any) currently active on this sub channel.

The SSTAT field is always 0 and as such, indicates that the channel received an RTS response of:

AES, LCD, ERT, or an undefined RTS Op Code

When an error occurs, the software can read the sub channel status register to determine which logical channel was involved.

The RDY bit, if set, indicates that a CHAIN command can be executed for this sub channel. The CHAIN command causes the CA to clear the RDY bit. The RDY bit will stay clear (0) until the DMA chain is completed if the sub channel is sub channel multiplexed, or until the chain of log channel initiates is completed if the sub channel is log channel multiplexed.

(Note : This Register resides on the Channel Adapter).

HPIB DA TSTAT Codes

The TSTAT provides status information regarding the transaction. The meaning of a particular value of TSTAT is the same for all transactions. Some meanings, however, are not applicable to all transactions and hence will never be returned for particular transactions. The TSTAT values and their corresponding meanings are tabulated below. The range of the values is 0 to 254. The value 255 is reserved for purposes of extending the range of the values if the need should ever develop.

TSTAT will reflect the first failure detected in the most recent transaction or may indicate terminating conditions or will indicate no exceptional conditions. Some transactions will have additional status information following TSTAT such as QSTAT for CS/80.

| (hex) TSTAT | Description |
|---|---|
| 00 | No exceptional conditions. (Does not mean QSTAT =0) |
| 01 | Read transaction was terminated by EOI |
| 02 | Read transaction was terminated by EOI; Count was odd |
| 03 | Read transaction was terminated by count |
| 04 | Read transaction was terminated by count; Count was odd |
| 05 | Read transaction was terminated by LF |
| 06 | Read transaction was terminated by LF; Count was odd |
| 07 | Read transaction was terminated by MSA |
| 08 | Read transaction was terminated by MSA; Count was odd |
| 09 | Transaction was terminated by host - data transfer to host was terminated by CEND instead of DEND |
| Additional TSTAT's for Read terminations are described below | |
| 0A | Transaction FCODE is not supported by the 27110B |
| 0B | Transaction requires 27110B to be SC and it is not |
| 0C | Transaction requires 27110B to be CIC and it is not |
| 0D | Transaction requires 27110B to not be CIC and it is |
| 0E | Transaction requires 27110B to be either addressed or not CIC (so some one else can address it) and it is not |

HPIB DA TSTAT Codes (Cont.)

- 0F Unexpected Level 3 Message has arrived since last Level 3 Status Message
- 10 HPIB DCL was detected
(See the data transfer transactions for details)
- 11 IFC abort of data transfer
- 12 27110B hardware failure due to HPIB chip "processor abort"
- 13 27110B hardware failure due to illegal DMA interrupt
- 14 27110B outbound data frozen due to presence of inbound data on the 27110B; won't happen when 27110B is CIC
- 15 Data error
- 16 reserved.
- 17 Can not be done because PPOLL interrupt is enabled
Can be returned in response to a set ATN false transaction
- 18 reserved
- : reserved
- 1F reserved
- 20 The data portion of the CS/80 request block was missing from the request phase
- 21 End of a FIFO disabled transfer occurred with an EOI on the last byte and the count ran down at the same time
- 22 Same as 21 only the count was odd
- 23 End of a FIFO disabled transfer occurred with an EOI and a LF
- 24 Same as 23 only the count was odd
- 25 End of a FIFO disabled transfer occurred with an EOI on the match byte

HPIB DA TSTAT Codes (Cont.)

- 26 Same as 25 only the count was odd
- 27 End of a FIFO disabled transfer occurred with a match byte
- 28 Same as 27 only the count was odd
- 29 A write transfer was terminated by a byte arriving in the device adapter inbound FIFO when the 271108 was not the CIC
- 2A A read or write was terminated by the 27110B receiving an DCL or SDC when it was not the CIC. For reads an extra byte is sent to the host in order to terminate the transfer. This byte is counted in the odd/even sense of the status.
- 2B Same as 2A for a read only the byte count was odd
- 2C reserved
- 2D Download_error. This condition occurs when the contents of the data block to be stored on the 27110B is inconsistent with the indicated byte count for the download.
- 2E reserved
- 2F No DAP downloaded. This error will be given when an execute downloaded DAP transaction is attempted before the DAP has been downloaded.

HPIB DA TSTAT Codes (Cont.)

CS/80 Timeout status values are as follows:

- 30 Timeout during Command. No PPOLL response prior to entering Execution.
- 34 Timeout during Execution. No PPOLL response prior to entering Report.
- 38 Timeout during Report. Command of Detailed report has not been sent.
- 3C Timeout during Detailed Report. Could be Command, Execution, or Report.
- 3X+1 Timeout and 27110B was not the CIC after timeout was detected.
- 3X+2 Timeout and a second timeout occurred while 27110B was trying to send UNT and UNL after the first timeout.
- 40 Timeout during Perform Amigo Identify transaction
- 41 Illegal DAL opcode attempted during DAP interpretation/execution
- 42 DAP boundary exceeded. I.E. C.I. program counter has bad value
- 43 Device Locked during some error report/recovery
- 44 reserved
- : reserved
- FD reserved
- FE No status available. This status is set upon receiving a function byte and indicates that the 27110B didn't complete the transaction but also didn't detect any particular error. This value will also set upon reset and power on.
- FF reserved for extension

QSTAT Codes

CS80 Transactions

0 - NORMAL COMPLETION

Indicates normal completion of the requested operation.

1 - HARD ERROR

Indicates that error information is available. The host must issue the Request Status command in order to determine what went wrong.

2 - POWER ON

Indicates that the device has just returned from a power failure or some form of operator intervention (such as removal of the storage media). Any incomplete transactions were aborted and should be repeated. The host must reconfigure any programmable operating parameters because they have returned to their power-on values.
(not used by ALINK-AMUX)

3 - INTERFACE ERROR

Indicates that an interface command error, such as illegal parity or loopback failure was detected by the device channel module.
(not used by ALINK-AMUX)

HSTAT Codes

HSTAT CODES

HSTAT is the operand from the halt instruction of the DAP (Device Adapter Program) program. It is used during tape transactions.

The DAP program actually verifies the DSJ (Device Specified Jump) value returned by the tape drive, and uses that value as the halt operand. Thus, HSTAT= DSJ returned value.

| HSTAT | Meaning |
|-------|---|
| 0 | No error |
| 1 | Error found during command execution See device status bytes |
| 2 | This usually indicates that the door was opened during command execution |

CS80 Hardware Status

IDENTIFICATION ERRORS (word 8)

```

1111 2222 22 22 22 33
6789 0123 45 67 89 01
<VVVV UUUU><SS SS SS SS>

```

VVVV = Volume number

UUUU = Unit number

SSSSSSSS = Value of the
lowest numbered unit
with status pending
(all ones, or 0xFF if
no units have status
pending)

Notes:

1. Error bit positions and word numbers correspond to IODC/PDC status data printed on console in 9740A HPPAs.
2. All fault errors are unmaskable.
3. Error uses parameter field.
4. Parameter field configuration is dependent on reported errors.

Highest priority is given to the lowest numbered error.

Masked errors relinquish their priority.

REJECT ERRORS (word 9)

```

0000 0000 0011 1111
0123 4567 8901 2345
<..A. .BCD><EFG. H...>

```

A = CHANNEL PARITY ERROR

A channel command was received without odd parity.

B = ILLEGAL OPCODE

An unrecognizable opcode was received.

C = MODULE ADDRESSING

An illegal volume or unit number was specified.

D = ADDRESS BOUNDS

The target address has exceeded the bounds for this device.

E = PARAMETER BOUNDS

A parameter (other than unit, volume, or target address) is not allowed for this device.

F = ILLEGAL PARAMETER

A parameter field was the wrong length for the opcode preceding it.

G = MESSAGE SEQUENCE

The message sequence has been violated. (Error suppressed if any reject or fault errors have occurred prior to sequence error.)

H = MESSAGE LENGTH

The total length of the execution message differs from the current default value.

CS80 Hardware Status (Cont.)

FAULT ERRORS (word 9) (2)

1111 2222 2222 2233
6789 0123 4567 8901
<.A.B ..C.><D.EF G.HI>

- A = CROSS-UNIT (3)
An error has occurred during a Copy Data operation.
- B = CONTROLLER FAULT
A hardware fault occurred in the controller.
- C = UNIT FAULT
A hardware fault has occurred in the unit addressed.
- D = DIAGNOSTIC RESULT (3)
Hardware failed the diagnostic shown in the parameter field.
- E,F,G= RELEASE REQUIRED
This command cannot be executed until after release is granted to the device.
- E = OPERATOR REQUEST
Release required for operator request (eg: load/unload...)
- F = DIAGNOSTIC REQUEST
Release required for diagnostic initiated from control panel (eg: HIO, selftest...)
- G = INTERNAL MAINTENANCE
Release required for internal maintenance (eg: head alignment error log...)
- H = POWER FAIL
The power to the unit failed, a diagnostic destroyed the configuration, or a pack was loaded. Device should be reconfigured.
- I = RETRANSMIT
The preceding transaction should be retried.

ACCESS ERRORS (word 10)

0000 0000 0011 1111
0123 4567 8901 2345
<ABCD EF..> <GH.I J...>

- A = ILLEGAL PARALLEL OPERATION
The requested operation cannot be executed in parallel with some other operation(s) currently in progress.
- B = UNINITIALIZED MEDIA
The host attempted to access unformatted media, or unusable media has been loaded.
- C = NO SPARES AVAILABLE
Spare Block cannot be executed due to lack of spare media.
- D = NOT READY
The selected unit is not ready for access at the time (eg: heads or media not yet fully loaded).
- E = WRITE PROTECT
The selected volume is write protected.
- F = NO DATA FOUND
A block accessed during a read has not been written.
- G = UNRECOVERABLE DATA OVERFLOW
The previous transaction generated more than 1 unrecoverable data error. The entire transfer should be considered in error.
- H = UNRECOVERABLE DATA (3)
Unrecoverable data at indicated block(s).
- I = END OF FILE
End of file encountered on file structured device.
- J = END OF VOLUME
The host attempted to access across a volume boundary.

CS80 Hardware Status (Cont.)

INFORMATION ERRORS (word 10)

1111 2222 2222 2233
 6789 0123 4567 8901
 <ABCD E..F> <..GHI .J..>

- A..C= REQUEST RELEASE (3)
 Device requests release for indicated reason.
- A = OPERATOR REQUEST (3)
 Release requested for operator request (eg: load/unload...)
- B = DIAGNOSTIC REQUEST (3)
 Release request initiated from diagnostic control panel (eg: HIO, selftest...)
- C = INTERNAL MAINTENANCE (3)
 Release requested for internal maintenance (eg: head alignment error log...)
- D = MEDIA WEAR
 Only one spare track (disc) or one spare block (tape) remaining.
- E = LATENCY INDUCED
 A latency was induced during the transfer due to slow transfer rate or seek retry.

PARAMETER BYTES

(words 11,12,13) (4)

<P1>.....<P10>

NO ERRORS: P1 through P6 indicate new Target Address. the address format, which is used any time P1 through P6 contain address information, is defined by the Set Return Addressing command.

NO ERRORS: P7 through P10 contain run-time drive error codes (DERRORS), except after a Spare Block command. The errors are arranged chronologically: P7 contains the most recent, and P 10 contains the oldest of the 4 errors recorded.

Note: Error codes 40H and CBH will always be followed by a single byte containing fault latch information.

After a Spare Block command, P1 through P6 contain the beginning address of the reformatted area. the address format is described above (disc operation only).

CROSS UNIT (word 9, bit 17)

P1 through P6 contain the encoded values of each unit which has experienced an error. A byte of all ones indicates no additional units

CS80 Hardware Status (Cont.)

| INFORMATION ERRORS (word 10) | PARAMETER BYTES (words 11,12,13) (4) |
|---|---|
| <pre> 1111 2222 2222 2233 6789 0123 4567 8901 <ABCD E..F> <.GHI .J..> </pre> | <pre> <P1>.....<P10> </pre> |
| <p>F = AUTO SPARING INVOKED A defective block has been automatically spared by the device.</p> <p>G = RECOVERABLE DATA OVERFLOW The previous transaction generated more than 1 recoverable data error.</p> <p>H = MARGINAL DATA (3) Data was recovered, but with difficulty.</p> <p>I = RECOVERABLE DATA (3) A latency was introduced in order to correct a data error.</p> <p>J = MAINTENANCE TRACK OVERFLOW Error and fault log area is full.</p> | <p>DIAGNOSTIC RESULTS (word9, bit 24) P1 through P6 contain the following: P1= most suspect component P2= next most suspect component P3= test error (TERROR) relating to P1 P4= test error (TERROR) relating to P2 P5 through P6 are not used P7 through P10 contain DERROR information (format described above).</p> <p>UNRECOVERABLE DATA (word 10, bit 9) P1 through P6 contain address of bad block</p> <p>REQUEST RELEASE (word10, bits 16..18) P1 through P6 contain the encoded values of each unit requesting release. A byte of all ones indicate no additional units.</p> <p>MARGINAL DATA (word10, bit 26) RECOVERABLE DATA (word 10, bit 27) P1 through P6 contain the address of offending block.</p> |

7974/78/79/80 Status Codes

| Bit# | Interpretation |
|-----------------------------------|--|
| BYTE S1 (Word 9.[0..7]) | |
| 0 | End of file (tape mark) |
| 1 | BOT (load point) |
| 2 | EOT (end of tape) |
| 3 | Recovered error check (see retry count) |
| 4 | Command rejected (see reject codes A1/BE) |
| 5 | File write protected (no write ring) |
| 6 | Unrecovered (data/format) error (see reject codes 29/49) |
| 7 | Unit on-line |
| BYTE S2 (Word 9.[8..15]) | |
| 8 | GCR format (6250 BPI) (7978B) |
| 9 | Unknown tape format/density |
| 10 | Data parity error (transport electronics) |
| 11 | Data timing error (shouldn't happen on 7974A/7978B) |
| 12 | Tape run-away |
| 13 | Door open |
| 14 | Long records supported (7978B) |
| 15 | Immediate response mode enabled |
| BYTE S3 (Word 9.[16..23]) | |
| 16 | PE format (1600 BPI) |
| 17 | NRZI format (800 BPI) (7974A) |
| 18 | Power restored or device cleared |
| 19 | HP-IB command parity error |
| 20 | Tape position lost or loss of tension (see reject codes 51/5E) |
| 21 | Formatter error (see reject codes 65/6E) |
| 22 | Servo error (see reject codes 51/5E) |
| 23 | Controller error (see reject codes 79/8C) |
| BYTE S4 (Word 9.[23..31]) | |
| 24 \ | 0 : Null code |
| 25 > | 1 : reserved |
| 26 / | 2 : Device reject (see reject codes) |
| | 3 : Protocol reject |
| | 4 : reserved |
| | 5 : Prior error abort |
| | 6 : reserved |
| | 7 : Error selftest and on-line |

7974/78/79/80 Status Codes (Cont.)

27 \

28 } Retry count

29 /

30 /

31 /

BYTE S5 (Word 10.[0..7])

| HEX Value | REJECT CODE | Meaning |
|-----------|-------------|---|
| 5 | | File protected on write |
| 6 | | Tape not tensioned |
| 7 | | Tape format option not present on write density command |
| 9 | | Cannot identify format from media on read |
| A | | Write command & format not identified (do write format command) |
| B | | Drive not on-line |
| 10 | | Write format but media not at BOT |
| 13 | | At BOT and command backwards received |
| 17 | | Protocol not synchronized |
| 18 | | Command byte not recognized |
| 1F | | Write record length too long for buffer |
| 21 | | Selftest failure |
| 25 | | Tape positioning failure after EOT sensed |
| 28 | | Door opened after EOT sensed |

(Unrecovered data/format errors)

| | |
|----|---|
| 29 | Tape speed out of spec |
| 2D | MTE (multiple track error during write) |
| 2F | Verify or write failed on TM or IDB |
| 30 | Noise read from media (data not valid) |
| 31 | Data format error |
| 32 | Failure to identify tape after rewind |
| 33 | Media failure on data portion of block (drop out) |
| 34 | Media failure on pre/post-amble of block (drop out) |
| 35 | Redundancy check character error |
| 36 | Uncorrected read parity error (7978B) |
| 37 | Abnormal command abort (door opened) (7974A) |
| 39 | Maximum skew exceeded (7974A) |
| 3A | False pre/post-amble detected (7974A) |
| 3B | Write data error corrected (7974A) |
| 3C | Buffer overrun |
| 3D | Data block timeout: no gap after data block |
| 3E | Media fail on Tape Mark (EOF) (drop out) |
| 3F | Tape mark not verified (doesn't meet ANSI) |
| 40 | Tape mark timeout |

7974/78/79/80 Status Codes (Cont.)

(Servo errors or loss of tension)

51 Servo controller unresponsive
 52 Servo failed to reach desired state
 53 Unexpected servo shutdown (tension lost)
 54 Servo controller hard failure
 55 Servo protocol error
 56 Servo run-time error
 57 "In position" interrupt not received by master controller
 58 No GAP detected after Read block, Write block, or TM
 59 Safety shutdown of motor driver
 5A No BOT detected on load/rewind
 5B Speed out of specifications
 5C Invalid request from master controller
 5E Tape positioning failure

(Formatter errors)

65 No "end of record" after data (7978B)
 66 Formatter HW error (7978B)
 67 Bad block type detected on write
 68 Erase failed (flux transitions detected on erased area)
 69 No data detected on write (read after write)
 6A Tracks out of sync on write verify
 6B Formatter HW error (7974A)
 6C Formatter unresponsive (7974A)
 6D Gap timer failed
 6E Formatter byte count <> data buffer byte count

(Controller errors)

79 Transaction ID mismatch (command Vs status)
 7A No pending command for the status received
 7B Invalid status received from device program
 7C Status queue overflow
 7D Unknown command received by device program
 7E Command queue overflow
 80 End of record missing in data buffer
 81 Data buffer parity error
 82 Data buffer underrun during write
 83 Write byte count <> read buffer byte count
 84 Bad message type received by channel program from device program
 85 CPU handshake abort (between HP-IB I/F and channel program)
 86 Unknown HP-IB condition detected
 89 Illegal access to servo controller registers detected
 8A Device program firmware error
 8B Hardware utilities firmware error
 8C Channel program firmware error
 8D On-line encoder inoperative

7974/78/79/80 Status Codes (Cont.)

(Command reject errors)

| | |
|----|--|
| A1 | Command queue not empty (request denied) |
| A2 | Request DSJ expected |
| A3 | Request status expected |
| A5 | Unknown unit selected |
| A6 | Tape command secondary expected |
| A7 | Data byte expected |
| A8 | Missing parameter EOI on COMMAND, selftest#, or END |
| AA | Protocol error for "write record" command in command phase |
| AC | Protocol error for "read record" command in status phase |
| AD | Protocol error in "status" request phase |
| AE | Protocol error in "Cold load sequence" |
| B0 | END "complete" or "complete idle" expected |
| B2 | END "data" expected |
| B4 | Unknown secondary command |
| B5 | Misplaced data byte |
| B8 | Protocol error (loopback) |
| B9 | Protocol error (selftest) |
| BC | Parity error in HP-IB command |
| BD | Operator reset during protocol sequence |
| BE | Device clear received (internal) |

BYTE S6 (word 10.[8..15])

This byte represents the number of commands rejected since the last error, including the command in error. It should be smaller than 14.

Memory Layout

| (HEX) | -MEMORY PAGE 0- | (DEC) |
|-------|--|-------|
| 0x000 | INITIALIZATION VECTORS | 0 |
| 0x040 | PROCESSOR DEPENDENT (PIM DATA) | 64 |
| 0x200 | (reserved) | 512 |
| 0x360 | [[0..15]=0 (reserved) MEM_ERR | 864 |
| 0x380 | MEM_FREE | 896 |
| 0x384 | HPA ADDRESS OF PROCESSOR | 900 |
| 0x388 | ADDRESS OF MEMORY BASED PDC | 904 |
| 0x38C | MEM_IOMSEC | 908 |
| 0x390 | MEMORY CONFIGURATION | 912 |
| 0x3A0 | CONSOLE CONFIGURATION | 928 |
| 0x3D0 | BOOT DEVICE CONFIGURATION | 976 |
| 0x400 | (reserved) | 1024 |
| 0x800 | MEMORY VERSION OF PDC | 2048 |
| | MEMORY VERSION OF IODC FOR CONSOLE DEVICE | < |
| | MEMORY VERSION OF IODC FOR BOOT DEVICE | |
| | START OF IPL CODE (page aligned) | |

Troubleshooting

Memory Layout (Cont.)

MEM_ERR: up to 8 entries, used by PDC to log non-fatal errors when PDC is called by S/W. Each entry contains the code that would be displayed by PDC on the HEX display of the CPU.

MEM_10MSEC: PDC places in here the calibration factor for the CPU timer (CR16), normalized to the number of clock ticks in 10 m-seconds.

-INITIALIZATION VECTORS-

| (HEX) | | (DEC) |
|-------|--|-------|
| 0x0 | -----+ 0x0 -----+ | 0 |
| 0x4 | -----+ POWER_FAIL -----+ | 4 |
| 0x8 | -----+ TRANSFER OF CONTROL (TOC) -----+ | 8 |
| 0xC | -----+ TOC_LENGTH (in bytes) -----+ | 12 |
| 0x10 | -----+ (reserved) -----+ | 16 |

-INITIAL MEMORY CONTROLLER ENTRY-

| (HEX) | | (DEC) |
|-------|--|-------|
| 0x390 | -----+ HARD PHYSICAL ADDRESS (HPA) -----+ | 912 |
| 0x394 | -----+ [0..30] = 0x0 sb -----+ | 916 |
| 0x398 | -----+ SPA_SIZE (in bytes) -----+ | 920 |
| 0x39C | -----+ MAX_MEM (in bytes) -----+ | 924 |

"sb" indicates type of last boot: 1= softboot, 0= hardboot
MAX_MEM <= SPA_SIZE (& both values are aligned to a power of 2)

Memory Layout (Cont.)

| (HEX) | -CONSOLE DEVICE- | (DEC) |
|-------|-------------------------------|-------|
| 0x3A0 | FLAGS BC(0) BC(1) BC(2) | 928 |
| 0x3A4 | BC(3) BC(4) BC(5) PM | 932 |
| 0x3A8 | CIO DEVICE ADAPTER SLOT # | 936 |
| 0x3AC | PORT NUMBER | 940 |
| 0x3B0 | (reserved) | 944 |
| 0x3C0 | HPA ADDRESS | 960 |
| 0x3C4 | SPA ADDRESS | 964 |
| 0x3C8 | IODC ENTRY_IO ADDRESS | 968 |
| 0x3CC | [0..27]=0 (reserved) CLASS | 972 |

For Boot devices:
 FLAGS.[0] = autoboot flag
 FLAGS.[1] = autosearch flag
 FLAGS.[6] = alternate boot path

For Console device:
 FLAGS.[0] = interactive
 FLAGS.[1] = buffers allocated
 FLAGS.[6] = hard conspath in use
 FLAGS.[7] = console initialized

BC(n) : Bus converter address
 (not used, = 0xFF)
 PM: Physical module number
 (= 4 * (Mid_bus slot #))
 Console path and alternate path
 format is the same, with the FLAGS=0,
 and word 0x3AC is the port number
 for the console path.
 CLASS defines the type of device:
 0= CL_NULL
 1= CL_RANDOM (random access, ie: disc)
 2= CL_SEQ (sequential access, ie: tape)
 7= CL_DUPLEX (point-to-point, ie: console)

| (HEX) | -BOOT DEVICE- | (DEC) |
|-------|-------------------------------|-------|
| 0x3D0 | FLAGS BC(0) BC(1) BC(2) | 976 |
| 0x3D4 | BC(3) BC(4) BC(5) PM | 980 |
| 0x3D8 | CIO DEVICE ADAPTER SLOT # | 984 |
| 0x3DC | HPIB DEVICE ADDRESS | 988 |
| 0x3E0 | UNIT NUMBER | 992 |
| 0x3E4 | (reserved) | 996 |
| 0x3F0 | HPA ADDRESS | 1008 |
| 0x3F4 | SPA ADDRESS | 1012 |
| 0x3F8 | IODC ENTRY_IO ADDRESS | 1016 |
| 0x3FC | [0..27]= 0 (reserved) CLASS | 1020 |

HPA : [0..3] = 0xF
 [4..13] = FLEX Address
 (= 0x3FE, for 974x)
 [14..19] = Physical Module Number
 [14..17] = MID-BUS Slot Number
 [20] = Privilege Page
 [21..29] = Register Number
 [30..31] = 0

DIAGNOSTICS

SECTION

5

The Diagnostics Section provides information pertaining to the supported diagnostics and utilities for MPE-XL and HP-UX operating systems. Also included in this section is booting up information when using the HP-UX Support Tape.



| | |
|---|------|
| HP 9740A SPU SELFTEST | 5-2 |
| Selftest Display | 5-2 |
| Diagnostic/Utility Orientation | 5-3 |
| Diagnostic User Interface (DUI) | 5-6 |
| CS/80 Disc Diagnostic (CS80DIAG) | 5-8 |
| Flex Disc Diagnostic (FLEXDIAG) | 5-10 |
| HP7974A & 7978A/B Magnetic Tape Drive Diagnostic (DIAG7478) | 5-11 |
| Ciper Line Printer Diagnostic (CIPERLPD) | 5-13 |
| Page Printer Diagnostic (PPDIAG) | 5-14 |
| AFI Device Adapter Diagnostic (AFIDAD) | 5-15 |
| HP-IB Device Adapter Diagnostic (HPIBDIAG) | 5-16 |
| HP-FL Device Adapter Diagnostic (HPFLDIAG) | 5-17 |
| Memory Array Diagnostic (MAD) | 5-18 |
| Six-Channel MUX Diagnostic (MUXDIAG) | 5-19 |
| Local Area Network Device Adapter Diagnostic (LANDAD) | 5-21 |
| I/O Test Tool (IOTT) | 5-23 |
| CIO Channel Adapter Diagnostic (CADIAG) | 5-27 |
| HP98720A Graphics Processor Diagnostic(GP3DDIAG) | 5-28 |
| System and Memory Log Analysis Tool (LOGTOOL) | 5-29 |
| System Map (SYSMAP) | 5-30 |
| HP-UX Logging Facility | 5-31 |
| MPE-XL Online Diagnostic Installer (DIAGINST) | 5-32 |
| MPE-XL Online Diagnostic System Implementation | 5-33 |
| Implementation Dependent Information | 5-33 |
| MPE-XL Specific Diagnostic Procedures/Features | 5-33 |
| HP-UX Online Diagnostic Implementation | 5-34 |
| Implementation Dependent Information | 5-34 |
| HP-UX Specific Diagnostic Procedures/Features | 5-34 |
| HP-UX Support Tape | 5-35 |
| Booting Up | 5-35 |
| Support Tape Main/Utilities Menus | 5-36 |

HP 9740A SPU SELFTEST

The HP 9740A SPU Selftest is responsible for initializing and testing the IU, EU, RF, TLB, CA boards, all installed memory controller and memory array boards, and I/O cards that have built in selftest code. It checks data paths and component functionality for all boards in the SPU processor.

Selftest code can be invoked in the following ways:

- Cold Power On (PON).
- External Reset (ER).
- High Priority Machine Check (HPMC).
- Return from Power Fail (Powerfail Recovery).
- Transfer of Control/Soft Reset (TOC/SRS).

Refer to Online Diagnostics Subsystem Manual, P/N 09740-90020, for detailed descriptions and procedures.

Selftest Display

The two types of display messages used for Selftest are displayed on a four digit hexadecimal display window located inside the front cabinet door (Refer to Section 4, Figure 4-4) and on the System Console. These display messages are:

1. **ERROR/WARNING MESSAGES** - Indicates failure in one of the defined Classes, directs user to slot number of the Field Replaceable Unit (FRU), and provides detailed information about the cause of error.
 - 300F is displayed at successful completion of selftest.
 - 300E is displayed at successful completion of selftest with warning.
 - 0000 is displayed to indicate a catastrophic error at an entry point in the execution of selftest.
2. **INFORMATIONAL/RUN TIME MESSAGES** - Indicates what the selftest is doing at any given time. On Informational displays, the detailed error numbers are set to zero.

For detailed descriptions of error messages, refer to Chapter 8 of the Hardware Support Manual, P/N 09740-90011.

DIAGNOSTIC/UTILITY ORIENTATION

The Online Subsystem Operating Software is the Diagnostic User Interface (DUI) that provides access to the following diagnostic programs:

- CS/80 Disc Diagnostic (CS80DIAG).
- HP 7974A/7978A Magnetic Tape Diagnostic (DIAG7478).
- CIPER Line Printer Diagnostic (CIPERLPD).
- HPIB Device Adapter Diagnostic (HPIBDIAG).
- Memory Array Diagnostic (MAD).
- Six-Channel MUX Diagnostic (MUXDIAG).
- Local Area Network Device Adapter Diagnostic (LANDAD).
- CIO Channel Adapter Diagnostic (CADIAG).
- HP-FL Device Adapter Diagnostic (HPFLDIAG)
- Eagle Diagnostic (EGLDIAG).
- Page Printer Diagnostic (PPDIAG).
- AFI Device Adapter Diagnostic (AFIDAD)
- Flex Disc Diagnostic (FLEXDIAG)
- HP98720A Graphics Processor Diagnostic (GP3DDIAG)

The following are the supported Utilities:

- I/O Test Tool (IOTT).
- System and Memory Log Analysis Tool (LOGTOOL).
- System Map (SYSMAP).
- HP-UX Logging Facility (DECODE and DELOG).
- MPE-XL Online Diagnostic Installer (DIAGINST).

The Diagnostic and Utility Subsystems are designed for:

- MPE-XL Diagnostic Implementation.
- HP-UX Online Diagnostic Implementation.

Diagnostics

Table 5-1. Supported Diagnostic Programs

| DIAGNOSTIC NAME | DESCRIPTION | MPE-XL | HP-UX |
|-----------------|--|--------|-------|
| CS80DIAG | CS/80 Disc Diagnostic | Yes | Yes |
| FLEXDIAG | Flex Disc Diagnostic | *N/R | *N/R |
| DIAG7478 | HP 7974A/7978A/B Magnetic Tape Diagnostic | Yes | Yes |
| CIPERLPD | CIPER Line Printer Diagnostic | Yes | Yes |
| PPDIAG | Page Printer Diagnostic | Yes | Yes |
| HPIBDIAG | HP-IB Device Adapter Diagnostic | Yes | Yes |
| HPFLDIAG | HP-FL Device Adapter Diagnostic | *N/R | Yes |
| MAD | Memory Array Diagnostic | No | Yes |
| MUXDIAG | Six-Channel MUX Diagnostic | Yes | Yes |
| LANDAD | Local Area Network (LAN) Device Adapter Diagnostic | Yes | Yes |
| GP3DDIAG | HP98720A Graphics Processor Diagnostic | *N/R | Yes |
| CADIAG | CIO Channel Adapter Diagnostic | Yes | No |
| AFIDAD | AFI Device Adapter Diagnostic | No | Yes |

*not released as of this printing date

Table 5-2. Supported Subsystem Utilities

| UTILITY NAME | DESCRIPTION | MPE-XL | HP-UX |
|--------------|-------------------------------------|--------|-------|
| IOTT | I/O Test Tool | Yes | No |
| LOGTOOL | System and Memory Log Analysis Tool | Yes | No |
| DECODE | HP-UX Logging Facility | No | Yes |
| DELOG | HP-UX Logging Facility | No | Yes |
| MEMLOGP | Memory Error Logging Process | Yes | No |
| SYSMAP | System Map | Yes | No |
| DIAGINST | MPE-XL Online Diagnostic Installer | Yes | No |

Diagnostic User Interface (DUI)

The Diagnostic User Interface (DUI) provides access to all programs in the Online Diagnostic System.

Mini-Operating Instructions

1. Enter the following system command to the system prompt:

`SYSDIAG (MPE-XL)`

`/USR/DIAG/BIN/SYSDIAG (HP-UX)`

The diagnostic will respond with the following header and welcome message indicating that access has been gained to the Online Diagnostic System:

```
*****  
*****          ONLINE DIAGNOSTIC SUBSYSTEM          *****  
*****          (c) Hewlett Packard Corporation          *****  
*****  DUI version xx.yy  Monitor version xx.yy  *****  
*****
```

Type "HELP" for assistance.

There is no Monitor version appearing on HP-UX systems. On HP-UX systems a positive integer will appear as part of the DUI prompt to represent how many commands have been entered into the current DUI session.

2. Enter HELP to the DUI prompt for the following list of available commands to appear:

DUI > HELP

| COMMAND | DESCRIPTION |
|------------|--|
| ABORT | Terminates active diagnostic programs. |
| CI or ! | Provide access to operating system interpreter (shell). |
| EXIT | Exit from the diagnostic system. |
| HARDCOPY | Echo information displayed on terminal to printer or file. |
| HELP or ? | Provide help information for DUI or diagnostic programs. |
| INSTALL | Add/update programs in the diagnostic system. |
| LIST | List the programs that are part of the diagnostic system. |
| MODE | Display/change current system mode. |
| PURGE | Delete programs from the diagnostic system. |
| REDO or ^ | Display and edit last DUI command. |
| RESUME | Allow a suspended program to resume processing. |
| RUN | Execute the specified program. |
| SHOWACTIVE | Display programs running in diagnostic system. |
| SUSPEND | Suspend the processing of the specified program. |
| TEST | Provides the ability to test a diagnostic program. |
| UNLOCK | Releases specified device from lock status. |
| USE | Causes DUI commands to be read from a file. |
| WAIT | Wait for background programs to terminate. |

NOTE

The commands INSTALL and PURGE are applicable for HP-UX, only. The commands TEST and UNLOCK are applicable for MPE-XL, only.

Installation, modification, and removal of Online Diagnostic Programs on MPE-XL operating systems is accomplished by using the MPE-XL Online Installer (DIAGINST) facility. Installation, modification, and removal of Online Diagnostic Programs on HP-UX operating systems is accomplished by using the HP-UX Online Installer facility. Refer to the Online Diagnostics Subsystem Manual, P/N 09740-90020 for detailed information regarding MPE-XL. Refer to the HP-UX System Administrator's manual (92453-90004) for detailed information regarding HP-UX.

3. To exit the DUI, type EXIT.

For a list of possible error messages which may appear when using the DUI, refer to Section 2 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

CS/80 Disc Diagnostic (CS80DIAG)

The CS/80 Disc Diagnostic (CS80DIAG) will test HP 7908/11/12/14 or HP 7933/35/37 disc drives. This diagnostic can detect failures of one or more Field Replaceable Unit (FRU).

Mini-Operating Instructions

1. Enter the following to the system prompt:

```
SYSDIAG (MPE-XL)
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following to the DUI prompt:

```
DUI> RUN CS80DIAG < RUN Command Options >
```

Typing **HELP** will cause a summary of the DUI function and its commands to appear on the screen. Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If sections and steps to be run are not specified, the default sections and steps will be executed. The default sections are Sections 2, 3, 4, 5, 8, and 9. Default steps are all steps within sections. Execution of these defaults is dependent on the test mode that has been granted by the system.

DEFAULT SECTIONS

- o Section 2 - Clear
- o Section 3 - Identify
- o Section 4 - Loopback (all steps)
- o Section 5 - Selftest
- o Section 8 - Common System Operations (all steps)
- o Section 9 - Status Tests (all steps)

- o Section 17 - CS/80 External Exerciser (Interactive Section)

ADDITIONAL SECTIONS AVAILABLE

- o Section 6 - Status
- o Section 7 - Error Logs



4. If Section 17 is selected, the CS/80 diagnostic prompt will appear.

CS80DIAG>

Entering **HELP** to the prompt will display a list of the available CS/80 External Exerciser commands.

CS80DIAG > HELP

| | |
|----------------|---|
| ADDRESS | Converts block addresses to 3-vector and visa versa. |
| BUTTERFLY SEEK | Performs a Butterfly Seek utility on a HP 7936/37 disc drive. |
| CANCEL | Tells the device to cancel the previous command. |
| CICLEAR | Issues a CS/80 Channel Independent Clear on the disc. |
| CLEAR LOGS | Clears the various error logs on the device. |
| DESCRIBE | Obtains describe information from the device. |
| DIAG | Provides access to device's internal diagnostics. |
| ERRSUM | Obtains an error summary from the device. |
| ERT LOG | Provides access to the device's ERT data error log. |
| EXIT | Terminates execution of the External Exerciser. |
| FAULT LOG | Provides access to the device's fault log. |
| HELP | Provides this list of commands as well as more detailed descriptions and syntax of each command. |
| INIT MEDIA | Initializes the device's media. |
| READ | Reads and displays a block of data from the device. |
| REV | Provides access to the revision data for the device. |
| RFSECTOR | Reads and displays a full sector of data from the disc, including header and trailer information. |
| RO ERT | Performs a read-only error rate test on the device. |
| RUN LOG | Reads the device's run-time data error log. |
| SDCLEAR | Performs a CS/80 Selected Device Clear on the device. |
| SENSE | Reads data from the device's environmental sensors. |
| SET PATTERN | Set pattern to be used in error rate tests. |
| SET RPS | Sets/resets the Rotational Position Sensing feature on the device. |
| SPARE | Spares a block of data on the device. |
| SUSPEND | Suspends CS80DIAG and returns control to the DUI. |
| TABLES | Provides access to the various tables on the device. |
| UNIT | Sets the unit number on the device. |
| WTR ERT | Performs a write-then-read error rate test on the device. |

5. Type **EXIT** to exit Section 17 and control will return to the Online Diagnostic System.

End of Section 17 - External Exerciser

For a list of error messages which may appear when using CS80DIAG, refer to the Online Diagnostics Subsystem Manual, P/N 09740-90020.

Flex Disc Diagnostic (FLEXDIAG)

The Flex Disc Diagnostic (FLEXDIAG) will test the Flex disc drives. This diagnostic can detect failures of one or more Field Replaceable Unit (FRU).

Mini-Operating Instructions

1. Enter the following to the system prompt:

```
SYSDIAG (MPE-XL)  
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following to the DUI prompt:

```
DUI> RUN FLEXDIAG < RUN Command Options >
```

Typing **HELP** will cause a summary of the DUI function and its commands to appear on the screen. Refer to the **DUI** section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the **RUN** command options.

3. The diagnostic responds with a header and welcome message.

If sections and steps to be run are not specified, the default sections and steps will be executed. The default sections are Sections 2, 3, 4, 5, 8, and 9. Default steps are all steps within sections. Execution of these defaults is dependent on the test mode that has been granted by the system.

DEFAULT SECTIONS

- o Section 2 - Clear
- o Section 3 - Identify
- o Section 4 - Loopback (all steps)
- o Section 5 - Selftest
- o Section 8 - Common System Operations (all steps)
- o Section 9 - Status Tests (all steps)

4. To exit FLEXDIAG, type **EXIT**. Control will return to the Online Diagnostic System.

HP 7974A and 7978A/B Magnetic Tape Drive Diagnostic (DIAG7478)

The HP 7974A and 7978A/B Magnetic Tape Drive Diagnostic (DIAG7478) will test an HP 7974A or HP 7978A/B Magnetic Tape Drive online and offline. Specify which sections and steps are to be run.

Mini-Operating Instructions

1. Ensure the tape drive to be tested is powered on. Ensure that a scratch tape has been mounted and the tape drive is placed online for sections which tape movement and write/read operations are to be run.

2. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

3. Enter the following command to the DUI prompt:

```
DUI > RUN DIAG7478 <RUN Command Options>
```

Type **HELP** for a summary of the available **RUN** commands. Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details.

4. The diagnostic responds with a header and welcome message.

If specific sections and steps are not specified, the following default sections and steps will be executed:

DEFAULT SECTIONS

- o Section 2 - Clear
- o Section 3 - Identify
- o Section 4 - Loopback
- o Section 6 - Hardware Status
- o Section 40 - Firmware Utilities
- o Section 50 - Image Utilities
- o Section 55 - Display Logs

For the HP 7974A Only:

- o Section 34 - HP 7974A Selftests

For the HP 7978A/B Only:

- o Section 38 - HP 7978A/B Selftests

ADDITIONAL SECTIONS AVAILABLE

- o Section 10 - Set Tape Density Commands
- o Section 15 - Write/Read Comparison Check (NRZI or GCR)
- o Section 16 - Write/Read Comparison Check (PE)
- o Section 20 - Selectable Tape Movement Commands
- o Section 23 - Selectable Tape Read Data Commands
- o Section 25 - Paces

Diagnostics

- o Section 45 - Download Diagnostics
- o Section 60 - Interactive Section
- o Section 62 - Do All Tests

| |
|-------------|
| NOTE |
|-------------|

For MPE-XL, the default magtape LDEV parameter is 7. For HP-UX, no default magtape device parameter exists.

5. Type EXIT and control will return to the Online Diagnostic System as soon as all requested steps are complete.

For a list of error messages that may appear when using DIAG7478, refer to Section 4 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

Ciper Line Printer Diagnostic (CIPERLPD)

The Control messages for Intelligent Peripherals (CIPER) Diagnostic will test an HP 2563A or HP 2565A/66A Line Printer to detect failures of a Field Replaceable Unit (FRU). The CE can:

- Specify which sections and steps are to be run.
- Set test parameters to control the handling of error messages.
- Select the number of test executions and the particular CIPER Line Printer unit to be tested.

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI > RUN CIPERLPD <RUN Command Options>
```

Enter **HELP** to display a summary of the available **RUN** commands. Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details.

3. The diagnostic responds with a header and welcome message.

If specific sections and steps are not specified, the following default sections and steps will be executed:

| |
|-------------|
| NOTE |
|-------------|

The CIPER device to be tested must be powered up and put online to ensure proper completion of all sections and steps.

DEFAULT SECTIONS

- o Section 2 - Reset
- o Section 3 - Clear/Identify
- o Section 5 - Selftest
- o Section 6 - Request Device Status (all steps)

ADDITIONAL SECTIONS AVAILABLE

- o Section 10 - Ripple Print
- o Section 12 - Request and Decode Environmental Status
- o Section 14 - Request and Decode Job Status

4. To exit CIPERLPD, type **EXIT** and control will return to the DUI upon completion of the current section and step.

For a list of error messages which may appear using CIPERLPD, refer to Section 5 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

Page Printer Diagnostic (PPDIAG)

The Page Printer Diagnostic (PPDIAG) tests the HP 2680A or HP 2688A Page Printer to detect failures of Field Replaceable Units (FRUs). The Page Printer Diagnostic program can be invoked by the I/O system on catastrophic errors for auto-diagnostic purposes. Only MPE-XL operating systems have auto-diagnostic capability.

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI> RUN PPDIAG <RUN Command Options>
```

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

| |
|-------------|
| NOTE |
|-------------|

The Page Printer to be tested must be powered up and put online to ensure proper completion of all sections and steps.

If specific sections and steps are not specified, the default sections and steps will be executed.

DEFAULT SECTIONS

Section 2 - Clear
Section 3 - Identify
Section 4 - Loopback
Section 5 - Selftest
Section 20 - Pattern Print

ADDITIONAL SECTIONS AVAILABLE

Section 6 - Display I/O Status
Section 8 - Display Environmental Status
Section 50 - Simulate Panel (HP 2680 only)

4. To exit PPDIAG type EXIT. Control will return to the DUI upon completion of the current section and step. A description of PPDIAG and all sections contained within are available through the DUI HELP facility.

For a list of warning and error messages that may appear when using PPDIAG, refer to Section 6 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

AFI Device Adapter Diagnostic (AFIDAD)

The AFI Device Adapter Diagnostic (Asynchronous FIFO Interface Device Diagnostic, AFIDAD) will test the HP 27114A AFL. This diagnostic runs on the HP 9000 Series 800 Computer System.

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
```

```
./USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI> RUN AFIDAD <RUN Command Options>
```

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If sections to be run are not specified, the default sections will be executed.

DEFAULT SECTION

- o Section 3 - Identify

4. To exit AFIDAD, type EXIT.

HP-IB Device Adapter Diagnostic (HPIBDIAG)

The HP-IB Device Adapter Diagnostic (HPIBDIAG) is a diagnostic system program that provides the capability to test online the functionality of the HP-IB Device Adapter, which is itself a Field Replaceable Unit (FRU).

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)  
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI> RUN HPIBDIAG <RUN Command Options>
```

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If specific sections and steps are not specified, the default sections and steps will be executed based on the following diagnostic system modes:

DEFAULT SECTIONS

- o Section 3 - Identify
- o Section 4 - Loopback
- o Section 5 - Selftest

ADDITIONAL SECTIONS AVAILABLE

- o Section 6 - Request Status
- o Section 12 - Rollcall

4. To exit HPIBDIAG type EXIT. Control will return to the Online Diagnostic System.

For a list of error messages that may appear when using HPIBDIAG refer to Section 9 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

HP-FL Device Adapter Diagnostic (HPFLDIAG)

The HP-FL Device Adapter Diagnostic (HPFLDIAG) is a diagnostic system program that provides the capability for online testing of the Device Adapter, which is itself a Field Replaceable Unit (FRU).

Mini-Operating Instructions

1. Enter the following to the system prompt:

```
SYSDIAG (MPE-XL)  
  
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following to the DUI prompt:

```
DUI> RUN HPFLDIAG < RUN Command Options >
```

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If sections and steps to be run are not specified, the default sections and steps will be executed. The default sections are Sections 10 and 11.

DEFAULT SECTIONS

- o Section 10 - Verification Trouble Tree
- o Section 11 - Diagnostic Trouble Tree

4. To exit HPFLDIAG, type EXIT. Control will return to the Online Diagnostic System.

Memory Array Diagnostic (MAD)

The Memory Array Diagnostic (MAD) tests and verifies the memory controllers and memory arrays online from the System Console or a remote maintenance terminal.

The Memory Array Diagnostic provides three diagnostic functions and one verifier function. The diagnostic functions consist of a total pattern test of memory, a partial pattern test of memory, and an interactive section.

Mini-Operating Instructions

1. Enter the following commands:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. `DUI > RUN MAD <RUN Command Options>`

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If specific sections and steps are not specified, the following default sections and steps are executed based on the diagnostic mode which has been selected by the Online subsystem. Refer to the Online Overview discussion of diagnostic modes in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details.

SECTIONS AVAILABLE

- o Section 10 - Full Automatic Memory Test (all steps)
- o Section 11 - Partial Automatic Memory Test (all steps)
- o Section 13 - User Interactive Testing (all steps)

4. To exit MAD type EXIT. Control will return to the Online Diagnostic System.

For a list of error messages that may appear when using MAD, refer to Section 10 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

Six-Channel MUX Diagnostic (MUXDIAG)

The Asynchronous Six-Channel Multiplexer Diagnostic (MUXDIAG) is a diagnostic subsystem program that checks the functionality of the HP 27140A Asynchronous Six-Channel Multiplexer Interface card, which is itself a Field Replaceable Unit (FRU).

Minimum Configuration

The hardware required to run the diagnostic is different for the MPE-XL or HP-UX operating system.

When running the HP-UX operating system, ensure that the following hardware is present:

- At least two MUX (6 channel) cards for running the diagnostic from a terminal attached to one card to test the other card.
- A System Console to run diagnostics for the other MUX card.

When running the MPE-XL operating system, ensure that the following hardware is present:

- One MUX card (6 channel).
- A configured and functional LAN system.
- A configured and functional Distributed Terminal Control (DTC) system.

Mini-Operating Instructions

1. Enter the following command:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

Typing HELP to the prompt will display a summary of the available RUN commands. Refer to Section 11 in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for details concerning these RUN command options.

2. Enter the following to the DUI prompt:

```
DUI1> MODE SUM           Go into Single User Mode
Single User Mode (SUM)   Displayed by SYSDIAG
DUI2> RUN MUXDIAG dev=/dev/diag/mux* <RUN Command Options>
```

| |
|-------------|
| NOTE |
|-------------|

When running MUXDIAG under HP-UX, it is recommended to specify an output file to which all diagnostic messages can be sent for determining if the MUX card needs to be replaced.

Diagnostics

3. The diagnostic will respond with a header and welcome message.

If specific sections and steps are not specified, the default sections and steps will be executed based on the following diagnostic system modes:

DEFAULT SECTIONS

- o Section 1 - State
- o Section 3 - Identify
- o Section 4 - Loopback

ADDITIONAL SECTIONS AVAILABLE

- o Section 2 - Clear
- o Section 5 - Selftest
- o Section 10 - Write/Read

4. To exit MUXDIAG type EXIT.

For a list of explanations of error messages that may be generated by MUXDIAG, refer to Section 11 in the Online Diagnostics Subsystem Manual, P/N 09740-90020.

Local Area Network Device Adapter Diagnostic (LANDAD)

The Local Area Network Device Adapter Diagnostic (LANDAD) tests HP 36921A LAN Links (used on HP 3000/930 Computer Systems) and HP 98194A LAN Links (used on HP 9000/840 Computer Systems). LANDAD is capable of detecting a failure in one or more Field Replaceable Unit (FRU). An FRU for LANDAD is the LAN interface card (LANIC), the LANIC connector cable, the attachment unit interface (AUI) cable, the medium attachment unit (MAU), and the medium interface (MDI).

Mini-Operating Instructions

Refer to Section 12 of the Online Diagnostics Subsystem Manual, P/N 09740-90020, for detailed explanations for running the diagnostics below.

1. Enter the following command to the system prompt.

```
SYSDIAG (MPE-XL)
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

```
*****
****                               ****
****      ONLINE DIAGNOSTIC SUBSYSTEM      ****
****      (c) Hewlett-Packard Company 1986      ****
****              Version x.yy              ****
****                               ****
*****
```

2. Enter the following command to the DUI prompt:

```
DUI 1> RUN LANDAD PDEV=8.4
      (where PDEV is the physical device number. The first digit is the Midbus
      number (usually 8) and the second digit is the CIB slot number in which LANIC
      is located.)
```

3. The diagnostic responds with a header and welcome message.

The diagnostic will request a routine which allocates the LANIC and displays the following sections which can be run:

```
DEFAULT SECTIONS
o Section 3 - Identify
o Section 4 - Local Loopback (to LANIC and back)
o Section 6 - Status
```

```
ADDITIONAL SECTIONS AVAILABLE
o Section 1 - More Help
o Section 2 - Reset
o Section 5 - Selftest
o Section 7 - Link Statistics
```

Diagnostics

- o Section 8 - External Loopback
- o Section 9 - Remote Node Test
- o Section 10 - Remote XID Test
- o Section 11 - AUI Cable Fault Isolation Test
- o Section 12 - Offline MAU Test

CAUTION

For MPE-XL, never abort LANDAD when Sections 3, 4, 9, or 10 are specified. This can cause the diagnostic to lose functionality the next time the diagnostic is run.

4. To access the HELP facility for LANDAD, enter HELP to the DUI prompt. The HELP messages are described in Section 12 of the Online Diagnostics Subsystem Manual, P/N 09740-90020.

LANDAD is not an interactive diagnostic, and contains no user accessible commands.

5. Type EXIT to terminate the LANDAD diagnostic. Control will return to the Online Diagnostic System.

I/O Test Tool (IOTT)

The I/O Test Tool (IOTT) is a utility intended for online diagnosis of I/O related problems from any system terminal. Numerous commands, instructions, and program statements are available as inputs through I/O Test Tool.

Mini-Operating Instructions

Before attempting to run the utility, ensure that the user has diagnostic level 0 security as described in the Online Diagnostics Subsystem Utilities Manual, P/N 09740-90021.

1. Enter the following command to the MPE-XL prompt:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI> RUN IOTT <RUN Command Options>
```

Refer to the Section on DUI for details concerning the RUN command options and the detailed IOTT command options in this section.

3. The diagnostic responds with a header and welcome message.

Once the I/O Test Tool is invoked, the following message will be displayed indicating an input request:

```
IOTT>
```

The four categories of input commands and the five categories of input Buffer Manipulation Instructions available for I/O Test Tool are provided in this section.

4. To exit IOTT type EXIT. Control will return to the Online Diagnostic System as shown by the appearance of the DUI prompt:

```
DUI>
```

For information on error messages that may appear when using IOTT, refer to Section 5 in the Online Diagnostics Subsystem Utilities Manual, P/N 09740-90021.

COMMAND SUMMARY

The four categories of input commands available with IOTT are listed as follows:

Control Commands (CC)

The following commands are used to control the current execution mode of I/O Test Tool:

```
ABORT  
EXIT
```

Diagnostics

```
RESUME
RUN[count]
SUSPEND
```

User Program File Commands (UPFC)

The following commands are available to utilize user program files:

```
LOAD (filename)
PURGE (filename)
SAVE (filename)
SHOWFILE [file specifier string]
```

Program Editing Commands (PEC)

The following commands can be used to manipulate the contents of the Program Storage Area:

```
DELETE [linenumber]
DELETE [linenumber]/[linenumber]
DELETE ALL
LIST [linenumber]
MODIFY [linenumber]
MOVE [linenumber]/[linenumber] TO [linenumber]
MOVE [linenumber] TO [linenumber]
RENUMBER [value]
```

Miscellaneous Commands (MC)

The following commands are available for general use:

```
HELP [command, instruction, or statement name][:SYNTAX]
REDO
```

INSTRUCTION SUMMARY

The five categories of input Buffer Manipulation Instructions available for IOTT are as follows:

Test Environment Instructions (TEI)

The following instructions are used to set the environment for the use of I/O Test Tool:

```
ERRPAUSE ON
ERRPAUSE OFF
RELDEVICE LDEV=[ldev]
RELDEVICE PDEV=[pdev]
SETDEVICE LDEV=[logical device number]
SETDEVICE PDEV=[CA#][.DA#][.Device#][.Unit#]]
SETTIMER (value)
SHOWDEV
```

Buffer Manipulation Instructions (BMI)

Buffer function instructions provide the availability to fill, modify, and display data which was used for the I/O request. The two types of buffers used are integer buffers (32-bit entities) and byte buffers (8-bit entities). For functions which involve two buffers, both buffers must be of the same type. The available instructions are:

```

ADJBUFF [buffer name]([index]),[value],[count]
ALTBUFF [buffer name]([index]),[value],[value]
ALTBUFF [buffer name]([index]),"ascii text"
COMPBUFF [buffer]([index]),[buffer]([index]),[length],[count]
        [diff
         similar]:[display mode]
COPYBUFF {buffer}({index}},{buffer}({index}},{length}],[count]
DBUFF {buffer name} [:display mode]
DBUFF {buffer name} [index] [:display mode]
DBUFF {buffer name} [index/index] [:display mode]
DEFBUFF {buffer name},{length},{BYTE} [:STATUS]
DEFBUFF {buffer name},{length},{WORD} [:STATUS]
FILLBUFF [buffer]([index]),[value],[count]
FINCBUFF {buffer name}({index}},{start},{end}[,inc]
RELBUFF {buffer name}
SHOWBUFF

```

Predefined I/O Request Instructions (PIORI)

The following instructions give all information needed for the predefined I/O request:

```

ABORTIO
EINCADDR {value}
EXECUTE {function}[,count][: UNBLOCK]
DSTATUS
INCADDR {value}
RESETIO
SETADDR CLY={cylinder};HEAD={head};SECT={sect}
SETADDR {value}
SETDATA {buffer},{length}
SETOPTION {option}[,option]
SHOWPARAM

```

HP-IB Device Adapter Program Instructions (HPIBPI)

I/O Test Tool provides instructions for creating unique HP-IB device adapter programs. This allows more control over the protocol between the HP-IB device adapter and a peripheral device. The instructions available are as follows:

```

{line number} CASEJUMP {value},{line number}[,line number]
CLEAR {value}
{line number} CRCCOMP {line number}
CRCINIT
CRCWRITE
{line number} DSJ {sindex},{line number}[,line number],[line number]

```


Diagnostics

```
ENDHPIB
HALT {status length},{hstat}
IDENTIFY {sindex}
{line number} JUMP {line number}
ONTIMEOUT [timeout],[sindex],[line number]
PINDEX {value}
RBURST {secondary},{buffer name},{length},{#burst},{burstlen}
RDATA {secondary},{sindex},{length}
RDMA {secondary},{buffer name},{length}
SETHPIB
SHOWHPIB [:display mode]
TIMEOUTOFF
TIMESTAMP {sindex}
UNLOCK
WAITPOLL [:nobreak]
WBURST {secondary},{buffer name},{length},{#burst}[:eoi]
WDATA {secondary},{buffer name},{length}[:eoi]
WDMA {secondary},{buffer name},{length}[:eoi]
WINTERF {buffer name},{length}
```

For further information on HP-IB Device Adapter Programs, refer to the HP 27110B CIO/HP-IB Interface Card Technical Reference and Programming Manual, P/N 27110-90005.

HP-CIO DMA Chain Instructions (HPCIOI)

I/O Test Tool provides the following instructions to control the protocol across the HP-CIO:

```
ADDQUAD {order ID},{buffer name},{length}[:hpcio optional]
ADDQUAD {cmd value},{buffer name},{length}
ENDHPCIO
SETHPCIO
SHOWHPCIO [:display mode]
```

PROGRAM STATEMENT SUMMARY

The following are program command statements available in IOTT:

```
COMMENT
DO-LOOPTO
GOTO
IF-THEN/IFN-THEN
PAUSE
PRINT
STOP
```

CIO Channel Adapter Diagnostic (CADIAG)

The CIO Channel Adapter Diagnostic (CADIAG) is a Diagnostic subsystem program providing capability to test online the functionality of the CIO Channel Adapter, which is itself a Field Replaceable Unit (FRU).

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI > RUN CADIAG <RUN Command Options>
```

Refer to the DUI section in the Online Diagnostics Subsystem Manual, P/N 09740-90020 for details concerning the RUN command options.

3. The diagnostic responds with a header and welcome message.

If the sections and steps to be run aren't specified, the following default sections and steps will be executed:

DEFAULT SECTIONS

- o Section 3 - Identify
- o Section 5 - Selftest
- o Section 6 - Request Status
- o Section 8 - Description

ADDITIONAL SECTIONS AVAILABLE

- o Section 9 - Rollicall
- o Section 10 - Subchannel Hardware Status

Enter HELP to provide a summary of the DUI commands to be printed.

4. Type EXIT to exit CADIAG and control will return to the Online Diagnostic System.

Refer to Section 8 in the Online Diagnostics Subsystem Manual, P/N 09740-90020, for a list of error messages which may appear when using CADIAG.

Diagnostics

HP98720A Graphics Processor Diagnostic (GP3DDIAG)

The HP98720A Diagnostic (HPFLDIAG) will test the HP98720A Graphics Display Station.

Mini-Operating Instructions

1. Enter the following to the system prompt:

SYSDIAG (MPE-XL)

/USR/DIAG/BIN/SYSDIAG (HP-UX)

2. Enter the following to the DUI prompt:

DUI> RUN GP3DDIAG < RUN Command Options >

Refer to the DUI section for details concerning RUN command options. The diagnostic responds with a header and welcome message. If the user does specify which section to run, then the default is "all".

Because some sections may be either disruptive or destructive, the diagnostic subsystem will grant the highest mode available based on the user's security level. Only those users with level 1 or 0 security will be able to execute all default sections.

3. When the specified/default sections have been completed, the diagnostic terminates and the following prompt is displayed:

DUI>

4. To exit the DUI, type EXIT. Control will return to the Online Diagnostic System.

System and Memory Log Analysis Tool (LOGTOOL)

The system and memory log analysis tool (LOGTOOL) provides capability to perform various operations on the system log files. Error logs may be identified, deleted, and created. Timing intervals for background log analysis may be displayed and reset.

Mini-Operating Instructions

1. Enter the following command:

```
SYSDIAG (MPE-XL)
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI > run logtool
```

3. The utility responds with a header and welcome message.

Refer to the detailed LOGTOOL command explanations in the Online Diagnostics Subsystem Utilities Manual, P/N 09740-90021, for more details. Once LOGTOOL has been invoked the following prompt will be displayed indicating an input request:

```
LOGTOOL >
```

4. Respond by entering a logtool command along with any necessary data, parameter(s), or options. Entering HELP will access the logtool HELP facility and display a complete list of logtool commands.

The four categories of input commands available are:

- System Log File Commands (SFL).
- Memory Log File Commands (MLF).
- Miscellaneous Commands (MC).

The following commands listed with their command category are available in LOGTOOL:

| | |
|-----------------|-------------------|
| DISPLAYLOG (MC) | PURGESYSLOG (SLF) |
| EXIT (MC) | PURGEWORK (SLF) |
| HELP (MC) | REDO (MC) |
| LAYOUT (SLF) | SELECT (SLF) |
| LIST (SLF) | STATUS (SLF) |
| MEMCLR (MLF) | SUSPEND (MC) |
| MEMRPT (MLF) | SWITCHLOG (SLF) |
| MENTIMER (MLF) | TYPES (SLF) |

5. Type EXIT to leave the HELP facility or to terminate any current logtool process.

For a list of warning and error messages that may appear when using LOGTOOL, refer to the Online Diagnostics Subsystem Utilities Manual, P/N 09740-90021.

System Map (SYSMAP)

The System Map (SYSMAP) utility provides information concerning these three areas of the HP Precision Architecture Computer System: Input/Output System (IOMAP), Central Processing Unit(s) (CPUMAP), and System Memory (MEMMAP). Maps of these three areas are available only on the host system.

Mini-Operating Instructions

1. Enter the following command:

```
SYSDIAG (MPE-XL)  
  
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

2. Enter the following command to the DUI prompt:

```
DUI > run sysmap
```

3. The utility responds with a header and welcome message.

Refer to the command descriptions in the Online Diagnostics Subsystem Utilities Manual, P/N 09740-90021, for details of SYSMAP commands. SYSMAP has no RUN command options. Once SYSMAP has been invoked the following prompt is displayed indicating an input request:

```
ENTER MAP>
```

3. Typing HELP will cause SYSMAP to list a menu of the following global SYSMAP commands:

```
IOMAP  
CPUMAP  
MEMMAP  
CONFIRM (ON/OFF)  
TIMEOUT  
SUSPEND  
EXIT
```

Respond with one of the above six commands.

4. Type EXIT to terminate any current mapping process or to leave the HELP facility.

HP-UX Logging Facility

The HP-UX Logging Facility provides a means of obtaining and decoding Diagnostic Event Messages (DEMs). The acquisition of the event messages is handled by the HP-UX DELOG (Diagnostic Event Logger) program. To decode these messages, use the HP-UX DECODE (Diagnostic Event Decoder) program.

Mini-Operating Instructions

1. Enter the following command to the system prompt:

```
SYSDIAG (MPE-XL)
```

```
/USR/DIAG/BIN/SYSDIAG (HP-UX)
```

The system responds with a header and welcome message. Enter HELP for assistance.

```
DUI (n) >
```

2. Enter desired command by preceding each command entry with an exclamation point:

```
DUI (n) > ! delog or
```

```
DUI (n) > ! decode
```

Use the DELOG command when the altering operation of the Delog background log process daemon is desired. Use the DECODE command when decoding and displaying a particular Diagnostic Event Message (DEM).

3. Refer to the Online Diagnostics Subsystem Utilities Manual (P/N 09740-90021) for detailed operating instructions or explanations of DELOG and DECODE.
4. Type EXIT to terminate program or to leave the HELP facility.

MPE-XL Online Diagnostic Installer (DIAGINST)

The MPE-XL Online Diagnostic Installer (DIAGINST) utility permits online updating of the Online Diagnostic Subsystem and its directory. This utility will serve as a remote and onsite support tool.

Mini-Operating Instructions

1. Enter the following command to the MPE-XL prompt:

```
:run diaginst.diag.sys;lib=g
```

After the introductory message is displayed at initialization, the following main menu will be displayed:

Available Commands:

```
ADD
CORRECT
EXIT
LIST
REMOVE
SHOWMSG
SYSTEM
XCHECK
INSTALLATION TASK (select by command name) >
```

2. Enter HELP to any prompt for assistance on the use of this program. Another facility available is HELP "GENERAL/COMMANDS/HELP/RECOVER".
3. To leave this program, enter EXIT as displayed in the main menu of MPE-XL Online Diagnostic Installer.

For a list of warning or error messages that may appear when using the program, refer to the Online Diagnostics Subsystem Manual, P/N 09740-90020.

MPE-XL Online Diagnostic Implementation

The MPE-XL operating system has components and conditions specific for implementation of the Online Diagnostic Subsystem.

Implementation Dependent Information

| | |
|---------------------------------|------------------------------------|
| Maximum USE file nesting level: | 10 |
| Maximum processes per DUI: | 10 |
| User Interrupt Key: | Control Y |
| Command (REDO) Stack depth: | 5 |
| Input/Output Files: | 80 Character Records Unnumbered |
| Directory "path": | file.group.acct |
| Monitor Version: | xx.yy |

MPE-XL Specific Diagnostic Procedures/Features

Information concerning MPE-XL system tables and configuration can be found by referring to the MPE-XL System Configuration Manual, P/N 32650-90042.

HP-UX Online Diagnostic Implementation

The HP-UX operating system has components and conditions specific for implementation of the Online Diagnostic Subsystem.

Implementation Dependent Information

| | |
|---------------------------------|---------------------------|
| Maximum USE file nesting level: | 10 |
| Maximum processes per DUI: | System Dependent |
| User Interrupt Key: | Control C |
| Command (REDO) Stack depth: | 10 |
| Input/Output Files: | Character String (80 max) |
| Directory "path": | /dir/dir/.../file |
| Monitor Version: | n/a |

HP-UX Specific Diagnostic Procedures/Features

Information concerning HP-UX Online Diagnostic subsystem security, the Online Diagnostic subsystem directory tree, Diagnostic special files, and DUI permissions can be found by referring to the HP-UX System Administrator's Manual, P/N 92453-90004.

HP-UX SUPPORT TAPE

The support tape (P/N 92452-13503 on 1600 BPI tapes and P/N 92452-13303 on Linus cartridge tapes) provides capability to diagnose and fix problems when the HP-UX operating system cannot be booted from system disc. For information on the HP-UX file system to use the support tape, refer to the HP 9000/840 System Administrator's Manual, P/N 92453-90004.

The minimum hardware configuration to use the support tape is:

- 8 Mb memory.
- Console.
- Magtape drive.
- Input/output paths to the console and tape drive.

Booting Up

If the system has halted and cannot be booted from the system disc, then booting up from the support tape is necessary. The procedure is as follows:

1. Select a tape drive to boot from and determine the drive's physical address. (The default alternate path physical address is 8.2.3.)
2. Load support tape on tape drive and put drive online.
3. Press system reset button and wait about 30 seconds.
4. If autoboot is enabled, the following will appear on the console:

```
Autoboot from primary boot path enabled.
To override, press any key within 10 seconds.
```

When a console key is pressed, this prompt will appear on the console:

```
Boot from primary boot path (Y or N)?>
```

5. Respond by typing N to this prompt. The next prompt is:


```
Boot from alternate boot path (Y or N)?>
```
6. Respond to this prompt by typing Y if the support tape is loaded on the tape drive that corresponds to the alternate boot path.

Respond by typing N if the support tape is not loaded on the tape drive that corresponds to the alternate boot path and then the following prompt will appear:

```
Enter boot path, command or ?>
```

Respond by entering the physical address of the drive you loaded the support tape onto.

After the appropriate response is given, the tape should start spinning and the prompt ISL> will appear.

NOTE

If autoboot is not enabled, the previously listed sequence of prompts and responses will occur with one exception. The first prompt, which allows the primary boot path to be overridden, will not appear.

7. Enter the HP-UX command to the ISL> prompt. An example with the default physical device address is as shown:

```
ISL> hpx tape1(8.2.3;0xa0000,1)
```

The address field of this command is the only part that may vary, but the rest of the command is exactly as shown.

8. After the HP-UX command is entered, the appropriate files from the support tape are loaded and an input/output tree will be displayed followed by the message:

```
System needs more CIO channels?
```

The above message can be disregarded since there is usually always more CIO channels than exist on HP-UX systems.

9. After successfully booting, the tape will be positioned at the beginning of Section 1. A login prompt, which is `login:` will appear on the System Console. Log in as "root". The password is "support". After logging in, the Support Tape Main Menu will be displayed on the console.

Support Tape Main/Utilities Menus

The Support Tape Main Menu is used by typing a single character followed by a carriage return. If booting from the tape drive at address 8.2.3, any character may be selected. If booting from another address other than 8.2.3, the character "u" must be selected because the tape unit number must be changed to conform to the physical address of the tape drive. The tape unit number is determined by the physical address of the tape drive.

The Support Tape Main Menu is as follows:

- s. Search for file
- l. Load a file
- d. On-line Diagnostics
- h. Help
- u. Utilities
- x. Exit to shell

Tape is unit 0

The Support Tape Utilities Menu is as follows:

- c. Change tape unit number
- p. Try to resynchronize position on tape
- t. Table of contents of a tape section
- r. Return to previous menu
- x. Exit to the shell

Select one of the above:

For additional information regarding the Support Tape, refer to the Support Tape Users Manual, P/N 92453-90010.

ADJUSTMENTS

SECTION

6

This section contains procedures for power supply adjustments for the HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S Computer Systems.

Power Supply Removal/Replacement - Power Supply #1 6-2
Power Supply Removal/Replacement - Power Supplies #2 and #3 6-4



Power Supply Removal/Replacement – Power Supply #1

The following procedure describes how to remove power supply #1 from the left side of the card cage:

1. Turn off Main Power Breaker (located on the rear of cabinet).
2. Open front door and disconnect AC power cord from front of Power Supply #1. See Figure 6-1.
3. Remove the flat control panel cable from system monitor.
4. Remove four screws holding system monitor in place and slide the system monitor out one inch in its slides without disconnecting the attached cables.
5. Remove the four screws and lock washers holding power supply in place.
6. Grasp and pull power supply to slide out of cabinet on its guides.
7. Install new power supply module by reversing this procedure.

CAUTION

To prevent damage to the computer system and/or power supply, ensure power supply is fully seated in cabinet, without forcing it.

8. Reconnect AC power cord to Power Supply #1.
9. Turn on Main Power Breaker and check PS1 voltage test points (located on system monitor) for proper voltages. Refer to Table 4-8 (Troubleshooting, Section 4) for the power supply test points and their voltage specifications. If voltages are out of tolerance, replace the power supply again. No adjustments are required.
10. Verify that system performs a normal boot-up.




Figure 6-1. Location of Power Supplies

Power Supply Removal/Replacement – Power Supplies #2 and #3

The following procedure describes how to remove power supply #2 or #3 from the right side of the card cage:

1. Turn off Main Power Breaker (located on rear of cabinet).
2. Open front door and disconnect AC power cords from each power supply (#1, #2, and #3). See Figure 6-1.
3. Remove the eight mounting screws and lockwashers holding the RFI plate and power supplies in place.
4. Loosen the two captive, extruded, RFI plate mounting screws and use them to pull the RFI plate away from the power supplies.
5. Grasp and pull the applicable power supply handle to slide the power supply out of cabinet on its guides.
6. Install new power supply module by reversing this procedure, ensuring that the mounting screws are aligned before tightening.

CAUTION

To prevent damage to the system and/or power supplies, ensure each power supply is fully seated in cabinet, without forcing it.

7. Reconnect AC power cords to all of the power supplies.
8. Turn on Main Power Breaker and check PS2 or PS3 voltage test points (located on system monitor) for proper voltages. Refer to Table 4-8 (Troubleshooting, Section 4) for the power supply test points and their voltage specifications. If voltages are out of tolerance, replace applicable power supply again. No adjustments are required.
9. Verify that system performs a normal boot-up.

PERIPHERALS

SECTION

7

This section describes the devices supported on the HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S Computer Systems.

| | |
|---|-----|
| Supported Peripheral Devices | 7-2 |
| General Information | 7-2 |
| MPE-XL/HP-UX Default Device Configuration | 7-2 |
| Distributed Terminal Device (DTC) | 7-4 |



Peripherals

SUPPORTED PERIPHERAL DEVICES

The types of peripherals supported by the SPU are terminals, printers, disc drives, mag tapes, and other devices. Additional information on specific peripherals supported by the SPU can be found in the Site Preparation and Requirements Guide, P/N 09740-90018, or the Installation and Configuration Guide, P/N 09740-90019. To install and verify the system peripherals, refer to the individual manuals supplied with the equipment.

General Information

The peripheral devices supported by the SPU use the following guidelines:

- Spacing between adjacent HP-IB/HP-FL devices on the same HP-IB/HP-FL cable must not exceed one meter (for disc drives) to two meters.
- Total cable length must not exceed 20 meters (15 meters for high speed devices) with appropriate loading.

MPE-XL/HP-UX Default Device Configuration

Default device configuration for MPE-XL and HP-UX supported peripherals are represented in Tables 7-1 and 7-2.

Table 7-1. MPE-XL Default Device Configuration

| LDEV# | I/O-PATH | CLASS NAME |
|-------|----------|-----------------------|
| 1 | 8.0.0 | DISC; SPOOL |
| 20 | 8.1.0 | CONSOLE |
| 6 | 16.3.4 | LP; (SYSTEM PTR) |
| 7 | 16.3.0 | TAPE; DDUMP (PRIMARY) |
| 10 | 16.3.7 | JOBTAPE |

NOTE

During the MPE-XL "install" process, the I/O. paths are critical for successful booting.

Table 7-2. HP-UX Default Device Configuration

| LU# | I/O-PATH | CLASS NAME |
|-----|----------|--------------|
| 0 | 8.0.0 | DISC |
| 1 | 8.0.1 | DISC |
| 2 | 8.0.2 | DISC |
| 3 | 8.0.3 | DISC |
| 0 | 8.1.0 | MUX (6 PORT) |
| 1 | 8.2.0 | PRINTER |
| 0 | 8.2.1 | PRINTER |
| 1 | 16.3.0 | TAPE |
| 0 | 16.3.4 | TAPE |
| 2 | 8.2.5 | TAPE |
| 0 | 8.2.7 | INSTRUMENT |
| 1 | 8.3.0 | MUX |
| 0 | 8.4.0 | LAN |
| 0 | 8.5.0 | GPIO |
| 4 | 8.6.0 | DISC |
| 5 | 8.6.1 | DISC |
| 6 | 8.6.2 | DISC |
| 7 | 8.6.3 | DISC |
| 2 | 8.7.1 | PRINTER |
| 3 | 8.7.2 | TAPE |
| 4 | 8.7.3 | TAPE |
| 1 | 8.7.7 | INSTRUMENT |
| 2 | 8.8.0 | MUX |
| 3 | 8.9.0 | MUX |
| 4 | 8.10.0 | MUX |
| 5 | 8.11.0 | MUX |
| 1 | 8.12.0 | ACCESS PORT |

Distributed Terminal Controller (DTC)

General Installation Information

The HP 2345A Distributed Terminal Controller (DTC) is only for MPE-XL supported computer systems. The HP 32480A and HP 19747B are equipped to support installation of DTC's. The DTC is mounted inside the Expansion Bay cabinet to allow multiple asynchronous workstations to communicate with the HP 3000/930 host computer system via any one connection point on an IEEE S02.3 Local Area Network (LAN) cable.

The DTC is delivered with all of the ordered options already fitted inside. For the hardware installation summary, refer to Installation in the DTC HP2345A Distributed Terminal Controller Installation and Service Manual, Part Number 02345-90001.

DTC Installation in the Expansion Bay Cabinet

Installation of the HP 2345A Distributed Terminal Controller into the Expansion Bay cabinet assumes the slide racks are in the required position in the cabinet. The procedure is as follows:

1. Unpack the HP 2345A from the shipping carton and inspect to ensure that it is not damaged. If the DTC is damaged, then do not install it. Have the customer notify the carrier and the nearest Hewlett-Packard office immediately. Retain the shipping carton and packing material for inspection by the carrier.
2. Before sliding the DTC into the slide repack, remove the two (2) shipping screws located on the Internal Protective Metal Plate. See Figure 7-1.
3. Loosen the four (4) captive screws on the Internal Protective Metal Plate to remove from the DTC, then slide DTC into rack through the front of the Expansion Bay cabinet. See Figure 7-1.

NOTE

A list of error codes associated with the DTC are referenced on the inside of the front panel. Also, make note of the LAN address, called the Nodal address, for later configuration using the NMMGR program.

4. Return the Internal Metal Plate to the DTC and tighten with the four (4) captive screws.
5. Connect the LAN, workstation and modem cables to the rear of the DTC. The peripheral cables from each Connector card in the DTC are routed alternatively to the left and to the right and draped around the cable management racks that are

attached to the support rails in the Expansion Bay cabinet. Route the cables between the support rails and the side panels to the base and down through the cabinet base cut-out, as shown in Figure 7-1 and Figure 7-2. Connect cables to applicable peripherals.





Figure 7-1. DTC Internal Protective Plate (Front View)

Peripherals



LG200050_004

Figure 7-2. DTC Internal Protective Plate (Rear View)



NOTE

On each Connector Card, all cables must be tied together and aligned horizontally to go through the cable management racks. Access to the Connector cards and the Processor card is then easily attained.

6. Connect the power cord to the PDU labeled for use of the HP 2345A DTCs, only (located inside the lower rear of the Expansion Bay cabinet). See Figure 7-2.
7. Switch the power switch, located on the rear left corner of the DTC, on ON. (It is not required to connect the workstations to the DTC before the DTC is powered up.) Installation of DTC hardware is completed.

DTC Selftest

The self-test routine is stored within DTC firmware. It checks the functional operation of all major DTC hardware components, including the LAN connection. The selftest is performed automatically when the DTC is powered on.

The DTC displays the results of the selftest on the two-digit hexadecimal display in the lower front left corner of the DTC. Refer to the label inside the Internal Metal Plate for a summary of the selftest sequence and appropriate error codes.

Successful completion of selftest assumes that there are no problems with the DTC hardware and that all LAN connections are good. The workstation/modem connections are not tested during the selftest. Refer to the DTC HP2345A Distributed Terminal Controller Installation and Service Manual, Part Number 02345-90001, for diagnostic programs, troubleshooting, and additional DTC related information.

Software Installation

Once the selftest has successfully completed, the host computer will start to download the software into the DTC. Once the download is complete, then the DTC is ready for normal operator.

The Distributed Terminal Subsystem (DTS) software should be configured first on the host computer, using the NMMGR program, for the software download to take place. Refer to the ASC System Administrators Reference Manual, Part Number 32022-90001, for information on the standard Fundamental Operating System that must be installed into the system.

REPLACEABLE PARTS

SECTION

8

The Replaceable Parts Catalog provides illustrations and parts lists to assist the user in locating replaceable assemblies for the HP 3000 Series 900 Model 930 and HP 9000 Series 800 Model 840S Computer Systems. The catalog contains part number data for the Customer Engineer (CE) when parts replacement is necessary.

Replaceable Parts Catalog 8-7







Figure 8-1. SPU, Front View
8-3

Replaceable Parts



- * Legend
 (1) - Refer to Table 8-1, (1 of 2)
 (2) - Refer to Table 8-2, (1 of 2)
 (3) - Refer to Table 8-2, (2 of 2)



REPLACEABLE PARTS CATALOG

The replaceable parts catalog is organized in the order of Exchange Parts and Non-Exchange Parts. Each system diagram (exploded view) shown in Figures 8-1 and 8-2, contains a legend that represents parts listed in Tables 8-1 and 8-2.

Table 8-1. Exchange Parts

| HP PART NO. | HP PART NO. (EXCHANGE) | DESCRIPTION |
|-------------|---------------------------|--|
| 09740-60101 | 09740-69511 | PCA-RGSTR File (CPU Register File Unit) |
| 09740-61701 | 09740-69671 | PCA-E Unit (CPU Execution Unit) |
| 09740-60301 | 09740-69531 | PCA-I Unit (CPU Instruction Unit) |
| 09740-61501 | 09740-69651 | PCA-TLB (CPU Translation Lookaside Buffer) |
| 09740-61602 | 09740-69662 | PCA-CACHE (CPU Cache) |
| 09740-60603 | 09740-69563 | PCA-CIOA MB (Channel I/O, C1) |
| 09740-60707 | 09740-69577 | PCA-CIOA CIO (Channel I/O, C2) |
| 09740-60905 | 09740-69595 | PCA-SYS MONITOR (System Monitor) |
| 09740-61001 | 09740-69601 | PCA-3MB Memory Controller |
| 19741-60001 | 19741-69001 | PCA-5MB Memory Array |
| 19730-60001 | 19730-69001 | PCA-12MB Memory Controller |
| 19731-60001 | 19731-69001 | PCA-20MB Memory Array |
| 19742-60004 | 19742-69004 | PCA-Floating Pt (CPU Floating Point Coprocessor) |
| 5061-2537 | 5061-2541 | PCA-AP (CIO Access Port) |
| 0950-1788 | 0950-1806 | Assy - Power Supply, 300 Watt |

NOTE

All exchange assemblies include ROMs. The ROMs will only be changed as part of update procedures.

Replaceable Parts

Table 8-2. Non-Exchange Parts (1 of 2)

| HP PART NO. | DESCRIPTION |
|-------------|---|
| 09740-60010 | Cable, PDU - Transformer |
| 09740-60015 | CA-CNTRL PANEL (INT/EXT Display) |
| 09740-60017 | CA-SYS MON, CNTRL (System Monitor, Control) |
| 09740-60018 | CA-SYS MON, BATT (System Monitor Battery Cable) |
| 09740-60019 | CA-SYS MON, PDU (System Monitor, PDU) |
| 09740-60024 | CA-CHAN ADAPT A, Channel Adapter A Cable |
| 09740-60025 | CA-CHAN ADAPT B, Channel Adapter B Cable |
| 09740-60803 | PCA-CIO Buffer (Channel I/O, C3) |
| 09740-61101 | PCA-Display Board, External |
| 09740-61202 | PCA-Display Board, Internal |
| 19746-60003 | SM, Config Board (Exp. Module) |
| 19746-60010 | Cable, CIO Buffer |
| 8120-4859 | AP CBL ASYM.LEGS (Access Port Cable) |

Table 8-2. Non-Exchange Parts (2 of 2)

| HP PART NO. | DESCRIPTION |
|-------------|--|
| 1390-0345 | Key, SPU Cabinet |
| 1390-0741 | Lock, door |
| 1420-0341 | Battery - Lithium |
| 2110-0051 | Fuse 10A SB, Power Supply |
| 3105-0209 | CKT BKR - 5 AMP (Fan Circuit Breaker) |
| 3105-0208 | CKT BKR - 15 AMP (Battery Circuit Breaker) |
| 3105-0228 | CKT BKR - .025 AMP (Exp. Bay PDU) |
| 3150-0504 | Filter, Air |
| 3160-0478 | Fan, AC |
| 9100-4177 | XFMR-ISLN (Isolation Transformer) |
| 09740-00027 | Door, Front CPU |
| 09740-00029 | Door, I/O Mid-Bus |
| 09740-00030 | Door, CIO Upper |
| 09740-00031 | Door, Memory Mid-Bus |
| 09740-00041 | Front Cover, PDU |
| 09740-00042 | Panel Cover, PDU |
| 09740-00049 | Cover, Power Supply |
| 09740-00051 | Door, CIO Lower |
| 09740-40002 | Panel, Control |
| 09740-60003 | Assy - Card Cage |
| 09740-60005 | Assy - Fan Tray |
| 09740-60007 | BATT 10V, 10AH (Battery Assembly) |
| 09740-60008 | Assy - PDU (Power Distribution Unit) |
| 09740-60012 | Assy - Door, Front |
| 09740-60020 | Ribbon Cable, CIO |
| 09740-60041 | Assy - Door, Rear |
| 09740-60042 | Backplane |
| 09740-61401 | TTL SPU CAB (SPU Cabinet Bay Assembly) |
| 19743-60001 | Parallel Card |
| 19746-00008 | Door, CIO |
| 19747-60003 | Assy - PDU (Exp. Module) |
| 19747-60005 | Assy - Expandr Cbnt |
| 19747-60010 | Cable Assy |
| 19770-67901 | Service Kit |
| 19771-67801 | Cable Kit |

NOTE

If the transformer fails, it is recommended that the SPU Cabinet Bay Assembly (P/N 09740-61401) be replaced.

Replaceable Parts

Table 8-3. CIO Expansion Bay/Module, Replaceable Parts

| Quantity | HP Part Number | Description |
|----------|----------------|----------------------------|
| Ref. | 19747A | CIO Expansion Bay |
| | 19747B | Expansion Bay w/DTC |
| | 19746A | CIO Expansion Module |
| | 19746B | Technical Expansion Bundle |
| | 19778C | CIO Expander, Misc. |
| | 19744A | TTL Channel Adapter Set |
| 1 | 0515-0928 | Scr-Mach M5X.8 |
| 1 | 0515-1655 | Screw Assy M4X0.7 |
| 1 | 0515-1724 | Screw-Cap |
| 1 | 0535-0093 | Nut |
| 1 | 2190-0647 | Wsh-Lk Ext T-B |
| 1 | 2510-0041 | Mach Scr, 8-32 |
| 1 | 3050-0139 | Flat Washer, #8 |
| 1 | 8120-4882 | CA, AC Power |
| 1 | 09740-00050 | Plate-Striker, Fr |
| 1 | 09740-00052 | Hinge, Front |
| 1 | 09740-40002 | Molded Control Panel |
| 1 | 09740-60011 | Assy-Door, Rear |
| 1 | 09740-60012 | Assy-Door, Front |
| 1 | 12679-20001 | Support Angle |
| 1 | 19746-00001 | Pwr Sup Guide Bracket |
| 1 | 19746-00002 | Switch Box |
| 1 | 19746-00003 | Fan Plate |
| 1 | 19746-00004 | U-Channel |
| 1 | 19746-00005 | Brkt-Config. |
| 1 | 19746-00006 | Card Cage |
| 1 | 19746-00007 | Mounting Bracket |
| 1 | 19746-00010 | Door, Fan |
| 1 | 19746-00011 | Bottom Plate |
| 1 | 19746-00012 | Top Cover |
| 1 | 19746-00016 | Door, CIO |
| 1 | 19746-60001 | PCA, Backplane |
| 1 | 19746-60002 | PCA-Display, Int |
| 1 | 19746-60003 | PCA-SM/Config |
| 1 | 19746-60004 | CA-Pwr Sup Backplane |
| 1 | 19746-60005 | CA-Int/Ext CP |
| 1 | 19746-60006 | CA-Fan |
| 1 | 19746-60007 | CA-AC Switch |
| 1 | 19746-60008 | CA-Backland/Control Panel |
| 1 | 19746-60009 | CA-Pwr Sup Shutdown |
| 1 | 19746-60010 | CA-Channel Buffer |
| 1 | 19746-60011 | Assy. Module |

Table 8-3. CIO Expansion Bay/Module, Replaceable Parts (cont.)

| Quantity | HP Part Number | Description |
|----------|----------------|-----------------------|
| 1 | 19747-00001 | Separator Plate |
| 1 | 19747-00002 | PDU Outlet Panel |
| 1 | 19747-00003 | PDU Bottom Panel |
| 1 | 19747-00004 | PDU Front Panel |
| 1 | 19747-00005 | PDU Side Panel |
| 1 | 19747-00006 | Rail Support |
| 1 | 19747-00008 | Guide-Cbl, Base |
| 1 | 19747-00019 | BKT-Fan Door/Pwr |
| 1 | 19747-60001 | PCA Ext. Display |
| 1 | 19747-60002 | Assy. Control Panel |
| 1 | 19747-60003 | Assy. PDU |
| 1 | 19747-60006 | Expndrcab, 1000mm |
| 1 | 19747-60011 | Assy. Door, Rear |
| 1 | 19747-60012 | CIO Exp. Bay & Module |
| 1 | 19747-60013 | Kit Number, DTC |
| 1 | 19747-80002 | Control Panel Label |
| 1 | 29400-00013 | Rear Key Striker |
| 1 | 29400-00023 | Assy-Blk Top Cap |
| 1 | 29400-61000 | Front Door Hinge Kit |
| 2 | 29400-61001 | Rear Door Hinge Kit |
| 1 | 29451-60001 | Cabinet Subassembly |
| 1 | 40118-60001 | Tie-together Kit |

DIAGRAMS

SECTION

9


The diagrams provided in this section are to aid the CE in troubleshooting the system.

| | |
|---|------|
| Overall Block Diagram - 9740 CPU | 9-3 |
| Series 800 Model 840S Block Diagram | 9-5 |
| Series 900 Model 930 Block Diagram | 9-7 |
| AC Power Distribution System | 9-9 |
| DC Power Distribution System | 9-10 |
| Expansion Bay/Module Block Diagram | 9-11 |
| Expansion Bay Power Distribution System | 9-12 |
| Cache Unit (CA+) Block Diagram | 9-13 |
| Execution Unit (EU+) Block Diagram | 9-14 |
| Floating Point Unit (FP) Block Diagram | 9-15 |
| Power Supply Block Diagram | 9-16 |
| System Monitor Block Diagram | 9-17 |
| Front Panel Indicators | 9-18 |
| Display Power Table | 9-19 |
| Instruction Unit (IU) Block Diagram | 9-20 |
| Register File Unit (RF) Block Diagram | 9-21 |
| Translation Lookaside Buffer (TL+) Block Diagram | 9-22 |
| HP 9000 Series 800 Model 840S Front/Rear Cabinet PCAs | 9-23 |
| HP 3000 Series 900 Model 930 Front/Rear Cabinet PCAs | 9-24 |
| System Monitor Card Backplane Connectors | 9-25 |
| Row C Connector Definition for Processor Board | 9-26 |
| System Monitor Card Front Panel Connectors | 9-27 |






9740 CPU




LC200008_020

Series 800 Model 840 Block Diagram






Series 900 Model 930 Block Diagram




AC POWER DISTRIBUTION SYSTEM




LG200012_016

DC POWER DISTRIBUTION SYSTEM




LQ200012_015

EXPANSION BAY/MODULE BLOCK DIAGRAM




Diagrams


EXPANSION BAY POWER DISTRIBUTION SYSTEM



CACHE UNIT (CA+) BLOCK DIAGRAM




EXECUTION UNIT (EU+) BLOCK DIAGRAM



CE42879/FE42801


Rev. 1/86

FLOATING POINT UNIT (FP) BLOCK DIAGRAM




Diagrams

POWER SUPPLY BLOCK DIAGRAM




LG200012_026

SYSTEM MONITOR BLOCK DIAGRAM



LG200012_027

FRONT PANEL INDICATORS



LG200012_028


DISPLAY POWER TABLE




| Control Panel Type | LED Color | LED Power | Driver Power | Driving Signal |
|-------------------------------|-----------|-----------|--------------|--------------------|
| Internal Control Panel | | | | |
| TEMP (OK) | Green | +12V1 | +5VS1 | TEMP.OK+ |
| TEMP (Warning) | Yellow | +12V1 | +5VS2 | OVT.WARNING+ |
| TEMP (Shutdown) | Red | +5B | +5B | OVT.SHDN- |
| DC POWER (OK) | Green | +12V1 | +5VS1 | PON+ |
| DC POWER (Fail) | Red | +5VS2 | +5B | PFW- |
| BATTERY (Charging) | Yellow | +12V1 | +5VS2 | BAT.CHG- |
| BATTERY (Dis-Charging) | Red | +5VS2 | +5B | BAT.USE- |
| SELFTEST (OK) | Green | +12V1 | +5VS1 | SELFTEST.OK+ |
| SELFTEST (I/O Error) | Yellow | +12V1 | +5VS1 | I/O.ERROR+ |
| SELFTEST (Failed) | Red | +5VS2 | +5VS1 | SELFTEST.FAIL+ |
| HEX DISPLAY | Red | +5V1 | -- | -- |
| External Control Panel | | | | |
| REMOTE ENABLED | Yellow | +12V1 | +5VS2 | REMOTE.ENABLE- |
| CONSOLE ENABLED | Yellow | +12V1 | +5VS2 | CONTROL ENABLE F/F |
| RUN | Green | +12V1 | +5VS2 | SYS.FCTN- |
| CHECK | Yellow | +12V1 | +5VS1 | CHK.SYS+ |
| FAULT | Red | +5VS1 | +5B | SYS.FAIL- |

LG200012_029

REGISTER FILE UNIT (RF) BLOCK DIAGRAM



TRANSLATION LOOKASIDE BUFFER (TL+) BLOCK DIAGRAM



OE48802/PE42801

Rev. 1/80

Diagrams

NOTE

Use +5S1 secondary power for Mid-bus Slots 11, 12, and 13.
Use +5S2 secondary power for Mid-bus Slots 8, 9, 10, and the IU and CA boards.

Row C Connector Definition for Processor Board (CIO slot 12)

Row C

| | |
|-------------------|----------------|
| 1 FGND | 16 GND |
| 2 CTL.ENABLE - | 17-20 RESERVED |
| 3 RESET.SYS - | 21 GND |
| 4 GND | 22 RESERVED |
| 5 SELFTTEST.SYS - | 23 GND |
| 6 FP.DATA + | 24-26 RESERVED |
| 7 GND | 27 GND |
| 8 FP.CLK + | 28-33 RESERVED |
| 9 REMOTE.EN- | 34 GND |
| 10 GND | 35-38 N.C. |
| 11 TXD-OUT-DP | 39 +5S |
| 12 RXD-IN-DP | 40 +5V |
| 13 GND | |
| 14-15 RESERVED | |




Figure 9-2. System Monitor Board Connector Location.

SYSTEM MONITOR CARD FRONT PANEL CONNECTORS

The four connectors on the front edge of the System Monitor Card are described as follows:

- J1 is a 50 pin connector to the front control panel.
- J2 is a 9 pin connector to the internal backup battery on the fan tray.
- J3 is a 5 pin connector to the AC Circuit Breaker (OVERTEMP SHUTDOWN and BATTERY ENABLE) on the PDU.
- J4 is a 2 pin connector provided for an optional external battery.

See Figure 9-2 for location of the front panel connectors.

J1 PIN ALLOCATION

| ROW A | ROW B |
|--------------------------------|--------------------------------|
| 1 +5V | 1 +5V |
| 2 DIAG.OUT 8+ | 2 DIAG.OUT 9+ |
| 3 DIAG.OUT 10+ | 3 DIAG.OUT 11+ |
| 4 DIAG.OUT 12+ | 4 DIAG.OUT 13+ |
| 5 DIAG.OUT 14+ | 5 DIAG.OUT 15+ |
| 6 GND | 6 GND |
| 7 DIAG.OUT 16+ | 7 DIAG.OUT 17+ |
| 8 DIAG.OUT 18+ | 8 DIAG.OUT 19+ |
| 9 DIAG.OUT 20+ | 9 DIAG.OUT 21+ |
| 10 DIAG.OUT 22+ | 10 DIAG.OUT 23+ |
| 11 GND | 11 GND |
| 12 DISPLAY LATCH (DIAG.OUT 1+) | 12 DISPLAY BLANK (DIAG.OUT 7+) |
| 13 +12V | 13 +12V |
| 14 OVERTEMP SHUTDOWN - | 14 MB.PON+ |
| 15 BATTERY CHARGING - | 15 MB.PFW- |
| 16 AP. PRESET + | 16 +5VB |
| 17 BATTERY IN USE - | 17 SELFTEST.OK + |
| 18 TEMP. OK + | 18 GND |
| 19 OVERTEMP WARNING + | 19 FP.REMOTE - |
| 20 GND | 20 GND |
| 21 SELFTEST.FAIL + | 21 FP.RESET - |
| 22 I/O ERROR + | 22 -12V |
| 23 SYS.FAIL - | 23 REMOTE.ENABLE - |
| 24 CHK. SYS. + | 24 SYS.FCTN - |
| 25 +5VS1 | 25 +5VS2 |

J2 PIN ALLOCATION

| |
|----------------|
| 1 GND |
| 2 GND |
| 3 GND |
| 4 GND |
| 5 N.C. |
| 6 +10V BATTERY |
| 7 +10V BATTERY |
| 8 +10V BATTERY |
| 9 +10V BATTERY |

J3 PIN ALLOCATION

| |
|-----------------------|
| 1 OVERTEMP.SHUTDOWN + |
| 2 +5VS1 |
| 3 GND |
| 4 BATTERY.ENABLE - |
| 5 +10V BATTERY |

J4 PIN ALLOCATION

| |
|-----------------------|
| 1 +12V BATTERY (EXT.) |
| 2 GND |



REFERENCE

SECTION 10

This section contains reference material to aid in troubleshooting the HP Precision Architecture Products.

Table 10-1. ASCII Code Table

ASCII Code Chart

HOW TO USE THIS TABLE

- The table is sorted by character code, each code being represented by its decimal, octal, and hexadecimal equivalent.
- Each row of the table gives the ASCII and EBCDIC meaning of the character code, the ASCII↔EBCDIC conversion code, and the Hollerith representation (punched card code) for the ASCII character.

The following examples describe several ways of using the table:

Example 1: Suppose you want to determine the ASCII code for the S character. Scan down the ASCII graphic column until you locate S, then look left on that row to find the character code - 36 (dec), 044 (oct), and 24 (hex). This is the code used by an ASCII device (terminal, printer, computer, etc.) to represent the S character. Its Hollerith punched card code is 11-3-8.

Example 2: The character code 5B (hex) is the EBCDIC code for what character? Also, when 5B is converted to ASCII (for example, by FCOPY with the EBCDICIN option), what is the octal character code? First, locate 5B in the hex character code column and move right on that row to the EBCDIC graphic which is S. The next column to the right gives the conversion to ASCII, 044. As a check, find 044 (oct) in the character code column, look right to the ASCII graphic column and note that S converted to EBCDIC is 133 (oct) which equals 5B (hex).

Table 10-1. ASCII Code Table

| CHAR CODE | | | ASCII | | | EBCDIC | | | |
|-----------|-----|-----|-----------|-----------------|------------|-----------|----------------|-----|--|
| Dec | Oct | Hex | Char/Code | to EBCDIC (Oct) | Hollerith | Char/Code | to ASCII (Dec) | | |
| 0 | 000 | 00 | NUL | 000 | 12-0-1 8 8 | NUL | 000 | | |
| 1 | 001 | 01 | SOH | 001 | 12-1-8 | SOH | 001 | | |
| 2 | 002 | 02 | STX | 002 | 12-2-9 | STX | 002 | | |
| 3 | 003 | 03 | ETX | 003 | 12-3-9 | ETX | 003 | | |
| 4 | 004 | 04 | EOF | 007 | 7-9 | FF | 294 | | |
| 5 | 005 | 05 | ENQ | 056 | 0-5-8 8 | HT | 011 | | |
| 6 | 006 | 06 | ACK | 056 | 0-8-8 9 | LC | 208 | | |
| 7 | 007 | 07 | BEL | 057 | 0-7-8 9 | DEL | 177 | | |
| 8 | 010 | 08 | BS | 026 | 11-4-8 | | 277 | | |
| 9 | 011 | 09 | HT | 005 | 12-5-9 | | 215 | | |
| 10 | 012 | 0A | LF | 045 | 0-5-9 | SMW | 216 | | |
| 11 | 013 | 0B | VT | 013 | 12-3-8 8 | VT | 013 | | |
| 12 | 014 | 0C | FF | 014 | 12-4-8 9 | FF | 014 | | |
| 13 | 015 | 0D | CR | 015 | 12-5-8 9 | CR | 015 | | |
| 14 | 016 | 0E | SO | 016 | 12-6-8 9 | SO | 016 | | |
| 15 | 017 | 0F | SI | 017 | 12-7-8 9 | SI | 017 | | |
| 16 | 020 | 10 | DLE | 020 | 12-11-8 9 | DLE | 020 | | |
| 17 | 021 | 11 | DC1 | 021 | 11-1-9 | DC1 | 021 | | |
| 18 | 022 | 12 | DC2 | 022 | 11-2-9 | DC2 | 022 | | |
| 19 | 023 | 13 | DC3 | 023 | 11-3-9 | TM | 023 | | |
| 20 | 024 | 14 | DC4 | 024 | 4-8 9 | RES | 235 | | |
| 21 | 025 | 15 | NAK | 025 | 5-8 9 | NL | 205 | | |
| 22 | 026 | 16 | SYN | 062 | 7-9 | BS | 010 | | |
| 23 | 027 | 17 | ETB | 046 | 0-6-9 | IL | 207 | | |
| 24 | 030 | 18 | CAN | 030 | 11-8 9 | CAN | 030 | | |
| 25 | 031 | 19 | EM | 031 | 11-9 9 | EM | 031 | | |
| 26 | 032 | 1A | SUB | 077 | 7-8 9 | CC | 272 | | |
| 27 | 033 | 1B | ESC | 047 | 0-7-9 | CU1 | 217 | | |
| 28 | 034 | 1C | | 75 | 034 | 11-4-8 9 | PS | 034 | |
| 29 | 035 | 1D | | GS | 035 | 11-5-8 9 | GS | 035 | |
| 30 | 036 | 1E | | RS | 036 | 11-6-8 9 | RS | 036 | |
| 31 | 037 | 1F | | US | 037 | 11-7-8 9 | US | 037 | |
| 32 | 040 | 20 | SP | 100 | 8-0-0 | OS | 200 | | |
| 33 | 041 | 21 | | 117 | 12-7-8 | SOS | 201 | | |
| 34 | 042 | 22 | | 177 | 7-8 | S | 202 | | |
| 35 | 043 | 23 | | 173 | 7-8 | | 203 | | |
| 36 | 044 | 24 | | 5 | 133 | 11-3-8 | BYP | 204 | |
| 37 | 045 | 25 | | 154 | 0-4-8 | LF | 017 | | |

| CHAR CODE | | | ASCII | | | EBCDIC | | |
|-----------|-----|-----|-----------|-----------------|-----------|-----------|----------------|--|
| Dec | Oct | Hex | Char/Code | to EBCDIC (Oct) | Hollerith | Char/Code | to ASCII (Dec) | |
| 48 | 060 | 30 | 0 | 360 | 0 | | 220 | |
| 49 | 061 | 31 | 1 | 361 | 1 | | 221 | |
| 50 | 062 | 32 | 2 | 362 | 2 | SVN | 026 | |
| 51 | 063 | 33 | 3 | 363 | 3 | | 223 | |
| 52 | 064 | 34 | 4 | 364 | 4 | PH | 224 | |
| 53 | 065 | 35 | 5 | 365 | 5 | RS | 225 | |
| 54 | 066 | 36 | 6 | 366 | 6 | UC | 226 | |
| 55 | 067 | 37 | 7 | 367 | 7 | EGT | 004 | |
| 56 | 070 | 38 | 8 | 370 | 8 | | 230 | |
| 57 | 071 | 39 | 9 | 371 | 9 | | 231 | |
| 58 | 072 | 3A | | 372 | 2-8 | | 232 | |
| 59 | 073 | 3B | | 376 | 11-4-8 | CU2 | 332 | |
| 60 | 074 | 3C | < | 114 | 12-4-8 | OC4 | 024 | |
| 61 | 075 | 3D | > | 176 | 6-8 | NAK | 025 | |
| 62 | 076 | 3E | > | 156 | 0-6-8 | | 236 | |
| 63 | 077 | 3F | ? | 157 | 0-7-8 | SUB | 032 | |
| 64 | 100 | 40 | @ | 174 | 4-8 | SP | 040 | |
| 65 | 101 | 41 | A | 301 | 12-1 | | 240 | |
| 66 | 102 | 42 | B | 302 | 12-2 | | 241 | |
| 67 | 103 | 43 | C | 303 | 12-3 | | 242 | |
| 68 | 104 | 44 | D | 304 | 12-4 | | 243 | |
| 69 | 105 | 45 | E | 305 | 12-5 | | 244 | |
| 70 | 106 | 46 | F | 306 | 12-6 | | 245 | |
| 71 | 107 | 47 | G | 307 | 12-7 | | 246 | |
| 72 | 110 | 48 | H | 310 | 12-8 | | 247 | |
| 73 | 111 | 49 | I | 311 | 12-9 | | 250 | |
| 74 | 112 | 4A | J | 321 | 11-1 | | 132 | |
| 75 | 113 | 4B | K | 322 | 11-2 | | 056 | |
| 76 | 114 | 4C | L | 323 | 11-3 | | 074 | |
| 77 | 115 | 4D | M | 324 | 11-4 | | 050 | |
| 78 | 116 | 4E | N | 325 | 11-5 | | 053 | |
| 79 | 117 | 4F | O | 326 | 11-6 | | 041 | |
| 80 | 120 | 50 | P | 327 | 11-7 | | 046 | |
| 81 | 121 | 51 | Q | 330 | 11-8 | | 251 | |
| 82 | 122 | 52 | R | 331 | 11-9 | | 252 | |
| 83 | 123 | 53 | S | 343 | 0-2 | | 253 | |
| 84 | 124 | 54 | T | 343 | 0-3 | | 254 | |
| 85 | 125 | 55 | U | 344 | 0-4 | | 255 | |

Table 10-1. ASCII Code Table (con't.)

| CHAR CODE | | | ASCII | | | EBCDIC | | |
|-----------|-----|-----|------------|------------------|-------------|------------|-----------------|------------------|
| Dec | Oct | Hex | Ctrl/Graph | HEX EBCDIC (Oct) | Hexadecimal | Ctrl/Graph | HEX ASCII (Oct) | HEX EBCDIC (Oct) |
| 38 | 046 | 26 | | & | 120 | 12 | E18 | 027 |
| 39 | 047 | 27 | | ' | 125 | 5 | ESC | 023 |
| 40 | 050 | 28 | | (| 115 | 12 | | 210 |
| 41 | 051 | 29 | |) | 135 | 11 | | 211 |
| 42 | 052 | 2A | | * | 134 | 14 | SM | 212 |
| 43 | 053 | 2B | | + | 116 | 12 | CUZ | 213 |
| 44 | 054 | 2C | | , | 153 | 0 | | 214 |
| 45 | 055 | 2D | | - | 140 | 11 | ENG | 005 |
| 46 | 056 | 2E | | . | 113 | 12 | ACK | 006 |
| 47 | 057 | 2F | | / | 141 | 0 | REL | 007 |
| 96 | 140 | 60 | | 0 | 171 | 1 | | 065 |
| 97 | 141 | 61 | | a | 201 | 12 | | 067 |
| 98 | 142 | 62 | | b | 202 | 10 | | 262 |
| 99 | 143 | 63 | | c | 203 | 12 | | 263 |
| 100 | 144 | 64 | | d | 204 | 10 | | 264 |
| 101 | 145 | 65 | | e | 205 | 12 | | 265 |
| 102 | 146 | 66 | | f | 206 | 10 | | 266 |
| 103 | 147 | 67 | | g | 207 | 12 | | 267 |
| 104 | 150 | 68 | | h | 210 | 10 | | 270 |
| 105 | 151 | 69 | | i | 211 | 12 | | 271 |
| 106 | 152 | 6A | | j | 221 | 12 | | 194 |
| 107 | 153 | 6B | | k | 222 | 10 | | 054 |
| 108 | 154 | 6C | | l | 223 | 12 | | 045 |
| 109 | 155 | 6D | | m | 224 | 10 | | 137 |
| 110 | 156 | 6E | | n | 225 | 12 | | 076 |
| 111 | 157 | 6F | | o | 226 | 10 | | 077 |
| 112 | 160 | 70 | | p | 227 | 12 | | 272 |
| 113 | 161 | 71 | | q | 230 | 10 | | 273 |
| 114 | 162 | 72 | | r | 231 | 12 | | 274 |
| 115 | 163 | 73 | | s | 242 | 10 | | 275 |
| 116 | 164 | 74 | | t | 243 | 12 | | 276 |
| 117 | 165 | 75 | | u | 244 | 10 | | 277 |
| 118 | 166 | 76 | | v | 245 | 12 | | 300 |
| 119 | 167 | 77 | | w | 246 | 10 | | 301 |
| 120 | 170 | 78 | | x | 260 | 11 | | 302 |
| 121 | 171 | 79 | | y | 260 | 10 | | 140 |
| 122 | 172 | 7A | | z | 261 | 12 | | 073 |
| 123 | 173 | 7B | | { | 300 | 10 | | 043 |
| 124 | 174 | 7C | | | 152 | 12 | | 100 |
| 125 | 175 | 7D | | } | 320 | 10 | | 047 |
| 126 | 176 | 7E | | ~ | 241 | 11 | | 075 |
| 127 | 177 | 7F | | DEL | 002 | 12 | | 042 |
| 128 | 200 | 80 | | 040 | 110 | 1 | | 303 |
| 129 | 201 | 81 | | 041 | 0 | 1 | | 141 |
| 130 | 202 | 82 | | 042 | 0 | 2 | | 142 |
| 131 | 203 | 83 | | 043 | 0 | 3 | | 143 |
| 132 | 204 | 84 | | 044 | 0 | 4 | | 144 |
| 133 | 205 | 85 | | 045 | 1 | 5 | | 145 |
| 134 | 206 | 86 | | 046 | 1 | 6 | | 146 |
| 135 | 207 | 87 | | 047 | 1 | 7 | | 147 |
| 136 | 210 | 88 | | 050 | 0 | 8 | | 150 |
| 137 | 211 | 89 | | 051 | 0 | 9 | | 151 |
| 138 | 212 | 8A | | 052 | 0 | A | | 304 |
| 139 | 213 | 8B | | 053 | 0 | B | | 305 |
| 140 | 214 | 8C | | 054 | 0 | C | | 306 |
| 141 | 215 | 8D | | 055 | 1 | D | | 307 |
| 142 | 216 | 8E | | 056 | 1 | E | | 308 |
| 143 | 217 | 8F | | 057 | 1 | F | | 309 |
| 144 | 220 | 90 | | 060 | 12 | 11 | | 312 |
| 145 | 221 | 91 | | 061 | 1 | 0 | | 152 |
| 146 | 222 | 92 | | 062 | 11 | 2 | | 153 |
| 147 | 223 | 93 | | 063 | 1 | 3 | | 154 |
| 148 | 224 | 94 | | 064 | 4 | 9 | | 155 |
| 149 | 225 | 95 | | 065 | 4 | 8 | | 156 |
| 150 | 226 | 96 | | 066 | 6 | 9 | | 157 |
| 151 | 227 | 97 | | 067 | 10 | 2 | | 160 |
| 152 | 230 | 98 | | 070 | 8 | 9 | | 161 |
| 153 | 231 | 99 | | 071 | 1 | 8 | | 162 |
| 154 | 232 | 9A | | 072 | 2 | 9 | | 313 |
| 155 | 233 | 9B | | 073 | 2 | 8 | | 314 |
| 156 | 234 | 9C | | 074 | 12 | 4 | | 315 |
| 157 | 235 | 9D | | 075 | 11 | 4 | | 316 |
| 158 | 236 | 9E | | 076 | 6 | 8 | | 317 |
| 159 | 237 | 9F | | 077 | 11 | 0 | | 320 |
| 160 | 240 | A0 | | 101 | 12 | 0 | | 321 |
| 161 | 241 | A1 | | 102 | 12 | 0 | | 176 |
| 162 | 242 | A2 | | 103 | 12 | 0 | | 163 |
| 163 | 243 | A3 | | 104 | 12 | 0 | | 164 |
| 164 | 244 | A4 | | 105 | 12 | 0 | | 165 |
| 165 | 245 | A5 | | 106 | 12 | 0 | | 166 |
| 166 | 246 | A6 | | 107 | 12 | 0 | | 167 |
| 167 | 247 | A7 | | 110 | 12 | 0 | | 170 |
| 168 | 250 | A8 | | 111 | 12 | 1 | | 171 |
| 169 | 251 | A9 | | 121 | 12 | 1 | | 172 |
| 170 | 252 | AA | | 122 | 12 | 1 | | 322 |
| 171 | 253 | AB | | 123 | 12 | 1 | | 323 |
| 172 | 254 | AC | | 124 | 12 | 1 | | 324 |
| 173 | 255 | AD | | 125 | 12 | 1 | | 325 |
| 174 | 256 | AE | | 126 | 12 | 1 | | 326 |
| 175 | 257 | AF | | 127 | 12 | 1 | | 327 |

| CHAR CODE | | | ASCII | | | EBCDIC | | |
|-----------|-----|-----|------------|------------------|-------------|------------|-----------------|------------------|
| Dec | Oct | Hex | Ctrl/Graph | HEX EBCDIC (Oct) | Hexadecimal | Ctrl/Graph | HEX ASCII (Oct) | HEX EBCDIC (Oct) |
| 86 | 126 | 56 | | v | 345 | 0 | | 256 |
| 87 | 127 | 57 | | w | 346 | 0 | | 257 |
| 88 | 130 | 58 | | x | 347 | 0 | | 260 |
| 89 | 131 | 59 | | y | 360 | 0 | | 261 |
| 90 | 132 | 5A | | z | 351 | 0 | | 135 |
| 91 | 133 | 5B | | [| 112 | 12 | | 044 |
| 92 | 134 | 5C | | \ | 340 | 0 | | 072 |
| 93 | 135 | 5D | |] | 132 | 12 | | 051 |
| 94 | 136 | 5E | | ^ | 137 | 11 | | 073 |
| 95 | 137 | 5F | | _ | 155 | 0 | | 136 |
| 176 | 260 | 80 | | 130 | 12 | 1 | | 320 |
| 177 | 261 | 81 | | 131 | 11 | 1 | | 321 |
| 178 | 262 | 82 | | 142 | 11 | 2 | | 322 |
| 179 | 263 | 83 | | 143 | 11 | 0 | | 323 |
| 180 | 264 | 84 | | 144 | 11 | 0 | | 324 |
| 181 | 265 | 85 | | 145 | 11 | 0 | | 325 |
| 182 | 266 | 86 | | 146 | 11 | 0 | | 326 |
| 183 | 267 | 87 | | 147 | 11 | 0 | | 327 |
| 184 | 270 | 88 | | 150 | 11 | 0 | | 340 |
| 185 | 271 | 89 | | 151 | 0 | 1 | | 341 |
| 186 | 272 | 8A | | 160 | 12 | 1 | | 342 |
| 187 | 273 | 8B | | 161 | 12 | 1 | | 343 |
| 188 | 274 | 8C | | 162 | 12 | 1 | | 344 |
| 189 | 275 | 8D | | 163 | 12 | 1 | | 345 |
| 190 | 276 | 8E | | 164 | 12 | 1 | | 346 |
| 191 | 277 | 8F | | 165 | 12 | 1 | | 347 |
| 192 | 300 | 90 | | 166 | 12 | 1 | | 173 |
| 193 | 301 | 91 | | 167 | 12 | 1 | | 101 |
| 194 | 302 | 92 | | 170 | 12 | 1 | | 102 |
| 195 | 303 | 93 | | 200 | 12 | 1 | | 103 |
| 196 | 304 | 94 | | 212 | 12 | 0 | | 104 |
| 197 | 305 | 95 | | 213 | 12 | 0 | | 105 |
| 198 | 306 | 96 | | 214 | 12 | 0 | | 106 |
| 199 | 307 | 97 | | 219 | 12 | 0 | | 107 |
| 200 | 310 | 98 | | 216 | 12 | 0 | | 110 |
| 201 | 311 | 99 | | 217 | 12 | 0 | | 111 |
| 202 | 312 | 9A | | 220 | 12 | 1 | | 250 |
| 203 | 313 | 9B | | 222 | 12 | 1 | | 251 |
| 204 | 314 | 9C | | 223 | 12 | 1 | | 252 |
| 205 | 315 | 9D | | 224 | 12 | 1 | | 253 |
| 206 | 316 | 9E | | 225 | 12 | 1 | | 254 |
| 207 | 317 | 9F | | 226 | 12 | 1 | | 255 |
| 208 | 320 | 90 | | 227 | 12 | 1 | | 175 |
| 209 | 321 | 91 | | 240 | 11 | 0 | | 112 |
| 210 | 322 | 92 | | 242 | 11 | 0 | | 113 |
| 211 | 323 | 93 | | 252 | 11 | 0 | | 114 |
| 212 | 324 | 94 | | 254 | 11 | 0 | | 115 |
| 213 | 325 | 95 | | 255 | 11 | 0 | | 116 |
| 214 | 326 | 96 | | 256 | 11 | 0 | | 117 |
| 215 | 327 | 97 | | 257 | 11 | 0 | | 120 |
| 216 | 330 | 98 | | 260 | 12 | 1 | | 121 |
| 217 | 331 | 99 | | 261 | 12 | 1 | | 122 |
| 218 | 332 | 9A | | 262 | 12 | 1 | | 256 |
| 219 | 333 | 9B | | 263 | 12 | 1 | | 257 |
| 220 | 334 | 9C | | 264 | 12 | 1 | | 360 |
| 221 | 335 | 9D | | 265 | 12 | 1 | | 361 |
| 222 | 336 | 9E | | 266 | 12 | 1 | | 362 |
| 223 | 337 | 9F | | 267 | 12 | 1 | | 363 |
| 224 | 340 | 90 | | 270 | 12 | 1 | | 134 |
| 225 | 341 | 91 | | 271 | 12 | 1 | | 237 |
| 226 | 342 | 92 | | 272 | 12 | 1 | | 123 |
| 227 | 343 | 93 | | 273 | 12 | 1 | | 124 |
| 228 | 344 | 94 | | 274 | 12 | 1 | | 125 |
| 229 | 345 | 95 | | 275 | 12 | 1 | | 126 |
| 230 | 346 | 96 | | 276 | 12 | 1 | | 127 |
| 231 | 347 | 97 | | 277 | 12 | 1 | | 130 |
| 232 | 360 | 98 | | 312 | 12 | 0 | | 131 |
| 233 | 361 | 99 | | 313 | 12 | 0 | | 132 |
| 234 | 362 | 9A | | 314 | 12 | 0 | | 364 |
| 235 | 363 | 9B | | 315 | 12 | 0 | | 365 |
| 236 | 364 | 9C | | 316 | 12 | 0 | | 366 |
| 237 | 365 | 9D | | 317 | 12 | 0 | | 367 |
| 238 | 366 | 9E | | 322 | 12 | 1 | | 370 |
| 239 | 367 | 9F | | 323 | 12 | 1 | | 371 |
| 240 | 360 | 90 | | 334 | 12 | 1 | | 060 |
| 241 | 361 | 91 | | 335 | 12 | 1 | | 061 |
| 242 | 362 | 92 | | 336 | 12 | 1 | | 062 |
| 243 | 363 | 93 | | 327 | 12 | 1 | | 063 |
| 244 | 364 | 94 | | 327 | 11 | 0 | | 064 |
| 245 | 365 | 95 | | 352 | 11 | 0 | | 065 |
| 246 | 366 | 96 | | 354 | 11 | 0 | | 066 |
| 247 | 367 | 97 | | 355 | 11 | 0 | | 067 |
| 248 | 370 | 98 | | 366 | 11 | 0 | | 070 |
| 249 | 371 | 99 | | 357 | 11 | 0 | | 071 |
| 250 | 372 | 9A | | 372 | 12 | 1 | | 372 |
| 251 | 373 | 9B | | 373 | 12 | 1 | | 373 |
| 252 | 374 | 9C | | 374 | 12 | 1 | | 374 |
| 253 | 375 | 9D | | 375 | 12 | 1 | | 375 |
| 254 | 376 | 9E | | 376 | 12 | 1 | | 376 |
| 255 | 377 | 9F | | 377 | 12 | 1 | | 377 |

Acronyms

| | |
|-------|---|
| AC | Analyzer Card |
| AFI | Asynchronous FIFO Interface Card |
| ALU | Arithmetic Logic Unit |
| AP | Access Port |
| ASC | Asynchronous Serial Communicator |
| AUI | Attachment Unit Interface |
| C1 | Channel Adapter (Card 1 of 3) Mid_Bus Interface |
| C2 | Channel Adapter (Card 2 of 3) CIO_Bus Interface |
| C3 | Channel Adapter (Card 3 of 3) Buffer Card |
| CA | Channel Adapter |
| CA+ | Cache Array Board |
| CAB | Console Attachment Board |
| CAM | Channel Adapter Manager |
| CI | Command Interrupter |
| CIB | Central Interface Bus Adapter |
| CIO | Channel I/O |
| CPU | Central Processor Unit |
| CR | Control Register |
| CRT | Cathode Ray Tube |
| CTB | Central Bus |
| DA | Device Adapter |
| DAM | Device Adapter Manager |
| DCE | Data Communications Equipment |
| DM | Device Manager |
| DMA | Direct Memory Access |
| DTC | Distributed Terminal Controller |
| DTE | Data Terminal Equipment |
| DUI | Diagnostic User Interface |
| ECL | Emitter Coupled Logic |
| EIR | External Interrupt Register |
| EIM | External Interrupt Message |
| EIEM | External Interrupt Elastic Mask |
| ERS | External Reference Specifications |
| ESD | Electrostatic Discharge |
| EU+ | Execution Unit |
| FP | Floating Point Coprocessor |
| FRU | Field Replacement Unit |
| GR | General Register |
| HPA | Hard Physical Address |
| HP-IB | Hewlett-Packard Interface Bus |
| HP-FL | Hewlett-Packard Fiber Optic Link |
| HPMC | High Priority Machine Check |
| HP-UX | Hewlett-Packard UNIX |
| IMS | Internal Maintenance Specification |
| I/O | Input/Output |
| IIR | Interrupt Instruction Register |
| IODC | I/O Dependent Code |
| IOR | Interrupt Offset Register |
| IOTT | I/O Test Tool |

Reference

| | |
|--------|--|
| IROM | Instruction Rom |
| ISL | Initial System Load |
| ISR | Interrupt Space Register |
| IU | Instruction Unit |
| IVA | Interrupt Vector Address |
| LAN | Local Area Network |
| LANIC | Local Area Network Interface Controller |
| LDM | Logical Device Manager |
| LED | Light Emitting Diode |
| LPMC | Low Priority Machine Check |
| LRU | Least Recently Used |
| LUT | Look-Up Table |
| MA | Memory Array |
| MAU | Media Attachment Unit |
| MC | Memory Controller |
| MPE-XL | Multi Programming Executive-Version XL |
| NIR | Next Instruction Register |
| NS | Network Services |
| OS | Operation System |
| PA | Physical Address |
| PA | Parallel I/O PCA |
| PAGE | 2K Bytes |
| PC | Program Counter or Parallel I/O Interface Card |
| PDC | Processor Dependent Code |
| PDIR | Page Directory Table |
| PF | Power Fail Warn |
| PFW | Power Fail Warn |
| PHI | Processor to HP-IB Interface |
| PID | Protection Identification Number |
| PL | Privilege Level |
| PON | Power On |
| PPN | Physical Page Number |
| PROM | Programmable ROM |
| PSW | Processor Status Word |
| Q | Quad |
| RAM | Random Access Memory |
| RF | Register File |
| RISC | Reduced Instruction Set Computer |
| ROM | Read Only Memory |
| RS232 | Standard for Serial Bus |
| SM | System Monitor Module |
| SPA | Soft Physical Address |
| SPU | System Processor Unit |
| SR | Space Register |
| TC | Transfer of Control |
| TLB | Translation Lookaside Buffer |
| TOS | Top-Of-Stack |
| TTL | Transister/Transister Logic |
| UART | Universal Synchronuous Receiver/Transmitter |
| VA | Virtual Address |
| VLSI | Very Large Scale Integration |
| VPN | Virtual Page Number |
| WORD | 4 Bytes, 32 Bits |

SERVICE NOTES

SECTION

11

Notes

Service Notes

Notes

11-2



SERVICE NOTE

Model(s) Affected:

Series 9000 Model 840
Series 3000 Model 930

Assemblies Affected:

Backplane 09740-60042

SUPERSEDES: none

| | | |
|--------------------------|---|---|
| APPLIES TO: | All Units <input checked="" type="checkbox"/> | Only Units on Agreement/Warranty <input type="checkbox"/> |
| PERFORM: | Immediately <input type="checkbox"/> | At PM/Normal Call <input type="checkbox"/> |
| | On Failure <input type="checkbox"/> | Information Only <input checked="" type="checkbox"/> |
| WARRANTY: | EXTENDED | NORMAL |
| LABOR: | | X |
| PARTS: | | X |
| TRAVEL: | | X |
| SERVICE | Return for update <input type="checkbox"/> | Use as is <input type="checkbox"/> |
| INVENTORY | Return for salvage <input type="checkbox"/> | See text <input type="checkbox"/> |
| WARRANTY EXTENDED UNTIL: | N/A | |

Purpose:

This Service Note is to inform the field of the ability to change backplane pins and of the tools available to perform this operation.

Action:

The pins on the 840/930 (9740A CPU) backplane can be replaced if they should accidentally get bent or broken. There are two kinds of pins in the backplane, both of which are made by AMP Inc. These pins can be ordered through CPC/PCE in minimum quantities of 100.

The connectors in the CIO section are of the MODU (AMP Reg Trademark) type. These connectors use the HP P/N 1252-2113 type of pins. When you order this part number you get 100 pins.

The rest of the Backplane uses HDI (Amp Reg. Trademark) connectors which use HP P/N 1252-2102 type of pins. When you order this part number you get 100 pins.

These two types of pins should NOT be interchanged. The MODU type of pins have longer heads and shorter tails than the HDI type.

Once a pin has been removed from the backplane it should NOT be reused because it has been deformed. Any one hole in the backplane can have a pin replaced up to ten times before degradation of the connection occurs.

The HP part number for the AMP pin extraction/insertion tool is P/N 8710-1758. The tool comes with instructions on how to use it. It can be ordered through CPC/PCE.

By: ALD 4/9/87
9320-4766 (1/83)



FOR MORE INFORMATION, CALL YOUR LOCAL HP SALES OR SERVICE OFFICE or East (201) 265-6000 • Midwest (312) 255-9800 • South (404) 955-1500 • West (213) 970-7500 or (415) 988-8200 OR WRITE, Hewlett-Packard, 1820 Embarcadero, Palo Alto, California 94303. IN EUROPE, CALL YOUR LOCAL HP SALES OR SERVICE OFFICE OR WRITE, Hewlett-Packard S.A., 7, rue du Bois-du-Lan, P.O. Box, CH-1217 Meyrin 2 - Geneva, Switzerland. IN JAPAN, Yokogawa-Hewlett-Packard Ltd., 1-27-15, Yabe Sagami-cho, Kanagawa Prefecture, Japan 229.

© 1983 Hewlett-Packard Company
Printed in U.S.A.

There is a second type of extraction tool available directly from AMP INC. for pulling backplane pins out from the front. This tool is considerably expensive (\$450.00) but is recommended when a pin cannot be reached from the back to be extracted. It requires no force at all to pull out a backplane pin. The tool exerts all of the force. This tool is not intended to be qualified with an HP part number due to its high cost and infrequency of use. This tool can be ordered from AMP Inc., Harrisburg, Pennsylvania 17105 (PHONE: 717-564-0100). The AMP part number is 5809-1. This tool will be more useful for future products (3000-950/9000-850) where the backplane pins cannot be reached from the back.