

# System 35 Desktop Computer

Microprocessor Development Software



 HEWLETT  
PACKARD

## **WARRANTY STATEMENT**

Hewlett-Packard (HP) warrants its computer software products against defects in materials and workmanship for a period of ninety (90) days. During the warranty period, HP will, at its option, repair or replace products which prove to be defective. Any defective materials must be returned directly to HP. Products that are installed are warranted from the installation date, all others from the ship date.

If the buyer schedules or delays the installation more than 30 days after delivery, then warranty period starts on the 31st day from the date of shipment.

HP warrants that its software and firmware designated by HP for use with a CPU will execute its programming instructions when properly installed on that CPU. HP does not warranty that the operation of the CPU, or software, or firmware will be uninterrupted or error free.

No other warranty is expressed or implied. The implied warranties of merchantability and fitness for a particular purpose are specifically disclaimed. There is no liability for any direct, indirect, special, incidental or consequential damages, however based.





## Microprocessor Development Software



**Hewlett-Packard Desktop Computer Division**  
Postfach 1430, 7030 Böblingen, Federal Republic of Germany

Copyright by Hewlett-Packard Company 1979

**HP Computer Museum**  
**[www.hpmuseum.net](http://www.hpmuseum.net)**

**For research and education purposes only.**



## Preface

The Microprocessor Development Software provides additional capabilities to the HP Desktop Computer Models 9835A and 9845B to allow you to write Assembler language programs for one of three microprocessor types.

The instructions given in this manual consider that you have a working knowledge of the 9835A or 9845B Desktop Computer. Complete operating instructions for these instruments are given in the appropriate manuals supplied with each Desktop Computer. Program operation with either Desktop Computer is essentially the same. Where a difference in key definition occurs, both are given. When using a software program, the keys CONTINUE (9835A), CONT (9845B) and EXECUTE have the same function. The word CONTINUE is used through-out this manual.

The manual does not present any information which will help you to understand your chosen Microprocessor. We advise you to refer to the manufacturers documentation to achieve an understanding of their microprocessors before reading this manual.

Section VII provides information and descriptions of the Assembler language instructions for each microprocessor type. These instructions apply to each particular type of microprocessor and they are not interchangeable.

If any program which is described in this manual fails, please contact your local HP Sales and Service Office. Office locations are listed at the back of this manual.

At the front of this manual you will find a Software Registration card that enables you to receive information concerning revisions, additions or modifications to this software pack for a period of one year.

(ii)

## Table of Contents

### Section One: Introductory Description

Introduction .....	1-1
Terms .....	1-2
Conventions .....	1-3
Specifications .....	1-4
Equipment Requirements – 9835A .....	1-5
Equipment Requirements – 9845B .....	1-6

### Section Two: Quick Reference Guide

Program Start .....	2-1
Generation .....	2-1
Obtaining the Main Menu .....	2-2
Initialization .....	2-2
Editor .....	2-2
Special Function Keys .....	2-2
Mainframe Keys .....	2-3
Assembler .....	2-4
Macros .....	2-4
Console Module .....	2-5
8080/85 Assembler Language Instructions .....	2-7
6800 Assembler Language Instructions .....	2-9
Z80 Assembler Language Instructions .....	2-11

### Section Three: Generation of the Program Cartridge

Introduction .....	3-1
Operating Procedure for Producing a Copy .....	3-2

### Section Four: Obtaining the Main Menu

Program Start .....	4-1
---------------------	-----

### Section Five: Initialization Module

Introduction .....	5-1
The Menus .....	5-1

### Section Six: The Editor Module

Introduction .....	6-1
Writing or Modifying Source Code .....	6-2
File Handling .....	6-2
Used as a Text Editor .....	6-2
The Keyboard .....	6-3
Keys that are Inactive .....	6-3
Keys that have the same Function as One Another .....	6-3
Keys whose Function Change between Edit and Command Modes .....	6-4
Keys with a Different Function to Mainframe .....	6-4
SFK Overlay .....	6-6
9835A Overlay .....	6-6
9845B Overlay .....	6-6



Special Function Keys . . . . .	6-7
SFK BREAK . . . . .	6-7
SFK CHANGE . . . . .	6-7
SFK COPY . . . . .	6-8
SFK DELETE . . . . .	6-8
SFK EDIT (9845B) . . . . .	6-8
PROGRAM Key EDIT (9835A) . . . . .	6-8
SFK EDIT KEY . . . . .	6-9
SFK EXIT . . . . .	6-9
SFK FIND . . . . .	6-9
SFK JOIN . . . . .	6-10
SFK LIST (9845B) . . . . .	6-10
PROGRAM Key LIST (9835A) . . . . .	6-10
SFK LOAD . . . . .	6-11
SFK RENUMBER . . . . .	6-11
SFK SCRATCH . . . . .	6-11
SFK STORE . . . . .	6-12
SFK SYNTAX . . . . .	6-12
Points to Remember . . . . .	6-13

### Section Seven: 8080/85 Assembler Language Instructions

Introduction . . . . .	7-1
Source Line Format . . . . .	7-1
The Label Field . . . . .	7-2
Instruction Field . . . . .	7-2
Operand Field . . . . .	7-2
Numbers . . . . .	7-3
Symbols . . . . .	7-3
Expressions . . . . .	7-3
ASCII Strings . . . . .	7-7
Comment Field . . . . .	7-7
Assembler Directives . . . . .	7-8
Define Byte . . . . .	7-8
Define Storage . . . . .	7-8
Define Word . . . . .	7-8
End of Program . . . . .	7-9
Equate . . . . .	7-9
Fail . . . . .	7-9
IF-ELSE-ENDIF . . . . .	7-10
IFC-ELSE-ENDIF . . . . .	7-10
IFNC-ELSE-ENDIF . . . . .	7-11
Origin . . . . .	7-11
Set . . . . .	7-11
Space . . . . .	7-11
Assembler Controls . . . . .	7-12
Example of Source Code . . . . .	7-14
Example of Assembled Code . . . . .	7-15
Example of Cross Reference Table . . . . .	7-16
Character Set . . . . .	7-16
Instruction Field . . . . .	7-17
Differences Between HP and the 8080/85 . . . . .	7-17

**Section Seven: 6800 Assembler Language Instructions**

Introduction	7-1
Source Line Format	7-1
Label Field	7-2
Instructions	7-2
Operand Field	7-2
Numbers	7-3
Symbols	7-3
Expressions	7-4
ASCII String	7-4
Void Operands	7-4
Direct and Extended Addressing	7-5
Indirect Addressing	7-5
Immediate Addressing	7-5
Comment Field	7-6
Assembler Directives	7-6
End	7-6
Equate	7-6
Fail	7-7
Form Constant Byte	7-7
Form Constant Character	7-7
Form Double Byte	7-8
IF-ELSE-ENDIF	7-8
IFC-ELSE-ENDIF	7-9
IFNC-ELSE-ENDIF	7-9
MON	7-9
Name	7-9
Origin	7-10
Page	7-10
Reserve Memory Bytes	7-10
Set	7-11
Space	7-11
Assembler Controls	7-11
Example of Source Code	7-14
Example of Assembled Code	7-15
Example of Cross Reference Table	7-16
Character Set	7-16
Instruction Field	7-17
Differences Between HP and the 6800	7-21

**Section Seven: Z80 Assembler Language Instructions**

Introduction	7-1
Source Line Format	7-1
Label Field	7-2
Instructions	7-2
Operand Field	7-2
Numbers	7-3
Symbols	7-3
Expressions	7-4

ASCII Strings .....	7-7
Special Operands .....	7-7
Comment Field .....	7-7
Assembler Directives .....	7-8
COND-ELSE-ENDC .....	7-8
Define Byte .....	7-9
Define Memory .....	7-9
Define Label .....	7-9
Define Storage .....	7-9
Define Word .....	7-10
End .....	7-10
Equate .....	7-10
Fail .....	7-10
IFC-ELSE-ENDC .....	7-11
IFNC-ELSE-ENDC .....	7-11
Origin .....	7-11
Space .....	7-11
Assembler Controls .....	7-12
Example of Source Code .....	7-14
Example of Assembled Code .....	7-15
Example of Cross Reference Table .....	7-16
Character Set .....	7-16
Instruction Field .....	7-17
Differences Between HP and the Z80 .....	7-26
<b>Section Eight: Macros</b>	
Introduction .....	8-1
Macro Statement Format .....	8-2
Macro Call .....	8-2
Nested Macro Calls .....	8-3
Macro Directives .....	8-4
Repeat Macro .....	8-4
Indefinite Repeat Macro .....	8-4
Indefinite Repeat Character Macro .....	8-5
Number Macro Parameter .....	8-5
Exit Macro .....	8-6
<b>Section Nine: Assembler Module</b>	
Introduction .....	9-1
Source File .....	9-1
Object Files .....	9-1
List/Cross Reference Format .....	9-2
Using The Assembler Module .....	9-2
SOURCE Instruction .....	9-2
OBJECT Instruction .....	9-2
BREAK Key .....	9-3
EXIT Key .....	9-3

**Section Ten: Console Module**

Introduction .....	10-1
Using Other Microprocessor Systems .....	10-2
Microprocessor System Modifications .....	10-2
Motorola Evaluation Module II .....	10-2
Intel SBC 80/30 Mounted in the SYS 80/30 Case .....	10-3
Zilog Z80 – MCB/16 .....	10-3
RS232C Lines .....	10-3
HP 98036A Interface .....	10-4
System and Cable Compatibility .....	10-4
Interface Dismantling .....	10-5
Switch Settings .....	10-6
Interface Installation .....	10-7
Running The System .....	10-7
Special Function Keys .....	10-8
Mainframe Keys .....	10-9
Object Code Formats .....	10-10
Intel .....	10-10
Intel Conversion .....	10-11
Motorola .....	10-12
Zilog .....	10-13
Useful Operating Hints .....	10-13
Intel Microprocessor Systems .....	10-13
Motorola Microprocessor Systems .....	10-15
Zilog Microprocessor Systems .....	10-16
CRT Driver used by the Console .....	10-17
Error Handling .....	10-17

**Section Eleven: Examples on applying the pack**

Introduction .....	11-1
The Editor .....	11-1
Change .....	11-1
Find .....	11-2
Copy .....	11-3
Loading and Storing Source Code without Line Numbers .....	11-5
Macro Examples .....	11-6
Macro Nesting .....	11-8
Calling Macros from a Mass Storage Device .....	11-10
General .....	11-11
ENDM Statements .....	11-13
General .....	11-15

# Section One Introductory Description



## Introduction


Your Microprocessor Development Software is a cartridge for use with the 9835A or 9845B Desktop Computer. The cartridge contains all the necessary Cross-Assembler programs and data files to generate Assembler language programs using the instructions of your chosen microprocessor type, namely the 8080/85, the 6800, or the Z80.

Capabilities of the program allow you to;

- Create or modify Source code
- Assemble Source code into Object code
- Download the Object code into a compatible target microprocessor system under control of the microprocessor monitor operating system.
- Communicate with the target microprocessor system.

The generation procedure loads the cartridge into the Desktop computer whereby a copy is made onto some chosen form of mass storage. When this phase is completed, the generated program asks you which of the four available modules you intend to work with.

- The Initialization Module, for changing the peripheral default values.
- The Editor Module, for writing your Source code.
- The Assembler Module, that translates your Source code into Object code.
- The Console Module, that allows you to transfer your final Object code to a Microprocessor system under control of the target processor operating system.



## Terms

During the course of this manual, phrases will be used which are in common circulation in the data processing industry. While the meaning of most are either well-known or deducible from the content, there are a few which may be new to you.

**Default Value.** Such parameters as printer width, paper length, tape cartridge selection code, printer select code etc., are stored on a file known as the default value file. These values are known as default values. Unless changes are made the default values are used during the operation of the program.

**Macro.** Defines a body of text that is automatically inserted into your Source code each time a Macro is called.

**Module.** In programming, a program segment which performs a specific, independent program task.

**msus** (mass storage unit specifier). This specifier tells the System which mass storage unit it is addressing and where it can be found. Refer to System 9835A/9845B Operating and Programming manual for further information.

**Object Code.** Is the result of putting the Source code through an Assembler program. It can also be called Machine code and is usually in hexadecimal code.

**Object file.** The file in which your absolute machine code is stored in the format of your particular microprocessor.

**Select code.** The computer accesses I/O devices with a select code. It is an expression in the range 0 through 16. Refer to the 9835A/9845B Operating and Programming manual for further information.

**SFK (Special Function Keys).** The keys to the top right of the keyboard have been predefined by the program. The definition is contained on the overlay. Some keys can be defined for use as typing aids for often used statements.

**Source Code.** This is the program written by you in Microprocessor Assembler language.

**Source file.** The file in which your written Source code is stored.

**Work files.** The files where any overflow of your Source code, from the Desktop Computer memory, is stored.

## Conventions

### Description and range of parameter values.

<LNA>, <LNB>, <LNC>, <LN>	– Different line numbers from 1 to 99999.
<INCREMENT>	– A number for the line increment.
<STR1>, <STR2>, <STR>	– A given string with a maximum of 74 characters.
<SC>	– Select Code. An integer in the range 0 through 16, or an HP-IB address, for example 7,1.
msus	– Mass storage unit specifier. For example:  “:T15” is the standard cartridge drive “:T14” is the optional cartridge drive “:F8” is the Flexible disc at select code 8.

### Syntax

The special rules of the command syntax are explained below.

- < > – Items within angled brackets must be replaced by an actual value.
- [ ] – Items within square brackets are optional.
- ... – Three dots indicate that the previous item can be repeated.
- | – A vertical line between two parameters means “or”; only one of the parameters can be included.

For more information refer to the 9835A or 9845B Operating and Programming Manual.

### File Protection

Files can be read that are either unprotected or protected with the protect code “P”. Files protected with some other protect code cannot be used.

Only unprotected files can be overwritten. To prevent a file from being overwritten, always use the protect code “P”. For further information, refer to the Protect file statement in the Desktop Computer’s Operating and Programming manual.

# Specifications

## LENGTH OF SOURCE FILE.

The length of the Source file depends upon:

- The size of the mass storage device.
- The maximum number of lines that can be input by the user. Maximum number 32767 lines.
- The line numbers generated by the Editor. Range 1 to 99999.

## LENGTH OF SOURCE FILE LINES

The maximum line length is 80 characters. The line number requires 6 and the other 74 are available for Source code.

## LENGTH OF OBJECT FILE.

The Object file must fit on one mass storage medium.

## GENERAL

Nesting levels for INCLUDE directive . . . . .	.8 levels
Conditional 'IF' nesting levels . . . . .	.8 levels
Macro nesting levels. . . . .	.8 levels
Serial Interface . . . . .	RS 232C
Baud rate. . . . .	.75-9600



## Equipment Requirements — Model 9835A

The Microprocessor Development Software package consists of:

09835-12531 Operating Manual.

7120-8903 An overlay illustrating the functions of the SFKs.

One, or all three of the following magnetic tape cartridges.

09835-12534 for the 6800 microprocessor type.

09835-12544 for the 8080/85 microprocessor type.

09835-12554 for the Z80 microprocessor type.

### THE HARDWARE CONFIGURATION

To use the Microprocessor Development Software, you require:

HP 9835A Desktop Computer, Option 201. At least 115K bytes of memory.

HP 98331A Mass Storage ROM

HP 9885M Flexible Disk Drive or equivalent.

HP 9876A Thermal Printer, HP 2631A Hard Copy Printer or equivalent.

HP 98036A Serial Interface, Option 001 for use between the 9835A and a Microprocessor Development system.

A Microprocessor Development system may be connected for debugging purposes. It should:

- Contain the microprocessor,
- Contain a Read/Write memory that can hold the Object code you intend to debug,
- Have a monitor (mini operating system) driving RS 232C system console. (See Section IX, Console Module for further information).

The table below gives you the number of Source lines that may be entered into the Desktop Computer memory. As can be seen, a large amount of memory allows you to write more Source line without an overflow onto a mass storage device.

Memory Size	Maximum number of Source lines that the Editor can hold before an overflow onto a mass storage device work file is necessary
114 706	170
180 152	805
246 200	1440

## Equipment Requirements — Model 9845B

The Microprocessor Development Software package consists of:

- 09845-12531 Operating Manual.
- 7120-8904 An overlay illustrating the functions of the SFKs.
- One, or all three of the following magnetic tape cartridges.
- 09845-12534 for the 6800 microprocessor type.
- 09845-12544 for the 8080/85 microprocessor type.
- 09845-12545 for the Z80 microprocessor type.

### THE HARDWARE CONFIGURATION

To use the Microprocessor Development Software, you need the following items:

HP 9845B Desktop Computer, option 204. At least 187K bytes of memory.

Optionally, any mass storage or printer supported by Hewlett-Packard for the HP 9845B Mainframe. Two mass storage channels are required. Recommended is one non-cartridge mass memory like the HP 9885M Flexible Disk Drive for reasons of speed. If the HP 9885M is used, then the HP 9845B must contain the 98413A Mass Storage ROM.

A Microprocessor Development System may be connected for debugging purposes. It should:

- Contain the microprocessor,
- Contain a Read/Write memory that can hold the Object code you intend to debug,
- Have a monitor (mini operating system) driving an RS 232C system console. (See Section Ten, Console Module for further information.
- Use the HP 98036A Serial Interface, Option 001, between the development system and the Desktop Computer.

The table below gives you the number of Source lines that may be entered into the Desktop Computer memory. As can be seen, a large amount of memory allows you to write more Source lines without an overflow onto a mass storage device.

Memory Size	Maximum number of Source lines that the Editor can hold before an overflow onto a mass storage device workfile is necessary.
187 146	805
318 026	2075
448 906	3345

## Section Two Quick Reference Guide

### Program Start

LOAD "AUTOST", 1 and press EXECUTE.



### Generation

Produces a copy that is optimised for your available memory size.

Symbol Reference Table.

A guide to the number of symbols you can enter in the Symbol table.

Memory Size in Bytes	Answer to the question "Symbol Table Size"							
	500		1000		2000		4094	
	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines
9835A								
115 402	4839	100	2939	200	—	—	—	—
180 842	13019	100	11119	200	7319	400	—	—
246 282	21326	100	19426	200	15626	400	7677	818
9845B								
187 146	13830	100	11929	200	8130	400	181	818
318 026	30190	100	28290	200	24490	400	16541	818
448 906	32767	1430	32767	1345	32767	1174	32767	818

## Obtaining the Main Menu

Obtaining the Main Menu.

Type MASS STORAGE IS msus.  
LOAD "AUTOST", 1

Press EXECUTE

### MAIN MENU

Choose and then press one of the SFKs

k0 for	INITIALIZATION
k1 for	EDITOR
k2 for	ASSEMBLER
k3 for	CONSOLE

Press STOP to terminate the program

## Initialization

Allows you to change the default values already stored in the default file of your mass storage device.

## Editor

Allows you to write Source code.

### Special Function Keys (SFK)

For Syntax conventions see Section One.

<b>BREAK</b>	Allows use of the Mainframe functions.
<b>CHANGE "&lt;STR&gt;" TO "&lt;STR2&gt;" [ FROM &lt;LNA&gt; [ , &lt;LNB&gt; ]]</b>	Allows String substitution.
<b>COPY &lt;LNA&gt; , &lt;LNB&gt; TO &lt;LNC&gt;</b>	Copies one range of lines to another.
<b>DELETE &lt;LNA&gt; , &lt;LNB&gt;</b>	Deletes all lines between and including those defined.
<b>EDIT [ &lt;LN&gt; [ , &lt;INCREMENT&gt; ]]</b>	Enters Edit mode. Specifies the line number and the line increment.
<b>EDIT KEY</b>	Permits the use of some SFKs for user-defined typing aids.

<b>EXIT</b>	Returns you to the Main Menu.
<b>FIND</b> "< STR >" [ FROM < LNA > [ , < LNB > ]]	Searches the Source code for a defined String.
<b>JOIN</b> "< FILE NAME > [ msus ]" [ < LN > ] [ @ ]	Links programs from a mass storage device onto a program in memory.
<b>LIST</b> [ # < SC > ; ] [ < LNA > [ , < LNB > ] ] [ @ ]	Lists defined parts of the program. # < SC > ; specifies select code for a different printer. Symbol @ prints code without line numbers.
<b>LOAD</b> "< FILE NAME > [ msus ]" [ @ ]	Transfers the Source code from a known device into memory. Symbol @ generates line numbers.
<b>RENUMBER</b> [ < LN > , [ < INCREMENT > ]]	Modifies line numbering.
<b>SCRATCH</b>	Deletes contents of Editor memory including working files.
<b>STORE</b> "< FILE NAME > [ msus ]" [ < LNA > [ , < LNB > ] ] [ @ ]	Stores the Source code as a data file on a given device. Symbol @ stores files without line numbers.
<b>SYNTAX</b>	Allows Editor to make an automatic Syntax check.

### Mainframe Keys

Model 9845B	Model 9835A
CLEAR → END	BACK
CLEAR LINE	CLR → END
DEL CHR	CLEAR LINE
DEL LN	DEL CHR
HOME	DEL LN
INS CHR	FWD
ROLL (up arrow)	HOME
ROLL (down arrow)	INS CHR
PRT ALL	PRT ALL
TAB CLEAR	TAB CLEAR
TAB SET	TAB SET
TYPWTR	TO END
Up arrow	TYPWTR
Down arrow	Up arrow
Right arrow	Down arrow
Left arrow	Right arrow
	Left arrow

Inactive keys in Edit mode.

STEP RUN RESULT PAUSE CLEAR SPACE DEPENDENT

Keys that do the same operation.

CONTINUE and EXECUTE except when BREAK is pressed.

Keys whose function change between the Edit and Command mode.

CONTINUE/EXECUTE RECALL

Keys which have a different function to the mainframe

CLEAR LINE HOME INS LN STORE down arrow

HOME/SHIFT (9845B)

SHIFT down arrow (9835A) SHIFT up arrow (9835A)

## Assembler

Translates your Source code into an absolute machine code.

**SOURCE** " < FILE NAME > [ msus ] " [ , < CONTROL1 > ] [ , < CONTROL2 > . . . ]

Specifies the name of the Source file to be assembled.

**OBJECT** [ " < FILE NAME > [ msus ] " ] [ , < CONTROL1 > ] [ , < CONTROL2 > . . . ]

Specifies the file name where the Object code is to be stored. If Object code need not be stored, press CONTINUE.

**BREAK** Allows a temporary use of the Mainframe functions.

**EXIT** Returns you to the Main Menu.

## Macros

Defines a body of text that is automatically inserted into the Source code each time a Macro is called.

< Macro name >     **MACRO**   [ = < Dummy Parameters > . . . ] [ < COMMENT > ] Defines Macro

[ < LABEL > ]       < Macro Name >   [ < Actual > ] , [ < Actual > . . . ] [ < COMMENT > ] Calls Macro

[ < LABEL > ]       **ENDM**   [ < COMMENT > ]     Terminates a Macro expansion.

[ < LABEL > ]       **EXITM** [ < COMMENT > ]     Terminates the current expansion level

[ < LABEL > ]       **IRP**       = < DUMMY > , < ACTUAL > [ , < ACT > . . . ] [ < COMMENT > ]

Repeats the code sequence between IPR and the ENDM directive for every actual parameter.

[ < LABEL > ]      **IRPC**      = < DUMMY >, < ACTUAL > [ < COMMENT > ]

Repeats the code sequence between IRPC and the ENDM directive for every character in the actual parameter.

[ < LABEL > ]      **REPT**      < EXPRESSION >      [ < COMMENT > ]

Repeats the code sequence between REPT and the ENDM directive by the number of times defined by the Expression

=            Dummy parameter prefixes.

^            Pre-evaluation prefixes.

=NUM       Dummy parameter that is replaced by a 4-digit number during Macro expansion.

---

**NOTE**

When using Macros, the syntax for the LABEL and COMMENT fields obey the rules of the particular microprocessor type concerned.

---

## Console Module

Provides the communication between the Desktop Computer and the Microprocessor system.

### COMMANDS

**LOAD** " < FILE NAME > [ msus ] "      Transfers file from the Desktop Computer to Microprocessor System

**STORE** " < FILE NAME > [ msus ] "      Transfers data from Microprocessor System to Desktop Computer file.

**BREAK**      Allows a temporary use of the Mainframe functions.

**EXIT**        Returns you to the Main Menu.

Note. 8080/85 Conversion. A letter W in front of the Object file will convert the Object code format to that required by the Insert format.

### Special Keys

	ASCII char.	HEX. value
<b>STORE</b>	CR	0D
<b>SHIFT/STORE</b>	LF	0A
<b>BACKSPACE</b>	BS	08
<b>TAB</b>	HT	09
<b>CLEAR LINE</b>	DEL	7F

**Operators for the 8080/85**

+	Addition.
-	Subtraction.
*	Multiplication.
/	Integer Division. Any remainder is discarded ( $7/2=3$ ).
MOD	Modulo. Result is the remainder caused by a division operation.
( )	Parenthesized expressions override any precedence.
SHR	Shift to the right.
SHL	Shift to the left.
HIGH	Isolate High Order 8 Bits of 16-bit value.
LOW	Isolate Low Order 8 Bits of 16-bit value.
NOT	Logical One's Complement.
AND	Logical AND.
OR	Logical OR.
XOR	Logical Exclusive OR.
EQ	Equal.
NE	Not Equal.
LT	Less Than.
LE	Less Than or Equal.
GT	Greater Than.
GE	Greater Than or Equal.

**Operators for the 6800**

+	Addition
-	Subtraction
*	Multiplication
/	Integer Division
( )	Parenthesized expressions override any precedence.

**Operators for the Z80**

+	Addition
-	Subtraction
*	Integer Multiplication
/	Integer Division. Any Remainder is disregarded ( $7/2=3$ )
.MOD.	Modulo. Result is the remainder caused by a div. operation.
( )	Parentheized expression overrides any precedence
.SHR.	Shift Operand to the right
.SHL.	Shift Operand to the left
.NOT. \	Logical One's Complement
.AND. &	Logical AND
.OR.	Logical OR
.XOR.	Logical Exclusive OR
.EQ.	Equal
.LT. <	Less Than
.GT. >	Greater Than
.UGT.	Unsigned Greater Than
.ULT.	Unsigned Less Than



## 8080/85 Assembler Language Instructions

### Assembler Directives

[ < LABEL > : ]	<b>DB</b>	< EXPR >   < STRING > [ , < EXPR >   < STRING > . . . ] [ ; < COMMENT > ]	Define Byte.
[ < LABEL > : ]	<b>DS</b>	< EXPRESSION > [ ; < COMMENT > ]	Define Storage.
[ < LABEL > : ]	<b>DW</b>	< EXPRESSION > [ , < EXPRESSION > . . . ] [ ; < COMMENT > ]	Define word
[ < LABEL > : ]	<b>END</b>	[ < START ADDRESS > ] [ ; < COMMENT > ]	Defines End of Source code.
< NAME >	<b>EQU</b>	< EXPRESSION > [ ; < COMMENT > ]	Equates a symbol to an Operand. It may only be used once in a program with the same Name/Label.
< LABEL > :	<b>EQU</b>	< EXPRESSION > [ ; < COMMENT > ]	
[ < LABEL > : ]	<b>FAIL</b>	'USER DEFINABLE ERROR MESSAGE'	Forces Assembler to print a user defined error message.
[ < LABEL > : ]	<b>IF</b>	< EXPRESSION > [ ; < COMMENT > ]	Code sequence following IF directive is assembled if least sign. bit of expression equals 1.
[ < LABEL > : ]	<b>IFC</b>	< OPER1 > , < OPER2 > [ ; < COMMENT > ]	Code sequence following IFC directive is assembled if Operands are equal.
[ < LABEL > : ]	<b>IFNC</b>	< OPER1 > , < OPER2 > [ ; < COMMENT > ]	Code sequence following IFNC directive is assembled if Operands are not equal.
[ < LABEL > : ]	<b>ELSE</b>	[ ; < COMMENT > ]	Separates the IF, IFC, or IFNC directive from the ENDIF directive in order that one of two sequences can be defined.
[ < LABEL > : ]	<b>ENDIF</b>	[ ; < COMMENT > ]	Used with IF, IFC, IFNC directives to end a sequence.
[ < LABEL > : ]	<b>ORG</b>	< EXPRESSION > [ ; < COMMENT > ]	Assigns origin of location counter.
< NAME >	<b>SET</b>	< EXPRESSION > [ ; < COMMENT > ]	Sets a symbol to an Operand. SET is redefinable in the same program.
< LABEL > :	<b>SET</b>	< EXPRESSION > [ ; < COMMENT > ]	
[ < LABEL > : ]	<b>SPC</b>	< EXPRESSION > [ ; < COMMENT > ]	Program listing is spaced < expression > lines.

**Assembler Controls**

<b>\$[ CONTROL [, CONTROL . . . ]]</b>	Gives optional control of the output format with one or more of the following:
<b>TITLE "ASCII String"</b>	Program heading
<b>EJECT</b>	Moves paper to the top of the next page.
<b>SOURCE "&lt; FILE NAME &gt; [ msus ]"</b>	A file on the mass storage, specified in the Operand field of this directive, is included in the assembly.
<b>INCLUDE "&lt; FILE NAME &gt; [ msus ]"</b>	Same as for SOURCE.
<b>OBJECT [ "&lt; FILE NAME &gt; [ msus ]"</b>	Specifies in which file the Object code is to be stored.
<b>SYMBOLS</b>	Prints the Symbol Table after the program listing.
<b>*NOSYMBOLS</b>	Suppresses Symbol Table print.
<b>*XREF</b>	Prints the cross reference of all user symbols. Only one list is printed if XREF and SYMBOLS have been specified.
<b>NOXREF</b>	Suppresses the cross reference.
<b>SAVE</b>	Current list control settings LIST, COND, and GEN are stored and remain valid until explicitly changed.
<b>RESTORE</b>	Recalls the list control settings.
<b>*LIST</b>	Instructs the Assembler to generate a program listing.
<b>NOLIST</b>	Suppresses the printing of the program listing. Error messages appear on the CRT.
<b>*COND</b>	Includes conditional skipped Source lines in the listing.
<b>NOCOND</b>	Does not include conditionally skipped lines in the listing.
<b>*GEN</b>	Lists MACRO expansion.
<b>NOGEN</b>	Does not list MACRO expansion.

\*Marked controls show default settings if others are not specified.

## 6800 — Assembler Language Instructions

### Assembly Directives

[ < LABEL > ]	<b>END</b>	[ < COMMENT > ]	Defines the end of a Source code.
< LABEL >	<b>EQU</b>	< EXPRESSION > [ < COMMENT > ]	Equates a symbol to an Operand. May only be used once in a program.
[ < LABEL > ]	<b>FAIL</b>	'USER DEFINABLE ERROR MESSAGE'	Forces the Assembler to print user defined error messages.
[ < LABEL > ]	<b>FCB</b>	< EXPR > [ , < EXPR > ... ] [ < COMMENT > ]	Form constant byte.
[ < LABEL > ]	<b>FCC</b>	/TEXT/ [ < COMMENT > ]	Form constant character.
[ < LABEL > ]	<b>FCC</b>	COUNT, TEXT	
[ < LABEL > ]	<b>FDB</b>	< EXPR > [ , < EXPR > ... ] [ < COMMENT > ]	Form double constant byte.
[ < LABEL > ]	<b>IF</b>	< EXPRESSION > [ < COMMENT > ]	Code sequence following IF is assembled if expression evaluates to a value other than zero.
[ < LABEL > ]	<b>IFC</b>	< OPER1 > , < OPER2 > [ < COMMENT > ]	Code sequence following IFC is assembled if Operands are equal.
[ < LABEL > ]	<b>IFNC</b>	< OPER1 > , < OPER2 > [ < COMMENT > ]	Code sequence following IFNC is assembled if Operands are not equal.
[ < LABEL > ]	<b>ELSE</b>	[ < COMMENT > ]	Separates the IF, IFC, or IFNC directive from the ENDIF directive in order that one of two sequences can be defined.
[ < LABEL > ]	<b>ENDIF</b>	[ < COMMENT > ]	Used with the IF, IFC, and IFNC directives to end a sequence.
[ < LABEL > ]	<b>MON</b>	< START ADDRESS > [ < COMMENT > ]	Used when the Microprocessor system requires the Start Address in Object code.
[ < LABEL > ]	<b>NAM</b>	PAGE HEADING	Defines the page heading.
[ < LABEL > ]	<b>ORG</b>	< EXPRESSION > [ < COMMENT > ]	Assigns origin of location counter.
[ < LABEL > ]	<b>PAGE</b>	[ < COMMENT > ]	Moves paper to top of next page.
[ < LABEL > ]	<b>RMB</b>	< EXPRESSION > [ < COMMENT > ]	Reserve memory bytes.
< LABEL >	<b>SET</b>	< EXPRESSION > [ < COMMENT > ]	Sets a symbol to an Operand. SET is redefinable.
[ < LABEL > ]	<b>SPC</b>	< EXPRESSION > [ < COMMENT > ]	Program listing is spaced < expression > lines.

**Assembler Controls.**

<b>[ &lt; LABEL &gt; ]</b>	<b>OPT</b>	<b>[ &lt; CONTROL &gt; [ , &lt; CONTROL &gt; . . . ] ]</b>	Gives optional control of output format with one or more of the following:
<b>SOURCE</b>	<b>" &lt; FILE NAME &gt; [ msus ] "</b>		A file on the mass storage, specified in the Operand field with this directive, is included in the assembly.
<b>OBJECT</b>	<b>[ " &lt; FILE NAME &gt; [ msus ] "</b>		Specifies in which file the Object code is to be stored.
<b>SYMBOL</b>			Prints the Symbol Table after the program listing.
<b>*NOSYMBOL</b>			Suppress Symbol Table print.
<b>*XREF</b>			Prints the cross reference of all user symbols. Only one list is printed if XREF and SYMBOL have been specified.
<b>NOXREF</b>			Suppresses the cross reference.
<b>SAVE</b>			Current list of control settings LIST, COND, GEN, and MEX are stored and remain valid until explicitly changed.
<b>RESTORE</b>			Recalls the list control settings.
<b>*LIST</b>			Instructs the Assembler to generate a program listing.
<b>NOLIST</b>			Suppresses the printing of the program listing.
<b>*COND</b>			Includes conditional skipped Source lines in the listing.
<b>NOCOND</b>			Does not include conditionally skipped lines.
<b>*MEX</b>			Lists MACRO expansion.
<b>NOMEX</b>			Does not list MACRO expansion.
<b>*GEN</b>			Lists all code generated by the FCC directive.
<b>NOGEN</b>			Lists only the first line generated by the FCC directive.
<b>*Marked controls show default settings if others are not specified.</b>			

## Z80 — Assembler Language Instructions

### Assembler Directives

[ < LABEL > : ]	<b>COND</b>	< EXPRESSION >	[ ; < COMMENT > ]	Code sequence following COND is assembled if the expression evaluates to a value other than zero.
[ < LABEL > : ]	<b>DEFB</b>	< EXPR >   < STRING > [ , < EXPR >   < STRING > ... ]	[ ; < COMMENT > ]	Defines byte.
< LABEL > :	<b>DEFL</b>	< EXPRESSION >	[ ; < COMMENT > ]	Defines a Label to an Operand. Is redefinable in same program.
[ < LABEL > : ]	<b>DEFM</b>	< EXPR >   < STRING > [ , < EXPR >   < STRING > ... ]	[ ; < COMMENT > ]	Defines memory.
[ < LABEL > : ]	<b>DEFS</b>	< EXPRESSION >	[ ; < COMMENT > ]	Defines storage
[ < LABEL > : ]	<b>DEFW</b>	< EXPRESSION > [ , < EXPRESSION > ... ]	[ ; < COMMENT > ]	Defines word.
[ < LABEL > : ]	<b>ELSE</b>		[ < ; COMMENT > ]	Separates the COND, IFC, or IFNC directives from the ENDC directive in order that one of the two sequences can be defined.
[ < LABEL > : ]	<b>ENDC</b>		[ ; < COMMENT > ]	Used with COND, IFC and IFNC directives to end a sequence.
[ < LABEL > : ]	<b>END</b>	[ < START ADDRESS > ]	[ ; < COMMENT > ]	Defines the end of a Source code.
< LABEL > :	<b>EQU</b>	< EXPRESSION >	[ ; < COMMENT > ]	Equates a symbol to an Operand. May only be used once for the same Label.
[ < LABEL > : ]	<b>FAIL</b>	'USER DEFINABLE ERROR MESSAGE'		Forces the Assembler to print user-defined error messages.
[ < LABEL > : ]	<b>IFC</b>	< OPER1 > , < OPER2 >	[ ; < COMMENT > ]	Code sequence following IFC assembled if Operands are equal.
[ < LABEL > : ]	<b>IFNC</b>	< OPER1 > , < OPER2 >	[ ; < COMMENT > ]	Code sequence following IFNC if assembled if Operands are not equal.
[ < LABEL > : ]	<b>ORG</b>	< EXPRESSION >	[ ; < COMMENT > ]	Assigns origin of location counter.
[ < LABEL > : ]	<b>SPC</b>	< EXPRESSION >	[ ; < COMMENT > ]	Program listing is spaced < expression > lines.

**Assembler Controls.**

<b>* [ CONTROL [ , CONTROL . . . ] ]</b>	Gives optional control of output format with one or more of the following:
<b>HEADING "ASCII String"</b>	Program heading.
<b>EJECT</b>	Advances paper to the top of the next page.
<b>SOURCE "&lt; FILE NAME &gt; [ msus ] "</b>	A file on the mass storage, specified in the Operand file of this directive, is included in the assembly.
<b>INCLUDE "&lt; FILE NAME &gt; [ msus ] "</b>	Same as for SOURCE.
<b>OBJECT [ "FILE NAME [ msus ] "</b>	Specifies in which file the Object code is to be stored.
<b>SYMBOLS ON</b>	Prints the Symbol Table after the program listing.
<b>*SYMBOLS OFF</b>	Suppresses Symbol Table print.
<b>*XREF ON</b>	Prints the cross reference of all user symbols. Only one list is printed if XREF and SYMBOLS ON have been specified.
<b>XREF OFF</b>	Suppresses the cross reference.
<b>*LIST ON</b>	Instructs the Assembler to generate a program listing.
<b>LIST OFF</b>	Suppresses the printing of the program listing.
<b>SAVE</b>	Current list control settings LIST, CONDLIST, and MACLIST are stored and remain valid until explicitly changed.
<b>RESTORE</b>	Recalls the list control settings.
<b>*CONDLIST ON</b>	Includes conditional skipped Source lines in the listing.
<b>CONDLIST OFF</b>	Does not include conditionally skipped lines in the listing.
<b>*MACLIST ON</b>	Lists MACRO expansion.
<b>MACLIST OFF</b>	Does not list MACRO expansion.
<b>*Marked controls show default settings if others are not specified.</b>	

# Section Three

## Generation of the Program Cartridge



### Introduction

The tape cartridge supplied to you by Hewlett-Packard will not run on your machine in its existing condition. It must first of all be copied (Initialized) onto a second mass storage device. This could be either another cartridge or a flexible disc. This copy would run on the Desktop Computer. If desired, the copy can then be re-copied onto another empty cartridge in the primary tape drive (:T15).

Cartridge generation is made so that the copy produced is optimized for your available memory size. Hence, after generation the cartridge will only run correctly on a Desktop Computer that has the identical amount of memory as the machine on which it was made.

---

#### CAUTION

Ensure that the Desktop Computer and the selected mass storage device are each set up according to their installation procedures. This includes power switch settings, grounding requirements, and installation of the proper fuses. Refer to the appropriate manuals for installation instructions. The power must be off on both units before the interface cable is connected. Failure to comply with this caution could result in damage to the equipment.

---

### Conventions

If you have any difficulty with the conventions used in this section, refer to Section One for a complete explanation.

## Operating Procedure for Producing a Copy

---

### NOTES

If, during the generation procedure an error occurs you must start the procedure again. Hewlett-Packard cannot guarantee that the program will work correctly if this is not done.

A generated cartridge will only work on a Desktop Computer that contains the identical amount of memory as the machine on which it was made.

---

The following procedure is basically identical for both the 9835A and 9845B Desktop Computers.

To simplify the presentation, the presented menus have been taken from the 9835A CRT while the 9845B messages, though similar, are not shown. Minor differences between the Desktop Computer messages are noted.

Insert the supplied program cartridge into the standard tape drive of your Desktop Computer. Ensure that the secondary mass storage device (:T14, :F8, or other) contains the necessary storage medium.

Load the program with the automatic start capability of the Desktop Computer. Alternatively, type LOAD "AUTOST", 1 and press EXECUTE.

The following message is displayed on the 9835A CRT.

Before you can run the program, it is necessary to duplicate the contents of this tape onto a secondary mass storage device.

This should be the Flexible disk drive :F8.

At the end of this procedure the possibility exists to retransfer the program from the secondary mass storage device to another mass storage device.

Input msus of secondary storage device. Press CONTINUE  
:F8



The 9845B Desktop Computer message reads:

Before you can run the program, it is necessary to duplicate the contents of this tape onto a secondary mass storage device.

This can be either:                      Optional tape cartridge :T14, or  
    Flexible disk drive :F8

At the end of this procedure the possibility exists to retransfer the program from the secondary magnetic storage device to another mass storage device.

If :T14 is used, a blank Initialized cartridge must be installed.

Input msus of secondary storage device. Press CONTINUE  
 :T14

Pressing CONTINUE puts the entered value in the middle of the CRT and the bottom two lines display the next question.

Input max. symbol table size (Default is 1000). Press CONTINUE  
 1000

It is here that you must decide the number of symbols required for the symbol table and the number of entries needed in the X-ref table. The amount of memory available must be divided between the two. One more factor to bear in mind is the space required if you are going to make use of Macros.

Knowing the maximum number of lines in your Source code, divide by 5 to give the approximate number of symbols you require. This number will vary considerably from user to user. If, from experience, you know that you use a lot of symbols then enter a high number. Conversely, enter a low number when only a small amount of symbols are going to be used.

Depending upon the number you enter, the program allocates a number of Macro lines. In most cases, this is the Symbol table number divided by 5. Having done this, some of the available memory space is now occupied by the Symbol table and Macro storage. The remainder is used for symbol references.

The X-ref program must also store in memory the information as to where the symbols are defined and referenced. If there is insufficient space to store all the symbol references, this will not affect the operation of the Assembler program but will merely leave some empty entries in the X-ref list. An error message is given in this case.

You should always enter more than sufficient symbols to ensure correct operation of the Assembler program as missing entries in the X-ref table are not a serious handicap.

For example, if you know that your program will be 5000 Source lines long then 1000 symbols is the number you need. Entering 1000 gives you space for 200 Macro lines. The remaining amount of memory is used for symbol references.

The reference table below, gives you a guide line as to the number you should enter in the CRT.

Symbol Reference Table

Memory Size in Bytes	Answer to the question "Symbol Table Size"							
	500		1000		2000		4094	
	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines	Symbol Refs	No of Macro Lines
9835A								
115 402	4839	100	2939	200	—	—	—	—
180 842	13019	100	11119	200	7319	400	—	—
246 282	21326	100	19426	200	15626	400	7677	818
9845B								
187 146	13830	100	11929	200	8130	400	181	818
318 026	30190	100	28290	200	24490	400	16541	818
448 906	32767	1430	32767	1345	32767	1174	32767	818

---

**NOTE**

The figures in the above table may vary slightly depending upon your particular system configuration.

---

Pressing CONTINUE puts the answers to all previous questions on the CRT and another message is given.

Ensure secondary storage device is ready. Press CONTINUE.

The CRT displays:

Your program cartridge is being duplicated.

Remember!

A generated cartridge will only work on a Desktop computer that contains the identical amount of memory as the machine on which it was made.

After duplication has been made a further message appears

You can now retransfer the program from your secondary mass storage device onto another mass storage device. If :T15 is used, a blank Initialized cartridge must be installed.

This will purge the program on the secondary mass storage device.

Do you want to retransfer (Y/N)? Press CONTINUE

To answer with a N (NO), a message informs you on how to run the program.

You may want to use a mass storage other than your present device. In this case, answering with a Y (YES) rewinds the original program cartridge for removal and you are asked if you would like to retransfer your program to some other mass storage device.

Answering YES brings-up the following message:

Input msus of the new storage device. Press CONTINUE.  
:T15

Enter appropriate msus. Press CONTINUE.

The next message informs you that the retransfer is taking place.

Your program is being retransferred to the storage device :T15

When duplication is finished, or if you had previously answered NO to the retransfer question, the following message appears.

PROGRAM HAS BEEN TRANSFERED, COPY NOW COMPLETE

To run the program, enter the msus of the device where your program is located, and call the Main menu for selection of the module you desire to work with.

Two commands need to be typed:

MASS STORAGE IS msus\* and press EXECUTE.

Followed by,

LOAD "AUTOST", 1 and press EXECUTE.

---

**NOTE**

\*The msus in the above menu is replaced, on your CRT, by the actual device select code where your program is located. This is the device select code you must type with the above commands.

---

The Main Menu appears

## Section Four Obtaining the Main Menu

### Program Start



Type MASS STORAGE IS msus\* and press EXECUTE.

Load the file with LOAD "AUTOST", 1 and press EXECUTE.

The Main Menu appears.

#### MAIN MENU

Choose and then press one of the SFKs

k0 for INITIALIZATION  
k1 for EDITOR  
k2 for ASSEMBLER  
k3 for CONSOLE

Press STOP to terminate the program

The above four modules are further explained in the following manual Sections.

---

#### NOTES

The SFK BREAK can be used to leave any of the above modules to perform an operation with the Desktop Computer such as a catalog or a mathematical calculation. The key CONTINUE brings you back to the module you were working with before pressing SFK BREAK.

The msus in the above instruction should be replaced by the actual mass storage unit specifier where your program is located.

---



# Section Five Initialization Module



## Introduction

Special Function Keys (SFK) allow you to change the peripheral default values that are already stored in the default file. Each time a Menu appears on the CRT, the program waits until you press one of the SFK's.

Inputs, sent to the program by pressing CONTINUE are checked for syntax correctness and you are informed of any errors that may exist in your input.

The SFK BREAK can be used to leave this module to perform an operation with the Desktop Computer such as a catalog or a mathematical calculation. The CONTINUE key brings you back to the Initialization module.

## Conventions

If you have any difficulty with the conventions used in this section, refer to Section One for a complete explanation.

## The Menus

Selecting SFK k0 from the Main menu results in the Initialization Menu appearing on the CRT.

INITIALIZATION MENU	
Choose and then press one of the SFKs	
k0	for PRINT-OUT of DEFAULTS
k1	for PRINTER
k2	for EDITOR and ASSEMBLER
k3	for CONSOLE
k5 (EXIT)	for INITIALIZATION completed

On the 9845B, press k7 (EXIT) when Initialization is complete.

Pressing SFK k0 produces a print-out of default values on the printer.

When you run this module for the first time ensure that the select code for the printer has been set correctly.

PRINT-OUT OF DEFAULT VALUES		
	System 9835	System 9845
<b>PRINTER</b>		
PRINTER SELECT CODE .....	7,1	.. 0
WIDTH .....	80	.. 80
NUMBER OF LINES EACH PAGE.....	70	.. 70
PAPER IS PERFORATED .....	Y	.. Y
FORMATTED LISTING.....	Y	.. Y
<b>EDITOR AND ASSEMBLER</b>		
msus FOR EDITOR WORK FILES.....	:F8	.. N
msus FOR SOURCE FILE .....	:F8	..:T14
msus FOR OBJECT FILE .....	:F8	..:T14
<b>CONSOLE</b>		
msus FOR LOAD FILE.....	:F8	..:T14
msus FOR STORE FILE.....	:F8	..:T14
SELECT CODE FOR SERIAL INTERFACE .....	11	.. 11
<b>SERIAL INTERFACE RS 232C/V24</b>		
BAUD RATE .....	9600	.. 9600
DATA WORD LENGTH.....	8	.. 8
PARITY CHECK.....	N	.. N
STOP BIT .....	1	.. 1
*INTEL FORMAT CONVERSION.....	Y	.. Y

The two right-hand columns list the default values for your system. Both columns are shown here however, only the column appropriate to your system will appear on the print-out. After the print-out has been made the program returns to the Initialization Menu.

---

**NOTE**

\*The "INTEL FORMAT CONVERSION" only appears on the 8080/85 program (refer to the Console module for more information).

---



To make changes in the following Menus, select the appropriate SFK and the given default value appears in the display line of the CRT. Make any necessary changes before pressing CONTINUE to put the new value back in the menu.

Pressing SFK k1, on the Initialization Menu, results in the following Printer Menu appearing on the screen.

PRINTER			
To change default values, press appropriate SFK			
k0	for	PRINTER SELECT CODE	7,1
k1	for	WIDTH (min 60 and max 260)	80
k2	for	NUMBER of LINES each page (min 40 and max 999)	70
k3	for	PAPER is PERFORATED (possibilities Y=yes/N=no)	Y
*k4	for	FORMATTED LISTING (possibilities Y=yes/N=no)	Y
k5	(EXIT)	for retrieving the Initialization Menu	

If changes are necessary, select one of the above SFKs and the displayed default value appears at the bottom of the CRT.

---

**NOTE**

\*Only answer Y (yes) to this question if your printer can execute form feeds.

---

After making the change, press CONTINUE and the correct statement is written in the menu. Further changes are made in the same way after pressing the appropriate SFK.

Press k5 EXIT (k7 on the 9845B) to retrieve the Initialization Menu.

To obtain the Editor and Assembler Menu, select SFK k2

EDITOR AND ASSEMBLER			
To change default values, press appropriate SFK.			
*k0	for	msus for EDITOR WORK FILES (possibilities msus/N=none)	N
k1	for	msus for SOURCE FILE	:F8
k2	for	msus for OBJECT FILE	:F8
k5	(EXIT)	for retrieving the Initialization Menu	

---

**NOTE**

\*The msus for the "Editor work files" is the mass storage device that the Editor is working with if the Source lines cannot be held in memory. Enter N if you do not wish to use work files. The maximum number of Source lines is then limited to the amount shown in the table that lists Source lines with respect to memory size (Equipment requirement paragraph, Section One).

---

After selection of the appropriate SFKs, change the default values and press CONTINUE to enter the information on the menu.

Press k5 EXIT (k7 on the 9845B) to retrieve the Initialization Menu.

To obtain the CONSOLE Menu, select SFK k3

CONSOLE			
To change default, press appropriate SFK.			
k0	for	msus for LOAD FILE	:F8
k1	for	msus for STORE FILE	:F8
k2	for	SELECT CODE for SERIAL INTERFACE	11
k3	for	SERIAL INTERFACE Sub-menu RS 232C/V24	
k5	(EXIT)	for retrieving the Initialization Menu	

After selection of the appropriate SFKs, change the default values and press CONTINUE to enter the information on the menu.

Press k5 EXIT (k7 on the 9845B) to retrieve the Initialization Menu.

Selecting the SFK k3 brings-up a further menu for the "Serial Interface RS 232C/V24".

SERIAL INTERFACE RS 232C/V24 SUB-MENU		
To change default values, press appropriate SFK.		
k0	for	BAUD RATE ..... 9600 (possibilities 75/110/150/300/ 600/1200/1800/2400/4800/9600)
k1	for	DATA WORD LENGTH..... 8 (possibilities 5/6/7/8)
k2	for	PARITY CHECK..... N (possibilities E=even/O=odd/N=none)
k3	for	STOP BIT ..... 1 (possibilities 1/1.5/2)
*k4	for	INTEL FORMAT CONVERSION..... Y (possibilities Y=yes/N=no)
k5	(EXIT)	for retrieving the CONSOLE menu

After selection of the appropriate SFKs, change the default values to one of the possibilities given. Press CONTINUE to enter the information on the menu.

---

**NOTE**

\*The k4 statement in the above menu only appears on the 8080/85 program menu.

---

At this stage, the Initialization is complete.

Press EXIT k5 (k7 on the 9845B) twice to return to the Initialization Menu.

# Section Six

## The Editor Module



### Introduction

The Editor allows you to generate, modify, and correct Source code. The working field of the Editor is the CRT. Writing and editing is performed by use of the cursor controlled by the display keys.


When using the Editor module, three terms will often occur. For a better understanding, a brief description of each term is given below.

**BREAK.** Use of the SFK BREAK, takes you out of the EDIT or COMMAND mode and all mainframe keys, except the SFKs, return to their original status. You may now perform such functions as calculations, catalog, etc. . . Pressing CONTINUE takes you to the Command mode.

**COMMAND MODE.** With this mode instructions can be given to the Desktop Computer that allow you to manipulate your Source code. Commands may either be typed on the CRT or called for by the various function keys.

**EDIT MODE.** This mode is entered by the PROGRAM key entitled EDIT on the 9835A or the SFK key entitled EDIT if you are using a 9845B. It allows you to write and edit your Source code. When in this mode, the operation of some mainframe keys change while others are inactive. Key descriptions are given later in this Section.

The following diagram gives you an overview of the Editor structure and how you can change between the various modes.



## Writing or Modifying Source Code

To use the Editor, call-up the Main Menu on the CRT and select SFK k1.

Before you start editing your Source code, you may wish to load a particular file from a mass storage device into memory. To begin a new Source code, enter the Edit mode by using the EDIT key.

Section VII of this manual gives a brief description of the Assembler Language instructions and differences that have been incorporated by Hewlett-Packard.

## File Handling

The Editor has a file handling system so that Source code can be handled that may be larger than the working space of the Desktop Computer memory.

A working file is created on the mass storage device whenever an overflow of the Editor memory occurs. The length of the file depends upon the size of the mainframe memory and the input Source code.

## Used as a Text Editor

Generally, the Editor works with Line numbers but by turning OFF the Syntax check and using the LIST statement followed by the @ sign, it can function as a text editor. Existing text already on a mass storage file, without line numbers, can be loaded.

When used for text editing, there is no provision in the program for vertical formatting of the listing (SPACE and PAGE commands are only recognized by the Assembler program).

You can put LF, FF characters into the text from the Desktop Computer keyboard, with the key CONTROL, that will effect the listing. However, it must be remembered that you have a default value, entered on the Printer Menu of the Initialization module, whereby the number of lines per page is given. Hence, everytime a print-out is made form feeds are automatically made when the respective number of lines is reached. It is possible to minimize the number of form feeds, executed by the Editor, by increasing the default value for the number of lines per page to 999.

## The Keyboard

A complete description of the Mainframe keyboard is given in your 9835A or 9845B Operating and Programming Manual.

The following is a list of keys which are the same as the Mainframe or very similar.

### Model 9845B

CLEAR → END  
 CLEAR LINE  
 DEL CHR  
 DEL LN  
 HOME  
 INS CHR  
 ROLL (up arrow ↑)  
 ROLL (down arrow ↓)  
 PRT ALL  
 TAB CLEAR  
 TAB SET  
 TYPWTR  
 up arrow ↑  
 down arrow ↓  
 right arrow →  
 left arrow ←

### Model 9835A

BACK  
 CLR → END  
 CLEAR LINE  
 DEL CHR  
 DEL LN  
 FWD  
 HOME  
 INS CHR  
 PRT ALL  
 TAB CLEAR  
 TAB SET  
 TO END  
 TYPWTR  
 up arrow ↑  
 down arrow ↓  
 right arrow →  
 left arrow ←

### Keys that are inactive

STEP  
 RUN  
 RESULT  
 PAUSE  
 CLEAR  
 SPACE DEPENDENT

### Keys that have the same function as one another

The CONTINUE and EXECUTE keys both have the same function except when the BREAK key has been pressed.

**Keys whose function change between Edit and Command Modes****CONTINUE/EXECUTE**

When in "EDIT MODE" – Continue key takes you from the Edit mode to the Command mode.

When in "COMMAND MODE" – Continue key executes a given command.

**RECALL**

When in "EDIT MODE" – Using the STORE, DELETE LINE, CLEAR LINE or CLR→END key puts the line in which the cursor is to the top of a recall buffer. It returns on using the RECALL key.

When in "COMMAND MODE" – The RECALL key has its Mainframe function.

**Keys with a different function to Mainframe.**

**CLEAR LINE** Clears the line of characters but the line numbers remain.

**HOME** Puts the cursor at the 7th character position on the same line that it was on before HOME was pressed.

**INS LN** Like its original mainframe function, the INS LN key inserts lines. However there is no restriction, as with the mainframe, where an insertion cannot be made if the difference between two line numbers is only one. With this key the Editor makes an insertion and then rennumbers a minimum number of following lines.

**STORE/**  
**down arrow ↓** In addition to moving the cursor through the Source code it also allows you to append empty lines with line numbers at the end of the code.

**TAB** Has tab default positions across the CRT. The first setting is at character position 7 and then with increments of 10 until position 77. These positions may be deleted with the TAB CLR and/or new ones added with TAB SET.



**9845B ONLY.**

**HOME/SHIFT** In the Edit mode it puts the cursor to the first blank space at the end of the Source line.

**9835A ONLY.**

**SHIFT down** Moves information on the CRT down 20 lines.  
**arrow ↓**

**SHIFT up** Moves information on the CRT up 20 lines in the printout area.  
**arrow ↑**

---

**NOTE**

It is not possible to change the line number during editing. Line numbering is handled by the program.

---

## SFK Overlay

The Editor module makes extensive use of the Special Function Keys. An SFK overlay is provided for the Hewlett-Packard Desktop computer and contains the pre-defined definitions that are implemented by the program.

The keys in the upper row, 0 through 4 (0 through 6 for the HP 9845B) can be defined by you as typing aids for statements, variable names or other series of often-used keystrokes (see EDIT KEY statement).

The overlays for the 9845B and 9835A are shown below.

### 9835A Overlay

						Microprocessor Development
S						BREAK
[Empty box]						
						EXIT
S	SYNTAX	DELETE	CHANGE	COPY	JOIN	RENUMBER
[Empty box]						
	SYNTAX	LOAD	FIND	STORE	EDIT KEY	SCRATCH

### 9845B Overlay

								Microprocessor Development
							BREAK	
[Empty box]								
								EXIT
S	SYNTAX	DELETE	CHANGE	COPY	JOIN	RENUMBER		
[Empty box]								
	SYNTAX	LOAD	FIND	STORE	EDIT KEY	EDIT	LIST	SCRATCH

## Special Function keys

The following is a description of the Special Function Keys whose definition has been defined by the program.

### Conventions

If you have any difficulty with the conventions used in this section, refer to Section One for a complete explanation.

### SFK — BREAK

The BREAK key takes you out of the Editor mode and allows you to use the standard features of the Desktop Computer. This would be used, for example, when a CAT (Catalog) is required or when you need to make a calculation.

### SFK — CHANGE

Complete Syntax: **CHANGE "<STR1>" TO "<STR2>" [ FROM <LNA>[ ,<LNB> ]]**

**CHANGE "<STR1>" TO "<STR2>"**

The Editor substitutes <STR2> for <STR1> throughout the complete Source code. The maximum length of either string is 74 characters.

If <STR2> is longer than <STR1> the Editor inserts the additional characters. If <STR2> is shorter than <STR1> then the remaining characters of <STR1> are deleted.

**CHANGE "<STR1>" TO "<STR2>" FROM <LNA>**

String substitution takes place from <LNA> until the end of the program.

**CHANGE "<STR1>" TO "<STR2>" FROM <LNA>, <LNB>**

This instruction defines the range within which the substitution should be made. The range begins at line <LNA> and continues to line <LNB>, all lines inclusive.

## SFK key — COPY

**COPY** <LNA>,<LNB> **TO** <LNC>

The range <LNA> to <LNB> is copied into the Source code beginning with location line <LNC>. An automatic renumbering takes place if there is insufficient space to insert the specified range. The renumbering is similar to pressing the INS LN key.

COPY can only be used if the line <LNC> does not exist. The line <LNC> cannot be placed between <LNA> and <LNB>.

## SFK — DELETE

**DELETE** <LNA>,<LNB>

Deletes all lines between and including <LNA> and <LNB>.

## SFK — EDIT (9845B) PROGRAM key — EDIT (9835A)

Complete Syntax: **EDIT** [ <LN>[ ,<INCREMENT> ] ]

### EDIT

Press EDIT and CONTINUE, and the CRT is ready for your inputs. Line number 10 appears on the CRT. If the Source is already in the Editor memory it appears in the CRT with the first line at the top. Upper and lower case letters, control characters, as well as all other types of ASCII characters may be input.

A line may contain a maximum of 74 characters (plus 6 for the line number). A beep is sounded when the maximum is reached and no more characters can be entered.

After you have finished with each line, use the STORE key to move the cursor to the start of the next. A syntax check is made when the SYNTAX is ON (default value).

The maximum line number is 99999, however only a total of 32767 lines can be stored.

**EDIT** <LN>

It is possible to find a particular line in your program by using the Edit command followed by <LN>, whereby <LN> is the line number you require. When found the line is displayed together with 19 additional lines. If <LN> is greater than the last available line, then the last 10 lines are displayed.

Use this Command to start a Source code at a given line number <LN>, (default is 10).

**EDIT <LN>,<INCREMENT>**

Applies when you begin to write your Source code in the Edit mode. The command specifies the starting line number and the increment. If used with an existing program, the <INCREMENT> is only effective for lines added at the end of the Source code.

**SFK — EDIT KEY**

Words or messages can be stored on the SFK's k0 through k4 (9835A) or k0 through k6 (9845B), and can be used afterwards as typing aids when entering your Source code. Text must be kept to less than 74 characters.

To program a SFK, follow the instructions in the display line on the CRT.

To recall your text, when in the Edit mode, press the SFK containing the programmed message and it will appear at the position of the cursor on the CRT.

**SFK — EXIT**

SFK EXIT returns you to the Main Menu. If you have not stored your Source code, a CRT prompt asks you if you want to or not. All previous code, and the work file on your mass storage device, are purged.

**SFK — FIND**

Complete Syntax: **FIND** "<STR>" [ **FROM** <LNA> [ , <LNB> ] ]

**FIND** "<STR>"

Using this command, the Source code is searched for a defined String. The maximum length of your defined String must not exceed 74 characters. The Source code is searched until the first string is found. This done, the cursor is located beneath the first character of the String. Modifications can now be made within the String.

Leaving the line with any other operation except CONTINUE causes the Command to end. The CONTINUE key continues the search for the next String.

**FIND** "<STR>" **FROM** <LNA>

The Source code is searched for the specified String <STR> beginning with <LNA>. The sequence ends by entering the Command mode.

**FIND** "<STR>" **FROM** <LNA>, <LNB>

The Source code is searched for the specified String <STR> within the range <LNA> to <LNB>. The sequence ends by entering the command mode.

## SFK — JOIN

Complete Syntax: **JOIN** "<FILE NAME> [msus]" [ <LN> ] [ @ ]

**JOIN** "<FILE NAME>"

Source code is loaded from the mass storage device and joined onto the Source code already in the Editor memory. When line numbers exist on the new code, and they are smaller or equal to the last line number on the existing code, and when no LN is specified, then the first line number of the new code will be the last line number of the already existing Source file plus the line increment.

**JOIN** "<FILE NAME> msus"

The msus defines the mass storage device from which the file is to be joined. If no msus specification is made, the default is the msus for the Source file stored in the Initialization module default file.

**JOIN** "<FILE NAME> msus" <LN>

If <LN> is specified then the file being joined has <LN> as the first file number. The <LN> may not be smaller than the last line number of the existing Source file.

The optional @ will generate line numbers in front of the lines being loaded irrespective of whether line numbers are there or not. The @ is normally used for Source code that does not have line numbers. If < LN > is specified, the Source code to be joined begins with the specified number.

## SFK — LIST (9845B) PROGRAM key — LIST (9835A)

Complete Syntax: **LIST** [ #<SC>; ] [ <LNA> [ ,<LNB> ] ] [ @ ]

<b>LIST</b>	The whole Source code is listed
<b>LIST</b> <LNA>	Listing is made from <LNA> to the end of the code.
<b>LIST</b> <LNA>, <LNB>	Listing is made from <LNA> to <LNB> inclusive.

The above three commands are listed on the printer whose Select Code is in the Initialization module default file.

Adding the option # <SC>; before an instruction specifies the Select Code of a different printer.

Additionally, to put the option @ after an instruction causes the Source code to be printed without line numbers.

## SFK — LOAD

Complete Syntax: **LOAD** "<FILE NAME> [msus]"[@]

**LOAD** "<FILE NAME>"

Type in the name of the file that is to be loaded from the default msus. The maximum length of a line should not exceed 74 characters plus another 6 for the line number. The maximum number of lines is 32767. No more than 6 characters are allowed in the file name. The Select Code is the msus for the Source file in the Initialization default file.

**LOAD** "<FILE NAME> msus"

Loads the Source code from a given mass storage device specified by the msus.

The optional @ will generate line numbers in front of the lines being loaded irrespective of whether line numbers are there or not. The @ is normally used for Source code that does not have line numbers.

## SFK — RENUMBER

Complete Syntax: **RENUMBER** [<LN> [,<INCREMENT> ]]

**RENUMBER**

This command allocates new line numbers to the existing Source code. If no specification is given, line numbers begin with 10, and increment by 10.

**RENUMBER** <LN>

Starts renumbering with <LN> as the first line of the Source code. Lines increment by 10.

**RENUMBER** <LN>,<INCREMENT>

Defines the first line number of the Source code and the increment.

## SFK — SCRATCH

This command deletes the contents of the Editor memory including work files.

## SFK — STORE

Complete Syntax: **STORE** "<FILE NAME> [ msus ]"[ <LNA> [,<LNB> ]] [@]

**STORE** "<FILE NAME>"

When you have finished with your Source code, it can be stored as a data file using the device given on the Initialization module default file.

**STORE** "<FILE NAME> msus"

Source code is stored on a specified mass storage device.

**STORE** "<FILE NAME> msus" <LNA>

It is also possible to store just a part of the Source code, beginning with <LNA> until the end of the code.

**STORE** "<FILE NAME> msus" <LNA> ,<LNB>

When both specifiers are given, the Source code between <LNA> and <LNB> is stored.

The optional specification @ means that the file is stored without line numbers.

## SFK — SYNTAX

The Editor makes a syntax check of each line, however it does not consider the logical data flow. If a syntax error is found, an error message is displayed at the bottom of the CRT and the cursor is placed over the mistake so that it can be corrected. A syntax check is made whenever a line is left, regardless of the type of instruction used. A line is also checked when an insert is made.

When the syntax rejects a statement it can be overridden by using the STORE key in conjunction with the SHIFT key (press SHIFT/STORE). The Syntax accepts the instruction as valid and the next line may be entered.

There are two possible states that can be entered:

**Syntax ON.** This is the initial state of the Editor. A syntax check is made and the word "SYNTAX" appear on the display line.

**Syntax OFF.** No syntax check occurs.



## Points To Remember

1. You cannot enter more Source lines than your Desktop Computer memory will accept without using work files. The specification section of this manual (Section I) lists the amount of Source lines possible with respect to memory size. Trying to exceed the maximum causes an error message. To remedy this you must store your Source code and then specify that you need files by entering the correct information in the "Editor and Assembler" menu of the Initialization Section.
2. When using the COPY, LOAD, or JOIN commands it may happen that you exceed the maximum amount of line numbers or maximum number of lines. Your Source code is still available up to the moment the Error message occurred. No more than 100 work files are possible.



# Section Seven

## 8080/85 Assembly Language Instructions



### Introduction

The following is a description of the Assembly Language instructions needed to write Source code for the 8080/8085 Microprocessor. We recommend that you make yourself acquainted with this explanation as it differs in some respects from the description given by 8080/85 Programming manuals.

### Source Line Format

A Program written in Assembler Language is called a Source code. It consists of symbolic commands called statements. Each statement is written on a single line and may consist of from one to four fields. From left to right the fields are:

(1) LABEL:           (2) INSTRUCTION       (3) OPERAND       (4) ;COMMENT

The following pages describe each field individually. An illustration of the format pattern is given below.

[ <LABEL>: ] [ <INSTRUCTION> ] [ <OPER> [ , <OPER> ... ] ] [ ; <COMMENT> ]

Space LABEL: space INSTRUCTION space OPERAND, OPERAND space ; COMMENT

Optional	Optional	at least one	Optional

To assist you when writing your Source code, it is not necessary to ensure that all your characters are inputted as capital letters as all lower case characters are converted to upper case.

## Label Field

A Label is required for statements involved in the definition of symbols and occasionally at destinations of branch and jump instructions.

A Label is a symbol name whose value is the location where the instruction is assembled. Any number of characters (limited by the line length) may be used however, the assembler only recognises up to eight alphanumeric characters whereby the first character must be alphabetic. A Label may be used in any Source line but need not begin in the first character position of a statement. All Labels must end with a colon.

In the 8080/85 language Labels are sometimes called Names. They may be used instead of a Label for the SET, EQU, and MACRO directives. These directives are described later in this Section. Names follow the same coding rules as Labels but are not terminated with a colon.

The Assembler maintains a location counter to provide addresses for the symbols in the Label field. When a symbol is found in the Label field the Assembler places the symbol and the corresponding location counter value in a symbol table.

## Instruction Field

Instructions are machine or pseudo mnemonics and must be present in all statements except when the statement consists only of a Comment or Label. Pseudo mnemonics are described later in this Section, and a list of 8080/85 machine mnemonics is given at the back of this Section.

## Operand Field

The Operand field identifies the data to be acted upon by the specified instruction. Some instructions require no Operand, while others require one or more.

The Operand field is separated from the Instruction field by at least one blank. If more than one Operand is required they are separated from each other by a comma.

The type of information placed in the Operand field depends upon the particular Instruction. The following are recognized by the Assembler as Operands:

- Numbers
- Symbols
- Expressions
- ASCII strings
- Location counter symbol (**\$**)

The listed Operand types are now described in more detail.

## Numbers

The Assembler accepts numbers in the Operand field in several different bases: binary, octal, decimal, and hexadecimal. Numbers are accepted in the following formats:

<Number>	Specifies a Decimal number	0-65536
<Number>D	Specifies a Decimal number	0D-65536D
<Number>H	Specifies a Hexadecimal number	0H-0FFFFH
<Number>O	Specifies an Octal number	0O-177777O
<Number>Q	Specifies an Octal number	0Q-177777Q
<Number>B	Specifies a Binary number	0B-1111111111111111B

The <Number> must always begin with a numeric character. For example:

A9FFH	Illegal (will be recognized as a Symbol)
0A9FFH	Correct specification.

## Symbols

Symbols can be divided into three separate identities, Reserved, User definable, and Assembler generated symbols.

Reserved symbols are those that already have a special meaning to the Assembler and therefore cannot appear as user-defined symbols. The mnemonic names for microprocessor instructions and the Assembler directives are all reserved symbols.

The following instruction Operand symbols are also reserved:

A	Register A
B	Register B, or Register pair B & C
C	Register C
D	Register D, or Register pair D & E
E	Register E
H	Register H, or Register pair H & L
L	Register L
SP	Stack Pointer
PSW	Program Status Word
M	Memory Reference Identification.
\$	Location Counter.

User-defined symbols are symbols you create to reference instructions and data addresses. These symbols are defined when they appear in the Label field of an instruction, EQU, SET, or MACRO.

## Expressions

An expression is an Operand entry consisting of either a single term or a combination of terms. It contains a valid series of numbers, and symbols that may be connected by operators.

An intermediate result, if obtained during the evaluation of expressions, will be truncated to a 16 bit value.

The Assembler includes five groups of Operators which permit the following Assembly-time operations:

- Arithmetic
- Shift
- Byte
- Logical
- Relational

It is important to remember that these are assembly-time operations. Once the Assembler has evaluated an expression, it becomes a permanent part of your program.

Expressions are evaluated from left to right. Operators with higher precedence are evaluated before other operators that immediately precede or follow them. When two operators have equal precedence, the left most is evaluated first.

The following list describes classes of operators in order of precedence.

Parenthesized expressions Unary Minus HIGH LOW * / MOD SHR SHL + - Relational Operators NOT AND OR XOR	High ↓ Low
--	------------------

The Assembler must complete the numeric evaluation of symbols and expressions in two passes. Only one level of forward addressing is permitted in the use of symbols or expressions in the Operand field of the Source statements.

For instance, in the example below P would not be evaluated.

P	EQU	R
R	EQU	Q
Q	EQU	5

## ARITHMETIC OPERATORS

Operator	Meaning
+	Addition
-	Subtraction
*	Multiplication
/	Integer Division. Any remainder is discarded ( $7/2=3$ ).
MOD	Modulo. Result is the remainder caused by a division operation. ( $7 \text{ MOD } 3 = 1$ )

Examples:

The following expressions generate the bit pattern for the ASCII character A, where A equals 65 decimal.

```
5+30*2
(25/5)+30*2
5+(-30*-2)
```

Example of MOD

The MOD operator must be separated from its Operands by spaces:

```
NUMBER MOD 8
```

Assuming that NUMBER has the value 25, then the expression evaluates to 1.

## SHIFT OPERATORS.

Operator	Meaning
y SHR x	Shift 'y' to the right 'x' bit positions.
y SHL x	Shift 'y' to the left 'x' bit positions.

The shift operators do not wraparound any bits shifted out of the byte. Bits vacated by the shift operation are zero filled. Note that the shift operator must be separated from its Operands by spaces.

Example:

Assume that NUMBER has the value 0101 0101B. The effect of the shift operators is as follows:

```
NUMBER SHR 2 0001 0101B
NUMBER SHL 1 1010 1010B
```

**BYTE ISOLATION OPERATORS**

Operator	Meaning
HIGH	Isolate High Order 8 Bits of 16-bit value.
LOW	Isolate Low Order 8 Bits of 16-bit value.

The Assembler regards expressions as 16-bit values. In certain cases, you need to deal with only part of an address, or you need to generate an 8-bit value. This is the function of the HIGH and LOW operators.

Example:

Assume that ADDRESS is an address manipulated at assembly time for building tables or lists of items that must all be below address 255 in memory. The following IF directive determines whether the HIGH-order byte of ADDRESS is zero, thus indicating that the address is still less than 256:

```
IF HIGH ADDRESS EQ 0
    ....
    ....
    ....
```

**LOGICAL OPERATORS.**

Operator	Meaning
NOT	Logical One's Complement
AND	Logical AND
OR	Logical OR
XOR	Logical Exclusive OR

The logical operators act only upon the least significant bit of values involved in the operation (except for the NOT operator).

Example:

```
If      VALUE1 = 12
        VALUE2 = 15
        VALUE3 = 20
```

```
Then VALUE1 AND VALUE2 AND VALUE3 = 0
```



**RELATIONAL OPERATORS.**

Operator	Meaning
EQ	Equal
NE	Not Equal
LT	Less Than
LE	Less Than or Equal
GT	Greater Than
GE	Greater Than or Equal

The relational operators produce a yes-no result. Thus, if the evaluation of the relation is TRUE, the value of the result is all ones. If false, the value of the result is all zeros.

Relational operators compare unsigned binary values. Hence, a  $-3$  will be evaluated as greater than 10.

Example:

The following IF directive tests the values of VALUE1 and VALUE2 for equality. If the result of the comparison is TRUE, the assembly language coding following the IF directive is assembled. Note that the relational operator must be separated from its Operand by spaces.

```
IF VALUE1 EQ VALUE2
    . . .
    . . .
```

**ASCII Strings**

All ASCII characters enclosed in single quotes define an ASCII String. Two successive quotes must be used to represent one single quote. For example:

```
'TODAY'S DATE' is written for TODAY'S DATE
```

Double quote marks can also be used to define an ASCII String. In this case, the double quotes determine the String delimiter while a single quote is regarded as a character within the String.

**Comment Field**

Comments can be optionally used at the end of a Source line. If present, they are ignored by the Assembler during translation and appear only in the program listing.

A Comment must begin with a semicolon. Alternatively, a line can exist as only a comment.

## Assembler Directives

The Assembler directives, sometimes called pseudo mnemonics, are instructions entered into the Source code which direct the Assembler when it generates the Object code. They control the operation of the Assembler program and define the format of the Assembler output listing.

The following examples are taken from an assembled program. Both the Source code and Assembler program are listed at the end of the examples in their entirety.

### DB – Define byte

```
[ <LABEL>: ] DB <EXPR> | <STRING> [ , <EXPR> | <STRING> ... ] [;<COMMENT> ]
```

An 8-bit value corresponding to each Operand is stored in a byte of the Object program. This directive may have one or more Operands, separated by commas. The number of Operands is limited by the Source line length of 80 characters. The Operand can be any constant, symbol, an expression evaluating to an 8-bit value, or an ASCII String. When the Label is present the address of the first generated byte is assigned to the symbol represented by the Label.

#### Example

```
210 1217 24          DB      00100100B ;BINARY VALUE
220 1218 54455854   DB      'TEXT'   ;ASCII "TEXT" INTO MEMORY
```

### DS – Define storage

```
[ <LABEL> : ] DS <EXPRESSION> [;<COMMENT> ]
```

The DS directive increases the location counter by the value of the expression. This reserves a block of memory equal to the size of the expression value. When a symbol is used, it must have been previously defined. A symbol that has been defined by a Label is assigned the address of the first byte reserved by this directive. The contents of the memory block are unchanged. The Assembler only advances the location counter and does not generate any Object code.

#### Example

```
240 121C          TEMP:   DS      8          ;CREATE AREA 8 BYTES LONG
```

### DW – Define word

```
[ <LABEL>: ] DW <EXPRESSION> [,<EXPRESSION> ... ] [;<COMMENT> ]
```

The DW directive is similar to the Define Byte directive except that it generates a double byte Object from a 16-bit value. The least significant bits are stored in the first byte. Strings of one or two characters are allowed, longer Strings cause errors.

#### Example

```
200 1215 0043      CONSTANT:DW      0414140   ;OCTAL VALUE
```

**END** – End of program.

```
[ <LABEL> :]  END  [ <START ADDRESS> ] [; <COMMENT> ]
```

This directive stops the Assembler program. If the END directive is missing, the Assembler program is terminated by the end of the file. However, the Assembler does not stop if an END directive is part of a file called by the INCLUDE or SOURCE control from your mass storage device. The directive is not translated into Object code. The start address should be present when it is required by your Micro-processor system. Refer to the Console Section of this manual for further information.

Example

```
480      120F          END      4623      ;STOPS THE ASSEMBLER
```

**EQU** – Equate

```
<LABEL>:  EQU  <EXPRESSION> [;<COMMENT> ]
```

The EQU directive assigns a value, given by the Operand field, to the Label or Name specified in the Label field. However, this name cannot be redefined by a subsequent EQU nor a SET directive.

Example

```
160      00D7          VALUE  EQU      3270      ;OCTAL VALUE
```

**FAIL**

```
[ <LABEL> :]  FAIL  'USER DEFINABLE ERROR MESSAGE'
```

The FAIL directive forces the Assembler to print out a user-defined error message. This directive would be contained in your Source code as an indication that unwanted code has been Assembled. It is often used within the IF-ELSE-ENDIF directives to ensure that the correct directive has been Assembled.

Example

```
**ASSEMBLING PART 2**
 340          FAIL      'ASSEMBLING PART 2'
```

**IF-ELSE-ENDIF**

```
[ <LABEL> :]   IF    <EXPRESSION> [; <COMMENT> ]
.
.
.
CODE SEQUENCE 1
.
.
[ <LABEL> :]   ELSE                [; <COMMENT> ]
.
.
.
CODE SEQUENCE 2
.
.
[ <LABEL> :]   ENDIF                [; <COMMENT> ]
```

Code sequences between the IF-ENDIF directives are controlled by the value after the IF directive.

A code sequence between the IF-ENDIF directive will be assembled when the least significant bit of the expression value evaluates to a 1.

When the ELSE directive is present, the code sequence between the IF and the ELSE directives is assembled when the least significant bit of the expression value evaluates to a 1. When the least significant bit of the expression evaluates to a 0, the code sequence between the ELSE and the ENDIF directives is assembled.

**Example**

```
260          IF    VALUE-3270    ;CONDITIONAL ASSEMBLY START
270
280          START: MVI    A,VALUE+2 ;THIS LINE IS NOT ASSEMBLED
290
300          ELSE
310
320 1224 3E47  START: MVI    A,'G'    ;THIS LINE IS ASSEMBLED
330
**'ASSEMBLING PART 2'**
340          FAIL    'ASSEMBLING PART 2'
350
360          ENDIF                ;CONDITIONAL ASSEMBLY END
```

**IFC-ELSE-ENDIF**

```
[ <LABEL> :]   IFC    <OPER1> ,<OPER2>    [; <COMMENT> ]
.
.
.
CODE SEQUENCE
.
.
[ <LABEL> :]   ENDIF                [; <COMMENT> ]
```

The IFC directive is similar to the IF directive. However, the code sequence is Assembled if the two Operands, following the IFC directive, are equal on a character for character basis. No evaluation is performed on the two Operands. Operands can be Symbols or Strings. You use the ELSE directive in the same manner as with the IF directive.

**IFNC-ELSE-ENDIF**

```
[ <LABEL> : ]   IFNC  <OPER1> , <OPER2>   [ ; <COMMENT> ]
                .
                CODE SEQUENCE
                .
[ <LABEL> : ]   ENDIF                        [ ; <COMMENT> ]
```

The IFNC directive is similar to the IFC directive, whereby the code sequence is Assembled if the two Operands, following the IFNC directive, are not equal on a character for character basis.

**ORG – Origin**

```
[ <LABEL> : ]   ORG  <EXPRESSION>         [ ; <COMMENT> ]
```

This directive defines the numerical address of the first byte of machine code which results from the assembly of the immediately subsequent section of a Source program. There may be any number of ORG statements in a program.

The ORG directive sets the location counter to the value expressed in the Operand field. This field may contain the actual value (decimal, hexadecimal, octal, or binary) to which the location counter is to be set. Alternatively, the Operand field may contain a previously defined symbol or expression which can be assigned a numerical value by the Assembler.

The location counter is initialized to 0000H before each assembly. If no ORG statement appears at the beginning of the program, the location counter begins as if an ORG zero had been entered.

**Example**

```
30 0000                ORG      4623      ;DECIMAL ADDRESS
```

**SET**

```
<LABEL> :           SET  <EXPRESSION>     [ ; <COMMENT> ]
```

The SET directive assigns the value given by the Operand field to the Label or Name specified in the Label field. This value remains unchanged until altered by a subsequent SET directive.

**Example**

```
150   00A0           LABEL  SET      00A0H   ;HEXADECIMAL ADDRESS
```

**SPC – Space**

```
[ <LABEL> : ]   SPC  <EXPRESSION>         [ ; <COMMENT> ]
```

The SPC directive inserts a number of blank lines in the program listing. The number of lines to be left blank is stated in the Operand field. When the SPC directive causes the listing to cross page boundaries, only those blank lines required to get to the top of the next page are generated.

## Assembler Controls

All Assembler Controls are preceded by the **§** sign which must be placed in the first character position. As many Controls as required may be included on one line and each Control must be separated by a blank or a comma. If more controls are required that can fit on one line, other lines may be used as long as each line begins with the **§** sign.

These Controls can also be entered after the SOURCE or OBJECT statement in the Assembler program. See Section IX.

**§** [ <CONTROL1> [ ,<CONTROL2> . . . ] ]                    [ ; COMMENT ]

**TITLE** "ASCII String" Defines the heading for the top of the page. If entered in the first line of the Source code it appears at the top of the first page. Entered into the Source code at any other time causes it to appear on the next page following its definition.

**EJECT**                    Advances the paper to the top of the next page.

**SOURCE** "<FILE NAME> [msus]" A file on the mass storage device is included in the assembly if specified in the Operand field with this control. If a Source line contains two or more SOURCE controls, then the last Source file specified is assembled first. Eight levels of nesting are allowed. Enter the msus if the Source file is not stored on the mass storage device specified in the default file.

**INCLUDE** "<FILE NAME> [msus]" Same as for SOURCE.

**OBJECT** [ "<FILE NAME> [msus]" ] As long as the file in which the Object code is to be stored was not specified with the OBJECT statement of the Assembler program, it may be specified by inserting this control in the Source code. Refer to Assembler module section. The position of this control in the Source code is not important, as the Object code for the entire Source code will still be stored.

Entering the OBJECT Control without a file name results in no Object code being stored.

If the Object file is specified, no other Object control is accepted.

**SYMBOLS**                Prints the Symbol Table after the program listing.

**\*NOSYMBOLS**            Suppress Symbol Table print.

**\*XREF**                    When the Assembler is finished the XREF generator is called and prints the cross reference of all user symbols. If XREF and SYMBOLS have been specified, then only an XREF is made.

**NOXREF**                 Suppresses the cross reference.

**SAVE** The current settings of LIST, COND and GEN are stored but remain valid until explicitly changed. Nesting up to 8 levels is valid.

This Control is useful if you know that the Assembler program will encounter another set of Controls and it is necessary to restore the original values afterwards.

**RESTORE** Recalls the list Control settings. If more RESTORE commands are given than there are SAVE commands, then the extra RESTORE commands are ignored.

**\*LIST** Instructs the Assembler to generate a program listing.

**NOLIST** Suppresses the printing of the program listing. Error messages appear on the CRT.

**\*COND** Includes conditional skipped Source lines in the listing.

**NOCOND** Does not include conditionally skipped lines.

**\*GEN** Lists MACRO expansion.

**NOGEN** Does not list MACRO expansion.

\*The Assembler uses these Controls unless otherwise specified.

#### Examples

To give your printed pages a heading, use the TITLE control followed by the heading enclosed in quotes

```
10          $ TITLE 'ASSEMBLER DIRECTIVE DEMO PROGRAM'
```

To save list controls, and suppress the Macro listing, type the following controls.

```
50          $ SAVE NOGEN
```

You can use the INCLUDE control to assemble several Source files within the same assembly. It is possible to terminate the Source file with an END directive. Once the included file has been assembled, the Assembler continues with the file that contained the INCLUDE control. Eight levels of nesting are possible.

```
100          $ INCLUDE "DEMO2:T14"
10          $ TITLE 'PROGRAM TO BE LINKED'
20
30 120F 3E3F          MWI      A,63
40 1211 3D           LOOP:   DCR   A
50 1212 021112        JNZ   LOOP
60                  END
110
120          $ RESTORE
130          ; THE REST IS THE MAIN PROGRAM AGAIN
```

Note that on the original Source code the \$ sign would be placed in the first character position.

## Example of Source Code

```

10 $ TITLE 'ASSEMBLER DIRECTIVE DEMO PROGRAM'
20
30          ORG          4623          ;DECIMAL ADDRESS
40
50 $ SAVE NOGEN
60
70 ; THE FOLLOWING PROGRAM HAS BEEN LINKED AND ASSEMBLED
80 ; TOGETHER WITH THE MAIN PROGRAM
90
100 $ INCLUDE "DEM02:T14"
110
120 $ RESTORE
130 ; THE REST IS THE MAIN PROGRAM AGAIN
140
150 LABEL   SET          00A0H          ;HEXADECIMAL ADDRESS
160 VALUE   EQU          3270          ;OCTAL VALUE
170
180          SPC      2              ;2 SPACES
190
200 CONSTANT:DW          0414140       ;OCTAL VALUE
210          DB          00100100B     ;BINARY VALUE
220          DB          'TEXT'        ;ASCII "TEXT" INTO MEMORY
230
240 TEMP:    DS          8              ;CREATE AREA 8 BYTES LONG
250
260          IF      VALUE-3270        ;CONDITIONAL ASSEMBLY START
270
280 START:   MVI          A,VALUE+2    ;THIS LINE IS NOT ASSEMBLED
290
300          ELSE
310
320 START:   MVI          A,'G'        ;THIS LINE IS ASSEMBLED
330
340          FAIL      'ASSEMBLING PART 2'
350
360          ENDIF          ;CONDITIONAL ASSEMBLY END
370
380          LXI      B,LABEL          ;LABEL=00A0H FROM LINE 140
390          LXI      H,CONSTANT+VALUE*2 ;EXPRESSION
400          MOV      M,A
410          JNZ      START          ;JUMPS TO LABEL START
420          JNC      $+3            ;PROGRAM COUNTER + 3
430          CMC
440
450 LABEL:   SET          00A1H          ;LABEL REDEFINED WITH SET
460          LXI      H,LABEL
470          MOV      M,A
480          END          4623          ;STOPS THE ASSEMBLER
490
500

```



## Example of Program Listing

ASSEMBLER DIRECTIVE DEMO PROGRAM

PAGE 2

```

LINE LOC.  OBJECT      SOURCE STATEMENT

10          # TITLE 'ASSEMBLER DIRECTIVE DEMO PROGRAM'
20
30 0000      ORG        4623      ;DECIMAL ADDRESS
40
50          # SAVE NOGEN
60
70          ; THE FOLLOWING PROGRAM HAS BEEN LINKED AND ASSEMBLED
80          ; TOGETHER WITH THE MAIN PROGRAM
90
100         # INCLUDE "DEMO2:T14"
10          # TITLE 'PROGRAM TO BE LINKED'
20
30 120F 3E3F      MVI        A,63
40 1211 3D      LOOP:    DCR        A
50 1212 C21112    JNZ        LOOP
60          END
110
120         # RESTORE
130         ; THE REST IS THE MAIN PROGRAM AGAIN
140
150         00A0      LABEL    SET        00A0H      ;HEXADECIMAL ADDRESS
160         00D7      VALUE    EQU       3270      ;OCTAL VALUE
170

190
200 1215 0C43      CONSTANT:DW      0414140      ;OCTAL VALUE
210 1217 24          DB          00100100B     ;BINARY VALUE
220 1218 54455854   DB          'TEXT'          ;ASCII "TEXT" INTO MEMORY
230
240 121C          TEMP:    DS        8          ;CREATE AREA 8 BYTES LONG
250
260          IF        VALUE=3270      ;CONDITIONAL ASSEMBLY START
270
280          START:    MVI        A,VALUE+2 ;THIS LINE IS NOT ASSEMBLED
290
300          ELSE
310
320 1224 3E47      START:    MVI        A,'G'      ;THIS LINE IS ASSEMBLED
330
**/ASSEMBLING PART 2/**
340          FAIL      'ASSEMBLING PART 2'
350
360          ENDIF      ;CONDITIONAL ASSEMBLY END
370
380 1226 01A000     LXI        B,LABEL      ;LABEL=00A0H FROM LINE 140
390 1229 21C313     LXI        H,CONSTANT+VALUE*2 ;EXPRESSION
400 122C 77         MOV        M,A
410 122D C22412     JNZ        START      ;JUMPS TO LABEL START
420 1230 D23312     JNC        #+3        ;PROGRAM COUNTER + 3
430 1233 3F        CMC
440
450         00A1      LABEL:    SET        00A1H      ;LABEL REDEFINED WITH SET
460 1234 21A100     LXI        H,LABEL
470 1237 77         MOV        M,A
480         120F      END        4623      ;STOPS THE ASSEMBLER

```

## Cross Reference List

SYMBOL	VALUE	DEFINED	REFERENCED
CONSTANT	1215	200	390
LABEL	00A1	150	RE-DEFINED: 450 380 460
LOOP	1211	40	50
START	1224	320	410
TEMP	1210	240	* UNREFERENCED *
VALUE	00D7	160	260 390

## Character Set

The Assembler recognizes the complete ASCII character set. Generally all characters are considered to be alphabetic and lower case are converted to upper case. The following are exceptions, and they each have a special meaning.

+	Plus sign	ADDITION	
-	Minus sign	SUBTRACTION	
*	Asterisk	MULTIPLICATION	
/	Slash	DIVISION	
(	Left Parenthesis	LEFT PARANTHESIS	
)	Right Parenthesis	RIGHT PARENTHESIS	
\$	Dollar sign	PROGRAM COUNTER AND CONTROL LINE ID	
'	Single quote	STRING DELIMITER	
"	Double quote	STRING DELIMITER	
:	Colon	LABEL DELIMITER SUFFIX	
;	Semicolon	COMMENT FIELD DELIMITER	
B		BINARY NUMBER SUFFIX	} B, D, H, O, Q, are also alpha characters
D		DECIMAL NUMBER SUFFIX	
H		HEX NUMBER SUFFIX	
O		OCTAL NUMBER SUFFIX	
Q		OCTAL NUMBER SUFFIX	
SPACE		FIELD SEPARATOR OR SYMBOL TERMINATOR	
HOR TAB		FIELD SEPARATOR OR SYMBOL TERMINATOR	
,	Comma	OPERAND SEPARATOR	
=	Equals sign	MACRO DUMMY ARGUMENT PREFIX	
^		MACRO PRE-EVALUATION PREFIX	

## Instructions

LINE	LOC.	OBJECT	SOURCE STATEMENT
10	0000	CEFF	ACI BYTE ;ADD IMMEDIATE TO A WITH CARRY.
20	0002	8F	ADC A ;ADD REGISTER TO A WITH CARRY.
30	0003	88	ADC B
40	0004	89	ADC C
50	0005	8A	ADC D
60	0006	8B	ADC E
70	0007	8C	ADC H
80	0008	8D	ADC L
90	0009	8E	ADC M ;ADD MEMORY TO A WITH CARRY
100	000A	87	ADD A ;ADD REGISTER TO A
110	000B	80	ADD B
120	000C	81	ADD C
130	000D	82	ADD D
140	000E	83	ADD E
150	000F	84	ADD H
160	0010	85	ADD L
170	0011	86	ADD M ;ADD MEMORY TO A.
180	0012	C6FF	ADI BYTE ;ADD IMMEDIATE TO A
190	0014	A7	ANA A ;AND REGISTER WITH A
200	0015	A0	ANA B
210	0016	A1	ANA C
220	0017	A2	ANA D
230	0018	A3	ANA E
240	0019	A4	ANA H
250	001A	A5	ANA L
260	001B	A6	ANA M ;ADD MEMORY WITH A.
270	001C	E6FF	ANI BYTE ;AND IMMEDIATE WITH A.
280	001E	CD3412	CALL ADDRESS ;CALL UNCONDITIONAL.
290	0021	DC3412	CC ADDRESS ;CALL ON CARRY.
300	0024	FC3412	CM ADDRESS ;CALL ON MINUS.
310	0027	2F	CMA ;COMPLEMENT A
320	0028	3F	CMC ;COMPLEMENT CARRY.
330	0029	BF	CMP A ;COMPARE REGISTER WITH A.
340	002A	B8	CMP B
350	002B	B9	CMP C
360	002C	BA	CMP D
370	002D	BB	CMP E
380	002E	BC	CMP H
390	002F	BD	CMP L
400	0030	BE	CMP M ;COMPARE MEMORY WITH A.
410	0031	D43412	CNC ADDRESS ;CALL ON NO CARRY.
420	0034	C43412	CNZ ADDRESS ;CALL ON NO ZERO.
430	0037	F43412	CP ADDRESS ;CALL ON POSITIVE.
440	003A	EC3412	CPE ADDRESS ;CALL ON PARITY EVEN.
450	003D	FEFF	CPI BYTE ;COMPARE IMMEDIATE WITH A.
460	003F	E43412	CPO ADDRESS ;CALL ON PARITY ODD.
470	0042	CC3412	CZ ADDRESS ;CALL ON ZERO.
480	0045	27	DAA ;DECIMAL ADJUST A.
490	0046	09	DAD B ;ADD B AND C TO H AND L.
500	0047	19	DAD D ;ADD D AND E TO H AND L.
510	0048	29	DAD H ;ADD H AND L TO H AND L.
520	0049	39	DAD SP ;DECREMENT STACK POINTER.
530	004A	3D	DCR A ;DECREMENT REGISTER
540	004B	05	DCR B

LINE	LOC.	OBJECT	SOURCE STATEMENT
550	004C	0D	DCR C
560	004D	15	DCR D
570	004E	1D	DCR E
580	004F	25	DCR H
590	0050	2D	DCR L
600	0051	35	DCR M ;DECREMENT MEMORY.
610	0052	0B	DCX B ;DECREMENT B AND C.
620	0053	1B	DCX D ;DECREMENT D AND E.
630	0054	2B	DCX H ;DECREMENT H AND L.
640	0055	3B	DCX SP ;DECREMENT STACK POINTER
650	0056	F3	DI ;DISABLE INTERRUPT.
660	0057	FB	EI ;ENABLE INTERRUPT.
670	0058	76	HLT ;HALT.
680	0059	DBFF	IN BYTE ;INPUT.
690	005B	3C	INR A ;INCREMENT REGISTER.
700	005C	04	INR B
710	005D	0C	INR C
720	005E	14	INR D
730	005F	1C	INR E
740	0060	24	INR H
750	0061	2C	INR L
760	0062	34	INR M ;INCREMENT MEMORY.
770	0063	03	INX B ;INCREMENT B AND C REGISTERS.
780	0064	13	INX D ;INCREMENT D AND E REGISTERS.
790	0065	23	INX H ;INCREMENT H AND L REGISTERS.
800	0066	33	INX SP ;INCREMENT STACK POINTER
810	0067	DA3412	JC ADDRESS ;JUMP ON CARRY.
820	006A	FA3412	JM ADDRESS ;JUMP ON MINUS.
830	006D	C33412	JMP ADDRESS ;JUMP UNCONDITIONAL.
840	0070	D23412	JNC ADDRESS ;JUMP ON NO CARRY.
850	0073	C23412	JNZ ADDRESS ;JUMP ON NO ZERO.
860	0076	F23412	JP ADDRESS ;JUMP ON POSITIVE
870	0079	EA3412	JPE ADDRESS ;JUMP ON PARITY EVEN.
880	007C	E23412	JPO ADDRESS ;JUMP ON PARITY ODD.
890	007F	CA3412	JZ ADDRESS ;JUMP ON ZERO.
900	0082	3A3412	LDA ADDRESS ;LOAD A DIRECT.
910	0085	0A	LDAX B ;LOAD A INDIRECT.
920	0086	1A	LDAX D ;LOAD A INDIRECT.
930	0087	2A3412	LHLD ADDRESS ;LOAD H AND L DIRECT
940	008A	017856	LXI B,WORD ;LOAD IMMEDIATE REG. PAIR B AND C
950	008D	117856	LXI D,WORD ;LOAD IMMEDIATE REG. PAIR D AND E
960	0090	217856	LXI H,WORD ;LOAD IMMEDIATE REG. PAIR H AND L
970	0093	317856	LXI SP,WORD ;LOAD IMMEDIATE STACK POINTER.
980	0096	7F	MOV A,A ;MOVE REG. TO REG.
990	0097	7B	MOV A,B
1000	0098	79	MOV A,C
1010	0099	7A	MOV A,D
1020	009A	7B	MOV A,E
1030	009B	7C	MOV A,H
1040	009C	7D	MOV A,L
1050	009D	7E	MOV A,M ;MOVE MEMORY TO REGISTER
1060	009E	47	MOV B,A ;MOVE REG. TO REG.
1070	009F	40	MOV B,B
1080	00A0	41	MOV B,C
1090	00A1	42	MOV B,D
1100	00A2	43	MOV B,E
1110	00A3	44	MOV B,H

LINE	LOC.	OBJECT	SOURCE STATEMENT
1120	00A4	45	MOV B,L
1130	00A5	46	MOV B,M ;MOVE MEMORY TO REGISTER
1140	00A6	4F	MOV C,A ;MOVE REG. TO REG.
1150	00A7	48	MOV C,B
1160	00A8	49	MOV C,C
1170	00A9	4A	MOV C,D
1180	00AA	4B	MOV C,E
1190	00AB	4C	MOV C,H
1200	00AC	4D	MOV C,L
1210	00AD	4E	MOV C,M ;MOVE MEMORY TO REGISTER
1220	00AE	57	MOV D,A ;MOVE REG. TO REG.
1230	00AF	50	MOV D,B
1240	00B0	51	MOV D,C
1250	00B1	52	MOV D,D
1260	00B2	53	MOV D,E
1270	00B3	54	MOV D,H
1280	00B4	55	MOV D,L
1290	00B5	56	MOV D,M ;MOVE MEMORY TO REGISTER
1300	00B6	5F	MOV E,A ;MOVE REG. TO REG.
1310	00B7	58	MOV E,B
1320	00B8	59	MOV E,C
1330	00B9	5A	MOV E,D
1340	00BA	5B	MOV E,E
1350	00BB	5C	MOV E,H
1360	00BC	5D	MOV E,L
1370	00BD	5E	MOV E,M ;MOVE MEMORY TO REGISTER
1380	00BE	67	MOV H,A ;MOVE REG. TO REG.
1390	00BF	60	MOV H,B
1400	00C0	61	MOV H,C
1410	00C1	62	MOV H,D
1420	00C2	63	MOV H,E
1430	00C3	64	MOV H,H
1440	00C4	65	MOV H,L
1450	00C5	66	MOV H,M ;MOVE MEMORY TO REGISTER
1460	00C6	6F	MOV L,A ;MOVE REG. TO REG.
1470	00C7	68	MOV L,B
1480	00C8	69	MOV L,C
1490	00C9	6A	MOV L,D
1500	00CA	6B	MOV L,E
1510	00CB	6C	MOV L,H
1520	00CC	6D	MOV L,L
1530	00CD	6E	MOV L,M ;MOVE MEMORY TO REGISTER
1540	00CE	77	MOV M,A ;MOVE REGISTER TO MEMORY
1550	00CF	70	MOV M,B
1560	00D0	71	MOV M,C
1570	00D1	72	MOV M,D
1580	00D2	73	MOV M,E
1590	00D3	74	MOV M,H
1600	00D4	75	MOV M,L
1610	00D5	3EFF	MVI A,BYTE ;MOVE IMMEDIATE REGISTER
1620	00D7	06FF	MVI B,BYTE
1630	00D9	0EFF	MVI C,BYTE
1640	00DB	16FF	MVI D,BYTE
1650	00DD	1EFF	MVI E,BYTE
1660	00DF	26FF	MVI H,BYTE
1670	00E1	2EFF	MVI L,BYTE
1680	00E3	36FF	MVI M,BYTE ;MOVE IMMEDIATE MEMORY.

LINE	LOC.	OBJECT	SOURCE STATEMENT
1690	00E5	00	NOP ;NO OPERATION
1700	00E6	B7	ORA A ;OR REGISTER WITH A.
1710	00E7	B0	ORA B
1720	00E8	B1	ORA C
1730	00E9	B2	ORA D
1740	00EA	B3	ORA E
1750	00EB	B4	ORA H
1760	00EC	B5	ORA L
1770	00ED	B6	ORA M ;OR MEMORY WITH A.
1780	00EE	F6FF	ORI BYTE ;OR IMMEDIATE WITH A.
1790	00F0	D3FF	OUT BYTE ;OUTPUT.
1800	00F2	C1	POP B ;POP REG. PAIR B AND C OFF STACK
1810	00F3	D1	POP D ;POP REG. PAIR D AND E OFF STACK
1820	00F4	E1	POP H ;POP REG. PAIR H AND L OFF STACK
1830	00F5	F1	POP PSW ;POP A AND FLAGS OFF STACK.
1840	00F6	C5	PUSH B ;PUSH REG. PAIR B AND C ON STACK
1850	00F7	D5	PUSH D ;PUSH REG. PAIR D AND E ON STACK
1860	00F8	E5	PUSH H ;PUSH REG. PAIR H AND L ON STACK
1870	00F9	F5	PUSH PSW ;PUSH A AND FLAGS ON STACK
1880	00FA	17	RAL ;ROTATE A LEFT THROUGH CARRY.
1890	00FB	1F	RAR ;ROTATE A RIGHT THROUGH CARRY.
1900	00FC	D8	RC ;RETURN ON CARRY
1910	00FD	C9	RET ;RETURN
1920	00FE	20	RIM ;READ INTERRUPT MASK.
1930	00FF	07	RLC ;ROTATE A LEFT.
1940	0100	F8	RM ;RETURN ON MINUS.
1950	0101	D0	RNC ;RETURN ON NO CARRY.
1960	0102	C0	RNZ ;RETURN ON NO ZERO.
1970	0103	F0	RP ;RETURN ON POSITIVE.
1980	0104	E8	RPE ;RETURN ON PARITY EVEN.
1990	0105	E0	RPO ;RETURN ON PARITY ODD.
2000	0106	0F	RRC ;ROTATE A RIGHT
2010	0107	C7	RST 0 ;RESTART
2020	0108	CF	RST 1
2030	0109	D7	RST 2
2040	010A	DF	RST 3
2050	010B	E7	RST 4
2060	010C	F7	RST 6
2070	010D	FF	RST 7
2080	010E	C8	RZ ;RETURN ON ZERO
2090	010F	9F	SBB A ;SUBTR. REG. FROM A WITH BORROW.
2100	0110	98	SBB B
2110	0111	99	SBB C
2120	0112	9A	SBB D
2130	0113	9B	SBB E
2140	0114	9C	SBB H
2150	0115	9D	SBB L
2160	0116	9E	SBB M ;SUBTR. MEMORY FROM A WITH BORROW.
2170	0117	DEFF	SBI BYTE ;SUBTR. IMMED. FROM A WITH BORROW
2180	0119	223412	SHLD ADDRESS ;STORE H AND L DIRECT.
2190	011C	30	SIM ;SET INTERRUPT MASK.
2200	011D	F9	SPHL ;H AND L TO STACK DIRECT.
2210	011E	02	STAX B ;STORE A INDIRECT.
2220	011F	12	STAX D ;STORE A INDIRECT.
2230	0120	37	STC ;SET CARRY
2240	0121	97	SUB A ;SUBTRACT REG. FROM A.
2250	0122	90	SUB B

LINE	LOC.	OBJECT	SOURCE STATEMENT
2260	0123	91	SUB C
2270	0124	92	SUB D
2280	0125	93	SUB E
2290	0126	94	SUB H
2300	0127	95	SUB L
2310	0128	96	SUB M ;SUBTRACT MEMORY FROM A.
2320	0129	D6FF	SUI BYTE ;SUBTRACT IMMEDIATE FROM A.
2330	012B	EB	XCHG ;EXCHANGE D AND E, H AND L REG.
2340	012C	AF	XRA A ;EXCLUSIVE OR REG. WITH A.
2350	012D	A8	XRA B
2360	012E	A9	XRA C
2370	012F	AA	XRA D
2380	0130	AB	XRA E
2390	0131	AC	XRA H
2400	0132	AD	XRA L
2410	0133	AE	XRA M ;EXCLUSIVE OR MEMORY WITH A
2420	0134	EEFF	XRI BYTE ;EXCLUSIVE OR IMMEDIATE WITH A.
2430	0136	E3	XTHL ;EXCHANGE TOP OF STACK H AND L.

## Differences between HP and the 8080/85

The following is a list of differences, known to us at the time of printing, that exist between the Hewlett-Packard software and other 8080/85 Assembler descriptions.

- a) The character set has been expanded.
- b) HP software accepts Labels in place of Names.
- c) DB and DW pseudo mnemonics accept more than 8 operands.
- d) The following pseudo mnemonics have been added:
 

FAIL	IFC
SPC	IFNC
- e) The Macro parameter syntax has been changed. The Assembler generated symbol mechanism has been changed (no local directive). The nul operator is replaced by IFC and IFNC directives.
- f) The Assembler does not have any relocation features.
- g) Instructions in the Operand field are not allowed.
- h) EQU and SET pseudo mnemonics do not allow register-type Operands in their Operand fields.
- i) The following 8080/85 controls are not implemented:
 

NOOBJECT	Replaced by OBJECT.
DEBUG	No debug facilities.
NODEBUG	
PRINT	List output on the mass storage is not provided.
NOPRINT	
PAGELength	Printer specifications are set-up during Initialization.
PAGewidth	
MACRODEBUG	No debug facilities.
NOMACRODEBUG	



# Section Seven

## 6800 Assembly Language Instructions



### Introduction

The following is a description of the Assembly Language instructions needed to write Source code for the 6800 Microprocessor types. We recommend that you make yourself acquainted with this explanation as it differs in some respects from the description given by 6800 Programming manuals.

### Source Line Format

A program written in Assembler Language is called a Source code. It consists of symbolic commands called statements. Each statement is written on a single line and may consist of from one to four fields. From left to right the four fields are:

(1) LABEL      (2) INSTRUCTION      (3) OPERAND      (4) COMMENT

The following pages describe each field individually. An illustration of the format pattern is given below.

[ <LABEL> ]   <INSTRUCTION>   [ <OPER> [, <OPER> ... ] ] [ <COMMENT> ]

LABEL space INSTRUCTION space OPERAND, OPERAND space COMMENT

One or more

At least one

At least one

An asterisk (\*) in the first character position indicates a Comment line and the entire line is ignored by the Assembler.

## Label Field

A Label is required for statements involved in the definition of symbols and occasionally at destinations of branch and jump instructions.

A Label is a symbol whose value is the location where the instruction is assembled. A Label must begin in the first character position of a statement. Any number of characters (limited by the line length) may be used. However, the Assembler only recognises up to eight alphanumeric characters whereby the first character must be alphabetic.

A Label may be used in any executable instruction at your option. However, it must be used in a statement which includes the Assembler directives SET, EQU, MACRO and it will be identical with the Symbol which the SET, EQU, MACRO directive is defining.

The Assembler maintains a location counter to provide addresses for the symbols in the Label field. When a symbol is found in the Label field, the Assembler places the symbol and the corresponding location counter value in a symbol table.

## Instruction Field

Instructions are machine or pseudo mnemonics and must be present in all statements except when the statement consists only of a Comment. Instructions must not start in the first character position.

Pseudo mnemonics are described later in this Section and a list of 6800 machine mnemonics is given at the back of this Section.

## Operand Field

The Operand field identifies the data to be acted upon by the specified instruction. Some instructions require no Operand, while others require one or more.

The Operand field is separated from the Instruction by one or more blanks. If more than one Operand is required, they are separated from each other by commas. Imbedded blanks are not allowed.

The type of information placed in the Operand field depends upon the particular instruction. The following are recognized by the Assembler as Operands:

- Numbers
- Symbols
- Expressions
- ASCII Strings
- Location Counter Symbol (\*)

The listed Operands are now described in more detail.

## Numbers

The Assembler accepts numbers in several different bases: binary, octal, decimal, and hexadecimal. Numbers (constants) are accepted in the following formats.

<Number>	Specifies a Decimal number	0–65536
<Number>D	Specifies a Decimal number	0D–65536D
<b>\$</b> <Number>	Specifies a Hexadecimal number	<b>\$</b> 0– <b>\$</b> FFFF
<Number>H	Specifies a Hexadecimal number	0H–0FFFFH
@<Number>	Specifies an Octal number	@0–@177777
<Number>O	Specifies an Octal number	0O–177777O
<Number>Q	Specifies an Octal number	0Q–177777Q
%<Number>	Specifies a Binary number	%0–%1111111111111111
<Number>B	Specifies a Binary number	0B–1111111111111111B

The number must begin with a numeric character. For example:

A9FFH	Illegal (will be recognized as a symbol).
0A9FFH	Correct specification.

## Symbols

Symbols can be divided into three separate identities, Reserved, User definable, and Assembler generated symbols.

Reserved symbols are those that already have a special meaning to the Assembler and therefore cannot appear as user-defined symbols. The mnemonic names for microprocessor instructions and the Assembler directives are all reserved symbols.

A symbol may consist of up to 74 characters, however only the first eight characters are significant.

A symbol must not be any of the single characters A, B, or X as they define microprocessor registers for the programmer and are not allowed in expressions.

The Assembler recognises the special symbol \* as a symbol for the location counter or as a multiplication depending on the context.

For example:

SYMBOL\*\*\*2 means that the SYMBOL is multiplied by the value of the location counter and the result is then multiplied by two.

## Expressions

An expression is a combination of symbols and numbers separated by one of the arithmetic operators +, -, \*, /, ( ). The Assembler evaluates expressions algebraically from left to right. There is no hierarchy of precedence among the arithmetic operators. However, this can be influenced by the use of parentheses. Nesting is only limited by the length of the expression that can be inserted into the Source line. An intermediate result will be truncated to an integer value if it is obtained during the evaluation of an expression.

Note: The Assembler must complete the numeric evaluation of symbols and expressions in two passes. Only one level of forward addressing is permitted in the use of symbols or expressions in the Operand field of Source statements.

For instance, in the example below, P would not be evaluated.

```
P EQU R
R EQU Q
Q EQU 5
```

## ASCII Strings

The apostrophe (') instructs the Assembler to translate the next character into the corresponding 7-bit ASCII code. Any ASCII character can be used. For example;

```
'S or '!'
```

Double quote marks can also be used to define an ASCII String. In this case, the double quotes determine the String delimiter while a single apostrophe is regarded as a character within the String. For example:

```
"TODAY'S DATE"
```

ASCII Strings of length 1 or 2 characters can be used in expressions like any other number. A 1 character String is evaluated to the unsigned 8-bit value, whereas a 2 character String will result in a 16-bit number.

## Void Operands

Void Operands are missing Operands. They are separated by commas, and are evaluated as a zero. For example:

```
OPERAND , , X is evaluated as OPERAND , 0 , X
```

## Direct and Extended Addressing

For Direct addressing, the Source code is translated into two bytes of machine code. The second byte will contain the address in unsigned 8-bit binary form.

For Extended addressing, the Source code is translated into three bytes of machine code. The second of these bytes will contain the highest 8 bits of the address. The third byte will contain the lowest 8 bits of the address. The contents of the second and third bytes will both be coded in unsigned 8-bit binary form.

For instructions which may use the Direct mode of addressing as well as the Extended mode, the Assembler selects the mode according to the following rule:

The Assembler will select the Direct addressing if the numerical address is defined at this time and is in the range from zero to 255 (decimal) It will select Extended addressing if the numerical address exceeds 255 (decimal).

## Indirect Addressing

The data, for obtaining the numerical address, may be written in any of the following formats:

X  
, X  
Number, X  
Symbol, X  
Expression, X

The single character "X" informs the Assembler that the indexed mode is to be used, the character "X" being reserved to denote the index register. When used alone, the format "X" instructs the Assembler that the address of the Operand is identical with the contents of the index register. (This format has the same effect on the assembly as if 0, X had been written). If a symbol or an expression is used rather than a number, the Assembler will find or compute a numerical value of that symbol or expression. The Source code must then include other statements which define a numerical value for the symbol or which enable the Assembler to compute a numerical value for the symbol or expression.

## Immediate Addressing

The Assembler can be instructed to select the Immediate address mode for an Instruction by placing the # symbol in front of the Operand.

## Comment Field

Comments can be optionally used at the end of a Source line. If present they are ignored by the Assembler during translation and appear only in the program listing. Separation of a Comment and Operand field is made by at least one blank.

An asterisk (\*) in the first character position indicates a Comment line and the entire line is ignored by the Assembler.

## Assembler Directives

The Assembler directives, sometimes called pseudo mnemonics, are instructions, entered into the Source code, which direct the Assembler when it generates the Object code. They control the generation of the Assembler program and define the format of the Assembler output listing.

The following examples are taken from an assembled program. Both the Source code and Assembler program are listed at the end of these examples in their entirety.

### END

```
[ <LABEL> ]   END           [ <COMMENT> ]
```

The END directive will stop the Assembler program. If the END directive is missing, the Assembler program is terminated by the end of the file. However, the Assembler does not stop if an END directive is part of a file called by the SOURCE control. The directive is not translated into Object code.

### EQU – Equate

```
<LABEL>      EQU    <EXPRESSION>    [ <COMMENT> ]
```

The EQU directive assigns a value, given by the Operand field, to the symbol specified in the Label field. However, this symbol cannot be redefined.

### Example

```
160      0007      VALUE    EQU    0327      OCTAL VALUE
```

**FAIL**

[ <LABEL> ] FAIL 'USER DEFINABLE ERROR MESSAGE'

The FAIL directive forces the Assembler to printout a user defined error message. This directive would be contained in your Source code as an indication that unwanted code has been Assembled. It is often used with the IF-ELSE-ENDIF directives to ensure that the correct directive has been Assembled.

**Example**

```
**      ASSEMBLING PART 2**
360                                FAIL      ASSEMBLING PART 2
```

**FCB – Form constant byte**

[ <LABEL> ] FCB <EXPRESSION> [ , <EXPRESSION> . . . ] [ <COMMENT> ]

An 8-bit value corresponding to each Operand is stored in a byte of the Object program. This directive may have one or more Operands, separated by commas. The number of Operands is limited by the Source line length of 80 characters. The Operand can be any constant, symbol, or expression evaluating to an 8-bit value. Void Operands are allowed.

When the Label is present the address of the first generated byte is assigned to the symbol represented by the Label.

**Example**

```
210 0100 AC                        FCB      2540      OCTAL VALUE
```

**FCC – Form constant character.**

[ <LABEL> ] FCC /TEXT/ [ <COMMENT> ]  
[ <LABEL> ] FCC COUNT, TEXT

The FCC directive translates a string of ASCII characters into their 7-bit codes and stores them into successive bytes of the Object code. The Label is assigned to the first generated byte.

The Operand can be defined in two ways:

## 1) /TEXT/

As the text enclosed between identical delimiters. In this case, the delimiters can be any single character. The text must not begin with a comma if the delimiter is a number.

## 2) COUNT, TEXT

COUNT (a given number) specifies how many ASCII characters are to be generated and the text commences after the first comma following the COUNT. Should COUNT be longer than the text, spaces are inserted to fill the COUNT to a maximum of 80 characters.

**Example**

```
220 0101 54455854                FCC      /TEXT/      ASCII STRING INTO MEMORY
```

**FDB** -- Form double byte

```
[ <LABEL> ]  FDB    <EXPRESSION> [ , <EXPRESSION> ... ]  [ <COMMENT> ]
```

The FDB directive may have one or more Operands separated by commas. The 16-bit unsigned binary number, corresponding to the value of each Operand, is stored in two bytes of the Object program. If there is more than one Operand, they are stored in successive bytes. An FDB directive may be written with a Label.

## Example

```
200 00FE 430C          CONSTANT FDB          0414140  OCTAL VALUE
```

**IF-ELSE-ENDIF**

```
[ <LABEL> ]  IF      <EXPRESSION>          [ <COMMENT> ]
```

```
      .          CODE SEQUENCE 1
```

```
[ <LABEL> ]  ELSE                    [ <COMMENT> ]
```

```
      .          CODE SEQUENCE 2
```

```
[ <LABEL> ]  ENDIF                    [ <COMMENT> ]
```

A code sequence between IF-ENDIF directive will be assembled when the expression evaluates to a value other than zero.

When the ELSE directive is included, the code sequence between the IF and the ELSE directive is assembled when the expression, following IF, evaluates to a value other than zero. When the expression equals zero, the code sequence between the ELSE and ENDIF directives is assembled.

## Example

```
280                                IF  VALUE=0327    CONDITIONAL ASSEMBLY START
290
300          START  LDA  A  #00100110B  THIS LINE NOT ASSEMBLED
310
320                                ELSE
330
340 010F 8647          START  LDA  A  #'G          THIS LINE IS ASSEMBLED
350
**  ASSEMBLING PART 2**
360                                FAIL          ASSEMBLING PART 2
370
380                                ENDIF          CONDITIONAL ASSEMBLY END
```



**IFC-ELSE-ENDIF**

```
[ <LABEL> ]   IFC      <OPER1>, <OPER2> [ <COMMENT> ]
```

```
                CODE SEQUENCE
```

```
[ <LABEL> ]   ENDIF                                [ <COMMENT> ]
```

The IFC directive is similar to the IF directive. However, the code sequence is assembled if the two Operands, following the IFC directive, are equal on a character for character basis. No evaluation is performed on the two Operands. Operands can be Symbols or Strings in double quotes. You use the ELSE directive in the same manner as with the IF directive.

**IFNC-ELSE-ENDIF**

```
[ <LABEL> ]   IFNC     <OPER1>, <OPER2> [ <COMMENT> ]
```

```
                CODE SEQUENCE
```

```
[ <LABEL> ]   ENDIF                                [ <COMMENT> ]
```

The IFNC directive is similar to the IFC directive, whereby the code sequence is Assembled if the two Operands, following the IFNC directive are not equal on a character for character basis.

**MON**

```
[ <LABEL> ]   MON      <START ADDRESS> [ <COMMENT> ]
```

The MON directive is used instead of the END directive when the microprocessor system requires the start address specification in Object code. For further information refer to the Console module.

**NAM – Name**

```
[ <LABEL> ]   NAM      <PAGE HEADING>
```

This directive defines the heading for the top of the page. This directive may be used anywhere in the program. The page name appears after it has been defined and it may be changed at any time. The heading appears on page one if written in the first Source line

**Example**

```
10                                NAM      ASSEMBLER DIRECTIVE DEMO PROGRAM
```

**ORG – Origin**

```
[ <LABEL> ]  ORG  <EXPRESSION>      [ <COMMENT> ]
```

This directive defines the numerical address of the first byte of machine code which results from the assembly of the immediately subsequent section of a Source program. There may be any number of ORG statements in a program. The ORG directive sets the location counter to the value expressed in the Operand field.

The Operand field may contain the actual value (decimal, hexadecimal, octal, or binary) to which the location counter is to be set. Alternatively, the Operand field may contain a symbol or an expression which can be assigned a numeric value by the Assembler. Symbols must be previously defined.

The location counter is initialized to 0000H before each assembly. If no ORG statement appears at the beginning of the program, the location counter begins as if an ORG zero had been entered.

**Example**

```
30 0000                ORG      000F9H    HEXADECIMAL ADDRESS
```

**PAGE**

```
[ <LABEL> ]  PAGE  [ <COMMENT> ]
```

The PAGE directive causes the Assembler to move the paper to the top of the next page. This directive does not appear on the program listing.

**RMB – Reserve memory bytes**

```
[ <LABEL> ]  RMB  <EXPRESSION>      [ <COMMENT> ]
```

The RMB directive causes the location counter to be increased by the value given in the Operand field. This reserves a block of memory equal to the size of the expression value. The Operand field may contain the actual number equal to the number of bytes to be reserved or the Operand may be a symbol or an expression which can be assigned a numerical value by the Assembler. When a symbol is used it must have been previously defined. A symbol that has been defined by a Label is assigned the address of the first byte reserved by this directive. The content of the memory block is unchanged. The Assembler only advances the location counter and does not generate any Object code.

**Example**

```
240 0105                TEMP    RMB  8          CREATE AREA 8 BYTES LONG
```

**SET**

**<LABEL> SET <EXPRESSION> [ <COMMENT> ]**

The SET directive assigns the value, given by the expression to the symbol specified in the Label field. This value remains unchanged until altered by a subsequent SET directive.

**Example**

```
150      00A0      LABEL      SET      $00A0      HEXADECIMAL ADDRESS
```

**SPC – Space**

**[ <LABEL> ] SPC <EXPRESSION> [ <COMMENT> ]**

The SPC directive inserts a number of blank lines, given by the expression in the program listing. The number of lines to be left blank is stated in the Operand field. When the SPC directive causes the listing to cross page boundaries only those blank lines required to get to the top of the next page are generated.

## Assembler Controls

All Assembler controls are preceeded by the OPT directive. As many Controls as required may be included on one line and each Control must be separated by a comma. If more controls are required that can fit on one line, other lines may be used as long as each line has the OPT directive.

These controls can also be entered after the SOURCE and OBJECT statements in the Assembler program. See Section IX.

**[ <LABEL> ] OPT [ <CONTROL1> [, <CONTROL2> . . . ] ] [ <COMMENT> ]**

**Controls**

**SOURCE** “<FILE NAME> [msus]” A file on the mass storage device is included in the assembly if specified in the Operand field with this control. If a Source line contains two or more SOURCE controls then the last Source file specified is assembled first. Eight levels of nesting are allowed. Enter the msus if the Source file is not stored on the mass storage device specified in the default file.

**OBJECT** [“<FILE NAME> [msus]”] As long as the file in which the Object code is to be stored was not specified with the OBJECT statement of the Assembler program, see Assembler Module Section IX, it may be specified by inserting this Control in the Source code. The position of this Control in the Source code is not important, as the Object code for the entire Source code will still be stored.

The Object code is not stored if the Object specification does not contain the file name.

If the Object file is specified, no other Object control is accepted.

<b>SYMBOL</b>	Prints the Symbol Table after the program listing.
<b>*NOSYMBOL</b>	Suppress Symbol Table print.
<b>*XREF</b>	When the Assembler is finished the XREF generator is called and prints the cross reference of all user symbols. If XREF and SYMBOL have been specified, then only an XREF is made.
<b>NOXREF</b>	Suppresses the cross reference.
<b>SAVE</b>	The current list Control settings LIST, COND, GEN and MEX are saved but remain valid until explicitly changed. Nesting up to 8 levels is possible.  This Control is useful if you know that the Assembler program will encounter another set of Controls and it is necessary to restore the original value afterwards.
<b>RESTORE</b>	Recalls the list control settings.
<b>*LIST</b>	Instructs the Assembler to generate a program listing.
<b>NOLIST</b>	Suppresses the printing of the program listing.
<b>*COND</b>	Includes conditional skipped Source lines in the listing.
<b>NOCOND</b>	Does not include conditionally skipped lines.
<b>*GEN</b>	Lists all code generated by the FCC directive.
<b>NOGEN</b>	Lists only the first line generated by the FCC directive.
<b>*MEX</b>	Lists Macro expansion.
<b>NOMEX</b>	Does not list Macro expansion.

\*The Assembler uses these Controls unless otherwise specified.

## Examples.

To save list controls, and print only one line generated by the FCC directive, type the following controls.

```
50          OPT      SAVE, NOGEN
```

Several Source files can be assembled in the same assembly using the SOURCE control. The Source file may be terminated with an END directive. Once the file, called by the SOURCE control from a Source code, has been assembled, the Assembler continues with the file that contained the SOURCE control. Eight nesting levels are possible.

```
100          OPT      SOURCE "DEM01:T14"
 10          NAM      DEM01 SUB PROGRAM MODULE
 20
 30 00F9 062D          LDA  B  #45
 40 00FB 5A           LOOP  DEC  B
 50 00FC 26FD          BNE  LOOP
 60          END
110          OPT      RESTORE
```

## Example of Source Code

```

10      NAM      ASSEMBLER DIRECTIVE DEMO PROGRAM
20
30      ORG      000F9H      HEXADECIMAL ADDRESS
40
50      OPT      SAVE, NOGEN
60
70 * THE FOLLOWING PROGRAM HAS BEEN LINKED AND ASSEMBLED
80 * TOGETHER WITH THE MAIN PROGRAM
90
100     OPT      SOURCE "DEM01:T14"
110     OPT      RESTORE
120
130 * THE REST IS THE MAIN PROGRAM AGAIN
140
150 LABEL SET      $00A0      HEXADECIMAL ADDRESS
160 VALUE EQU      0327      OCTAL VALUE
170
180     SPC      2              2 SPACES
190
200 CONSTANT FDB    0414140    OCTAL VALUE
210     FCB      2540          OCTAL VALUE
220     FCC      /TEXT/       ASCII STRING INTO MEMORY
230
240 TEMP  RMB      8              CREATE AREA 8 BYTES LONG
250
260     LDA      B      #%00100100  BINARY VALUE
270
280     IF      VALUE-0327      CONDITIONAL ASSEMBLY START
290
300 START LDA      A      #00100110B  THIS LINE NOT ASSEMBLED
310
320     ELSE
330
340 START LDA      A      #'G        THIS LINE IS ASSEMBLED
350
360     FAIL      ASSEMBLING PART 2
370
380     ENDIF      CONDITIONAL ASSEMBLY END
390
400     LDX      #LABEL
410     STA      A      X
420     LDX      CONSTANT+1
430     STA      A      ,X
440     LDX      CONSTANT+VALUE*2      EXPRESSION
450     STA      A      0,X
460     STA      A      VALUE,X
470     BNE      START      JUMPS TO LABEL START
480     BCC      ++3        PROGRAM COUNTER + 3
490     CLC
500
510 LABEL SET      $00A1      LABEL REDEFINED WITH SET
520     STA      A      LABEL
530     MON      00F9H      DEFINE START ADDRESS
540

```

## Example of Program Listing

ASSEMBLER DIRECTIVE DEMO PROGRAM

PAGE 2

LINE	LOC.	OBJECT	SOURCE	STATEMENT
10			NAM	ASSEMBLER DIRECTIVE DEMO PROGRAM
20				
30	0000		ORG	000F9H    HEXADECIMAL ADDRESS
40				
50			OPT	SAVE, NOGEN
60				
70				* THE FOLLOWING PROGRAM HAS BEEN LINKED AND ASSEMBLED
80				* TOGETHER WITH THE MAIN PROGRAM
90				
100			OPT	SOURCE "DEM01:T14"
10			NAM	DEM01 SUB PROGRAM MODULE
20				
30	00F9	062D	LDA	B    #45
40	00FB	5A	DEC	B
50	00FC	26FD	BNE	LOOP
60			END	
110			OPT	RESTORE
120				
130				* THE REST IS THE MAIN PROGRAM AGAIN
140				
150		00A0	LABEL SET	#00A0    HEXADECIMAL ADDRESS
160		00D7	VALUE EQU	@327    OCTAL VALUE
170				
190				
200	00FE	430C	CONSTANT FDB	0414140    OCTAL VALUE
210	0100	AC	FCB	2540    OCTAL VALUE
220	0101	54455854	FCC	/TEXT/    ASCII STRING INTO MEMORY
230				
240	0105		TEMP RMB	8    CREATE AREA 8 BYTES LONG
250				
260	010D	0624	LDA	B    #%00100100    BINARY VALUE
270				
280			IF	VALUE=@327    CONDITIONAL ASSEMBLY START
290				
300			START LDA	A    #00100110B    THIS LINE NOT ASSEMBLED
310				
320			ELSE	
330				
340	010F	8647	START LDA	A    #'G    THIS LINE IS ASSEMBLED
350				
**		ASSEMBLING PART 2**		
360			FAIL	ASSEMBLING PART 2
370				
380			ENDIF	CONDITIONAL ASSEMBLY END
390				
400	0111	CE00A0	LDX	#LABEL
410	0114	A700	STA	A    X
420	0116	DEFF	LDX	CONSTANT+1
430	0118	A700	STA	A    ,X
440	011A	FE03AA	LDX	CONSTANT+VALUE*2    EXPRESSION
450	011D	A700	STA	A    0,X
460	011F	A7D7	STA	A    VALUE,X
470	0121	26EC	BNE	START    JUMPS TO LABEL START
480	0123	2401	BCC	**3    PROGRAM COUNTER + 3
490	0125	0C	CLC	
500				
510		00A1	LABEL SET	#00A1    LABEL REDEFINED WITH SET
520	0126	97A1	STA	A    LABEL
530		00F9	MON	00F9H    DEFINE START ADDRESS

## Sample Cross Reference

SYMBOL	VALUE	DEFINED	REFERENCED
CONSTANT	00FE	200	420 440
LABEL	00A1	150	RE-DEFINED: 510 400 520
LOOP	00FB	40	50
START	010F	340	470
TEMP	0105	240	* UNREFERENCED *
VALUE	00D7	160	280 440 460

## Character Set

The Assembler recognizes the complete ASCII character set. Generally all characters are considered to be alphabetic.

The following are exceptions, and the each have a special meaning:

+	Plus sign	ADDITION	
-	Minus sign	SUBTRACTION	
*	Asterisk	MULTIPLICATION	
/	Slash	DIVISION	
#		IMMEDIATE ADDRESSING MODE	
\$	Dollar	HEXADECIMAL NUMBER PREFIX	
@	Commercial at	OCTAL NUMBER PREFIX	
%	Percent	BINARY NUMBER PREFIX	
'	Single quote	SPECIFIES ASCII LITERAL CHARACTER	
"	Double quote	STRING DELIMITER	
B		BINARY NUMBER SUFFIX	} B, D, H, O, Q are also alpha characters
D		DECIMAL NUMBER SUFFIX	
H		HEXADECIMAL NUMBER SUFFIX	
O		OCTAL NUMBER SUFFIX	
Q		OCTAL NUMBER SUFFIX	
SPACE		FIELD SEPARATOR	
HOR TAB		FIELD SEPARATOR	
,	Comma	OPERAND SEPARATOR	
=	Equal sign	MACRO DUMMY ARGUMENT PREFIX	
^		MACRO PRE-EVALUATION PREFIX	



# Instructions

LINE	LOC.	OBJECT	SOURCE	STATEMENT
10			NAM	6800/02 MACRO ASSEMBLER INSTRUCTION SET
20		00FF	IMM EQU	\$FF 8 BIT IMMEDIATE DATA
30		FFFF	IMM2 EQU	\$FFFF 16 BIT IMMEDIATE DATA
40		00FF	DIR EQU	\$FF DIRECT ADDRESSING (BASE PAGE)
50		FFFF	EXT EQU	\$FFFF EXTENDED ADDRESSING
60		0000	IND EQU	\$00 INDEX VAL. FOR INDEX. ADDRESSING
70		0081	REL EQU	\$81 DISPL. VAL. FOR RELAT. ADDRESSING
80		0000	START ORG	\$4000 BEGINNING ADDRESS FOR ASSEMBLY
90	4000	1B	ABA	ADD ACCUMULATORS
100	4001	89FF	ADC A	#IMM ADD ACCUMULATOR A WITH CARRY
110	4003	99FF	ADC A	DIR
120	4005	B9FFFF	ADC A	EXT
130	4008	A900	ADC A	IND,X
140	400A	C9FF	ADC B	#IMM ADD ACCUMULATOR B WITH CARRY
150	400C	D9FF	ADC B	DIR
160	400E	F9FFFF	ADC B	EXT
170	4011	E900	ADC B	IND,X
180	4013	8BFF	ADD A	#IMM ADD ACCUMULATOR A
190	4015	9BFF	ADD A	DIR
200	4017	BBFFFF	ADD A	EXT
210	401A	AB00	ADD A	IND,X
220	401C	CBFF	ADD B	#IMM ADD ACCUMULATOR B
230	401E	DBFF	ADD B	DIR
240	4020	FBFFFF	ADD B	EXT
250	4023	EB00	ADD B	IND,X
260	4025	84FF	AND A	#IMM LOGICAL AND ACCUMULATOR A
270	4027	94FF	AND A	DIR
280	4029	B4FFFF	AND A	EXT
290	402C	A400	AND A	IND,X
300	402E	C4FF	AND B	#IMM LOGICAL AND ACCUMULATOR B
310	4030	D4FF	AND B	DIR
320	4032	F4FFFF	AND B	EXT
330	4035	E400	AND B	IND,X
340	4037	78FFF	ASL	EXT ARITHMETIC SHIFT LEFT OF MEMORY
350	403A	6800	ASL	IND,X
360	403C	48	ASL A	ARITHMETIC SHIFT LEFT OF ACCUM A
370	403D	58	ASL B	SAME AS A
380	403E	77FFFF	ASR	EXT ARITHMETIC SHIFT RIGHT OF MEMORY
390	4041	6700	ASR	IND,X
400	4043	47	ASR A	ARITHMETIC SHIFT RIGHT OF ACCUM A
410	4044	57	ASR B	SAME AS A
420	4045	247F	BCC	*+REL BRANCH IF CARRY CLEAR
430	4047	257F	BCS	*+REL BRANCH IF CARRY SET
440	4049	277F	BEQ	*+REL BRANCH IF EQUAL (ZERO)
450	404B	2C7F	BGE	*+REL BRANCH IF >= (ZERO)
460	404D	2E7F	BGT	*+REL BRANCH IF > (ZERO)
470	404F	227F	BHI	*+REL BRANCH IF HIGHER (UNSIGNED)
480	4051	85FF	BIT A	#IMM BIT TEST ACCUMULATOR A AND MEMORY
490	4053	95FF	BIT A	DIR
500	4055	85FFFF	BIT A	EXT
510	4058	A500	BIT A	IND,X
520	405A	C5FF	BIT B	#IMM BIT TEST ACCUMULATOR B AND MEMORY
530	405C	D5FF	BIT B	DIR
540	405E	F5FFFF	BIT B	EXT
550	4061	E500	BIT B	IND,X
560	4063	2F7F	BLE	*+REL BRANCH IF <= (ZERO)
570	4065	237F	BLS	*+REL BRANCH IF LOWER OR SAME (UNSIGNED)

LINE	LOC.	OBJECT	SOURCE	STATEMENT
580	4067	2D7F	BLT	*+REL BRANCH IF < (ZERO)
590	4069	2B7F	BMI	*+REL BRANCH IF MINUS
600	406B	267F	BNE	*+REL BRANCH IF NOT EQUAL ZERO
610	406D	2A7F	BPL	*+REL BRANCH IF PLUS
620	406F	207F	BRA	*+REL BRANCH ALWAYS
630	4071	8D7F	BSR	*+REL BRANCH TO SUBROUTINE
640	4073	287F	BVC	*+REL BRANCH IF OVERFLOW CLEAR
650	4075	297F	BVS	*+REL BRANCH IF OVERFLOW SET
660	4077	11	CBA	COMPARE ACCUMULATORS
670	4078	0C	CLC	CLEAR CARRY
680	4079	0E	CLI	CLEAR INTERRUPT MASK
690	407A	7FFFFFF	CLR	EXT CLEAR MEMORY
700	407D	6F00	CLR	IND,X
710	407F	4F	CLR A	CLEAR ACCUMULATOR A
720	4080	5F	CLR B	SAME FOR B
730	4081	0A	CLV	CLEAR OVERFLOW
740	4082	81FF	CMP A	#IMM COMPARE ACCUM. A WITH MEMORY
750	4084	91FF	CMP A	DIR
760	4086	B1FFFF	CMP A	EXT
770	4089	A100	CMP A	IND,X
780	408B	C1FF	CMP B	#IMM COMPARE ACCUM. B WITH MEMORY
790	408D	D1FF	CMP B	DIR
800	408F	F1FFFF	CMP B	EXT
810	4092	E100	CMP B	IND,X
820	4094	73FFFF	COM	EXT BIT COMPLEMENT MEMORY
830	4097	6300	COM	IND,X
840	4099	43	COM A	BIT COMPLEMENT ACCUMULATOR A
850	409A	53	COM B	SAME AS B
860	409B	8CFFFF	CPX	#IMM2 COMPARE INDEX REG. AND MEMORY
870	409E	9CFF	CPX	DIR
880	40A0	BCFFFF	CPX	EXT
890	40A3	AC00	CPX	IND,X
900	40A5	19	DAA	DECIMAL ADJUST ACCUMULATOR A
910	40A6	7AFFFF	DEC	EXT DECREMENT MEMORY
920	40A9	6A00	DEC	IND,X
930	40AB	4A	DEC A	DECREMENT ACCUMULATOR A
940	40AC	5A	DEC B	SAME FOR B
950	40AD	34	DES	DECREMENT STACK POINTER
960	40AE	09	DEX	DECREMENT INDEX REGISTER
970	40AF	88FF	EOR A	#IMM EXCL. OR ACCUM. A AND MEMORY
980	40B1	98FF	EOR A	DIR
990	40B3	B8FFFF	EOR A	EXT
1000	40B6	A800	EOR A	IND,X
1010	40B8	C8FF	EOR B	#IMM EXCL. OR ACCUM. B AND MEMORY
1020	40BA	D8FF	EOR B	DIR
1030	40BC	F8FFFF	EOR B	EXT
1040	40BF	E800	EOR B	IND,X
1050	40C1	7CFFFF	INC	EXT INCREMENT MEMORY
1060	40C4	6C00	INC	IND,X
1070	40C6	4C	INC A	INCREMENT ACCUMULATOR B
1080	40C7	5C	INC B	SAME AS B
1090	40C8	31	INS	INCREMENT STACK POINTER
1100	40C9	08	INX	INCREMENT INDEX REGISTER
1110	40CA	7EFFFF	JMP	EXT JUMP
1120	40CD	6E00	JMP	IND,X
1130	40CF	BDFFFF	JSR	EXT JUMP TO SUBROUTINE
1140	40D2	AD00	JSR	IND,X
1150	40D4	86FF	LDA A	#IMM LOAD ACCUMULATOR A
1160	40D6	96FF	LDA A	DIR
1170	40D8	B6FFFF	LDA A	EXT

LINE	LOC.	OBJECT	SOURCE	STATEMENT	
1180	40DB	A600	LDA A	IND,X	
1190	40DD	C6FF	LDA B	#IMM	LOAD ACCUMULATOR B
1200	40DF	D6FF	LDA B	DIR	
1210	40E1	F6FFFF	LDA B	EXT	
1220	40E4	E600	LDA B	IND,X	
1230	40E6	8EFFFF	LDS	#IMM2	LOAD STACK POINTER
1240	40E9	9EFF	LDS	DIR	
1250	40EB	BEFFFF	LDS	EXT	
1260	40EE	AE00	LDS	IND,X	
1270	40F0	CEFFFF	LDX	#IMM2	LOAD INDEX REGISTER
1280	40F3	DEFF	LDX	DIR	
1290	40F5	FEFFFF	LDX	EXT	
1300	40F8	EE00	LDX	IND,X	
1310	40FA	74FFFF	LSR	EXT	LOGICAL SHIFT RIGHT OF MEMORY
1320	40FD	6400	LSR	IND,X	
1330	40FF	44	LSR A		LOG. SHIFT RIGHT OF ACCUM. A
1340	4100	54	LSR B		SAME AS B
1350	4101	70FFFF	NEG	EXT	NEGATE (2'S COMPLEMENT) MEMORY
1360	4104	6000	NEG	IND,X	
1370	4106	40	NEG A		NEGATE (2'S COMPL.) ACCUM. A
1380	4107	50	NEG B		SAME AS B
1390	4108	01	NOP		NO OPERATION
1400	4109	8AFF	ORA A	#IMM	INCL. OR ACCUM. A WITH MEMORY
1410	410B	9AFF	ORA A	DIR	
1420	410D	BAFFFF	ORA A	EXT	
1430	4110	AA00	ORA A	IND,X	
1440	4112	CAFF	ORA B	#IMM	INCL. OR ACCUM. B WITH MEMORY
1450	4114	DAFF	ORA B	DIR	
1460	4116	FAFFFF	ORA B	EXT	
1470	4119	EA00	ORA B	IND,X	
1480	411B	36	PSH A		PUSH ACCUMULATOR A ONTO STACK
1490	411C	37	PSH B		PUSH ACCUMULATOR B ONTO STACK
1500	411D	32	PUL A		PULL ACCUMULATOR A FROM STACK
1510	411E	33	PUL B		PULL ACCUMULATOR B FROM STACK
1520	411F	79FFFF	ROL	EXT	ROTATE MEMORY LEFT
1530	4122	6900	ROL	IND,X	
1540	4124	49	ROL A		ROTATE ACCUMULATOR A LEFT
1550	4125	59	ROL B		ROTATE ACCUMULATOR B LEFT
1560	4126	76FFFF	ROR	EXT	ROTATE MEMORY RIGHT
1570	4129	6600	ROR	IND,X	
1580	412B	46	ROR A		ROTATE ACCUMULATOR A RIGHT
1590	412C	56	ROR B		SAME FOR B
1600	412D	3B	RTI		RETURN FROM INTERRUPT
1610	412E	39	RTS		RETURN FROM SUBROUTINE
1620	412F	10	SBA		SUBTRACT ACCUMULATORS
1630	4130	B2FF	SBC A	#IMM	SUBTR. FROM ACCUM. A WITH CARRY
1640	4132	92FF	SBC A	DIR	
1650	4134	B2FFFF	SBC A	EXT	
1660	4137	A200	SBC A	IND,X	
1670	4139	C2FF	SBC B	#IMM	SUBTR. FROM ACCUM. B WITH CARRY
1680	413B	D2FF	SBC B	DIR	
1690	413D	F2FFFF	SBC B	EXT	
1700	4140	E200	SBC B	IND,X	
1710	4142	0D	SEC		SET CARRY
1720	4143	0F	SEI		SET INTERRUPT MASK
1730	4144	0B	SEV		SET OVERFLOW
1740	4145	97FF	STA A	DIR	STORE ACCUMULATOR A IN MEMORY
1741	4147	B7FFFF	STA A	EXT	
1750	414A	A700	STA A	IND,X	
1760	414C	D7FF	STA B	DIR	STORE ACCUMULATOR B IN MEMORY

LINE	LOC.	OBJECT	SOURCE STATEMENT
1761	414E	F7FFFF	STA B EXT
1770	4151	E700	STA B IND,X
1780	4153	9FFF	STS DIR STORE STACK REGISTER
1790	4155	BFFFFFF	STS EXT
1800	4158	AF00	STS IND,X
1810	415A	DFFF	STX DIR STORE INDEX REGISTER
1820	415C	FFFFFF	STX EXT
1830	415F	EF00	STX IND,X
1840	4161	80FF	SUB A #IMM SUB FROM ACCUMULATOR A
1850	4163	90FF	SUB A DIR
1860	4165	B0FFFF	SUB A EXT
1870	4168	A000	SUB A IND,X
1880	416A	C0FF	SUB B #IMM SUB FROM ACCUMULATOR B
1890	416C	D0FF	SUB B DIR
1900	416E	F0FFFF	SUB B EXT
1910	4171	E000	SUB B IND,X
1920	4173	3F	SWI SOFTWARE INTERRUPT
1930	4174	16	TAB TRANSFER ACCUM. A TO B
1940	4175	06	TAP TRANSFER ACCUM. A TO CC REGISTER
1950	4176	17	TBA TRANSFER ACCUMULATOR B TO A
1960	4177	07	TPA TRANSFER CC REGISTER TO ACCUM. A
1970	4178	7DFFFF	TST EXT TEST MEMORY
1980	417B	6D00	TST IND,X
1990	417D	4D	TST A TEST ACCUMULATOR A
2000	417E	5D	TST B TEST ACCUMULATOR B
2010	417F	30	TSX TRANSFER STACK POINTER TO INDEX REGISTER
2020	4180	35	TXS TRANSFER INDEX REG TO STACK POINTER
2030	4181	3E	WAI WAIT FOR INTERRUPT
2040			END

## Differences between HP and the 6800

The following is a list of differences, known to us at the time of printing, that exist between the Hewlett-Packard software and other 6800 Assembler descriptions.

- a) The character set has been expanded.
- b) The following pseudo mnemonics have been added:

```

FAIL      ENDIF
SET       IFC
IF        IFNC
ELSE

```

- c) A complete set of Macros have been added.
- d) NAM directive can appear anywhere in the program.
- e) COUNT in the FCC directive is limited to 80 characters.
- f) The following Assembler controls have been added:

```

MEX       RESTORE
NOMEX     SOURCE
SAVE

```

The following 6800 controls are not implemented:

```

ERROR
SERROR
NOERROR
SLIST
MEMORY
NOMEMORY
OTAPE      Replaced by OBJECT "file name"
NOOTAPE    Replaced by OBJECT
PAGE
NOPAGE
GENERATE   Replaced by GEN
NOGENERATE Replaced by NOGEN
TAB
NOTAB

```



# Section Seven

## Z80 Assembly Language Instructions



### Introduction

The following is a description of the Assembly Language instructions needed to write Source code for the Z80 Microprocessor. We recommend that you make yourself acquainted with this explanation as it differs in some respects from the description given by Z80 Programming Manual.

### Source Line Format

A Program written in Assembler Language is called a Source code. It consists of symbolic commands called statements. Each statement is written on a single line and may consist of from one to four fields. From left to right the fields are:

(1) LABEL:            (2) INSTRUCTION        (3) OPERAND        (4) COMMENT

The following pages describe each field individually. An illustration of the format pattern is given below.

[ <LABEL>:] [ <INSTRUCTION> ] [ <OPER> [, <OPER> . . . ] ] [ ;<COMMENT> ]

Space	LABEL:	space	INSTRUCTION	space	OPERAND, OPERAND	space	; COMMENT
Optional	Optional	One or more	Optional	Optional	Optional	Optional	Optional

## Label Field

A Label is required for statements involved in the definition of Symbols and occasionally at destinations of branch and jump instructions.

A Label is a symbol name whose value is the location where the instruction is assembled. Any number of characters (limited by the line length) may be used. However, the Assembler only recognizes up to eight alphanumeric characters whereby the first character must be alphabetic.

All Labels must end with a colon, except if it starts in column one.

Label may consist of any permutation of upper and lower case. However, two names which differ in case construction will be considered as two different names. Thus, LABEL, label and LaBel will be considered as three different names.

The Assembler maintains a location counter to provide addresses for the symbols in the Label field. When a symbol is found in the Label field the Assembler places the symbol and the corresponding location counter value in a symbol table.

## Instruction Field

Instructions are machine or pseudo mnemonics and must be present in all statements except when the statement consists only of a Comment or Label. Instructions must not start in the first character position. Pseudo mnemonics are described later in this Section, and a list of Z80 machine mnemonics is given at the back of this Section.

## Operand Field

The Operand field identifies the data to be acted upon by the specified instruction. Some instructions require no Operand, while others require one or more.

The Operand field is separated from the Instruction field by at least one blank. If more than one Operand is required they are separated from each other by a comma.

The type of information placed in the Operand field depends upon the particular Instruction. The following are recognized by the Assembler as Operands:

- Numbers
- Symbols
- Expressions
- ASCII strings
- Location counter symbol (\$)

The listed Operand types are now described in more detail.



## Numbers

The Assembler accepts numbers in the Operand field in several different bases: binary, octal, decimal, and hexadecimal. Numbers are accepted in the following formats:

<Number>	Specifies a Decimal number	0-65536
<Number>D	Specifies a Decimal number	0D-65536D
<Number>H	Specifies a Hexadecimal number	0H-0FFFFH
<Number>O	Specifies an Octal number	0O-177777O
<Number>Q	Specifies an Octal number	0Q-177777Q
<Number>B	Specifies a Binary number	0B-1111111111111111B

The <Number> must always begin with a numeric character. For example:

A9FFH	Illegal (will be recognized as a Symbol)
0A9FFH	Correct specification.

## Symbols

Symbols can be divided into three separate identities, Reserved, User definable, and Assembler generated symbols.

Reserved symbols are those that already have a special meaning to the Assembler and therefore cannot appear as user-defined symbols. The mnemonic names for microprocessor instructions and the Assembler directives are all reserved symbols.

The following instruction Operand symbols are also reserved:

A	Register A
B	Register B
C	Register C
D	Register D
E	Register E
H	Register H
L	Register L
BC	Register Pair B and C
DE	Register Pair D and E
HL	Register Pair H and L
SP	Stack Pointer
IX	Index Register
IY	Index Register
AF	Register Pair A and F
AF.	Register Pair A' and F' (Zilog Assembler AF')
§	Location Counter

User-defined symbols are symbols you create to reference instruction and data addresses. These symbols are defined when they appear in the Label field of the instruction, the EQU, DEFL or MACRO.

## Expressions

An expression is an Operand entry consisting of either a single term or a combination of terms. It contains a valid series of Symbols and Numbers that can be connected by operators.

The Assembler includes five groups of operators which permit the following Assembly-time operations:

- Arithmetic
- Shift
- Logical
- Relational
- Result

It is important to remember that these are assembly-time operations. Once the Assembler has evaluated an expression, it becomes a permanent part of your program.

Expressions are evaluated from left to right. Operators with higher precedence are evaluated before other operators that immediately precede or follow them. When two operators have equal precedence, the left most is evaluated first.

The following list describes classes of operators in order of precedence.

Parenthesized expressions	High
Unary Minus .NOT. \ .RES.	↓
* / .MOD. .SHR. .SHL.	
+ -	
.AND. &	
.OR. .XOR.	
Relational Operators	↓
	Low

The Assembler must complete the numeric evaluation of symbols and expressions in two passes. Only one level of forward addressing is permitted in the use of symbols or expressions in the Operand field of the Source statement.

For instance, in the example below P would not be evaluated.

P	EQU	R
R	EQU	Q
Q	EQU	5

## ARITHMETIC OPERATORS

Operator	Meaning
+	Addition
-	Subtraction
*	Multiplication
/	Integer Division. Any remainder is discarded ( $7/2=3$ ).
.MOD.	Modulo, Result is the remainder caused by a division operation. (7 .MOD. 3 = 1)

Examples:

The following expressions generate the bit pattern for the ASCII character A, where A equals 65 decimal.

```
5+30*2
(25/5)+30*2
5+(-30*-2)
```

Example of .MOD.

The .MOD. operator must be separated from its Operands by spaces:

```
NUMBER .MOD. 8
```

Assuming that NUMBER has the value 25, then the expression evaluates to 1.

## SHIFT OPERATORS.

Operator	Meaning
y .SHR. x	Shift 'y' to the right 'x' bit positions.
y .SHL. x	Shift 'y' to the left 'x' bit positions.

The shift operators do not wraparound any bits shifted out of the byte. Bits vacated by the shift operation are zero filled. Note that the shift operator must be separated from its Operands by spaces.

Example:

Assume that NUMBER has the value 0101 0101B. The effect of the shift operators is as follows:

```
NUMBER .SHR. 2 0001 0101B
NUMBER .SHL. 1 1010 1010B
```

Note that a shift one bit position to the left has the effect of multiplying a value by two; a shift one bit position to the right has the effect of dividing a value by two.

## LOGICAL OPERATORS.

Operator	Meaning
.NOT.	\ Logical One's Complement
.AND.	& Logical AND
.OR.	Logical OR
.XOR.	Logical Exclusive OR

Example:

```
If      VALUE1 = 12
        VALUE2 = 15
        VALUE3 = 20
```

```
Then VALUE1 .AND. VALUE2 .AND. VALUE3 = 4
```

## RELATIONAL OPERATORS.

Operator	Meaning
.EQ.	Equal
.LT.	< Less Than
.GT.	> Greater Than
.UGT.	Unsigned Greater Than
.ULT.	Unsigned Less Than

The relational operators produce a yes-no result. Thus, if the evaluation of the relation is TRUE, the value of the result is all ones. If FALSE, the value of the result is all zeros.

Relational operators .UGT. and .ULT. compare unsigned binary values. Hence, a -3 will be evaluated as greater than 10.

Example:

The following COND directive tests the values of VALUE1 and VALUE2 for equality. If the result of the comparison is TRUE, the assembly language coding following the COND directive is assembled. Note that the relational operator must be separated from its Operand by spaces.

```
COND VALUE1 .EQ. VALUE2
```

## RESULT OPERATOR

Assume, for example, that your Source code contains a statement that will put an intermediate calculation outside of the limits 32767 to -32767 that the program can work with. Assuming also that the end result will be in the range, then by putting the .RES. operator before the expression gives the correct answer to your problem. Without the .RES. operator, an error is given.

## ASCII Strings

All ASCII characters enclosed in single quotes define an ASCII String. Two successive quotes must be used to represent one single quote.

Double quote marks can also be used to define an ASCII String. In this case, the double quotes define the string delimiter while a single quote is regarded as a character within the string. For example:

'TODAY'S DATE' or "TODAY'S DATE"

## Special Operands

An expression or Register Pair completely enclosed in parenthesis indicates a memory address.

For example:	12+3	Constant with value 15
	(12+3)	Memory address 15

## Comment Field

Comments can be optionally used at the end of a Source line. If present, they are ignored by the Assembler during translation and appear only in the program listing.

Separation of a Comment and Operand field is made by a semicolon.



**DEFB** – Define byte

**DEFM** – Define Memory

```
[ <LABEL>:]  DEFB  <EXPR>|<STRING> [,<EXPR>|<STRING> ... ] [;<COMMENT> ]
```

```
[ <LABEL>:]  DEFM  <EXPR>|<STRING> [,<EXPR>|<STRING> ... ] [;<COMMENT> ]
```

An 8-bit value corresponding to each Operand is stored in a byte of the Object code. This directive may have one or more Operands, separated by commas. The number of Operands is limited by the Source line length of 80 characters. The Operand can be any constant, symbol, an expression evaluating to an 8-bit value, or an ASCII String.

The Label is optional. However, when it is present the address of the first generated byte is assigned to the symbol represented by the Label.

Example

```
210 1216 24          DEFB  00100100B ;BINARY VALUE
220 1217 54455854   DEFM  <TEXT>   ;ASCII "TEXT" INTO MEMORY
```

**DEFL** – Define label

```
<LABEL> :          DEFL  <EXPRESSION>          [;<COMMENT> ]
```

This directive assigns the value given by the Operand field to the Symbol specified in the Label field. This value remains unchanged until altered by a subsequent DEFL directive.

Example

```
150      00A0      LABEL  DEFL  00A0H      ;HEXADECIMAL ADDRESS
```

**DEFS** – Define storage

```
[ <LABEL> : ]      DEFS  <EXPRESSION>          [ ;<COMMENT> ]
```

The DEFS directive causes the location counter to be increased by the value given in the Operand field. This reserves a block of memory equal to the size of the expression value. The Operand field may contain the actual number equal to the number of bytes to be reserved or the Operand may be a symbol or an expression which can be assigned a numerical value by the Assembler. When a symbol is used it must have been previously defined. A symbol that has been defined by a Label is assigned the address of the first byte reserved by this directive. The content of the memory block is unchanged. The Assembler only advances the location counter and does not generate any Object code.

Example

```
240 121B          TEMP:  DEFS  8              ;CREATE AREA 8 BYTES LONG
```

**DEFW – Define word**

```
[ <LABEL> : ]   DEFW   <EXPR> [ , <EXPR> ... ] [ ; <COMMENT> ]
```

The DEFW directive may have one or more Operands separated by commas. It is similar to the Define Byte directive except that it generates a double byte Object from a 16-bit value. The least significant bits are stored in the first byte. Strings of one or two characters are allowed however longer Strings cause errors.

**Example**

```
200 1214 0043      CONSTANT:DEFW      0414140    ;OCTAL VALUE
```

**END**

```
[ <LABEL> : ]   END     [ <START ADDRESS> ] [ ; <COMMENT> ]
```

This directive stops the Assembler program. If the END directive is missing, the assembler program is terminated by the end of the file. However, the Assembler does not stop if an END directive is a part of a file called by the INCLUDE or SOURCE control from a Source code. The directive is not translated into Object code. The start address should be present when it is required by your Micro-processor system. Refer to the Console Section of this manual for further information.

**Example**

```
480      0000      END      ;STOPS THE ASSEMBLER
```

**EQU**

```
<LABEL> :      EQU   <EXPRESSION>      [ ; <COMMENT> ]
```

This directive assigns a value, given by the Operand field, to the symbol specified in the Label field. However, this directive cannot redefine the symbol by a subsequent EQU directive.

**Example**

```
160      0007      VALUE EQU      3270      ;OCTAL VALUE
```

**FAIL**

```
[ <LABEL> : ]   FAIL   'USER DEFINABLE ERROR MESSAGE'
```

The FAIL directive forces the Assembler to printout a user defined error message. This directive would be contained in your Source code as an indication that unwanted code has been assembled. It is often used within the COND-ELSE-ENDC directives to ensure that the correct code has been assembled.

**Example**

```
**ASSEMBLING PART 2**  
340      FAIL      'ASSEMBLING PART 2'
```



**IFC-ELSE-ENDC**

```
[ <LABEL> : ]   IFC     <OPER1> , <OPER2>   [ ; <COMMENT> ]
                .
                CODE SEQUENCE
                .
[ <LABEL> : ]   ENDC                               [ ; <COMMENT> ]
```

The IFC directive is similar to the COND directive. However, the code sequence is Assembled if the two Operands, following the IFC directive, are equal on a character for character basis. No evaluation is performed on the two Operands. Operands can be Symbols or Strings. You use the ELSE pseudo in the same manner as with the COND directive.

**IFNC-ELSE-ENDC**

```
[ <LABEL> : ]   IFNC    <OPER1> , <OPER2>   [ ; <COMMENT> ]
                .
                CODE SEQUENCE
                .
[ <LABEL> : ]   ENDC                               [ ; <COMMENT> ]
```

The IFNC directive is similar to the IFC directive, whereby the code sequence is Assembled if the two Operands, following the IFNC directive, are not equal on a character for character basis.

**ORG – Origin**

```
[ <LABEL> : ]   ORG     <EXPRESSION>       [ ; <COMMENT> ]
```

This directive defines the numerical address of the first byte of machine code which results from the assembly of the immediately subsequent section of a Source code. There may be any number of ORG statements in a program. The ORG directive sets the location counter to the value expressed in the Operand field. This field may contain the actual value (decimal, hexadecimal, octal, or binary) to which the location counter is to be set. Alternatively, the Operand field may contain a symbol or an expression which can be assigned a numeric value by the Assembler. Symbols must be previously defined.

The location counter is initialized to 0000H before each assembly. If no ORG statement appears at the beginning of the program, the location counter begins as if an ORG zero had been entered.

**Example**

```
30 0000                ORG     4623        ;DECIMAL ADDRESS
```

**SPC – Space**

```
[ <LABEL> : ]   SPC     <EXPRESSION>       [ ; <COMMENT> ]
```

The SPC directive inserts a number of blank lines in the program listing. The number of lines to be left blank is stated in the Operand field. When the SPC directive causes the listing to cross page boundaries only those blank lines required to get to the top of the next page are generated.

## Assembler Controls

All Assembler Controls are preceded by the asterisk (\*) sign which must be placed at the first character position in the Source code. As many Controls as required may be included on one line and each Control must be separated by a blank or a comma. If more Controls are required that can fit on one line, other lines may be used as long as each line begins with the asterisk sign.

These Controls can also be entered after the SOURCE or OBJECT statement in the Assembler program. See Section IX.

\*[ <CONTROL1> [ , <CONTROL2> . . . ] [ ; COMMENT]

**HEADING 'ASCII String'** Defines the heading for the top of the page. If entered in the first line of the Source code it appears at the top of the first page. Entered into the Source code at any other time causes it to appear on the next page following its definition.

**EJECT** Advances the paper to the top of the next page.

**SOURCE "<FILE NAME> [msus]"** A file on the mass storage device is entered in the assembly if specified in the Operand field with this control. If a Source line contains two or more SOURCE controls, then the last Source file specified is assembled first. Eight levels of nesting are allowed. Enter the msus if the Source file is not stored on the mass storage device specified in the default file.

**INCLUDE "<FILE NAME> [msus]"** Same as for SOURCE.

**OBJECT ["<FILE NAME> [msus]"** As long as the file on which the Object code is to be stored was not specified with the OBJECT statement of the Assembler program, see Assembler Module Section IX, it may be specified by inserting this Control in the Source code. The position of this Control in the Source code is not important, as the Object code for the entire Source code will still be stored.

Entering the OBJECT Control without a file name results in no Object code being stored. If the Object file is specified, no other Object control is accepted.

**SYMBOLS ON** Prints the Symbol Table after the program listing. The symbol table listing is generated by the cross reference generator. Only the cross reference list is generated if both the Symbol and cross reference control commands are selected.

**\*SYMBOLS OFF** Suppresses the Symbol Table print.

**\*XREF ON** When the Assembler is finished the XREF generator is called and prints the cross reference of all user symbols. If XREF ON SYMBOLS ON have been specified, then only an XREF is made.

**XREF OFF** Suppresses the cross reference.

<b>SAVE</b>	The current list control settings LIST, CONDLIST and MACLIST are saved but remain valid until explicitly changed. Nesting up to eight levels is possible.
<b>RESTORE</b>	Recalls the list Control settings. If more RESTORE commands are given than there are SAVE commands, then the extra RESTORE commands are ignored.
<b>*LIST ON</b>	Instructs the Assembler to generate a program listing.
<b>LIST OFF</b>	Suppresses the printing of the program listing.
<b>*CONDLIST ON</b>	Includes conditional skipped Source lines in the listing.
<b>CONDLIST OFF</b>	Does not include conditionally skipped lines.
<b>*MACLIST ON</b>	Lists MACRO expansion.
<b>MACLIST OFF</b>	Does not list MACRO expansion.
*The Assembler uses these Controls unless otherwise specified.	



### Examples

To give your printed pages a title, use the HEADING Control followed by the title enclosed in quotes.

```
10          * HEADING 'ASSEMBLER DIRECTIVE DEMO PROGRAM'
```

To save list controls, and suppress the Macro listing, type the following controls.

```
50          * SAVE MACLIST OFF
```

You can use the INCLUDE Control to assemble several Source files within the same assembly. It is possible to terminate the Source file with an END directive. Once the included file has been assembled, the Assembler continues with the file that contained the INCLUDE Control. Eight levels of nesting are possible.

```
100          * INCLUDE "DEM03:T14"
10          * HEADING 'PROGRAM BEING LINKED'
20 120F CB6F          BIT          5,A
30 1211 3D          LOOP:      DEC          A
40 1212 20FD          JR          NZ,LOOP
50          0000          END
110
120          * RESTORE
130          ; THE REST IS THE MAIN PROGRAM AGAIN
```

Note that on the original Source code the \* sign would be placed in the first character position.

## Example of Source Code

```

10 * HEADING 'ASSEMBLER DIRECTIVE DEMO PROGRAM'
20
30          ORG          4623          ;DECIMAL ADDRESS
40
50 * SAVE MACLIST OFF
60
70 ; THE FOLLOWING PROGRAM HAS BEEN LINKED AND ASSEMBLED
80 ; TOGETHER WITH THE MAIN PROGRAM
90
100 * INCLUDE "DEM03:T14"
110
120 * RESTORE
130 ; THE REST IS THE MAIN PROGRAM AGAIN
140
150 LABEL    DEFL        00A0H        ;HEXADECIMAL ADDRESS
160 VALUE    EQU         3270         ;OCTAL VALUE
170
180          SPC      2              ;2 SPACES
190
200 CONSTANT:DEFW      0414140       ;OCTAL VALUE
210          DEFB       00100100B    ;BINARY VALUE
220          DEFM       'TEXT'       ;ASCII "TEXT" INTO MEMORY
230
240 TEMP:     DEFS      8              ;CREATE AREA 8 BYTES LONG
250
260          COND  VALUE-3270         ;CONDITIONAL ASSEMBLY START
270
280 START:    ADD        A,VALUE+2    ;THIS LINE IS NOT ASSEMBLED
290
300          ELSE
310
320 START:    ADD        A,'G'        ;THIS LINE IS ASSEMBLED
330
340          FAIL        'ASSEMBLING PART 2'
350
360          ENDC          ;CONDITIONAL ASSEMBLY END
370
380          ADD        A,LABEL        ;LABEL=00A0H FROM LINE 140
390          ADC        A,0FH&(CONSTANT+VALUE*2) ;EXPRESSION
400          SUB        45D           ;DECIMAL VALUE
410          JR        NZ,START       ;JUMPS TO LABEL START
420          JR        NC,$+3         ;PROGRAM COUNTER + 3
430          CCF
440
450 LABEL:    DEFL        00A1H        ;LABEL REDEFINED WITH SET
460          SBC        A,LABEL
470          DEC        B
480          END          ;STOPS THE ASSEMBLER
490
500

```



## Cross Reference List

SYMBOL	VALUE	DEFINED	REFERENCED
CONSTANT	1214	200	390
LABEL	00A1	150	RE-DEFINED: 450 380 460
LOOP	1211	30	40
START	1223	320	410
TEMP	121E	240	* UNREFERENCED *
VALUE	00D7	160	260 390

## Character Set

The Assembler recognizes the complete ASCII character set and generally all characters are considered to be alphabetic except the following who each have a special meaning.

+	Plus sign	ADDITION	
-	Minus sign	SUBTRACTION	
*	Asterisk	MULTIPLICATION	
/	Slash	DIVISION	
(	Left Parenthesis	LEFT PARENTHESIS	
)	Right Parenthesis	RIGHT PARENTHESIS	
\$	Dollar sign	LOCATION COUNTER SYMBOL	
&	Ampersign	LOGICAL AND OPERATOR	
\	Backslash	LOGICAL NOT OPERATOR	
>	Greater than sign	GREATER THAN OPERATOR	
<	Less than sign	LESS THAN OPERATOR	
'	Apostroph	STRING DELIMITER	
"	Quotes	STRING DELIMITER	
:	Colon	LABEL DELIMITER	
;	Semicolon	COMMENT FIELD DELIMITER	
B		BINARY NUMBER SUFFIX	} B, D, H, O, Q, are also alpha characters
D		DECIMAL NUMBER SUFFIX	
H		HEX NUMBER SUFFIX	
O		OCTAL NUMBER SUFFIX	
Q		OCTAL NUMBER SUFFIX	
SPACE		FIELD SEPARATOR OR SYMBOL TERMINATOR	
HOR TAB		FIELD SEPARATOR OR SYMBOL TERMINATOR	
.	Comma	OPERAND SEPARATOR	
=	Equals sign	MACRO DUMMY ARGUMENT PREFIX	
^		MACRO PRE-EVALUATION PREFIX	

## Instructions

LINE	LOC.	OBJECT	SOURCE STATEMENT
10	0003	8E	ADC A,(HL) ;ADD WITH CARRY OPERAND TO ACC.
20	0004	DD8E05	ADC A,(IX+d)
30	0007	FD8E05	ADC A,(IY+d)
40	000A	8F	ADC A,A
50	000B	88	ADC A,B
60	000C	89	ADC A,C
70	000D	8A	ADC A,D
80	000E	8B	ADC A,E
90	000F	8C	ADC A,H
100	0010	8D	ADC A,L
110	0011	CE20	ADC A,n
120	0013	ED4A	ADC HL,BC ;ADD WITH CARRY REG PAIR TO HL
130	0015	ED5A	ADC HL,DE
140	0017	ED6A	ADC HL,HL
150	0019	ED7A	ADC HL,SP
160	001B	86	ADD A,(HL) ;ADD OPERAND TO ACC.
170	001C	DD8605	ADD A,(IX+d)
180	001F	FD8605	ADD A,(IY+d)
190	0022	87	ADD A,A
200	0023	80	ADD A,B
210	0024	81	ADD A,C
220	0025	82	ADD A,D
230	0026	83	ADD A,E
240	0027	84	ADD A,H
250	0028	85	ADD A,L
260	0029	C620	ADD A,n
270	002B	09	ADD HL,BC ;ADD REG. PAIR TO HL
280	002C	19	ADD HL,DE
290	002D	29	ADD HL,HL
300	002E	39	ADD HL,SP
310	002F	DD09	ADD IX,BC ;ADD REG. PAIR TO IX
320	0031	DD19	ADD IX,DE
330	0033	DD29	ADD IX,IX
340	0035	DD39	ADD IX,SP
350	0037	FD09	ADD IY,BC ;ADD REG. PAIR TO IY
360	0039	FD19	ADD IY,DE
370	003B	FD29	ADD IY,IY
380	003D	FD39	ADD IY,SP
390	003F	A6	AND (HL) ;LOGICAL AND OF OPERAND AND ACC.
400	0040	DDA605	AND (IX+d)
410	0043	FDA605	AND (IY+d)
420	0046	A7	AND A
430	0047	A0	AND B
440	0048	A1	AND C
450	0049	A2	AND D
460	004A	A3	AND E
470	004B	A4	AND H
480	004C	A5	AND L
490	004D	E620	AND n
500	004F	CB46	BIT 0,(HL) ;TEST BIT B OF LOCATION OR REG.
510	0051	DDCB0546	BIT 0,(IX+d)
520	0055	FDCB0546	BIT 0,(IY+d)
530	0059	CB47	BIT 0,A
540	005B	CB40	BIT 0,B
550	005D	CB41	BIT 0,C
560	005F	CB42	BIT 0,D
570	0061	CB43	BIT 0,E

LINE	LOC.	OBJECT	SOURCE STATEMENT
580	0063	CB44	RIT 0,H
590	0065	CB45	RIT 0,L
600	010F	DC8405	CALL C,nn ;CALL SUBROUTINE AT LOC. nn IF
610	0112	FC8405	CALL M,nn ;CONDITION TRUE
620	0115	D48405	CALL NC,nn
630	0118	C48405	CALL NZ,nn
640	011B	F48405	CALL P,nn
650	011E	EC8405	CALL PE,nn
660	0121	F48405	CALL PD,nn
670	0124	CC8405	CALL Z,nn
680	0127	CD8405	CALL nn ;UNCONDITIONAL CALL TO SUBROUT.
681			;AT nn
690	012A	3F	CCF ;COMPLEMENT CARRY FLAG
700	012B	BE	CP (HL) ;COMPARE OPERAND WITH ACC.
710	012C	DDRE05	CP (IX+d)
720	012F	FDRE05	CP (IY+d)
730	0132	BF	CP A
740	0133	B8	CP B
750	0134	B9	CP C
760	0135	BA	CP D
770	0136	BB	CP E
780	0137	BC	CP H
790	0138	BD	CP L
800	0139	FE20	CP n
810	013B	FDA9	CPD ;COMPARE LOC. (HL) AND ACC.
811			;DECREMENT HL AND BC
820	013D	EDB9	CPDR ;COMPARE LOC. (HL) AND ACC. DECR.
821			;HL AND BC, REPEAT UNTIL BC=0
830	013F	EDA1	CPI ;COMPARE LOC. (HL) AND ACC.
831			;INCREMENT HL AND DECREMENT BC
840	0141	EDR1	CPDR ;COMPARE LOC. (HL) AND ACC. INCR.
841			;HL, DECR. BC, REPEAT UNTIL BC=0
850	0143	2F	CPL ;COMPLEMENT ACC.
860	0144	27	DAA
870	0145	35	DEC (HL) ;DECREMENT OPERAND
880	0146	DD3505	DEC (IX+d)
890	0149	FD3505	DEC (IY+d)
900	014C	3D	DEC A
910	014D	05	DEC B
920	014E	0D	DEC C
930	014F	15	DEC D
940	0150	1D	DEC E
950	0151	25	DEC H
960	0152	2D	DEC L
970	0153	0B	DEC BC
980	0154	1B	DEC DE
990	0155	2B	DEC HL
1000	0156	DD2B	DEC IX
1010	0158	FD2B	DEC IY
1020	015A	3B	DEC SP
1030	015B	F3	DI ;DISABLE INTERRUPTS.
1040	015C	102E	DJNZ \$+e ;DECR. B AND JUMP RELATIVE IF B=0
1050	015E	FB	EI ;ENABLE INTERRUPTS.
1060	015F	E3	EX (SP),HL ;EXCHANGE LOCATION AND (SP).
1070	0160	DDE3	EX (SP),IX
1080	0162	FDE3	EX (SP),IY
1090	0164	0B	EX AF,AF' ;EXCHANGE CONTENTS OF AF AND AF'
1100	0165	EB	EX DE,HL ;EXCHANGE CONTENTS OF DE AND HL.
1110	0166	D9	EXX ;EXCHANGE CONTENTS OF BC,DE,HL.



LINE	LOC.	OBJECT	SOURCE STATEMENT
1111			;WITH CONTENTS OF BC', DE', HL'
1112			;RESPECTIVELY.
1120	0167	76	HALT ;WAIT FOR INTERRUPT OF RESET.
1130	0168	ED46	IM 0 ;SET INTERRUPT MODE.
1140	016A	ED56	IM 1
1150	016C	ED5E	IM 2
1160	016E	ED78	IN A,(C) ;LOAD REG. WITH INPUT FROM DEVICE.
1170	0170	ED40	IN B,(C)
1180	0172	ED48	IN C,(C)
1190	0174	ED50	IN D,(C)
1200	0176	ED58	IN E,(C)
1210	0178	ED60	IN H,(C)
1220	017A	ED68	IN L,(C)
1230	017C	23	INC HL ;INCREMENT OPERAND
1240	017D	03	INC BC
1250	017E	13	INC DE
1260	017F	33	INC SP
1270	0180	DD23	INC IX
1280	0182	FD23	INC IY
1290	0184	DB20	IN A,(n) ;LOAD ACC. WITH INPUT FROM
1291			;DEVICE n.
1300	0186	34	INC (HL)
1310	0187	DD3405	INC (IX+d)
1320	018A	FD3405	INC (IY+d)
1330	018D	3C	INC A
1340	018E	04	INC B
1350	018F	0C	INC C
1360	0190	14	INC D
1370	0191	1C	INC E
1380	0192	24	INC H
1390	0193	2C	INC L
1400	0194	EDAA	IND ;LOAD LOC. (HL) WITH INPUT FROM
1401			;PORT (C). DECREMENT HL AND B.
1410	0196	EDBA	INDR ;LOAD LOC. (HL) WITH INPUT FROM
1411			;PORT (C). DECREMENT HL AND B.
1412			;REPEAT UNTIL B=0.
1420	0198	EDA2	INI ;LOAD LOC. (HL) WITH INPUT FROM
1421			;PORT (C). INCR. HL AND DECR. B
1430	019A	EDB2	INIR ;LOAD LOC. (HL) WITH INPUT FROM
1431			;PORT (C). INCR. HL, DECR. B,
1432			;REPEAT UNTIL B=0.
1440	019C	E9	JP (HL) ;UNCONDITIONAL JUMP TO LOCATION.
1450	019D	DDE9	JP (IX)
1460	019F	C38405	JP nn
1470	01A2	FDE9	JP (IY)
1480	01A4	DA8405	JP C,nn ;JUMP TO LOC. IF CONDITION TRUE
1490	01A7	FA8405	JP M,nn
1500	01AA	D28405	JP NC,nn
1510	01AD	C28405	JP NZ,nn
1520	01B0	F28405	JP P,nn
1530	01B3	EA8405	JP PE,nn
1540	01B6	F28405	JP PO,nn
1550	01B9	CA8405	JP Z,nn
1560	01BC	382E	JR C,\$+e ;JUMP RELAT. TO PC+e IF COND. TRUE
1570	01BE	302E	JR NC,\$+e
1580	01C0	202E	JR NZ,\$+e
1590	01C2	282E	JR Z,\$+e
1600	01C4	182E	JR \$+e ;UNCONDITIONAL JUMP RELAT. TO PC+e
1610	01C6	02	LD (BC),A ;LOAD SOURCE TO DESTINATION

LINE	LOC.	OBJECT	SOURCE STATEMENT
1620	01C7	12	LD (DE),A
1630	01C8	77	LD (HL),A
1640	01C9	70	LD (HL),B
1650	01CA	71	LD (HL),C
1660	01CB	72	LD (HL),D
1670	01CC	73	LD (HL),E
1680	01CD	74	LD (HL),H
1690	01CE	75	LD (HL),L
1700	01CF	3620	LD (HL),n
1710	01D1	DD7705	LD (IX+d),A
1720	01D4	DD7005	LD (IX+d),B
1730	01D7	DD7105	LD (IX+d),C
1740	01DA	DD7205	LD (IX+d),D
1750	01DD	DD7305	LD (IX+d),E
1760	01E0	DD7405	LD (IX+d),H
1770	01E3	DD7505	LD (IX+d),L
1780	01E6	DD360520	LD (IX+d),n
1790	01EA	FD7705	LD (IY+d),A
1800	01ED	FD7005	LD (IY+d),B
1810	01F0	FD7105	LD (IY+d),C
1820	01F3	FD7205	LD (IY+d),D
1830	01F6	FD7305	LD (IY+d),E
1840	01F9	FD7405	LD (IY+d),H
1850	01FC	FD7505	LD (IY+d),L
1860	01FF	FD360520	LD (IY+d),n
1870	0203	328405	LD (nn),A
1880	0206	ED438405	LD (nn),BC
1890	020A	ED538405	LD (nn),DE
1900	020E	228405	LD (nn),HL
1910	0211	DD228405	LD (nn),IX
1920	0215	FD228405	LD (nn),IY
1930	0219	ED738405	LD (nn),SP
1940	021D	0A	LD A,(BC)
1950	021E	1A	LD A,(DE)
1960	021F	7E	LD A,(HL)
1970	0220	DD7E05	LD A,(IX+d)
1980	0223	FD7E05	LD A,(IY+d)
1990	0226	7F	LD A,A
2000	0227	78	LD A,B
2010	0228	79	LD A,C
2020	0229	7A	LD A,D
2030	022A	7B	LD A,E
2040	022B	7C	LD A,H
2050	022C	7D	LD A,L
2060	022D	3E20	LD A,n
2070	022F	46	LD B,(HL)
2080	0230	DD4605	LD B,(IX+d)
2090	0233	FD4605	LD B,(IY+d)
2100	0236	47	LD B,A
2110	0237	40	LD B,B
2120	0238	41	LD B,C
2130	0239	42	LD B,D
2140	023A	43	LD B,E
2150	023B	44	LD B,H
2160	023C	45	LD B,L
2170	023D	0620	LD B,n
2180	023F	4E	LD C,(HL)
2190	0240	DD4E05	LD C,(IX+d)
2200	0243	FD4E05	LD C,(IY+d)

LINE	LOC.	OBJECT	SOURCE STATEMENT
2210	0246	4F	LD C,A
2220	0247	4B	LD C,B
2230	0248	49	LD C,C
2240	0249	4A	LD C,D
2250	024A	4B	LD C,E
2260	024B	4C	LD C,H
2270	024C	4D	LD C,L
2280	024D	0E20	LD C,n
2290	024F	56	LD D,(HL)
2300	0250	DD5605	LD D,(IX+d)
2310	0253	FD5605	LD D,(IY+d)
2320	0256	57	LD D,A
2330	0257	50	LD D,B
2340	0258	51	LD D,C
2350	0259	52	LD D,D
2360	025A	53	LD D,E
2370	025B	54	LD D,H
2380	025C	55	LD D,L
2390	025D	1620	LD D,n
2400	025F	5E	LD E,(HL)
2410	0260	DD5E05	LD E,(IX+d)
2420	0263	FD5E05	LD E,(IY+d)
2430	0266	5F	LD E,A
2440	0267	58	LD E,B
2450	0268	59	LD E,C
2460	0269	5A	LD E,D
2470	026A	5B	LD E,E
2480	026B	5C	LD E,H
2490	026C	5D	LD E,L
2500	026D	1E20	LD E,n
2510	026F	66	LD H,(HL)
2520	0270	DD6605	LD H,(IX+d)
2530	0273	FD6605	LD H,(IY+d)
2540	0276	67	LD H,A
2550	0277	60	LD H,B
2560	0278	61	LD H,C
2570	0279	62	LD H,D
2580	027A	63	LD H,E
2590	027B	64	LD H,H
2600	027C	65	LD H,L
2610	027D	2620	LD H,n
2620	027F	6E	LD L,(HL)
2630	0280	DD6E05	LD L,(IX+d)
2640	0283	FD6E05	LD L,(IY+d)
2650	0286	6F	LD L,A
2660	0287	68	LD L,B
2670	0288	69	LD L,C
2680	0289	6A	LD L,D
2690	028A	6B	LD L,E
2700	028B	6C	LD L,H
2710	028C	6D	LD L,L
2720	028D	2E20	LD L,n
2730	028F	3A8405	LD A,(nn)
2740	0292	ED5F	LD A,R
2750	0294	ED4B8405	LD BC,(nn)
2760	0298	018405	LD BC,nn
2770	029B	ED5B8405	LD DE,(nn)
2780	029F	118405	LD DE,nn
2790	02A2	2A8405	LD HL,(nn)

LINE	LOC.	OBJECT	SOURCE STATEMENT
2800	02A5	218405	LD HL,nn
2810	02A8	ED47	LD I,A
2820	02AA	DD2A8405	LD IX,(nn)
2830	02AE	DD218405	LD IX,nn
2840	02B2	FD2A8405	LD IY,(nn)
2850	02B6	FD218405	LD IY,nn
2860	02BA	ED4F	LD R,A
2870	02BC	ED7B8405	LD SP,(nn)
2880	02C0	F9	LD SP,HL
2890	02C1	DDF9	LD SP,IX
2900	02C3	FDf9	LD SP,IY
2910	02C5	318405	LD SP,nn
2920	02C8	EDA8	LDD ;LOAD LOC. (DE) WITH LOC. (HL),
2921			;DECREMENT DE,HL, AND BC.
2930	02CA	EDB8	LDDR ;LOAD LOC. (DE) WITH LOC. (HL),
2931			;REPEAT UNTIL BC=0.
2940	02CC	EDA0	LDI ;LOAD LOC. (DE) WITH LOC. (HL),
2941			;INCREMENT DE,HL, DECREMENT BC.
2950	02CE	EDR0	LDIR ;LOAD LOC. (DE) WITH LOC. (HL),
2951			;INCR. DE,HL, DECR. BC UNTIL BC=0.
2960	02D0	ED44	NEG ;NEGATE ACC. (2's COMPLEMENT).
2970	02D2	00	NOP ;NO OPERATION.
2980	02D3	B6	OR (HL) ;LOGICAL OR OF OPERAND AND ACC.
2990	02D4	DDR605	OR (IX+d)
3000	02D7	FDR605	OR (IY+d)
3010	02DA	B7	OR A
3020	02DB	B0	OR B
3030	02DC	B1	OR C
3040	02DD	B2	OR D
3050	02DE	B3	OR E
3060	02DF	B4	OR H
3070	02E0	B5	OR L
3080	02E1	F620	OR n
3090	02E3	EDBB	OTDR ;LOAD OUTPUT PORT (C) WITH LOC.
3091			; (HL), DECR. HL AND B UNTIL B=0.
3100	02E5	EDB3	OTIR ;LOAD OUTPUT PORT (C) WITH LOC. (HL)
3101			;INCR. HL, DECR B, UNTIL B=0.
3110	02E7	ED79	OUT (C),A ;LOAD OUTPUT PORT(C) WITH REG.
3120	02E9	ED41	OUT (C),B
3130	02EB	ED49	OUT (C),C
3140	02ED	ED51	OUT (C),D
3150	02EF	ED59	OUT (C),E
3160	02F1	ED61	OUT (C),H
3170	02F3	ED69	OUT (C),L
3180	02F5	D320	OUT (n),A ;LOAD OUTPUT PORT (n) WITH ACC.
3190	02F7	EDAB	OUTD ;LOAD OUTPUT PORT (C) WITH LOC. (HL)
3191			;DECREMENT HL AND B.
3200	02F9	EDA3	OUTI ;LOAD OUTPUT PORT (C) WITH LOC. (HL)
3201			;INCREMENT HL AND DECREMENT B.
3210	02FB	F1	POP AF ;LOAD DESTINATION WITH TOP OF STACK
3220	02FC	C1	POP BC
3230	02FD	D1	POP DE
3240	02FE	E1	POP HL
3250	02FF	DDE1	POP IX
3260	0301	FDE1	POP IY
3270	0303	F5	PUSH AF ;LOAD SOURCE TO STACK
3280	0304	C5	PUSH BC
3290	0305	D5	PUSH DE
3300	0306	E5	PUSH HL

LINE	LOC.	OBJECT	SOURCE STATEMENT
3310	0307	DDES	PUSH IX
3320	0309	FDES	PUSH IY
3330	030B	CB86	RES 0,(HL) ;RESET BIT b OF OPERAND
3340	030D	DDCB0586	RES 0,(IX+d)
3350	0311	FDCB0586	RES 0,(IY+d)
3360	0315	CB87	RES 0,A
3370	0317	CB80	RES 0,B
3380	0319	CB81	RES 0,C
3390	031B	CB82	RES 0,D
3400	031D	CB83	RES 0,E
3410	031F	CB84	RES 0,H
3420	0321	CB85	RES 0,L
3430	030B	C9	RET ;RETURN FROM SUBROUTINE
3440	03CC	D8	RET C ;RETURN FROM SUBROUTINE IF COND.
3441			;COND. TRUE
3450	03CD	F8	RET M
3460	03CE	D0	RET NC
3470	03CF	C0	RET NZ
3480	03D0	F0	RET P
3490	03D1	E8	RET PE
3500	03D2	E0	RET PO
3510	03D3	C8	RET Z
3520	03D4	ED4D	RETI ;RETURN FROM INTERRUPT
3530	03D6	ED45	RETN ;RETURN FROM NON MASKABLE INTERRUPT
3540	03D8	CB16	RL (HL) ;ROTATE LEFT THROUGH CARRY
3550	03DA	DDCB0516	RL (IX+d)
3560	03DE	FDCB0516	RL (IY+d)
3570	03E2	CB17	RL A
3580	03E4	CB10	RL B
3590	03E6	CB11	RL C
3600	03F8	CB12	RL D
3610	03EA	CB13	RL E
3620	03EC	CB14	RL H
3630	03EE	CB15	RL pL
3640	03F0	17	RLA ;ROTATE LEFT ACC. THROUGH CARRY
3650	03F1	CB06	RLC (HL) ;ROTATE LEFT CIRCULAR
3660	03F3	DDCB0506	RLC (IX+d)
3670	03F7	FDCB0506	RLC (IY+d)
3680	03FB	CB07	RLC A
3690	03FD	CB00	RLC B
3700	03FF	CB01	RLC C
3710	0401	CB02	RLC D
3720	0403	CB03	RLC E
3730	0405	CB04	RLC H
3740	0407	CB05	RLC L
3750	0409	07	RLCA ;ROTATE LEFT CIRCULAR ACC.
3760	040A	ED6F	RLD ;ROTATE DIGIT LEFT AND RIGHT
3761			;BETWEEN ACC. AND LOC. (HL).
3770	040C	CB1E	RR (HL) ;ROTATE RIGHT THROUGH CARRY.
3780	040E	DDCB051E	RR (IX+d)
3790	0412	FDCB051E	RR (IY+d)
3800	0416	CB1F	RR A
3810	0418	CB18	RR B
3820	041A	CB19	RR C
3830	041C	CB1A	RR D
3840	041E	CB1B	RR E
3850	0420	CB1C	RR H
3860	0422	CB1D	RR L
3870	0424	1F	RRA ;ROTATE RIGHT ACC. THROUGH CARRY

LINE	LOC.	OBJECT	SOURCE STATEMENT
3880	0425	CB0E	RRC (HL) ;ROTATE RIGHT CIRCULAR
3890	0427	DDCB050E	RRC (IX+d)
3900	042B	FDCB050E	RRC (IY+d)
3910	042F	CB0F	RRC A
3920	0431	CB08	RRC B
3930	0433	CB09	RRC C
3940	0435	CB0A	RRC D
3950	0437	CB0B	RRC E
3960	0439	CB0C	RRC H
3970	043B	CB0D	RRC L
3980	043D	0F	RRCA ;ROTATE RIGHT CIRCULAR ACC.
3990	043E	ED67	RRD ;ROTATE DIGIT RIGHT AND LEFT
3991			;BETWEEN ACC. AND LOC. (HL)
4000	0440	C7	RST 00H ;RESTART TO LOCATION
4010	0441	CF	RST 08H
4020	0442	D7	RST 10H
4030	0443	DF	RST 18H
4040	0444	E7	RST 20H
4050	0445	EF	RST 28H
4060	0446	F7	RST 30H
4070	0447	FF	RST 38H
4080	0448	9E	SBC A,(HL) ;SUBTRACT OPERAND FROM ACC.
4090	0449	DD9E05	SBC A,(IX+d) ;WITH CARRY.
4100	044C	FD9E05	SBC A,(IY+d)
4110	044F	9F	SBC A,A
4120	0450	98	SBC A,B
4130	0451	99	SBC A,C
4140	0452	9A	SBC A,D
4150	0453	9B	SBC A,E
4160	0454	9C	SBC A,H
4170	0455	9D	SBC A,L
4180	0456	DE20	SBC A,n
4190	0458	ED42	SBC HL,BC
4200	045A	ED52	SBC HL,DE
4210	045C	ED62	SBC HL,HL
4220	045E	ED72	SBC HL,SP
4230	0460	37	SCF ;SET CARRY FLAG (C=1)
4240	0461	CBC6	SET 0,(HL) ;SET BIT b OF LOCATION
4250	0463	DDCB05C6	SET 0,(IX+d)
4260	0467	FDCB05C6	SET 0,(IY+d)
4270	046B	CBC7	SET 0,A
4280	046D	CBC0	SET 0,B
4290	046F	CBC1	SET 0,C
4300	0471	CBC2	SET 0,D
4310	0473	CBC3	SET 0,E
4320	0475	CBC4	SET 0,H
4330	0477	CBC5	SET 0,L
4340	0521	CB26	SLA (HL) ;SHIFT OPERAND LEFT ARITHMETIC
4350	0523	DDCB0526	SLA (IX+d)
4360	0527	FDCB0526	SLA (IY+d)
4370	052B	CB27	SLA A
4380	052D	CB20	SLA B
4390	052F	CB21	SLA C
4400	0531	CB22	SLA D
4410	0533	CB23	SLA E
4420	0535	CB24	SLA H
4430	0537	CB25	SLA L
4440	0539	CB2E	SRA (HL) ;SHIFT OPERAND RIGHT ARITHMETIC
4450	053B	DDCB052E	SRA (IX+d)

LINE	LOC.	OBJECT	SOURCE	STATEMENT
4460	053F	FDCB052E	SRA	(IY+d)
4470	0543	CB2F	SRA	A
4480	0545	CB28	SRA	B
4490	0547	CB29	SRA	C
4500	0549	CB2A	SRA	D
4510	054B	CB2B	SRA	E
4520	054D	CB2C	SRA	H
4530	054F	CB2D	SRA	L
4540	0551	CB3E	SRL	(HL) ;SHIFT OPERAND RIGHT LOGICAL
4550	0553	DDCB053E	SRL	(IX+d)
4560	0557	FDCB053E	SRL	(IY+d)
4570	055B	CB3F	SRL	A
4580	055D	CB38	SRL	B
4590	055F	CB39	SRL	C
4600	0561	CB3A	SRL	D
4610	0563	CB3B	SRL	E
4620	0565	CB3C	SRL	H
4630	0567	CB3D	SRL	L
4640	0569	96	SUB	(HL) ;SUBTRACT OPERAND FROM ACC.
4650	056A	DD9605	SUB	(IX+d)
4660	056D	FD9605	SUB	(IY+d)
4670	0570	97	SUB	A
4680	0571	90	SUB	B
4690	0572	91	SUB	C
4700	0573	92	SUB	D
4710	0574	93	SUB	E
4720	0575	94	SUB	H
4730	0576	95	SUB	L
4740	0577	D6FF	SUB	255
4750	0579	AE	XOR	(HL) EXCLUSIVE OR OPERAND AND ACC.
4760	057A	DDAE05	XOR	(IX+d)
4770	057D	DDAE05	XOR	(IY+d)
4780	0580	AF	XOR	A
4790	0581	A8	XOR	B
4800	0582	A9	XOR	C

## Differences between HP and the Z80

The following is a list of differences, known to us at the time of printing, that exist between the Hewlett-Packard software and other Z80 Assembler descriptions.

- a) The character set has been expanded.
- b) Imbedded blanks are allowed in expressions.
- c) DEFB and DEFM directives accept expressions and strings.
- d) Conditional nesting is allowed.
- e) The following pseudo mnemonics have been added:
  - FAIL        IFC
  - SPC         IFNC
  - ELSE
- f) The Macro parameter syntax has been changed. Definition nesting is allowed and Repeat Macros have been added.
- g) The following Assembler controls have been added:
  - CONDLIST ON/OFF
  - SOURCE "file name"
  - OBJECT "file name"
  - OBJECT
  - SYMBOLS ON/OFF
- h) The Assembler predefined symbol AF' has been changed to AF.
- i) HP software does not have exponentiation \*\*.
- j) HP software will not recognize lower case mnemonics, operators, and predefined symbols. For example 'ld' will not be recognized as 'LD'.
- k) The operators = and ^ are not available as they conflict with Macro prefixes.
- l) One or two character strings are processed like numbers (8 bit value or 16 bit value), thus the instruction

```
LD IX, 'AB'
```

results in the following Object code:

```
DD 214221
```



# Section Eight

## Macros



### Introduction

A Macro defines a body of text which is automatically inserted into your Source code each time a Macro is called.

Many instruction sequences are often repeated several times in a program, with only certain parameters changed. Instead of rewriting this code each time it occurs, it is useful to code the sequence once and call it with a single instruction whenever it is needed. The code sequence contains dummy parameters that can be replaced with actual values when it is called.

A Macro definition is initiated by the MACRO assembler directive, that lists the name by which the Macro can later be called. It also lists the dummy parameters that are to be replaced during macro expansion. Macros cannot be called before they have been defined. The definition is terminated by the ENDM directive. The instructions bounded by the Macro and the ENDM directives are called the Macro body. Each body, whether in the same program or on another mass storage device, must contain the ENDM directive.

A Macro may be contained in the same program section or on some other mass storage device. If another device is used, it must be called with the SOURCE directive.

Functionally, when the Assembler encounters a MACRO, REPT (Repeat Macro), IRP (Idefinite Repeat Macro), or an IRPC (Idefinite Repeat Character Macro) statement, it stops assembling the microprocessor instructions into Object code. All instructions, after one of the above statements, are stored in the Macro storage area of the Desktop Computer memory until an ENDM statement is seen. If the Assembler encounters another MACRO, REPT, IRP, or IRPC statement before the ENDM statement, then it must see the same number of ENDM statements before it will continue its normal Assembler operation.

The Macro Call statement starts the Macro expansion. It retrieves the lines of Source code from the Macro storage area, makes the necessary parameter replacements, inserts them into the main Source code and then they are assembled.

Duplicating a block of code several times can easily be made using the REPT, IRP and the IRPC directives. In the same way as a MACRO directive, these directives are terminated by ENDM.

The macros, described in this Section, apply to all three microprocessors types whether they be 6800, 8080/85 or the Z80.

## Macro Statement Format

The format of the Macro line is identical to the syntax that is required for the Source code.

```
<LABEL>    MACRO    [= <DUMMY1> [ ,=<DUMMY2> ... ] ] [ <COMMENT> ]
```

Example

```
MAC1      MACRO    =VAR1,=VAR2
           .
           .
           ENDM
```

The Label defines the Macro name given to the Macro body. Any valid user-defined symbol can be used.

The Instruction contains the **MACRO** directive that informs the Assembler of a Macro definition.

The Operand field consists of a list of dummy parameters for use in the Macro. A dummy parameter is any valid user-defined symbol, prefixed by an equals sign. If more than one dummy parameter is used, they must be separated by a comma. A maximum of 75 characters is allowed for dummy parameters. Each dummy has an overhead of two characters.

Dummy parameters are not only limited to the Operand field within a Macro body but may be placed in all fields.

A macro definition can be contained completely within the body of another macro definition. That is to say, macro definitions can be nested. No limit is imposed by the Assembler on the depth of macro definition nesting. The nested definitions or redefinitions of the same Macro are performed when the outer Macro is called. Thus the inner Macro cannot be called before the outer Macro has been expanded.

## Macro Call

Once a Macro has been defined, it can be called any number of times within a program. The call consists of the Macro name and the actual parameters to replace the dummy parameters. During assembly, each encountered call is replaced by the Macro definition code with actual parameters substituted for dummy parameters.

```
[ <LABEL> ]  <MACRO NAME>          [ <PAR1> [ , <PAR2> ... ] ] [ <COMMENT> ]
```

Example

```
START      MAC1 "2" ,XYZ,^XYZ+2
```

The Label is optional. When used, the value of the current location counter is assigned to it.

The Instruction field contains the Macro name like any other machine or pseudo instruction.

The Operand field contains the actual parameters, separated by commas. Parameters are replaced on a one-to-one basis and in the same order as they are listed in the MACRO directive. If fewer parameters appear in the Macro call than in the definition, a null string is substituted for the remaining dummy parameters. Conversely, if more parameters appear in the Macro call than in the definition, the extras are ignored.

Any parameter within double quotes is passed. Quotes are not needed for anything that obeys the rules of Symbols and Numbers.

An expression can be prefixed with the pre-evaluation character (^) if pre-evaluation is required. This character instructs the Assembler to first evaluate the expression and then pass the value into the Macro body.

---

#### NOTE

When writing Source code, the Editor's Syntax checker will reject the Macro call statement, and statements involving any Macro dummy parameter. This can be overwritten by using the STORE key in conjunction with the SHIFT key (press SHIFT/STORE). The Syntax accepts the statement as valid and the next line of text may be inserted.

---

## Nested Macro Calls

Macro calls can be nested within Macro definitions up to eight levels. A Macro definition can also contain nested calls to itself (recursive Macro calls) up to eight levels. This operation must be controlled using the conditional assembly directives, IF-ELSE-ENDIF, as described in Section Seven. If this is not done you will run into nesting level overflow.

### Example

LINE	LOC.	OBJECT	SOURCE STATEMENT
10			EXAMPLE MACRO =ABC, =DEF, =GHI, =JKL
20			
30			STA A =ABC
40			LDX #=DEF
50			LDA B #=GHI
60			LDA B #=JKL
70			
80			ENDM
90			
100		005F	XYZ EQU #5F
110			EXAMPLE "2", XYZ, "XYZ+25", ^XYZ+25
	0000	9702	STA A 2
	0002	CE005F	LDX #XYZ
	0005	C678	LDA B #XYZ+25
	0007	C678	LDA B #120
120			END

## Macro Directives

### REPT Macro (Repeat Macro)

```
[ <LABEL> ] REPT <EXPRESSION> [ <COMMENT> ]
```

This directive causes a sequence of Source code lines to be repeated as defined by the expression. A maximum of 255 times is allowed. All lines appearing between the REPT directive and a subsequent ENDM directive constitute the block to be repeated. If symbols are used in the expression, they must have been previously defined.

For example, Complement Accumulator four times

```
REPT 4
CMA A
ENDM
```

The Source code generated would be:

```
CMA A
CMA A
CMA A
CMA A
```

### IRP (Indefinite Repeat Macro)

```
[ <LABEL> ] IRP =<DUMMY> , <PAR1> [ , <PAR2> ... ] [ <COMMENT> ]
```

The Operand field for this directive must contain one dummy parameter followed by a list of actual parameters. The code sequence between the IRP directive and the subsequent ENDM directive is repeated for every actual parameter. For example:

```
IRP      =BOB, "1", "2", "3"
LDA A    #=BOB
ENDM
```

The above example would generate the following Source code.

```
LDA A    #1
LDA A    #2
LDA A    #3
```

## IRPC (Indefinite Repeat Character Macro)

```
[ <LABEL> ] IRPC =<DUMMY> ,<PAR1> [ <COMMENT> ]
```

This directive provides the capability to treat each character of PAR1 individually. The code sequence between the IRPC directive and the subsequent ENDM directive is repeated for every character of PAR1. Characters should not be separated by commas. For example:

```
IRPC      =BOB, "ABCDE"
MVI       =BOB, 10
ENDM
```

The Source code generated would be:

```
MVI  A,10
MVI  B,10
MVI  C,10
MVI  D,10
MVI  E,10
```

Note that the difference between the IRP and the IPRC directives is that the IPRC directive only passes one character at a time while the IRP directive passes the whole actual parameter. It is also useful to know that the above three directives may be used as standard Source code and not necessarily be inside a MACRO body. They can be seen as a Macro definition and implied Macro call.

## =NUM (Number Macro Parameter)

Using Labels in Macros can cause problems if a Macro is called more than once. In a case like this, the Label would have to be different for each Macro. One way of doing this is to let the Assembler generate different Labels for each Macro called. Using the dummy parameter =NUM causes the Macro to replace the parameter with a four digit number which, in turn, will be incremented by each Macro call. The =NUM parameter is predefined by the Assembler and has a starting value of 0000. A maximum of 9999 numbers can be used.

For example

LINE	LOC.	OBJECT	SOURCE	STATEMENT
10			MIKE	MACRO     =VALUE
20			L=NUM	LDA A     #=NUM
30				=VALUE    L=NUM     THIS IS THE =NUM TIME
40				ENDM
50				
60			START	MIKE     "BRA"
	0000	9600	L0000	LDA A     #0000
	0002	20FC		BRA     L0000     THIS IS THE 0000 TIME
70				MIKE     "JMP"
	0004	9601	L0001	LDA A     #0001
	0006	7E0004		JMP     L0001     THIS IS THE 0001 TIME
80				MIKE     "LDX"
	0009	9602	L0002	LDA A     #0002
	000B	DE09		LDX     L0002     THIS IS THE 0002 TIME
				END

## EXITM (Exit Macro)

The EXITM directive provides an alternative way to terminate a Macro expansion or REPT/IRP/IRPC repetition. This instruction terminates only the current expansion level. It can be used anywhere within a Macro body but will not terminate the Macro definition. It can be used to prematurely terminate a macro expansion as, for example, when using the IF-ELSE-ENDIF directive. It cannot be used instead of the ENDM directive. For example:

```

10          MODUL      MACRO      =STAT
20
30          LD          (BC),A
40          =STAT
50          SBC        A,B
60          RRC        L
70          ENDM
80
90          MODUL      "RST      30H"
          LD          (BC),A
          RST        30H
          SBC        A,B
          RRC        L
100         MODUL      "RL      D"
          LD          (BC),A
          RL         D
          SBC        A,B
          RRC        L
120         MODUL      EXITM
          LD          (BC),A
130         0000      0000      END

```

# Section Nine Assembler Module



## Introduction

The Assembler module translates your written Source code into an Absolute machine code. This code is then stored in a specified Object file in the format of your particular microprocessor manufacturer. The Assembler performs the translation in two passes. Pass 1 builds the Symbol table, while pass 2 makes the actual translation, outputs the program listing and the Object code before finally producing a cross-reference listing.

## Source File

The input for the Assembler is the Source code stored on your mass storage device. A file can be with or without line numbers. Whether the first Source line contains line numbers or not will decide the format for the entire file. When line numbers are present the Source file begins with the character position 7 (5 positions are required for the line number) and the line numbers are left unchanged. If no line numbers are present then the Assembler assigns them beginning with 10 and increments by 10.

Example of a Source code.

```
10      LDX    $A000
20      JMP    X
30 LOOP  CMP   A    #'S
40      BNE   LOOP
```

## Object Files

The Object file is the file on the mass storage device where the Assembler program stores the Object code during pass 2. It is stored in the format used for transferring to your microprocessor system. Refer to the Console Module Section for further information.

## List/Cross Reference Format

For an example of the List and Cross Reference formats, refer to Section Seven – Assembler Instructions.

## Using The Assembler Module

### SOURCE Instruction

```
SOURCE " <FILE NAME> [msus] " [ , <CONTROL1> [ , <CONTROL2> . . . ] ]
```

Once the Assembler module has been selected from the Main Menu, the CRT displays

```
COMMAND MODE
SOURCE
```

Enter the Source file name. The msus is also required if it is different from the default value contained in the default file. Only one Source file can be specified to start the assembly.

At this stage it is also possible to add Assembler Controls in the SOURCE line. For example:

```
COMMAND MODE
SOURCE "MIKE:T14", NOLIST
```

Press CONTINUE

The Source code stored in file MIKE is assembled and no listing is provided by the printer.

### OBJECT Instruction

```
OBJECT [ " <FILE NAME> [msus] " ] [ , <CONTROL1> [ , <CONTROL2> . . . ] ]
```

The CRT displays,

```
COMMAND MODE
OBJECT
```

If the Object code is not to be stored, do not enter a file name, just press CONTINUE.



Example with Object code stored.

```
COMMAND MODE  
OBJECT "EDI:T14"
```

Your Source code will be Assembled and the Object code is stored in the file named EDI.

Assembler Controls can also be added in this line as with the Source line. The last seen Controls are taken as valid. For instance, Controls written in the Source instruction can be corrected in the Object instruction. However, any Controls contained in the Source code will override those listed in the instructions above.

## **BREAK Key**

Temporarily interrupts the operation of the Assembler and allows use of the Mainframe functions. For instance, when you want to change printer paper, make a calculation etc. etc.

## **EXIT Key**

Takes you from the Assembler module and returns you to the Main Menu.



# Section Ten Console Module



## Introduction

This module provides the communication between your Desktop Computer and a Microprocessor system. It permits you to transfer your final Object code to the Microprocessor system for testing and debugging. It also allows you to control the functions of the Monitor ROM during the testing/debugging process. Data is transferable in both directions.

Listed below are the Microprocessor systems that Hewlett-Packard have had experience with and on which the information in this Section is based. To the best of our knowledge the facts stated in this Section are correct however, we accept no responsibility for malfunction of the software due to any changes that may have been made by the Microprocessor manufacturer since the time of writing.

Systems complete with a power supply and a housing can be directly connected to a Hewlett-Packard Desktop Computer by use of the RS232C Interface cable, HP 98036A Option 001. A female connector, compatible with the Hewlett-Packard's Interface cable, must be connected to individual microprocessor boards.

6800	8080/85	Z80
Motorola	Intel	Zilog
Evaluation Module II with Minibug II or Minibug III	SBC 80/10 80/20 80/30	Z80 – MCB/4 – MCB/16
*Exorcisor with Exbug Monitor ROM	With 1K Monitor ROM.  These OEM boards are also available in a case with a power supply, under the system numbers;	With M01 1K Monitor ROM.  A case, power supply, etc. . for these boards are available under the number;
	SYS 80/10 80/20 80/30	Z80 – SCE 4

\* Note: The Motorola Exorcisor has the CTS line connected to ground. It is necessary to cut this and connect it to the RS232C socket via an RS232C/TTL level converter. The MC1489AL/U29B may be used for this purpose.

## Using Other Microprocessor Systems

Generally, this is possible providing that their RS232C interface and Monitor ROM have the same specifications and characteristics as the above mentioned systems and also work in half-duplex mode.

Other systems perhaps not using the RS232C interface can be interfaced provided that you write your own version of the Console module.

The format with which the Object codes are stored on your mass storage device are included later in this section.

## Microprocessor System Modifications

Three Microprocessor systems have been used extensively by Hewlett-Packard and the following wiring information is that which was required to use the Microprocessor System with the Hewlett-Packard hardware.


### Motorola Evaluation Module II

a) A wiring change was made to the circuit board to set the baud rate to 9600 bauds.

Modify the socket designated U24, in the bottom left-hand corner of the board, such that pin 5 is connected to pin 16. Above the socket are holes designated with the letter E. Connect E7A to E14.

b) Connections for an interface socket.

The following diagram illustrates the connections for a standard 25-pin RS232C socket.



## Intel SBC 80/30 mounted in the SYS 80/30 case

The following changes were made to the circuit board:

- a) The USART 8251A was found not to work with the Hewlett-Packard Console module because after stopping the USART transmitting data by removing the CTS line it repeats the least sent character on moving the CTS line back to its original condition. The 8251 operates correctly. This information was true as of September 1979.
- b) Break the connection between circuit board pins 67 and 68 in order to activate the CTS line.

## Zilog Z80 — MCB/16

The following changes were made to the circuit board:

Jumpers on connector J4.

Break the connection between pins 5 and 6. This breaks the short circuit between CTS and RTS.

Connect the pin 6 to pin 13. This connects the CTS line to the outside RS232C connector.

## RS232C Lines

The following interface lines are used for communication between the Desktop Computer and the Microprocessor system.

**Transmitted Data, (TD), pin 2.** This line outputs data from the Console Module to the Microprocessor system.

**Received Data (RD), pin 3.** This line inputs data from the Microprocessor system to the Console Module.


**Request to Send (RTS), pin 4.** Enables the Microprocessor system so that data can be transmitted. The moment this line falls the Microprocessor system must stop transmitting after the entire character has been sent. With some Microprocessor systems this line is connected to ground. This connection must be broken and the CTS line connected to the RS232C socket.

**Clear to Send Data (CTS), pin 5.** Enables the Console Module so that data can be transmitted. If this line falls, the Console module stops transmission after the entire character has been sent.

**Data Terminal Ready (DTR), pin 20.** Line goes high to prevent the Microprocessor system from sending data. Indicates a busy state of the Console module. This line has always the complement state of the RTS line. Only one or the other is used.

**GND, pin 7.** Circuit ground

The diagram below illustrates the connection between Hewlett-Packard equipment and a Microprocessor Development System.



## HP 98036A Interface

### System and Cable Compatibility

Peripheral default values, contained in the "Serial Interface RS232C Sub-menu" of the Initialization Module, and the various switch settings on the Interface card must be the same.

Most Microprocessor Systems use an 8-bit, no parity, 1 Stop bit data. Check the Operating manual for your Microprocessor system that this is correct. If it is correct, the following values are recommended and should be set accordingly:


- Baud Rate .....9600
- Data Word Length.....8
- Parity Check .....None
- Stop Bit.....1

## Interface Dismantling

Before installing the Interface cable in your Desktop Computer, check the configuration switch settings on the Interface.

To access the switches it is necessary to separate the Interface housing. Refer to the figure when using the procedure below.

- 1) Remove the four screws that hold the rear housing to the front house.
- 2) Pull the rear housing away from the front slightly, disconnect the cable connector from the PC assembly and remove the rear housing.
- 3) Remove the remaining four screws in the front housing and separate the front housing cases.
- 4) Carefully separate the printed circuit assemblies.
- 5) The various interface switches are shown in the figure below.
- 6) After setting the switches, reverse this procedure to assemble the interface. Be sure that the pins on the A2 assembly are properly seated in the connectors on the A1 board assembly.




## Switch Settings

Once the printed circuit boards have been parted, set the switches as follows:

Select Code switch to 11.

I/O Mode switch to "Down RS232C"

Switches "C1" through "C4" as below.



### Default Mode Switch

The switch setting are set automatically by Desktop Computer software.

Baud Rate switch. Position 1. (9600 baud)

If needed, other baud rate settings are:

Switch position	Baud Rate	Switch position	Baud Rate
2	4800	6	600
3	2400	7	300
4	1800	8	150
5	1200	9	110
		0	75



## Interface Installation

After the Interface switches have been set, assemble the interface housing by reversing the disassembly procedure. Make sure that the pins on the A2 assembly are properly seated in the connectors on the A1 assembly. With the Desktop Computer switched off, install the interface housing into any one of the I/O slots on the back of the Computer. Connect the other end of the cable to your microprocessor system.

---

### CAUTION

Before making any connections to the Desktop Computer, ensure that it is turned off.


---

## Running the System

Call-up the Main Menu on the Desktop Computer.

With the Main Menu present, select SFK k3 for the Console Module. The module is loaded.

A functional diagram of the Console and an associated Microprocessor System is shown below.



## Special Function Keys

The following commands may only be called by pressing the SFKs. They may not be typed.

### LOAD

**LOAD " <FILE NAME> [msus] "** This command allows you to transfer your data (e.g. Object code) from your mass storage device to the Microprocessor System.

### STORE

**STORE " <FILE NAME> [msus] "** This Command allows you to store data, for example, Object code sent by the Microprocessor system to the mass storage device.

To terminate the transfer, this key must be pressed once more at the end of data transfer.

If a file must be created, you are asked for the file capacity in bytes after the Mainframe STORE key has been pressed. You must enter the number of bytes which are to be input. Remember, when you are dumping the microprocessor memory in the Object code format, the microprocessor sends about three times the amount of bytes that you are dumping because of the formatting.

### BREAK

This SFK takes you out of the Console module and allows you to use the standard features of the Desktop Computer. This would be used, for example, when a CAT (Catalog) is required or when you need to make a calculation. Use CONTINUE to return.

### EXIT

Allows you to leave the Console Module. Main Menu SFK k3 must be selected to return.

---

#### NOTE

When using either the LOAD or the STORE command, it is possible to interrupt the operation by pressing the appropriate key, LOAD or STORE.

---

## Mainframe Keys

PRINT ALL	All commands and data that appear on the CRT are duplicated on the printer.
STORE	Sends the ASCII character CR to the Microprocessor system. Hexadecimal value – 0D
SHIFT/STORE	Sends the ASCII character LF to the Microprocessor system. Hexadecimal value – 0A
BACKSPACE/ Left arrow	Sends the ASCII character BS to the Microprocessor system. Hexadecimal value – 08.
TAB	Sends the ASCII character HT to the Microprocessor system. Hexadecimal value – 09.
CLEAR LINE	Sends the ASCII character DEL to the Microprocessor system. Hexadecimal value – 7F.
FWD/ Right arrow	Sends the character, where the cursor is positioned on the CRT, to the Microprocessor system.

---

### CAUTION

When either the Load or Store operation is taking place do not operate any of the keyboard keys as any interruption could cause loss of information.

---

## Object Code Formats

The Assembler program stores the Object code in this format on the mass storage device. It is transferred in this format by the Console to the Microprocessor system. An exception is the Intel Microprocessor system which requires a converted format. Refer to the paragraph, Intel Conversion, given below.

### Intel

Number of bytes	2	4	2		2
	: (LENGTH)	(ADDRESS)	(TYPE)	(OBJECT CODE ...)	(CHECK SUM)
	: (LENGTH)	(ADDRESS)	(TYPE)	(OBJECT CODE ...)	(CHECK SUM)
	: (LENGTH)	(ADDRESS)	(TYPE)	(OBJECT CODE ...)	(CHECK SUM)
	.				
	.				
	.				
	: (LENGTH)	(ADDRESS)	(TYPE)	(OBJECT CODE ...)	(CHECK SUM)

Where LENGTH is number of Object code bytes in the data string. An end-of-file string has 00 in this field.

ADDRESS specifies where the first Object code byte is to be stored. Successive bytes are stored in successive memory locations.

If you put an <address> after the END directive in your Source code then this address will appear in this field if it is the end-of-file string. If you put no <address> after the END statement then the end-of-file string contains only a colon followed by two zeros.

TYPE. Data strings have 00 in this position, end-of-file strings have 01.

OBJECT CODE is your Object code program that is transferred to the Microprocessor System.

CHECK SUM is two's complement of the 8-bit sum of the data that results from converting each pair of ASCII hexadecimal digits to one byte of binary from the LENGTH to, and including, the last byte of the Data string.

## Intel Conversion

The 1K Monitor ROM, used in the Intel Microprocessor systems SBC 10/20/30, accepts data in the format given opposite when the Object code is input with the R Command.

As the protocol of this command is designed for use with a paper tape reader it will not work satisfactorily with the Console module in its existing form. The Console module converts this code into a format which can be transmitted to the Microprocessor system. The code is converted to the following format:

```
Iyyyy CR
<data . . . > ESC
```

where I	is the Insert command to the Monitor ROM
yyyy	is the start address
CR	is the ASCII character carriage return
<data>	the Object code in hexadecimal code.
ESC	is the ASCII character Escape

---

### NOTE

The I (Insert) command is included in the data sent from the Desktop Computer. You do not need to input it.

---

When you are using the Intel 1K Monitor ROM it is necessary to activate the conversion process by giving a positive answer (Y) to the question contained on the Initialization module RS232C submenu that asks if an "Intel Format Conversion" should be made.

If "Intel Format Conversion" has been selected then the Assembler program puts a W in front of the Object code file. Only files with a W at the beginning of the Object code are converted by the Console module.

This permits you to use the conversion process for Object code. It also allows you to transfer non-Object code data between the Microprocessor system and the mass storage device by not having this W at the beginning of the data file.

An automatic 'read after write' comparison is made by the Console. That is to say, each character is echoed from the Microprocessor system and checked by the Console that it was the correct character sent.

## Motorola

Number of bytes	2	4		2
S0	(LENGTH)	(ADDRESS)	(OBJECT CODE ...)	(CHECK SUM)
S1	(LENGTH)	(ADDRESS)	(OBJECT CODE ...)	(CHECK SUM)
S1	(LENGTH)	(ADDRESS)	(OBJECT CODE ...)	(CHECK SUM)
		.		
		.		
		.		
S9	(LENGTH)	(ADDRESS)	(OBJECT CODE ...)	(CHECK SUM)

Where S0 indicates the start of the transmission and that the data file will follow. The Object code in this string is not stored in memory.

S1 precedes the data strings containing your Object code.

S9 indicates the finish of the transmission. If you have not put the MON directive in your Source code, then the EOF string consists of S9. If you have used the MON directive, then this ADDRESS will be the <address> that you entered in your Source code.

After receiving the Object code transmission some Microprocessor Systems automatically commence running the program at the address specified.

LENGTH is the number of bytes in the data string from (LENGTH) until, and including, the CHECK SUM. An end-of-file string has 03H in this field.

ADDRESS specifies where the first Object code byte is to be stored. Successive bytes are stored in successive memory locations.

OBJECT CODE is your Object code program that is transferred to the Microprocessor System.

CHECK SUM is one's complement of the 8-bit sum of the data that result from converting each pair of ASCII hexadecimal digits to one byte of binary from the LENGTH to, and including, the last byte of the Data string.



## Zilog

Number of bytes	2	4	2	2
	: (LENGTH) (ADDRESS) (TYPE) (OBJECT CODE . . .) (CHECK SUM)			
	: (LENGTH) (ADDRESS) (TYPE) (OBJECT CODE . . .) (CHECK SUM)			
	: (LENGTH) (ADDRESS) (TYPE) (OBJECT CODE . . .) (CHECK SUM)			
	.			
	.			
	: (LENGTH) (ADDRESS) (TYPE) (OBJECT CODE . . .) (CHECK SUM)			

Where LENGTH is number of Object code bytes in the data string. An end-of-file record has 00 in this field.

ADDRESS specifies where the first Object code byte is to be stored. Successive bytes are stored in successive memory locations.

TYPE. Data records have 00 in this position, end-of-file records have 01.

OBJECT CODE is your Object code program that is transferred to the Microprocessor System.

CHECK SUM is two's complement of the 8-bit sum of the datas that result from converting each pair of ASCII hexadecimal digits to one byte of binary from the LENGTH to, and including, the last byte of the Data string.

## Useful Operating Hints

The following information is based on Hewlett-Packard's experience with the previously mentioned Microprocessor systems. Due to changes that microprocessor manufacturers make from time to time it could happen that some instructions do not function as given in this manual. If this is the case, we recommend that you refer to the manufacturer's documentation.

### Intel Microprocessor Systems

The following procedure downloads your Object code into the Microprocessor System

- a) Press **SFK k3** to select the Console module.
- b) Press the Microprocessor system **RESET** button.
- c) Press the capital letter **U** on the Desktop Computer keyboard.

A decimal point (.) appears on the Desktop Computer CRT. This indicates that the Microprocessor system is waiting for further commands.

d) Press **SFK LOAD**

e) Enter the **FILE NAME**

**LOAD " <FILE NAME> [msus]"**

The file name is where you stored your Object code that was generated by the Assembler.

f) Press **CONTINUE**.

After loading is complete a decimal point (.) will appear in the CRT indicating the Microprocessor system is waiting for further commands.

Refer now to the instruction manual of your Microprocessor system for the commands necessary to run and debug your Object code.

When you have finished testing and debugging you may want to retransfer your modified Object code back to the mass storage unit of your Desktop Computer.

a) Press **SFK STORE**.

Type the name you want to give to the Object code. For example.

**STORE " <FILE NAME> [msus]"**

b) Press **CONTINUE**.

c) Press the capital letter **W** on the Desktop Computer keyboard.

d) Type the start and finish address. For example:

**WAAAA,BBBB**

Where **AAAA** is the start address and **BBBB** is the finish address

e) Press **STORE** to transmit the ASCII character CR to the Microprocessor system.

f) When the Object code has been transferred (this can be seen from the CRT), press the **SFK STORE** once more.



## Motorola Microprocessor Systems

The following procedure downloads your Object code into the Microprocessor System.

- a) Press **SFK k3** to select the Console module.
- b) Press the Microprocessor system **RESET** button.

An asterisk (\*) appears on the Desktop Computer CRT. This indicates that the Microprocessor system is waiting for further commands.

- c) Press the capital letter **L** on the Desktop Computer keyboard.
- d) Press **SFK LOAD**
- e) Enter the **FILE NAME**

**LOAD "<FILE NAME> [msus]"**

The file name is where you stored your Object code that was generated by the Assembler.

- f) Press **CONTINUE**.

After loading is complete an asterisk (\*) will appear in the CRT indicating the Microprocessor system is waiting for further commands.

Refer now to the instruction manual of your Microprocessor system for the commands necessary to run and debug your Object code.

When you have finished testing and debugging you may want to retransfer your modified Object code back to the mass storage unit of your Desktop Computer.

- a) Press **SFK STORE**.

Type the name you want to give to the Object code. For example:

**STORE "<FILE NAME> [msus]"**

- b) Press **CONTINUE**.
- c) Press the capital letter **P** on the Desktop Computer keyboard.
- d) Type the start and finish address. For example:

**P AAAA BBBB**

Where **AAAA** is the start address and **BBBB** is the finish address

- e) When the Object code has been transferred (this can be seen from the CRT), press the **SFK STORE** once more.

## Zilog Microprocessor Systems

The following procedure downloads your Object code into the Microprocessor System

- a) Press **SFK k3** to select the Console module.
- b) Press the Microprocessor system **RESET** button.

The sign ( > ) appears on the Desktop Computer CRT. This indicates that the Microprocessor system is waiting for further commands.

- c) Press the capital letter **L** on the Desktop Computer keyboard.
- d) Press the **STORE** key.

This sends the ASCII character CR to the Microprocessor system.

- e) Press **SFK LOAD**
- f) Enter the **FILE NAME**

**LOAD "<FILE NAME> [msus]"**

The file name is where you stored your Object code that was generated by the Assembler.

- g) Press **CONTINUE**.

After loading is complete the sign ( > ) will appear in the CRT indicating the the Microprocessor system is waiting for further commands.

Refer now to the instruction manual of your Microprocessor system for the commands necessary to run and debug your Object code.

When you have finished testing and debugging you may want to retransfer your modified Object code back to the mass storage unit of your Desktop Computer.

- a) Press **SFK STORE**.

Type the name you want to give to the Object code. For example.

**STORE "<FILE NAME> [msus]"**

- b) Press **CONTINUE**.
- c) Press the capital letter **P** on the Desktop Computer keyboard.
- d) Type the start and finish address. For example:

**P AAAA,BBBB**

Where **AAAA** is the start address and **BBBB** is the finish address

- e) Press **STORE** to transmit the ASCII character CR to the Microprocessor system.
- f) When the Object code has been transferred (this can be seen from the CRT), press the **SFK STORE** once more.

## CRT Driver Used By The Console

All received characters are immediately shown on the CRT except for most of the ASCII Control characters (code less than 20H) which are ignored by the CRT driver. Only the following ASCII Control characters are interpreted:

Hex. Value	Name
07	BEL (beep)
08	BS
09	HT (Interpreted as space)
0A	LF
0C	FF (Interpreted as LF)
0D	CR

Characters with values in the range 80H through 87H are interpreted as CRT Control characters:

Hex. Value	Name
80	CLR (Clear all special features)
81	IV (Inverse video)
82	BL (Blinking)
83	IV + BL
84	UL (Underline)
85	IV + UL
86	BL + UL
87	IV + BL + UL

The CRT Control characters are used by the Console CRT driver in the same way that the Mainframe uses them.

The characters with value 88H through FFH are interpreted as foreign characters.

Many microprocessor programs buffer the Console inputs in the Microprocessor system. When doing this it is useful to define "BS" or "Left arrow" to cancel the last buffered character and use the "Right arrow" to advance in the microprocessor input buffer.

## Error Handling

If an error occurs, the appropriate message is given on the CRT. To continue program execution it is necessary to press the CONTINUE key.



# Section Eleven

## Examples on Applying the Pack



### Introduction

This section takes a look at some of the refinements of Source code writing. It is a collection of examples that illustrate ways of making the best use of commands and directives.

### The Editor

#### Change

It could well be that you have some Source code from another Development System that you want to assemble on your Hewlett-Packard Desktop Computer. It is possible that the Source code, from the other System, contains some slight differences in the mnemonics to your –hp– software and you would like to change these.

Alternatively, if you have entered a lot of Source code with the Editor program and have incorrectly spelt a word from beginning to end, it would be useful to be able to change the spelling automatically.

In both these cases, you should use the CHANGE statement.

#### Example

The following source code has the statement CAL spelt wrongly, it should have been written CALL.

```

10          MOV      E,A          ;CALCULATE RECORD LENGTH
20          MVI      D,0          ;INITIALIZE D FOR HOLDING CHECKSUM
30          MVI      C,01H       ;
40          CAL      PD          ;PUNCH RECORD MARK CHARACTER
50          MOV      A,E          ;PUT RECORD LENGTH IN A
60          CAL      PBYTE       ;PUNCH RECORD LENGTH
70          CAL      PADR        ;PUNCH STARTING ADDRESS
80          XRA      A           ;ZERO A
90          CAL      PBYTE       ;RECALL RECORD TYPE

```

Using the statement **CHANGE "CAL" TO "CALL"** produces the following:

```

10          MOV      E,A          ;CALCULATE RECORD LENGTH
20          MVI      D,0          ;INITIALIZE D FOR HOLDING CHECKSUM
30          MVI      C,'/'        ;
40          CALL     PD           ;PUNCH RECORD MARK CHARACTER
50          MOV      A,E          ;PUT RECORD LENGTH IN A
60          CALL     PBYTE        ;PUNCH RECORD LENGTH
70          CALL     PADR         ;PUNCH STARTING ADDRESS
80          XRA      A            ;ZERO A
90          CALL     PBYTE        ;RECALL RECORD TYPE

```

Notice that not only the **CAL** statements in lines 40, 60, 70 and 90 have been changed but that the word **CALCULATE** in line 10 and **RECALL** in line 90 have also been changed.

To avoid this, use the statement in a different way. Namely

**CHANGE " CAL " TO " CALL "** (Note the spaces before and after the quotes).

```

10          MOV      E,A          ;CALCULATE RECORD LENGTH
20          MVI      D,0          ;INITIALIZE D FOR HOLDING CHECKSUM
30          MVI      C,'/'        ;
40          CALL     PD           ;PUNCH RECORD MARK CHARACTER
50          MOV      A,E          ;PUT RECORD LENGTH IN A
60          CALL     PBYTE        ;PUNCH RECORD LENGTH
70          CALL     PADR         ;PUNCH STARTING ADDRESS
80          XRA      A            ;ZERO A
90          CALL     PBYTE        ;RECALL RECORD TYPE

```

It is now clear that the comments have not been affected and that the listing is in the correct position.

The reason for the difference is that space is also a valid character for the change algorithm and is included in the conversion.

## Find

Normally Source code can be changed automatically by using the **CHANGE** statement as above. However sometimes you do not want to change all of the items. It can sometimes happen that despite putting spaces or other characters in the **CHANGE** statement you still cannot automatically change the items you want and leave the others intact.

In a case like this, use the **FIND** statement. Items are found and you can modify them or not as you wish.

In the following example it is not possible to change only the instructions in the instruction field from JUMP to JMP with the CHANGE statement without also changing the words JUMP in the comment area.

```

10      MOV      E,A      ;CALCULATE RECORD LENGTH
20      MVI      D,8      ;INITIALIZE D FOR HOLDING CHECKSUM
30      MVI      C,2:1    ;
40 LABEL: JUMP  P0      ;JUMP TO MARK CHARACTER
50      MOV      A,E      ;PUT RECORD LENGTH IN A
60      JUMP     PBYTE    ;PUNCH RECORD LENGTH
70      JUMP     PADR     ;PUNCH STARTING ADDRESS
80      XRA      A        ;ZERO A
90 START: JUMP  PBYTE    ;JUMP TO RECORD

```

However, by inputting,

**FIND "JUMP"**

the cursor will stop at the points marked with a ■ (in the example) and you can change those that you want to.

## Copy

This statement is very useful for moving sections of Source code from one position in the code to another. If the original code is not deleted afterwards it can be used as a means of duplicating routines in the Source code. In the following example it is used to duplicate code.

The following statements must first be entered by hand.

```

10      LDA      A      #56
20      STA      A      $A000

```

If you now execute **COPY 10 , 20 TO 30** you get

```

10      LDA      A      #56
20      STA      A      $A000
30      LDA      A      #56
40      STA      A      $A000

```

If you now enter **COPY 10 , 40 TO 50** you get

```

10      LDA   A   #56
20      STA   A   $A000
30      LDA   A   #56
40      STA   A   $A000
50      LDA   A   #56
60      STA   A   $A000
70      LDA   A   #56
80      STA   A   $A000

```

In this manner, code can be duplicated as often as desired.

As long as the destination line number does not exist and that it is smaller than the lowest line number to be copied or, higher than the highest, then there are no limits as to what can be done with this statement.

If you try to copy into an area where there is insufficient space between the line numbers, then the program will automatically renumber those line numbers at the high end of this area such that this insert works. The whole Source code from this point on will not be renumbered, only those lines necessary to enable the insertion.

This example demonstrates what this command can do.

```

10      MOV    A,M      ;
20      ORA   A         ;SET F/F'S
30      JZ    EXIT      ;BRANCH IF AT END OF TABLE
40      PUSH  H         ;PUT POINTER ON STACK
50      MOV    E,M      ;
60      MVI   D,HREGS   ;FETCH ADDRESS OF SAVE LOCATION
70      INX   H         ;.....THE END.....

```

Using the command **COPY 10 , 70 TO 5** results in the following:

```

5       MOV    A,M      ;
6       ORA   A         ;SET F/F'S
7       JZ    EXIT      ;BRANCH IF AT END OF TABLE
8       PUSH  H         ;PUT POINTER ON STACK
9       MOV    E,M      ;
10      MVI   D,HREGS   ;FETCH ADDRESS OF SAVE LOCATION
11      INX   H         ;.....THE END.....
20      MOV    A,M      ;
21      ORA   A         ;SET F/F'S
30      JZ    EXIT      ;BRANCH IF AT END OF TABLE
40      PUSH  H         ;PUT POINTER ON STACK
50      MOV    E,M      ;
60      MVI   D,HREGS   ;FETCH ADDRESS OF SAVE LOCATION
70      INX   H         ;.....THE END.....

```

Notice that the original source code has been duplicated as from line 5 and that lines 10 and 20 have been renumbered to 20 and 21 to allow this. Line numbers 30 to 70 have not been affected.



## Loading and Storing Source Code without Line numbers

As a user you might want to input some Source code into your Desktop Computer that was originated by some other system.

You can do this by interfacing the other system or by reading the Source code from paper tape with the HP 9883A Paper Tape Reader.

The Source code should then be stored on your magnetic storage device so that it can either be modified by the Editor or assembled.

In the eventuality that your Source code does not have line numbers or that the line numbers are not complete or are not accepted by the Editor you can load them into the Editor with the statement.

**LOAD "<FILENAME>" @**

The code will then be loaded with possibly 2 sets of line numbers if your original code had line numbers.

### Example

The following Source code is stored on the mass storage device under the file name RECORD

```

      MOV      E,A
      MVI      D,0
30    MVI      C,1:1
40    CALL     PD
50    MOV      A,E
60    XRA     A
70    CALL     PADR

```



This code would give an error message if you try to load it because the first two lines have no line numbers.

By using **LOAD "RECORD" @** the file can be loaded.

```

10      MOV      E,A
20      MVI      D,0
30  30    MVI      C,1:1
40  40    CALL     PD
50  50    MOV      A,E
60  60    XRA     A
70  70    CALL     PADR

```

The first two lines can now be modified with the Editor functions such that they have the line numbers 10 and 20. The Source code is restored onto the mass storage device with,

```
STORE "RECORD" @
```

It is then restored without the first column of line numbers and with the first two line numbers corrected. The Source code may now be loaded into the Editor by using the ordinary LOAD statement as the line numbers in the file are now correct.

The procedure described in the above section is not necessary if the Source code has an understandable line number in each line. These line numbers need not necessarily even be in numerical order. Provided they exist and are understandable, the LOAD statement without the @ will replace the faulty line numbers by correctly sequenced ones.

## Macro Examples

### Macro Redefinition

After it has been defined, a Macro may be redefined to have the same name but a different body.

The Macro definitions should all be at the beginning of your Source code or at least before they are called. To have a redefined Macro in this list does not achieve anything as the least definition is the one that is used. The original definition will never be used.

A Macro redefinition is therefore normally put into the body of another Macro. This could be either the Macro defined with the same name or some other. Alternatively, a SOURCE or INCLUDE statement can be inserted into the body of a Macro such that the redefinition is loaded for the mass storage device. The redefinition is carried out when the Macro is called.

The following Source code is an example of redefining a Macro.

```
10 DEMO      MACRO      =ABC      ;ORIGINAL DEFINITION
20          LXI        B, =ABC
30          DB         'TEST'
40
50 DEMO      MACRO      =DEF      ;REDEFINITION
60          MVI        A, =DEF
70
80          ENDM
90          ENDM
100
110          DEMO      "123"      ;CALLING ORIGINAL
120          DEMO      "245"      ;CALLING REDEFINITION
130
140          END
```

The following is the result of assembling the Source code.

```

10          DEMO      MACRO      =ABC      ;ORIGINAL DEFINITION
20          LXI       B,=ABC
30          DB        '<TEST>'
40
50          DEMO      MACRO      =DEF      ;REDEFINITION
60          MVI       A,=DEF
70
80          ENDM
90          ENDM
100
110         DEMO      "123"      ;CALLING ORIGINAL
          0000 017B00      LXI       B,123
          0003 54455354      DB        '<TEST>'
          DEMO      MACRO      =DEF      ;REDEFINITION
          MVI       A,=DEF
          ENDM
120         DEMO      "245"      ;CALLING REDEFINITION
          0007 3EF5        MVI       A,245
130
140          END

```

The Macro called DEMO is first defined in line 10 and then redefined in line 50.

From line 10 to line 90 the assembler program lists the Macro definitions while, at the same time, stores them in memory.

In line 110 the Macro is called with a value of 123 to be passed into the dummy parameter = ABC. The Assembler listing then shows the expansion of the macro with this value.

The Assembler now recognises the new definition for DEMO and lists this. DEMO is now called again, in line 120, with a value of 245 for the dummy parameter = DEF. The listing then shows the expansion of the redefined Macro with this value.

## Macro Nesting

When a Macro is called from the main Source code, the Macro body is expanded and inserted into the main Source code at the point where it was called.

It is possible, in the Macro body, to have a call to another Macro and in this macro a call to yet another one, and so on. This process is called Macro nesting and can be repeated (nested) up to 8 times.

The following Source code is an example of Macros nested 4 deep.

```

10 DEMO      MACRO      =ABC
20 ; WE ARE NOW IN MACRO - DEMO
30          MOV        E,A
40          DEMO1      "=ABC"      ;CALL MACRO DEMO1
50 ; WE ARE BACK IN      - DEMO
60          ENDM
70
80
90 DEMO1     MACRO      =DEF
100 ; WE ARE NOW IN MACRO - DEMO1
110         LXI        B,=DEF
120         DEMO2      "=DEF"      ;CALL MACRO DEMO2
130 ; WE ARE BACK IN      - DEMO1
140         ENDM
150
160
170 DEMO2    MACRO      =GHI
180 ; WE ARE NOW IN MACRO - DEMO2
190         MVI        A,=GHI
200         DEMO3      "H"          ;CALL MACRO DEMO3
210 ; WE ARE BACK IN      - DEMO2
220         ENDM
230
240
250 DEMO3    MACRO      =JKL
260 ; WE ARE NOW IN MACRO - DEMO3
270         INX        =JKL
280         ENDM
290
300
310         DEMO      "12"          ;CALL MACRO DEMO
320         END

```



The following is the result of assembling this Source code.

```

10          DEMO      MACRO      =ABC
20          ; WE ARE NOW IN MACRO - DEMO
30          MOV       E,A
40          DEMO1     "=ABC"      ;CALL MACRO DEMO1
50          ; WE ARE BACK IN      - DEMO
60          ENDM
70
80
90          DEMO1     MACRO      =DEF
100         ; WE ARE NOW IN MACRO - DEMO1
110        LXI       B,=DEF
120        DEMO2     "=DEF"      ;CALL MACRO DEMO2
130        ; WE ARE BACK IN      - DEMO1
140        ENDM
150
160
170        DEMO2     MACRO      =GHI
180        ; WE ARE NOW IN MACRO - DEMO2
190        MVI       A,=GHI
200        DEMO3     "H"         ;CALL MACRO DEMO3
210        ; WE ARE BACK IN      - DEMO2
220        ENDM
230
240
250        DEMO3     MACRO      =JKL
260        ; WE ARE NOW IN MACRO - DEMO3
270        INX       =JKL
280        ENDM
290
300
310        DEMO      "12"         ;CALL MACRO DEMO
          ; WE ARE NOW IN MACRO - DEMO
0000 5F          MOV       E,A
          DEMO1     "12"         ;CALL MACRO DEMO1
          ; WE ARE NOW IN MACRO - DEMO1
0001 010C00     LXI       B,12
          DEMO2     "12"         ;CALL MACRO DEMO2
          ; WE ARE NOW IN MACRO - DEMO2
0004 3E0C      MVI       A,12
          DEMO3     "H"         ;CALL MACRO DEMO3
          ; WE ARE NOW IN MACRO - DEMO3
0006 23        INX       H
          ; WE ARE BACK IN      - DEMO2
          ; WE ARE BACK IN      - DEMO1
          ; WE ARE BACK IN      - DEMO
320          END

```

First of all, the assembler lists the Macros. This could have been suppressed by putting the NOLIST control before line 10 and the LIST control in line 290. The first Macro called DEMO is called, replacing = ABC by 12.

In line 40, the Macro DEMO calls the Macro DEMO1 passing the = ABC for = DEF as 12 was substituted for = DEF.

Line 120, of the second macro, calls DEMO2 (the 2nd macro) substituting = DEF, which is still equal to 12, for = GHI. This means that = GHI also becomes 12.

The last call is in line 200 where the macro DEMO3 is called and substitutes H for = JKL.

The ENDM statement in line 280 terminates the expansion of DEMO3 and the Assembler returns to expanding DEMO2 where an ENDM statement is also encountered (line 220). This terminates the expansion of DEMO2 and the Assembler returns to DEMO1. This too has an ENDM statement and the assembler returns in a similar fashion to DEMO. Here the ENDM statement returns the Assembler back to the main program in line 320, where the assembly finishes.

## Calling Macros from a Mass Storage Device

As well as being put at the beginning of the Source code, a Macro can also be stored on a mass storage device. For example, the left-hand tape drive (: T14) of the HP 9845B Desktop Computer or an HP 9885M Flexible Disc Drive.

They can then be called into the main program by use of the Assembler Controls.

```

OPT   SOURCE "<FILE NAME> [msus]" - 6800
$ INCLUDE "<FILE NAME> [msus]"     - 8080/85
* INCLUDE "<FILE NAME> [msus]"     - Z80

```

There are two different ways of doing this.

### METHOD 1

The main Source code has the statements:

```

<macro name>   MACRO   <dummy parameters> .....
                OPT   SOURCE "<FILE NAME>"
                ENDM
                .
                .
                .
                <macro name>   ; MACRO CALL
                .
                .

```

In this case, on assembling, the first three lines of Source code (the Macro definitions) are stored in the Desktop Computer memory. However, the Macro body, which is stored on the mass storage device under <FILE NAME> , is left where it is. On calling the Macro from the main Source code, the OPT SOURCE statement has an effect for the first time and the Macro body is inserted into the main source code.

## METHOD 2

The main Source code has the statements

```

OPT SOURCE "<FILE NAME>"
.
.
.
<macro name>    ; MACRO CALL
.
.

```

and the Macro stored on the mass storage device under <FILE NAME> contains the statements

```

<macro name>  MACRO
.
.
. <macro body>
.
.
ENDM

```

In this case, on running the Assembler, the OPT SOURCE statement will load the entire Macro into the Desktop Computer memory together with the MACRO and ENDM statements. On reaching the Macro call statement the Macro will then be inserted into the main Source code.

## General

Both these methods achieve the same results except that Method 1 will allow you, in general, to assemble programs with more Macros lines than Method 2 because it uses less memory. On the other hand, Method 2 will assemble faster if the same Macro is used several times. This is because the Macro code, already in memory, does not need to be loaded from your mass storage device every time it is called.

## Examples

## Method 1

The following Source code is on the mass storage device with the name SUBMAC

```
10      MOV      E, A
20      MVI      D, 0
30      MVI      C, ':'
40      XRA      A
```

The following is the main Source code

```
10 DEMO      MACRO
20 $ INCLUDE "SUBMAC"
30          ENDM
40
50
60
70          DEMO      ; MACRO CALL STATEMENT
80          END
```

As a result of assembling the above program we have:

```
10          DEMO      MACRO
20          $ INCLUDE "SUBMAC"
30          ENDM
40
50
60
70          DEMO      ; MACRO CALL STATEMENT
          $ INCLUDE "SUBMAC"
          0000 5F          MOV      E, A
          0001 1600       MVI      D, 0
          0003 0E3A       MVI      C, ':'
          0005 AF        XRA      A
80          END
```

## Method 2

The following is on the mass storage device with the name SUBMAC.

```
10 DEMO      MACRO
20      MOV      E, A
30      MVI      D, 0
40      MVI      C, ':'
50      XRA      A
60      ENDM
```



The following is the main Source code.

```

10 # INCLUDE "SUBMAC"
20
30
40
50     DEMO     ; MACRO CALL STATEMENT
60     END

```

As a result of assembling the above program we have.

```

10     # INCLUDE "SUBMAC"
10     DEMO     MACRO
20             MOV     E,A
30             MVI     D,0
40             MVI     C,':/
50             XRA     A
60             ENDM
20
30
40
50     DEMO     ; MACRO CALL STATEMENT
0000 5F     MOV     E,A
0001 1600   MVI     D,0
0003 0E3A   MVI     C,':/
0005 AF     XRA     A
70     END

```

## ENDM Statements

As described at the beginning of Section 9 (Macros) the Macro Assembler program ceases the assembly process as soon as it encounters a MACRO statement. It puts the Source lines that follow the MACRO statement into the Macro storage area in the Desktop Computer memory. This process continues until the Macro assembler encounters an ENDM statement.

If you make certain that the ENDM statement is in the same file as the MACRO statement then you will have no problems.

Using Method 1, try the following.

Macro body on the mass storage device	Main Source code
(macro body)	<macro name> <b>MACRO</b>
.	<b>OPT SOURCE "&lt;filename&gt;"</b>
.	.
.	.
<b>ENDM</b>	<b>MACRO CALL</b>

The above will not work because the Assembler program will start to assemble the main Source code, will see the **MACRO** statement, and then will store everything after it into the Macro storage area.

The **OPT SOURCE** statement will be stored and not executed, and hence, the Macro body with the **ENDM** statement will not be loaded.

Consequently the Assembler will not see the **ENDM** statement and will store the Macro call plus the rest of the main Source code into the Macro storage area.

Using method 2, try the following.

Macro body on the Mass storage device	Main Source code
<Macro name> <b>MACRO</b>	<b>OPT SOURCE "&lt;file name&gt;"</b>
.	<b>ENDM</b>
.	.
.(macro body)	.
.	.
.	.
.	<b>MACRO CALL</b>
.	.
	.(main Source code)

This example will work, as the **OPT SOURCE** statement will load the file from the mass storage device into the Desktop Computer and the Assembler will encounter the **MACRO** statement.

The entire Macro body will then be stored in the Desktop Computer Macro storage area until the end of the file on the mass storage device is reached.

The Assembler will now encounter the ENDM statement, will cease storing the Macro body and will continue assembling the Source code.

---

**NOTE**

The Macro body stored on the mass storage device should not contain an END statement.

---

## **General**

The above section on the ENDM statement, used together with Macro bodies stored on mass storage files, illustrates what points should be considered.

A good rule to follow in order to avoid problems is:

**THE MACRO AND ENDM STATEMENTS SHOULD BE IN THE SAME FILE**



**HEWLETT  
PACKARD**

**SALES & SERVICE OFFICES**

**AFRICA, ASIA, AUSTRALIA**

**ANGOLA**

Telectra  
Empresa Técnica de Equipamentos  
ELECTROS, S.A.R.L.  
R. Barbosa Rodrigues, 42-10T.  
Caixa Postal, 6487  
Luanda  
Tel: 355156  
Cable: TELECTRA Luanda

**AUSTRALIA**

Hewlett-Packard Australia Pty. Ltd.  
31-41 Joseph Street  
Blackburn, Victoria 3130  
P.O. Box 36  
Doncaster East, Victoria 3109  
Tel: 896351  
Tel: 31-024  
Cable: HEWPARO Melbourne  
Hewlett-Packard Australia Pty. Ltd.  
31 Bridge Street  
Pyrmont  
New South Wales, 2073  
Tel: 4496566  
Tel: 21561  
Cable: HEWPARO Sydney  
Hewlett-Packard Australia Pty. Ltd.  
153 Greenhill Road  
Parkside, S.A. 5063  
Tel: 2725911  
Tel: 82536  
Cable: HEWPARO Adelaide  
Hewlett-Packard Australia Pty. Ltd.  
141 Sirling Highway  
Newlands, W.A. 6009  
Tel: 3865455  
Tel: 93855  
Cable: HEWPARO Perth  
Hewlett-Packard Australia Pty. Ltd.  
121 Wollongong Street  
Fyshwick, A.C.T. 2609  
Tel: 804244  
Tel: 62650  
Cable: HEWPARO Canberra  
Hewlett-Packard Australia Pty. Ltd.  
5th Floor  
Teachers Union Building  
495-499 Boundary Street  
Spring Hill, Queensland 4000  
Tel: 2291544  
Cable: HEWPARO Brisbane

**BANGLADESH**

The General Electric Co. of Bangladesh Ltd.  
Magnet House 72  
Oilkusha Commercial Area  
Motijheel, Dacca 2  
Tel: 252415, 252419  
Tel: 734  
Cable: GECDAC Dacca

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
11620A - 168th Street  
Edmonton T5M 3T9  
Tel: (403) 452-3679  
TWX: 610-631-2431

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
210,720 Fisher St. S.E.  
Calgary T2H 2H8  
Tel: (403) 253-2713  
Twx: 601-821-6441

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
10891 Shwinburn Way  
Richmond BC V6V 2W7  
Tel: (604) 270-2277  
TWX: 610-625-5059

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
380-550 Century St.  
Winnipeg R3M 0Y1  
Tel: (204) 786-6701  
TWX: 610-671-3531

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
800 Windmill Road  
Dartmouth NS B3B 1L1  
Tel: (902) 469-7820  
TWX: 600-271-4482

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
552 Newbold Street  
London N6E 2S5  
Tel: (519) 686-9181

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
275 Hymus Blvd  
Pointe Claire H9R 1G7  
Tel: (514) 697-4232  
TWX: 610-422-3022  
TLX: 05-821-521 HPCL

**BANGLADESH**

Hewlett-Packard (Canada) Ltd.  
3200 Hillview Ave  
Palo Alto, California 94304  
Tel: (415) 856-1501  
TWX: 910-373-1260  
Cable: HEWPACK Palo Alto  
Tel: 034-8300, 034-8493

**ETHIOPIA**

Adella Abduimalk  
P.O. Box 2635  
Addis Abeba  
Tel: 11 93 40

**GUAM**

Guam Medical Supply, Inc.  
Suite C, Airport Plaza  
P.O. Box 8947  
Tamuning 96911  
Tel: 646-4513  
Cable: EARMED Guam

**HONG KONG**

Schmidt & Co. (Hong Kong) Ltd.  
Wing On Centre, 26th Floor  
Connaught Road, C.  
Hong Kong  
Tel: 5-455644  
Tel: 4786 SCHMC HK

**INDIA**

Blue Star Ltd.  
Kastur Buildings  
Jamshedi Tata Rd  
Bombay 400 020  
Tel: 29 50 71  
Tel: 011-21156  
Cable: BLUEFROST  
Blue Star Ltd.  
Sahas  
414/2 Vir Savarkar Marg  
Prabhadevi  
Bombay 400 025  
Tel: 45 78 87  
Tel: 011-4093  
Cable: FROSTBLUE

**INDIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDIA**

Blue Star Ltd.  
7 Hera Street  
P.O. Box 506  
Calcutta 700 001  
Tel: 23 0131  
Tel: 021-7655  
Cable: BLUESTAR  
Blue Star Ltd.  
Bhandari House  
7th & 8th Floor  
91 Nehru Place  
New Delhi 110 024  
Tel: 05-334770 & 635186  
Tel: 031-2463  
Cable: BLUESTAR

**INDIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDIA**

Blue Star Ltd.  
7 Hera Street  
P.O. Box 506  
Calcutta 700 001  
Tel: 23 0131  
Tel: 021-7655  
Cable: BLUESTAR  
Blue Star Ltd.  
Bhandari House  
7th & 8th Floor  
91 Nehru Place  
New Delhi 110 024  
Tel: 05-334770 & 635186  
Tel: 031-2463  
Cable: BLUESTAR

**INDIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDIA**

Blue Star Ltd.  
7 Hera Street  
P.O. Box 506  
Calcutta 700 001  
Tel: 23 0131  
Tel: 021-7655  
Cable: BLUESTAR  
Blue Star Ltd.  
Bhandari House  
7th & 8th Floor  
91 Nehru Place  
New Delhi 110 024  
Tel: 05-334770 & 635186  
Tel: 031-2463  
Cable: BLUESTAR

**INDIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDIA**

Blue Star Ltd.  
7 Hera Street  
P.O. Box 506  
Calcutta 700 001  
Tel: 23 0131  
Tel: 021-7655  
Cable: BLUESTAR  
Blue Star Ltd.  
Bhandari House  
7th & 8th Floor  
91 Nehru Place  
New Delhi 110 024  
Tel: 05-334770 & 635186  
Tel: 031-2463  
Cable: BLUESTAR

**INDONESIA**

BERCA Indonesia P.T.  
P.O. Box 496Jkt.  
Jin Abdul Mus 62  
Jakarta  
Tel: 349255, 349886  
Tel: 46748 BERSIL IA  
Cable: BERSAL  
BERCA Indonesia P.T.  
P.O. Box 174/Sby  
23 Jln. Jmerto  
Surabaya  
Tel: 42027  
Cable: BERCCAN

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**INDONESIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Yokogawa-Hewlett-Packard Ltd.  
Nakamo Building  
24 Kami Sasajima-cho  
Nakamura-ku, Nagoya, 450  
Tel: 052-371-5171  
Yokogawa-Hewlett-Packard Ltd.  
Tanigawa Building  
2-24-1 Tsuruya-cho  
Kanagawa-ku  
Yokohama, 221  
Tel: 045-312-1252  
Tel: 382-3204 YHP YOK

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**JAPAN**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Advanced Communications Ltd.  
P.O. Box 30070  
Nairobi  
Tel: 313955  
Tel: 22639  
Medical Only  
International Aeradio E.A. Ltd  
P.O. Box 19012  
Nairobi Airport  
Nairobi  
Tel: 336055-56  
Tel: 22201/2301  
Cable: INTAERIO Nairobi  
Medical Only  
International Aeradio E.A. Ltd  
P.O. Box 95221  
Nairobi  
Tel: 336055-56  
Tel: 22201/2301  
Cable: INTAERIO Nairobi

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**KENYA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**LIBERIA**

Protel Engineering  
P.O. Box 187  
Lot 259, Satok Road  
Kuching, Sarawak  
Tel: 53544  
Cable: PROTLENG  
MOZAMBIQUE  
A. N. Gonçalves, Ltd  
162, 1<sup>o</sup> Apt. 14 Av. O. Luis  
Caixa Postal 107  
Maputo  
Tel: 27091, 27114  
Tel: 6-203 NEGON Mo  
Cable: NEGON  
NEW GUINEA  
Hewlett-Packard Australia  
Pty. Ltd.  
Development Bank Building  
Ground Floor  
Ward Strip  
Port Moresby, Papua  
Tel: 258933  
NEW ZEALAND  
Hewlett-Packard (N.Z.) Ltd  
4-12 Churchbank Street  
Kilburne, Wellington 3  
P.O. Box 9443  
Courtney Place  
Wellington  
Tel: 877-139  
Cable: HEWPACK Wellington  
Hewlett-Packard (N.Z.) Ltd  
Pakuranga Professional Centre  
257 Pakuranga Highway  
Box 51092  
Pakuranga  
Tel: 569-851  
Cable: HEWPACK Auckland  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
Scientific Division  
257 Pakuranga Road, Newmarket  
P.O. Box 1234  
Auckland  
Tel: 75-289  
Cable: DENTAL Auckland  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
Norne and Parumona Streets  
Porirua  
Tel: 75-098  
Tel: 3858  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
P.O. Box 1510  
Cable: HEWPACK Singapore  
239 Stanmore Road  
Christchurch  
Tel: 892-019  
Cable: DENTAL Christchurch  
Analytical/Medical Only  
Medical Supplies N.Z. Ltd.  
303 Great King Street  
P.O. Box 233  
Dunedin  
Tel: 88-817  
Cable: DENTAL Dunedin

**LIBERIA**

Blue Star Ltd.  
Band Box House  
Prabhadevi  
Bombay 400 025  
Tel: 45 73 01  
Tel: 011 3751  
Cable: BLUESTAR  
Blue Star Ltd.  
Shardap  
Stadium Road  
Ahmedabad 380 014  
Tel: 42880  
Cable: BLUEFROST

**LIBERIA</**