





Handshake








RHS
Top ←



(Plotter Cable)





(To 09826-60131 PCB)