

HEWLETT-PACKARD

READ THIS FIRST



Dear Customer:

Take a moment to read this sheet. It tells you how to start using your computer, lists what is packed in the shipping carton, and describes factory-installed accessories. **Keep this sheet for later reference.**

HOW DO I GET STARTED?

1. Unpack the computer and the accessory box (bottom of carton).
2. Go through the system checklist below to ensure that you have everything.
3. Turn to chapter 1, "Getting Started," in the *Setting Up the Portable Vectra CS* manual.


SYSTEM CHECKLIST

- Portable Vectra CS, serial number 2835A10876.
- Setup disc.
- Accessory Box (in bottom of carton).
 - Rear cover strip for use with LCD removed.
 - Recharger.
 - Power cord.
 - Setting Up the Portable Vectra CS* manual.
 - Support Guide*.
 - HP Terminal Program package.

The following items are installed in your computer:

- Two 1.44M-byte flexible disc drives.
- **Slot 1:** dual-serial/EMS adapter. The 9-pin male connector is for RS-232C, and the 25-pin female connector is for both RS-232C and HP-422. Please note that the EMS subsystem is disabled on the adapter.
- **Slot 4:** Display/printer adapter. The 9-pin connector is the display connector, and the 25-pin connector is the parallel printer connector.

You may purchase additional adapters and install them in your computer yourself. A modem or dual-serial/EMS adapter is required for the HP Terminal Program to communicate with an HP 3000 computer.



HEWLETT
PACKARD

5955-8737
D1001A#EMP