

OPERATING AND SERVICE MANUAL

12880A
12880A-001

KEYBOARD-DISPLAY TERMINAL INTERFACE KIT

(FOR 2100-SERIES COMPUTERS)

Card Assembly

12880-60001, Rev. 1017, 1411, and 1432

Note

This manual should be retained with the applicable computer documentation.

LIST OF EFFECTIVE PAGES

Changed pages are identified by a change number adjacent to the page number. Changed information is indicated by a vertical line in the outer margin of the page. Original pages do not include a change number and are indicated as change number 0 on this page. Insert latest changed pages and destroy superseded pages.

Change 0 (Original) JAN 1976

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied or reproduced without the prior written consent of Hewlett-Packard Company.

TABLE OF CONTENTS

| Section | Page | Section | Page |
|--|------|--|------|
| I GENERAL INFORMATION | | III THEORY OF OPERATION | |
| 1-1. Introduction | 1-1 | 3-1. Introduction | 3-1 |
| 1-3. General Description | 1-1 | 3-3. Functional Description | 3-1 |
| 1-6. Card Identification | 1-1 | 3-4. Data Codes | 3-1 |
| 1-8. Specifications | 1-1 | 3-6. Character Length | 3-1 |
| II INSTALLATION AND PROGRAMMING | | 3-8. Basic Circuits of the Interface Card. | 3-1 |
| 2-1. Introduction | 2-1 | 3-10. Detailed Circuit Description | 3-1 |
| 2-3. Unpacking and Inspection | 2-1 | 3-11. Power On. | 3-1 |
| 2-5. Installation | 2-1 | 3-16. Input Operations | 3-2 |
| 2-6. Jumper Wire W1 | 2-1 | 3-28. Output Operations | 3-4 |
| 2-8. Card Installation | 2-1 | IV MAINTENANCE | |
| 2-10. Reshipment | 2-1 | 4-1. Introduction | 4-1 |
| 2-14. Programming | 2-1 | 4-3. Preventive Maintenance | 4-1 |
| 2-16. HP 2600A Terminal Characteristics | 2-2 | 4-5. Diagnostics | 4-1 |
| 2-18. HP 2600A Special Considerations | 2-2 | 4-7. Troubleshooting | 4-1 |
| 2-20. HP 2615A Terminal Characteristics and Special Considerations. | 2-3 | 4-9. Cable Assembly Connector Pin Functions | 4-1 |
| 2-21A. HP 2640A Terminal and Special Characteristics. | 2-3 | V REPLACEABLE PARTS | |
| 2-22. Status Check | 2-3 | 5-1. Introduction | 5-1 |
| 2-24. Timing | 2-3 | 5-4. Ordering Information | 5-1 |
| 2-27. Assembly Language Program | 2-3 | | |

LIST OF ILLUSTRATIONS

| Figure | Title | Page | Figure | Title | Page |
|--------|--|------|--------|--|------|
| 1-1. | HP 12880A Keyboard-Display Terminal Interface Kit | 1-1 | 3-5. | Initial Condition After Power Turn-On or Preset, Flow Diagram | 3-7 |
| 2-1. | HP 2600A Terminal ASCII Character Set | 2-2 | 3-6. | Interface Card Input Operation, Flow Diagram | 3-9 |
| 3-1. | Data Transfer, Simplified Block Diagram | 3-1 | 3-7. | Interface Card Output Operation, Flow Diagram | 3-11 |
| 3-2. | Data Bits for Transfer of the Letter "M" | 3-1 | 4-1. | Interface Card Logic Diagram and Parts Location View | 4-3 |
| 3-3. | Input Operation, Timing Diagram | 3-3 | 4-2. | Integrated Circuit Diagrams | 4-5 |
| 3-4. | Output Operation, Timing Diagram | 3-5 | | | |

LIST OF TABLES

| Table | Title | Page | Table | Title | Page |
|-------|--|------|-------|---|------|
| 1-1. | Interface Kit Specifications | 1-2 | 4-3. | Integrated Circuit Characteristics | 4-5 |
| 2-1. | Status Check | 2-3 | 5-1. | HP 12880A Keyboard-Display Terminal Interface Kit Numeric Parts List | 5-2 |
| 2-2. | Program Control Words | 2-3 | 5-2. | Code List of Manufacturers | 5-3 |
| 2-3. | Assembly Language Program | 2-4 | 5-3. | Reference Designations and Abbreviations | 5-4 |
| 4-1. | Wiring List for Interconnecting Cables | 4-1 | | | |
| 4-2. | Interface Card Replaceable Parts | 4-2 | | | |

SECTION I

GENERAL INFORMATION

1-1. INTRODUCTION.

1-2. This operating and service manual covers general information, installation, programming, theory of operation, maintenance, and replaceable parts information for the Hewlett-Packard 12880A Keyboard-Display Terminal Interface Kit. (See figure 1-1.)

1-3. GENERAL DESCRIPTION.

1-4. The standard HP 12880A Interface Kit provides the necessary equipment to interface the HP 2600A Keyboard-Display Terminal or the HP 2615A Terminal with an HP 2100-Series Computer. The kit contains the following items:

- a. 12880-60001 Keyboard-Display Terminal Interface Card.
- b. 12880-60003 Cable Assembly.
- c. 12880-90001 Operating and Service Manual.

1-4A. The option 001 kit includes the items provided with the standard kit except 12880-60003 Cable Assembly is replaced by 02640-60058 Cable Assembly. The option 001 cable is designed to typically connect to certain terminals in the 2640 family of terminals.

1-5. The interface card contains control and interrupt logic for both input and output computer functions and a shift register for temporary storage of data between the


computer and the terminals. Eight data bits are transferred in parallel between the interface card and the computer; an 11-bit word in American Standard Code for Information Interchange (ASCII) is transferred in serial between the interface card and the terminals. The interface card can provide automatic readback to the terminals without computer intervention. The cable assembly connects the interface card to the terminals.

1-6. CARD IDENTIFICATION.

1-7. Printed-circuit card revisions are identified by a letter, a date code, and a division code stamped on the card (e.g., A-1005-22). The letter code identifies the version of the etched trace pattern on the unloaded card. The date code (four middle digits) refers to the electrical characteristics of the loaded card. The division code (last two digits) identifies the Hewlett-Packard division that manufactured the card. If the date code stamped on the printed-circuit card does not agree with the date code shown on the title page of this manual, there are differences between your card and the card described in this manual. These differences are described in manual supplements available at the nearest HP Sales and Service Office.

1-8. SPECIFICATIONS.

1-9. Specifications for the keyboard-display terminal interface kit are listed in table 1-1.



2110-10

Figure 1-1. HP 12880A Keyboard-Display Terminal Interface Kit

Table 1-1. Interface Kit Specifications

| | | |
|--|--|----------------------|
| CURRENT REQUIRED FROM COMPUTER: | | |
| +12-volt supply: | 0.24 ampere | |
| +4.5-volt supply: | 0.76 ampere | |
| -2-volt supply: | 0.05 ampere | |
| -12-volt supply: | 0.01 ampere | |
| DATA TRANSFER RATE: | 10 to 960 characters per second (110 to 9600 baud). Actual value depends upon external clock input from terminals. | |
| EXTERNAL CLOCK FREQUENCY REQUIRED: | Eight times the selected baud rate to and from the terminals. | |
| TYPES OF CODES USED: | ASCII between interface card and terminals. HP Character Set between interface card and computer. | |
| LOGIC VOLTAGE LEVELS: | <u>LOGIC 1</u> | <u>LOGIC 0</u> |
| To and from terminals: | -3V dc to - 12V dc | +3V dc to +12V dc |
| Signal condition: | Marking | Spacing |
| To and from computer: | +4.5V dc | 0V dc |
| <p>Note: Data transfer via the direct memory access (DMA) option is not recommended with the HP 12880A Keyboard Display Terminal Interface Kit when used in conjunction with the HP 2100 series computers. The results of such data transfers are unspecified.</p> | | |

SECTION II

INSTALLATION AND PROGRAMMING

2-1. INTRODUCTION.

2-2. This section provides information on unpacking, inspection, installation, reshipment, and programming for the HP 12880A Keyboard-Display Terminal Interface Kit.

Note: Data transfer via the direct memory access (DMA) option is not recommended with the HP 12880A Keyboard Display Terminal Interface Kit when used in conjunction with the HP 2100 series computers. The results of such data transfers are unspecified.

2-3. UNPACKING AND INSPECTION.

2-4. If the shipping container is damaged upon receipt, request that the carrier's agent be present when the kit is unpacked. Inspect the kit contents for damage (cracks in circuit card, broken parts, etc.). If the kit is damaged and fails to meet specifications, notify the carrier and the nearest HP Sales and Service Office immediately. (Sales and Service Offices are listed at the back of this manual.) Retain the shipping container and packing material for the carrier's inspection. The HP Sales and Service Office will arrange for repair or replacement of the damaged part without waiting for any claims against the carrier to be settled.

2-5. INSTALLATION.

2-6. JUMPER WIRE W1.

2-7. The interface card is shipped with jumper wire W1 in position B to allow the terminal to provide an external clock that controls the data transfer rate. Inspect the card and verify that the jumper wire is in the correct position. See the parts location view in figure 4-1 to determine the physical location of the jumper.

2-8. CARD INSTALLATION.

2-9. Install the interface card and cable assembly as follows:

a. Determine if the computer power supplies will provide the additional current required for operation of the interface card. Refer to the Hewlett-Packard computer documentation for a listing of current available from the computer power supplies.

b. Turn off computer and terminal power.

CAUTION

Make certain that power is off at the computer before installing the interface kit, or damage to the interface card or the computer may result.

c. Open computer for access to I/O card slots.

d. Plug interface card into I/O slot assigned for the particular computer system. Make certain that all higher priority slots have either another I/O card or a priority jumper card installed.

e. Pass interface card connector of the cable assembly through opening at rear of computer. Slide connector onto interface card and close computer.

f. Connect other end of cable assembly to mating connector on terminal.

g. Run diagnostic test to verify that the interface card is functioning properly. See paragraph 4-6.

2-10. RESHIPMENT.

2-11. If an item of the interface kit is to be shipped to Hewlett-Packard for service or repair, attach a tag to the item identifying the owner and indicating the service or repair to be accomplished. Include the model number of the kit.

2-12. Package the item in the original factory packaging material, if available. If the original material is not available, standard factory packaging material can be obtained from a local Hewlett-Packard Sales and Service Office.

2-13. If standard factory packaging material is not used, wrap the item in Air Cap TH-240 Cushioning (or equivalent) manufactured by Sealed Air Corp., Hawthorne, N.J. and place in a corrugated carton (200 pound test material). Seal the shipping carton securely and mark it "FRAGILE" to assure careful handling.

Note

In any correspondence, identify the interface kit by model number. Refer any questions to the nearest Hewlett-Packard Sales and Service Office.

2-14. PROGRAMMING.

2-15. The following paragraphs provide information for programming the interface card and the terminals. This information consists of the HP 2600A terminal characteristics, status and timing considerations, and a sample assembly language program. Additional programming information is available in the HP 2615A Terminal Operating and Service Manual, part no. 02615-90004, the HP 2640A Terminal Owner's Manual, part no. 02640-90011, and in software manuals supplied with the computer. It should be noted that the ASCII character sets for the terminals are not completely compatible.

2-16. HP 2600A TERMINAL CHARACTERISTICS.

2-17. The terminal contains a keyboard, cathode-ray tube display, character generator, memory, and interface components. Keyboard operation is similar to operation of a teleprinter keyboard in that characters are generated by typing. Generated characters are either of two types: graphic characters that are displayed on the CRT screen, or control characters that cause some action to occur such as positioning of the displayed characters. When any character is generated, a signal representing an equivalent ASCII character is generated at the same time. By programming, these generated signals are sent through the interface card to computer memory. The computer also outputs ASCII character signals through the interface card for display by the terminal. Data bits that make up each ASCII character are transferred serially between the terminal and the interface card data register and in parallel between the data register and computer memory. Figure 2-1 shows the ASCII character set used by the terminal.

| BIT NUMBER | | | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------------|---|---|---|-----------------|-----------|-----|---|---|---|---|---------|
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 |
| 0 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 |
| 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 |
| 0 | 0 | 1 | 1 | | | SP | ␣ | @ | P | | |
| 0 | 1 | 0 | 0 | | X on | ! | 1 | A | Q | | |
| 0 | 1 | 0 | 1 | | | " | 2 | B | R | | |
| 0 | 1 | 1 | 0 | | X off | # | 3 | C | S | | |
| 0 | 1 | 1 | 1 | | | \$ | 4 | D | T | | |
| 1 | 0 | 0 | 0 | WRU | | % | 5 | E | U | | |
| 1 | 0 | 0 | 1 | F ^{cs} | | & | 6 | F | V | | |
| 1 | 0 | 1 | 0 | BELL | | ' | 7 | G | W | | |
| 1 | 0 | 1 | 1 | | c → | (| 8 | H | X | | |
| 1 | 1 | 0 | 0 | | c ← |) | 9 | I | Y | | |
| 1 | 1 | 0 | 1 | LINE FEED | c ↑ | * | : | J | Z | | |
| 1 | 1 | 1 | 0 | | c ↓ | ESC | + | : | K | [| |
| 1 | 1 | 1 | 1 | | HOME DOWN | , | < | L | \ | | |
| 1 | 1 | 1 | 0 | RE-TURN | HOME UP | - | = | M |] | | |
| 1 | 1 | 1 | 1 | SPOW LATCH | ERASE EOL | . | > | N | ↑ | | |
| 1 | 1 | 1 | 1 | SPOW UN-LATCH | ERASE EOF | / | ? | O | ← | | RUB OUT |

NOTE: C = CURSOR

2110-14

Figure 2-1. HP 2600A Terminal ASCII Character Set

2-18. HP 2600A SPECIAL CONSIDERATIONS.

2-19. The data transmission and receiving rate, as expressed in bits per second, is selectable through a BAUD RATE switch at the rear of the terminal. Because the time

required to execute commands is sometimes greater than the data transfer rate, it is necessary to compensate for the command delays through programming. Most special programming considerations are concerned with the cursor. The cursor indicates the next character position on the CRT screen by flashing at the indicated position. To move the cursor requires a displayed character, which automatically moves the cursor to the next position, or a cursor direction arrow command. The cursor is also moved by erase EOF, erase EOL, home up, and home down commands. Special programming information required to ensure proper execution of cursor commands is provided in the following paragraphs.

a. The cursor direction arrow command moves the cursor one increment in the direction of the arrow: either up, down, right, or left. These cursor direction arrow commands are given at any time. However, special filler characters must be given with the cursor command to provide a total filler and cursor character time of 16.67 milliseconds. Filler characters are non-functioning control characters such as control-shift with the "F" character. (See figure 2-1 for the ASCII equivalent of F^{cs}.) The number of filler characters required depends on the BAUD RATE switch position as follows: no fillers required for positions 110 through 600; one filler required for position 880; two fillers required for positions 1200 and 1760; and three fillers required for position 2400.

b. The erase EOF and erase EOL commands clear portions of the CRT screen. Erase EOF clears from the cursor position to the end of the frame while erase EOL clears from the cursor position to the end of the line. To properly execute these commands, the commands should be sent in multiples that provide a total time of 16.67 milliseconds for either command. The number of commands required therefore depends on the BAUD RATE switch position as follows: one command for positions 110 through 600; two commands for positions 880 and 1200; three commands for position 1700; and four commands for position 2400.

c. The home up and home down commands move the cursor to the top left and bottom left, respectively, on the CRT screen. Home up commands have no restriction and work at any data transfer rate. Home down commands, however; cannot be used at BAUD RATE switch positions above 300 because of logic restrictions. To reach the home down position at faster data transfer rates, program a home up command followed by 25 down cursor direction arrow commands.

d. The terminal provides an automatic carriage return and line feed after 72 characters are displayed on any line. If a carriage return and line feed is also programmed after 72 characters, a double space will occur between lines of the display.

e. Line feed commands are also restricted at BAUD RATE switch positions above 600 when the cursor is at the home down (bottom line) position. If the line feed command is then followed by a different command or a

printing character, the terminal speed buffer falls behind. The first two sequences (a sequence is one line feed command followed by any different command or a character) are not restricted. However, before programming the third, successive sequence, four filler characters must be programmed to prevent data from being lost. This restriction does not apply when any number of line feed commands are programmed successively without intermixing other commands or characters.

2-20. HP 2615A TERMINAL CHARACTERISTICS AND SPECIAL CONSIDERATIONS.

2-21. Characteristics and programming information for the HP 2615A Terminal are contained in the HP 2615A Terminal Operating and Service Manual, part no. 02615-90004. It should be noted that the HP 2615A Terminal ASCII character set differs from the HP 2600A Terminal ASCII character set.

2-21A. HP 2640A TERMINAL CHARACTERISTICS AND SPECIAL CONSIDERATIONS.

2-21B. Characteristics and programming information for the HP 2640A Terminal are contained in the Owner's Manual, part no. 02640-90011. It should be noted that the HP 2640A Terminal ASCII character set differs from the HP 2600A Terminal ASCII character set.

2-22. STATUS CHECK.

2-23. A method for checking status is shown in table 2-1. These program steps check bit 15 to determine if the terminal is transferring a character to the computer. Bit 15 is set true by the first input bit to the interface card and remains true until the tenth input bit. This allows time for the full character to be transferred before bit 15 is set

Table 2-1. Status Check

| OPCODE | OPERAND | REMARKS |
|--------|---------|-----------------------------------|
| LIA | CRT | Put buffered data into A-register |
| SSA | | Busy? |
| JMP | *-2 | Yes, jump back two instructions. |
| --- | | No, program continuation. |

Table 2-2. Program Control Words

| LABEL | OPCODE | OPERAND | REMARKS |
|-------|--------|---------|--|
| TERM | EQU | nn | Where nn is the select code. |
| DOPR | OCT | 120000 | Data out (computer to terminal). |
| DINP | OCT | 140000 | Data in (terminal to computer). |
| DINPR | OCT | 160000 | Data in (with return to terminal for display). |
| CHAR1 | OCT | 000000 | Temporary data. |
| CHAR2 | OCT | 000000 | Storage locations. |

to logic 0. Bit 15 remains set to logic 0 when the computer is transferring data to the interface card.

2-24. TIMING.

2-25. The terminal operation is synchronized by a clock signal provided by the terminal. This clock signal is always available when the terminal is turned-on and is connected to a pulse counter (divider) on the interface card. During input operations the counter starts counting clock pulses when the first input bit is received from the terminal. For output operations, the counter starts counting clock pulses when an STC instruction is issued. In either case, the counter provides one bit count output for every eighth clock pulse and one character count output for every tenth bit count output. As each bit count occurs, the data register is clocked so that the ASCII character bits are serially transferred either in or out of the data register. On the tenth bit count the character count output clears the counter to inhibit further counting and also signals the computer by setting the Flag FF. Setting the Flag FF provides either an Interrupt Request or Skip Flag signal, depending on the method of data transfer, which indicates that the serial data transfer is complete.

2-26. Computer input and output operations are controlled by program control words and the STC instruction. The program control words are listed in table 2-2 along with other program constants that are useful in programming the terminal. Timing diagrams for input- and output operations are provided in figures 3-3 and 3-4, respectively and flow diagrams showing the sequence of input and output operations are provided in figures 3-6 and 3-7, respectively.

2-27. ASSEMBLY LANGUAGE PROGRAM.

2-28. Table 2-3 provides an assembly language program that indicates the operations and instructions required to transfer data between the terminals and the computer. Computer input and output operations are both shown. This program, when assembled on an object tape, transfers data to and from the terminals using the noninterrupt (skip-if-flag-set) method of data transfer. The interrupt method of data transfer can also be used; however, the program is more complex because of subroutine requirements.

Table 2-3. Assembly Language Program

```

0001          ASMB,A,L,B,T
0002*  SAMPLE PROGRAM FOR HP2600A KEYBOARD DISPLAY
0003*  TERMINAL
0004*
0005  01000          ORG 1000B
0006  01000 102511   LIA TRM          CHECK TERMINAL BUSY STATUS B15
0007  01001 002020   SSA              REMAIN IN WAIT CHECK UNTIL
0008  01002 025000   JMP *-2          B15=0
0009*
0010  01003 061077   LDA DOUT        SEND OUTPUT CONTROL WORD
0011  01004 102611   OTA TRM          TO TERMINAL
0012  01005 061132   TRM02 LDA HU          MOVE CURSOR TO TOP OF DISPLAY
0013  01006 015051   JSB CHOUT       SO SCREEN CAN BE CLEARED WHEN
0014  01007 061104   LDA M4          THE ERASE EOF CHARACTER IS
0015  01010 065127   LDB EEOFA       SENT TO TERMINAL. SEND 4-EEOF
0016  01011 015032   JSB OUT         CHARACTERS FOR 2400 BAUD
0017  01012 061106   LDA M22        CALLING SEQUENCE FOR
0018  01013 065107   LDB MSG1A       MESSAGE OUTPUT TO DISPLAY
0019  01014 015032   JSB OUT         *INPUT PRINT CHARACTER DESIRED
0020  01015 015057   JSB CHIN        INPUT KEYBOARD CHARACTER
0021  01016 061103   LDA LF          OUTPUT LINE-FEED
0022  01017 015051   JSB CHOUT       AND
0023  01020 061102   LDA CR          CURSOR RETURN
0024  01021 015051   JSB CHOUT       TO DISPLAY
0025*
0026*  OUTPUT 21 CHARACTERS DIAGONALLY ACROSS THE
0027*  SCREEN AS INPUT FROM THE KEYBOARD
0028  01022 061106   LDA M22        INITIALIZE COUNTER TO REPEAT
0029  01023 071135   STA RPT        INPUT CHARACTER 22-TIMES
0030  01024 061105   TRM01 LDA M6    PREPARE CALLING SEQUENCE TO
0031  01025 065123   LDB MSG2A       OUTPUT CHARACTER AND CURSOR
0032  01026 015032   JSB OUT         CONTROLS AT 2400 BAUD
0033  01027 035135   ISZ RPT
0034  01030 025024   JMP TRM01
0035  01031 025005   JMP TRM02       REPEAT PROGRAM SEQUENCE
0036*
0037*  SUBROUTINE TO OUTPUT MESSAGE
0038  01032 000000   OUT  NOP
0039  01033 071134   STA CHCT       SAVE OUTPUT CHARACTER COUNT
0040  01034 075133   STB BUFF       SAVE MESSAGE BUFFER ADDRESS
0041  01035 065100   LDB ULFL       UPPER/LOWER FLAG
0042  01036 161133   OUT01 LDA BUFF,I GET WORD CONTAINING CHARACTER
0043  01037 006021   SSB,RSS        IF UPPER/LOWER FLAG SAYS UPPER
0044  01040 001727   ALF,ALF        (SIGN=0) ROTATE TO LOWER
0045  01041 011101   AND M377       REMOVE UPPER CHARACTER
0046  01042 015051   JSB CHOUT       OUTPUT CHARACTER IN A(07-00)
0047  01043 006020   SSB            IF CHARACTER OUTPUT WAS LOWER
0048  01044 035133   ISZ BUFF       CHARACTER ADD 1 TO BUFF ADDRESS
0049  01045 005200   RBL           SET UPPER/LOWER FLAG;NEXT CHAR
0050  01046 035134   ISZ CHCT       INDEX CHARACTER COUNTER
0051  01047 025036   JMP OUT01      NOT ZERO; MORE TO OUTPUT
0052  01050 125032   JMP OUT,I      RETURN
0053*
0054*  SUBROUTINE TO OUTPUT CHARACTER
0055  01051 000000   CHOUT NOP
0056  01052 102611   OTA TRM        OUTPUT CHARACTER TO I/O BUFFER
0057  01053 103711   STC TRM,C     SEND ENCODE AND CLEAR FLAG
0058  01054 102311   SFS TRM        WAIT UNTIL TERMINAL
0059  01055 025054   JMP *-1        ACCEPTS CHARACTER
0060  01056 125051   JMP CHOUT,I    RETURN

```

Table 2-3. Assembly Language Program (Continued)

```

0061*
0062*   SUBROUTINE TO INPUT CHARACTER FROM TERMINAL
0063  01057 000000  CHIN  NOP
0064  01060 061076          LDA DIN      SEND INPUT CONTROL WORD
0065  01061 102611          OTA TRM      TO TERMINAL
0066  01062 103711          STC TRM,C   SEND ENCODE TO TERMINAL
0067  01063 102311          SFS TRM      WAIT FOR CHARACTER TO BE INPUT
0068  01064 025063          JMP *-1    FROM KEYBOARD
0069  01065 106511          LIB TRM      GET CHARACTER FROM BUFFER AND
0070  01066 005727          BLF,BLF    PREPARE FOR MESSAGE INSERTION
0071  01067 061077          LDA DOUT   SEND OUTPUT CONTROL WORD
0072  01070 102611          OTA TRM      TO TERMINAL
0073  01071 061124          LDA MSG2   INSERT
0074  01072 011101          AND M377   INPUT
0075  01073 030001          IOR B      CHARACTER INTO
0076  01074 071124          STA MSG2   MESSAGE
0077  01075 125057          JMP CHIN,I  RETURN
0078*
0079*   DATA
0080  00011          TRM  EQU 118
0081  00001          B    EQU 1
0082  01076 160000   DIN  OCT 160000
0083  01077 120000   DOUT OCT 120000
0084  01100 052525   ULFL OCT 52525
0085  01101 000377   M377 OCT 377
0086  01102 000015   CR   OCT 15
0087  01103 000012   LF   OCT 12
0088  01104 177774   M4   DEC -4
0089  01105 177772   M6   DEC -6
0090  01106 177752   M22  DEC -22
0091  01107 001110   MSG1A DEF MSG1
0092  01110 044516   MSG1  ASC 11,INPUT PRINT CHARACTER
      01111 050125
      01112 052040
      01113 050122
      01114 044516
      01115 052040
      01116 041510
      01117 040522
      01120 040503
      01121 052105
      01122 051040
0093  01123 001124   MSG2A DEF MSG2
0094  01124 000006   MSG2  OCT 12,3006,14013
      01125 003006
      01126 014013
0095  01127 001130   EEOF  DEF EEOF
0096  01130 017437   EEOF  OCT 15510,15512,15512
      01131 017437
0097  01132 000035   HU   OCT 35
0098  01133 000000   BUFF BSS 1
0099  01134 000000   CHCT BSS 1
0100  01135 000000   RPT  BSS 1
0101          END
** NO ERRORS*

```


SECTION III THEORY OF OPERATION

3-1. INTRODUCTION.

3-2. This section contains a brief functional description of the interface card followed by a detailed circuit description. As an aid in following the discussions given in the paragraphs below, refer to the interface card flow diagrams in figures 3-5 through 3-7 and the logic diagram in figure 4-1.


3-3. FUNCTIONAL DESCRIPTION.

3-4. DATA CODES.

3-5. American Standard Code for Information Interchange (ASCII) is the data code generated by the terminal. Character transfer between the interface card and the terminal is in ASCII (11-bit serial) format. Character transfer between the interface card and the computer is in HP Character Set (least significant 8 bits parallel) format. Only seven bits are used in the HP Character Set. Whether bit 8 is a logic 1 or 0 during input operations, depends on the parity functions of the terminal being used. Programming masks bit 8 before placing the data in memory; therefore, the logic level of bit 8 is immaterial. During output operations, standard HP software furnished with the computer automatically sets bit 8 to a logic 1.


3-6. CHARACTER LENGTH.

3-7. For each character transferred between the interface card and the terminal, either 10 or 11 bits of information are required. The interface card transfers 11 bits serially to the terminal and receives either 10 or 11 bits serially depending upon the bit transfer rate of the terminal. (Refer to the terminal manual for transfer rates and number of bits.) Since the bits are transferred one at a time, the basic data unit is a bit. Figure 3-1 shows a simplified block diagram of data transfer. Of the 10 or 11 bits, one is a start bit, eight are character bits, and one or two are stop bits. If the terminal transfers 11 bits per character, the interface card ignores the second stop bit (bit 10). The 11-bit format for transfer of the letter M is shown in figure 3-2.



2110-1A

Figure 3-1. Data Transfer, Simplified Block Diagram



2110-2A

Figure 3-2. Data Bits for Transfer of the Letter "M"

3-8. BASIC CIRCUITS OF THE INTERFACE CARD.

3-9. The interface card contains standard flag and interrupt logic circuits, control-word decoding circuits, data register, clock divider circuits, and level converter circuits. The standard flag and interrupt logic circuits permit operation under the skip-flag method or the interrupt method. The control-word decoding circuits prepare the card for an input or output operation. The data register provides serial-to-parallel and parallel-to-serial conversion of data for transfer between the terminal and the computer. The clock divider circuits divide the external clock signal from the terminal to provide the proper clock rate for the data register. The clock divider circuit also counts the bits during data transfer to and from the terminal to determine when the last bit of a character is transferred. The level converter circuits are in the data lines to and from the terminal to provide conversion between the signal levels used by the terminal and the signal levels used by the computer.

3-10. DETAILED CIRCUIT DESCRIPTION.

3-11. POWER ON.

3-12. When computer power is initially turned on, the POPIO and CRS signals are applied simultaneously to the interface card to establish initial conditions on the card. (See figure 3-5.) The POPIO signal sets the Flag Buffer FF, which in turn sets the Flag FF at time T2 (ENF true). The CRS signal clears the Control FF, Clock Enable FF, and the Read FF; direct sets the In/Out FF; and direct clears the Print FF, Punch FF, and Divider FFs.

3-13. The true clear-side outputs from the Print and Punch FFs hold transistor Q4 off, which in turn holds Q9 off. (The output of Q4 is coupled to the input of Q9 by jumper wires in the interconnecting cable.) This ensures that the output data line to the terminal is held in a mark condition (about -12 volts) while an input or output operation is not being performed.

3-14. The false set-side output of the Clock Enable FF direct clears FF U85A and direct sets FF U85B of the Data Register. The false clear-side output of FF U85B ensures that the output data line is held in the mark condition until the Data Register is clocked during an output operation. The false set-side output from FF U85A provides the start bit (space condition) when the Data Register receives the first clock pulse during an output operation.

3-15. The input data line from the terminal is maintained in a mark condition when data is not present on the line. This provides a logic 1 at the set input to FF U124B of the Data Register.

3-16. INPUT OPERATIONS.

3-17. To prepare the interface card for an input operation, control word bits 14 and 15 (both true) are transferred by an OTA/B instruction to the interface card. (See figure 3-6.) The LSCM, LSCL, and IOG(B) signals are "anded" to enable the instruction logic gates starting at time T3. The IOO signal, resulting from the OTA/B instruction, is "anded" with T3 to direct clear Data Register FFs U95B through U125A and to direct set FF U124B of the Data Register.

3-18. Control word bit 15 is "anded" with the IOO signal to clock the In/Out FF, Print FF, and Punch FF at time T5. The In/Out FF is set by control word bit 14. The true In signal from the In/Out FF performs the following functions:

- a. Enables gate U94C to clock the Data Register FFs when the set-side output of the C FF of the Divider is true.
- b. Enables gate U34A to set the Clock Enable FF when the first bit is received from the terminal.
- c. Enables gate U24B to pass the input data through transistors Q4 and Q9 to the terminal for display when either the Print FF or the Punch FF is set by the control word.

3-19. Next, an STC,C instruction is issued from the computer program. The STC signal sets the Control FF to allow the interface card to cause an interrupt if the interrupt system is on. The CLF signal clears the Flag Buffer and Flag FFs. The true clear-side output of the Flag FF is applied to the skip flag logic and to gate U104C to enable the data bits to enter the data register.

3-20. Data bits from the terminal are applied through Q8 to the Schmitt trigger circuit (Q1,Q2). (Jumper wires in the interconnecting cable connect the output from Q8 to the Schmitt trigger circuit.) Transistor Q8 converts the positive and negative voltage levels of the true and false signals from the terminal to +12 volts and ground, respectively. The Schmitt trigger circuit shapes the leading edges of the data bits. Transistor Q3 converts the logic levels of the data bits to +4.5 volts (true) and ground (false).

3-21. The first data bit (bit 0), always false, is inverted and "anded" with the In signal to set the Clock Enable FF. The set-side output of the Clock Enable FF enables the External Clock signal from the terminal to enter the Divider FFs. The External Clock signal is divided by eight when the set-side output of the C FF becomes true. This matches the bit transfer rate of the terminal. Each time the C FF set-side output becomes true, it is "anded" with the In signal to clock the Data Register FFs. (See figure 3-3.)

3-22. After the 10 input data bits have been clocked into the data register, the divide-by-11 portion of the Divider FFs has counted to 10, which direct clears the Counter Reset FF at time T3. At time T5 (SIR true) the Divider FFs are direct cleared and the Flag Buffer FF is set. Also, the Clock Enable FF is cleared which prevents the External Clock signal from entering the Divider FFs. At time T2 of the following machine cycle, the Flag FF is set by the true ENF signal.


3-23. If the skip-flag method for determining data availability is used, the true set-side output of the Flag FF is "anded" with the SFS signal to generate the SKF signal.

3-24. If the interrupt method is used, the true set-side output of the Flag FF is "anded" with IEN, the Control FF set-side output, PRH, SIR, and the Flag Buffer FF set-side output signals to set the IRQ FF at time T5. The IRQ FF set-side output generates the FLGL and IRQL signals to cause an interrupt on the next available machine cycle.

3-25. During the fetch phase immediately following the interrupt phase, IAK becomes true and is "anded" with the IRQ FF set-side output to clear the Flag Buffer FF.

3-26. Data is input to the computer by an LIA/B instruction to the interface card select code. The resulting IOI signal strobes the data bits from the Data Register onto the IOBI lines.

3-27. If either the Print FF or the Punch FF was set by the control word during an input operation, the serial data from gate U104A is transferred to the terminal through gate U24B, Q4, and Q9. (Jumper wires in the interconnecting cable connect the output of Q4 to the input of Q9.)



2110-3A

Figure 3-3. Input Operation, Timing Diagram

3-28. OUTPUT OPERATIONS.

3-29. To prepare the interface card for an output operation, control word bits 13 and 15 must be true and bit 14 must be false. (See figure 3-7.) The control word bits are transferred to the card by an OTA/B instruction to the interface card. The LSCM, LSCL, and IOG(B) signals are "anded" to enable the instruction logic gates starting at time T3. The IOO signal, resulting from the OTA/B instruction, is "anded" with T3 to direct clear the Data Register FFs, and to direct set FF U124B of the Data Register.

3-30. Control word bit 15 is "anded" with the IOO signal to clock the In/Out FF, Print FF, and Punch FF at time T5. The In/Out FF is cleared by the false control word bit 14. The true Out signal of the In/Out FF performs the following:

- a. Enables the Clock Enable FF to be set when an STC instruction is issued by the computer program.
- b. Enables the Data Register to be clocked when the clear-side output from the C FF of the Divider is true.
- c. Enables gate U24C at the output of the Data Register, along with the set state of the Print FF, to transfer the data bits to the terminal.
- d. Allows the Divider FFs and the Clock Enable FF to be cleared and the Flag Buffer FF to be set when the divide-by-11 portion of the Divider reaches a count of 11.

3-31. Next, an OTA/B instruction is issued to the interface card by the computer program to output the eight data bits to the Data Register. The resulting IOO signal enables the true IOBO bits to direct set the corresponding Data Register FFs at time T4.


3-32. An STC,C instruction to the interface card is issued by the computer program to set the Control FF and the Clock Enable FF. The true set-side output of the

Control FF allows an interrupt, if the interrupt system is enabled (IEN signal true), after the data bits have been transferred to the terminal. The true set-side output of the Clock Enable FF allows the External Clock signal to enter the Divider circuit.

3-33. Each time the clear-side output of the C FF of the Divider goes true, the Data Register FFs are clocked. (See figure 3-4.) The clocking continues until all the inputs to gate U66B are true. At this point, the Data Register has been clocked 11 times. The Counter Reset FF is direct cleared at time T3 and stays cleared until the end of T2 on the following machine cycle. At time T5 the Divider FFs are direct cleared, the Clock Enable FF is cleared, and the Flag Buffer FF is set. This provides the necessary conditions for operation under the skip-flag method or the interrupt method, as discussed previously.

3-34. When the first clock pulse is received by the Data Register, the data is shifted down one FF. Since FF U85A was direct cleared when the Clock Enable FF was cleared after the previous operation, a false set-side output of FF U85A is clocked into FF U85B. The true clear-side output of FF U85B provides the start bit, or space condition, to the terminal. The next eight clock pulses shift the data bits stored in the Data Register from the IOBO lines out to the terminal. The last two clock pulses shift out the true, or mark condition, stop bits. The first stop bit was generated by direct setting FF U124B of the Data Register when the last OTA/B instruction was issued. This provided a logic 1 to the set input of FF U125A before the Data Register was clocked. The last stop bit was generated by the mark condition of the input data line which provided a true signal to the set input of FF U124B of the Data Register before the first clock pulse was received.

3-35. Clearing the Clock Enable FF at the end of the data transfer inhibits the External Clock signal from entering the Divider circuit, direct sets FF U85B of the Data Register to maintain the data output line in a mark condition, and direct clears FF U85A of the Data Register to provide the start bit for the next output operation.



2110-4A

Figure 3-4. Output Operation, Timing Diagram




Figure 3-5. Initial Condition After Power Turn-On or Preset, Flow Diagram





Figure 3-6. Interface Card Input Operation, Flow Diagram



NOTES:
 THE ASTERISK (*) INDICATES PROGRAMMED INSTRUCTIONS THAT REQUIRE THE TERMINAL SELECT CODE AND THE IOG SIGNAL TO BE EFFECTIVE.

2110-13A

Figure 3-7. Interface Card Output Operation, Flow Diagram

SECTION IV MAINTENANCE

4-1. INTRODUCTION.

4-2. This section contains information on diagnostics and troubleshooting for the HP 12880A Keyboard-Display Terminal Interface Kit.

4-3. PREVENTIVE MAINTENANCE.

4-4. Detailed preventive maintenance procedures and schedules are provided in the applicable computer documentation. There are no separate preventive maintenance procedures to be performed on the interface kit.

4-5. DIAGNOSTICS.

4-6. The interface card may be checked with a terminal using the diagnostic described in the following appropriate diagnostic reference manual: part no. 24200-90002 for HP 2600A; part no. 02615-90002 for HP 2615A; part no. 02640-90020 for HP 2640; and part no. 02644-90012 for HP 2644.

4-7. TROUBLESHOOTING.

4-8. Troubleshooting for the interface card is accomplished by performing the diagnostic tests in the diagnostic program and analyzing the error halts that occur as the test is being run. Continuity checks of the interconnecting cable may be performed by using table 4-1. To further isolate the trouble, refer to logic diagram and parts location view in figure 4-1. Table 4-2 contains a parts list for the interface card with the parts listed in alphanumeric order by reference designation. Logic and pin location diagrams for the integrated circuits used on the interface card are contained in figure 4-2. Table 4-3 gives the integrated circuit input levels, output levels, and delay times which correspond to the integrated circuit characteristic number shown below each diagram in figure 4-2.

4-9. CABLE ASSEMBLY CONNECTOR PIN FUNCTIONS.


4-10. Table 4-1 contains a list of cable assembly pin assignments for the interface card connector and the terminal connector.

Table 4-1. Wiring List for Interconnecting Cables

| INTERFACE CARD CONNECTOR PINS | TERMINAL CONNECTOR PINS | WIRE COLOR | FUNCTION |
|--|----------------------------|--------------|------------------------------|
| INTERCONNECTING CABLE ASSY 12880-60003 (STANDARD) | | | |
| L | 16 | Orange | External clock from terminal |
| W | 3 | Brown | Data output to terminal |
| X | 2 | White | Data input from terminal |
| BB | 1 | Shield | Ground |
| 17 | 6 | Red | (Not used) |
| 24 | 7 | Black | Ground |
| INTERCONNECTING CABLE ASSY 02640-60058 (OPTION 001) | | | |
| U | E,J | Orange | +12 volts/clear to send |
| W | C | Red | Data output to terminal |
| X | B | Brown | Data input from terminal |
| L | K | Yellow | External clock from terminal |
| 24 | H | Green/Shield | Ground |
| Notes: Jumpers within both interface card connector hoods tie the following pins together: <ul style="list-style-type: none"> a. D, 4, and Y. b. T, 16, and V. | | | |

Table 4-2. Interface Card Replaceable Parts

| REFERENCE DESIGNATION | HP PART NO. | DESCRIPTION | MFR CODE | MFR PART NO. |
|--|-------------|---|----------|--------------------|
| C1 | 0160-2146 | Capacitor, Fxd, Cer, 0.025 uF, +80 -20%, 100 VDCW | 28480 | 0160-2146 |
| C2 | 0160-0153 | Capacitor, Fxd, My, 1000 pF, 10%, 200 VDCW | 28480 | 0160-0153 |
| C3,4,8,10, C12 thru C24 | 0180-0291 | Capacitor, Fxd, Elect, 1 uF, 10%, 35 VDCW | 56289 | 150D105X 9035A2 |
| C5 | 0180-0228 | Capacitor, Fxd, Elect, 22 uF, 10%, 15 VDCW | 28480 | 0180-0228 |
| C6,7 | 0160-0165 | Capacitor, Fxd, My, 0.056 uF, 10% | 28480 | 0160-0165 |
| C9 | 0180-0338 | Capacitor, Fxd, Elect, 25 uF, +75 -10%, 25 VDCW | 28480 | 0180-0338 |
| CR1 | 1902-0022 | Diode, Breakdown, 2.67V | 28480 | 1902-0022 |
| CR2,3* | 1910-0030 | Diode, Ge, 100 mA, 0.65V | 28480 | 1910-0030 |
| CR4,5 | 1910-0022 | Diode, Ge, 5 WIV | 28480 | 1910-0022 |
| CR6,7,8* | 1901-0040 | Diode, Si, 30 mA, 30 WV | 07263 | FDG1088 |
| L1 thru L3 | 9140-0082 | Coil, Fxd, RF, 15 uH | 28480 | 9140-0082 |
| Q1 thru Q3, Q10 thru Q12 | 1854-0094 | Transistor, Si, NPN | 28480 | 1854-0094 |
| Q4,5 | 1854-0215 | Transistor, Si, NPN | 28480 | 1854-0215 |
| Q6,7 | 1853-0036 | Transistor, Si, PNP | 28480 | 1853-0036 |
| Q8,9 | 1853-0058 | Transistor, Si, PNP | 07263 | 2N3644 |
| R1 | 0698-3635 | Resistor, Fxd, Met Ox, 680 ohms, 5%, 2W | 28480 | 0698-3635 |
| R3,21,25 | 0698-0084 | Resistor, Fxd, Flm, 2.15k, 1%, 1/8W | 28480 | 0698-0084 |
| R4 | 0698-3153 | Resistor, Fxd, Flm, 3.83k, 1%, 1/8W | 28480 | 0698-3153 |
| R5 | 0757-0421 | Resistor, Fxd, Flm, 825 ohms, 1%, 1/8W | 28480 | 0757-0421 |
| R6 | 0757-0274 | Resistor, Fxd, Flm, 1.21k, 1%, 1/8W | 28480 | 0757-0274 |
| R7,29 | 0698-3132 | Resistor, Fxd, Flm, 261 ohms, 1%, 1/8W | 28480 | 0698-3132 |
| R8,27,31,42* | 0757-0442 | Resistor, Fxd, Flm, 10.0k, 1%, 1/8W | 28480 | 0757-0442 |
| R9,34,45 | 0698-3155 | Resistor, Fxd, Flm, 4.64k, 1%, 1/8W | 28480 | 0698-3155 |
| R10 | 0698-3154 | Resistor, Fxd, Flm, 4.22k, 1%, 1/8W | 28480 | 0698-3154 |
| R11,28,32,39,48 | 0757-0280 | Resistor, Fxd, Flm, 1k, 1%, 1/8W | 28480 | 0757-0280 |
| R12 | 0698-0090 | Resistor, Fxd, Flm, 464 ohms, 1%, 1/2W | 28480 | 0698-0090 |
| R13 | 1810-0008 | Resistor Network (6 fxd flm resistors) | 28480 | 1810-0008 |
| R14,15,17,18 | 1810-0020 | Resistor Network (7 fxd flm resistors) | 28480 | 1810-0020 |
| R16 | 0757-0394 | Resistor, Fxd, Flm, 51.1 ohms, 1%, 1/8W | 28480 | 0757-0394 |
| R22,24 | 0698-0085 | Resistor, Fxd, Flm, 2.61k, 1%, 1/8W | 28480 | 0698-0085 |
| R23,26 | 0757-0200 | Resistor, Fxd, Flm, 5.62k, 1%, 1/8W | 28480 | 0757-0200 |
| R30 | 0757-1078 | Resistor, Fxd, Flm, 1.47k, 1%, 1/2W | 28480 | 0757-1078 |
| R35 | 0757-0199 | Resistor, Fxd, Flm, 21.5k, 1%, 1/8W | 28480 | 0757-0199 |
| R36 | 0757-0465 | Resistor, Fxd, Flm, 100k, 1%, 1/8W | 28480 | 0757-0465 |
| R37 | 0757-0444 | Resistor, Fxd, Flm, 12.1k, 1%, 1/8W | 28480 | 0757-0444 |
| R38,40 | 0757-0278 | Resistor, Fxd, Flm, 1.78k, 1%, 1/8W | 28480 | 0757-0278 |
| R41 | 2100-1660 | Resistor, Var, WW, 10k, 10%, 1W | 28480 | 2100-1660 |
| R43 | 0698-3440 | Resistor, Fxd, Flm, 196 ohms, 1%, 1/8W | 28480 | 0698-3440 |
| R44 | 0698-3445 | Resistor, Fxd, Flm, 348 ohms, 1%, 1/8W | 28480 | 0698-3445 |
| R46,47 | 0757-1094 | Resistor, Fxd, Flm, 1.47k, 1%, 1/8W | 28480 | 0757-1094 |
| U14,17,27 | 1820-0956 | Integrated Circuit, CTL | 07263 | U6A995679X |
| U15 | 1820-0069 | Integrated Circuit, TTL | 01295 | SN7420N |
| U16,25,34,36,45,46,55,56,76, 86,94,104 | 1820-0054 | Integrated Circuit, TTL | 01295 | SN7400N |
| U24,26,35,44 | 1820-0068 | Integrated Circuit, TTL | 01295 | SN7410N |
| U54,66,84 | 1820-0071 | Integrated Circuit, TTL | 01295 | SN7440N |
| U64,65,74,75 | 1820-0075 | Integrated Circuit, TTL | 01295 | SN7473 |
| U85,95,105,114,115,124,125 | 1820-0077 | Integrated Circuit, TTL | 01295 | SN7474N |
| U96,106,116,126,127 | 1820-0974 | Integrated Circuit, CTL | 28480 | 1820-0974 |
| W1 | 8159-0005 | Jumper Wire | 28480 | 8159-0005 |
| *NOTE: CR7 and CR8 are part no. 1901-0040 on card rev. 1411 and above. CR7 and CR8 are part no. 1910-0030 on card rev. 1017 and below. R42 is part no. 0757-0444 for card rev. 1432 and above. | | | | |



2110-5A

Figure 4-2. Integrated Circuit Diagrams

Table 4-3. Integrated Circuit Characteristics

| CHARACTERISTIC | INPUT LEVEL | | OUTPUT LEVEL | | OPEN INPUT ACTS AS: | MAXIMUM PROPAGATION DELAY | |
|----------------|----------------------|----------------------|----------------------|----------------------|---------------------|---------------------------|-------------------------|
| | LOGIC 1 (VOLTS, MIN) | LOGIC 0 (VOLTS, MAX) | LOGIC 1 (VOLTS, MIN) | LOGIC 0 (VOLTS, MAX) | | TO LOGIC 1 (NANOSECOND) | TO LOGIC 0 (NANOSECOND) |
| 2 | +2.0 | +0.8 | +2.4 | +0.4 | Logic 1 | 29 | 15 |
| 7 (See note 1) | +2.0 | +0.8 | +2.4 | +0.4 | Logic 1 | 50 | 50 |
| 8 | +2.0 | +0.8 | +2.4 | +0.4 | Logic 1 | 35 | 50 |
| 17 | +1.25 | +0.5 | +2.25 | -0.36 | Logic 0 | 18 | 18 |
| 22 | +1.5 | +0.4 | +2.2 | -0.3 | Logic 0 | 24 | 24 |

Note: 1. Required clock pulse width is 20 ns minimum; required direct-clear input is 25 ns minimum.

SECTION V

REPLACEABLE PARTS

5-1. INTRODUCTION.

5-2. This section contains information for ordering replacement parts for the HP 12880A Keyboard-Display Terminal Interface Kit. Table 5-1 lists parts in numeric order by HP part number and lists the following information for each part:

- a. Description of the part. (Refer to table 5-3 for an explanation of abbreviations and reference designations used in the DESCRIPTION column.)
- b. Typical manufacturer of the part in a five-digit code; refer to list of manufacturers in table 5-2.
- c. Manufacturer's part number.
- d. Total quantity of each part used in the interface kit.

5-3. A separate parts list is provided along with the parts location view for the interface card in section IV of this manual. This parts list presents the parts in alpha-numeric order by reference designation.

5-4. ORDERING INFORMATION.

5-5. To order replacement parts, address the order or inquiry to the local Hewlett-Packard Sales and Service Office. (Refer to the list at the end of this manual for addresses.) Specify the following information for each part ordered:

- a. Interface kit model and serial number.
- b. Hewlett-Packard part number for each part.
- c. Description of each part.
- d. Circuit reference designation.

Table 5-1. HP 12880A Keyboard-Display Terminal Interface Kit
Numeric Parts List

| HP PART NO. | DESCRIPTION | MFR CODE | MFR PART NO. | TQ |
|-------------|---|----------|--------------------|-----|
| 0160-0153 | Capacitor, Fxd, My, 1000 pF, 10%, 200 VDCW | 28480 | 0160-0153 | 1 |
| 0160-0165 | Capacitor, Fxd, My, 0.056 uF, 10% | 28480 | 0160-0165 | 2 |
| 0160-2146 | Capacitor, Fxd, Cer, 0.025 uF, +80 -20%, 100 VDCW | 28480 | 0160-2146 | 1 |
| 0180-0228 | Capacitor, Fxd, Elect, 22 uF, 10%, 15 VDCW | 28480 | 0180-0228 | 1 |
| 0180-0291 | Capacitor, Fxd, Elect, 1 uF, 10%, 35 VDCW | 56289 | 150D105X 9035A2 | 17 |
| 0180-0338 | Capacitor, Fxd, Elect, 25 uF, +75 -10%, 25 VDCW | 28480 | 0180-0338 | 1 |
| 0698-0084 | Resistor, Fxd, Flm, 2.15k, 1%, 1/8W | 28480 | 0698-0084 | 3 |
| 0698-0085 | Resistor, Fxd, Flm, 2.61k, 1%, 1/8W | 28480 | 0698-0085 | 2 |
| 0698-0090 | Resistor, Fxd, Flm, 464 ohms, 1%, 1/2W | 28480 | 0698-0090 | 1 |
| 0698-3132 | Resistor, Fxd, Flm, 261 ohms, 1%, 1/8W | 28480 | 0698-3132 | 2 |
| 0698-3153 | Resistor, Fxd, Flm, 3.83k, 1%, 1/8W | 28480 | 0698-3153 | 1 |
| 0698-3154 | Resistor, Fxd, Flm, 4.22k, 1%, 1/8W | 28480 | 0698-3154 | 1 |
| 0698-3155 | Resistor, Fxd, Flm, 4.64k, 1%, 1/8W | 28480 | 0698-3155 | 3 |
| 0698-3440 | Resistor, Fxd, Flm, 196 ohms, 1%, 1/8W | 28480 | 0698-3440 | 1 |
| 0698-3445 | Resistor, Fxd, Flm, 348 ohms, 1%, 1/8W | 28480 | 0698-3445 | 1 |
| 0698-3635 | Resistor, Fxd, Met Ox, 680 ohms, 5%, 2W | 28480 | 0698-3635 | 1 |
| 0757-0199 | Resistor, Fxd, Flm, 21.5k, 1%, 1/8W | 28480 | 0757-0199 | 1 |
| 0757-0200 | Resistor, Fxd, Flm, 5.62k, 1%, 1/8W | 28480 | 0757-0200 | 2 |
| 0757-0274 | Resistor, Fxd, Flm, 1.21k, 1%, 1/8W | 28480 | 0757-0274 | 1 |
| 0757-0278 | Resistor, Fxd, Flm, 678k, 1%, 1/8W | 28480 | 0757-0278 | 2 |
| 0757-0280 | Resistor, Fxd, Flm, 1k, 1%, 1/8W | 28480 | 0757-0280 | 5 |
| 0757-0394 | Resistor, Fxd, Flm, 51.1 ohms, 1%, 1/8W | 28480 | 0757-0394 | 1 |
| 0757-0421 | Resistor, Fxd, Flm, 825 ohms, 1%, 1/8W | 28480 | 0757-0421 | 1 |
| 0757-0442 | Resistor, Fxd, Flm, 10.0k, 1%, 1/8W | 28480 | 0757-0442 | 4** |
| 0757-0444 | Resistor, Fxd, Flm, 12.1k, 1%, 1/8W | 28480 | 0757-0444 | 1** |
| 0757-0465 | Resistor, Fxd, Flm, 100k, 1%, 1/8W | 28480 | 0757-0465 | 1 |
| 0757-1078 | Resistor, Fxd, Flm, 1.47k, 1%, 1/2W | 28480 | 0757-1078 | 1 |
| 0757-1094 | Resistor, Fxd, Flm, 647k, 1%, 1/8W | 28480 | 0757-1094 | 2 |
| 1480-0116 | Pin, Grooved | 28480 | 1480-0116 | 2 |
| 1810-0008 | Resistor Network (6 fxd flm resistors) | 28480 | 1810-0008 | 1 |
| 1810-0020 | Resistor Network (7 fxd flm resistors) | 28480 | 1810-0020 | 4 |
| 1820-0054 | Integrated Circuit, TTL | 01295 | SN7400N | 12 |
| 1820-0068 | Integrated Circuit, TTL | 01295 | SN7410N | 4 |
| 1820-0069 | Integrated Circuit, TTL | 01295 | SN7420N | 1 |
| 1820-0071 | Integrated Circuit, TTL | 01295 | SN7440N | 3 |
| 1820-0075 | Integrated Circuit, TTL | 01295 | SN7473 | 4 |
| 1820-0077 | Integrated Circuit, TTL | 01295 | SN7474N | 7 |
| 1820-0956 | Integrated Circuit, CTL | 07263 | U6A995679X | 3 |
| 1820-0974 | Integrated Circuit, CTL | 28480 | 1820-0974 | 5 |
| 1853-0036 | Transistor, Si, PNP | 28480 | 1853-0036 | 2 |
| 1853-0058 | Transistor, Si, PNP | 07263 | 2N3644 | 2 |
| 1854-0094 | Transistor, Si, NPN | 28480 | 1854-0094 | 6 |
| 1854-0215 | Transistor, Si, NPN | 28480 | 1854-0215 | 2 |
| 1901-0040 | Diode, Si, 30 mA, 30 WV | 28480 | 1901-0040 | 3* |
| 1902-0022 | Diode, Breakdown, 2.67V | 28480 | 1902-0022 | 1 |
| 1910-0022 | Diode, Ge, 5 WIV | 28480 | 1910-0022 | 2 |
| 1910-0030 | Diode, Ge, 100 mA, 0.65V | 28480 | 1910-0030 | 2* |
| 2100-1660 | Resistor, Var, WW, 10k, 10%, 1W | 28480 | 2100-1660 | 1 |
| 8159-0005 | Jumper Wire | 28480 | 8159-0005 | 1 |
| 9140-0082 | Coil, Fxd, RF, 15 uH | 28480 | 9140-0082 | 3 |

Table 5-1. HP 12880A Keyboard-Display Terminal Interface Kit
Numeric Parts List (Continued)

| HP PART NO. | DESCRIPTION | MFR CODE | MFR PART NO. | TQ |
|---|--|----------|--------------|----|
| 5040-6065 | PC Extractor | 28480 | 5040-6065 | 2 |
| 02640-60058 | Cable Assy (Option 001 only) | 28480 | 02640-60058 | 1 |
| 12880-60001 | Circuit Card, Keyboard-Display Terminal Interface | 28480 | 12880-60001 | 1 |
| 12880-60003 | Cable Assembly | 28480 | 12880-60003 | 1 |
| 12880-90001 | 12880A Operating and Service Manual | 28480 | 12880-90001 | 1 |
| NOTE: *TQ for card rev. 1017 and below is 1 for part no. 1901-0040 and 4 for part no. 1910-0030. Quantities shown are for card rev. 1411. **TQ for card rev. 1432 and above is 3 for part no. 0757-0442 and 2 for part no. 0757-0444. | | | | |

Table 5-2. Code List of Manufacturers

| The following code numbers are from the Federal Supply Code for Manufacturers Cataloging Handbooks H4-1 and H4-2, and the latest supplements. | | | | | |
|---|--|----------------|----------|----------------------|--------------------|
| Code No. | Manufacturer | Address | Code No. | Manufacturer | Address |
| 01295 | Texas Instruments, Inc. | | 28480 | Hewlett-Packard Co. | |
| | Transistor Products Division | Dallas, Texas | | | Palo Alto, Cal. |
| 07263 | Fairchild Camera & Inst. Corp., | | 56289 | Sprague Electric Co. | |
| | Semiconductor Division | Mt. View, Cal. | | | North Adams, Mass. |

Table 5-3. Reference Designations and Abbreviations

| REFERENCE DESIGNATIONS | | |
|----------------------------------|---|---|
| A = assembly | K = relay | TB = terminal board |
| B = motor | L = inductor | TP = test point |
| BT = battery | M = meter | U = integrated circuit |
| C = capacitor | MC = microcircuit | V = vacuum tube, neon bulb, photocell, etc. |
| CR = diode | P = plug connector | VR = voltage regulator |
| DL = delay line | Q = transistor | W = cable, jumper |
| DS = indicator (lamp) | R = resistor | X = socket |
| E = misc hardware | RT = thermistor | Y = crystal |
| F = fuse | S = switch | Z = tuned cavity, network |
| FL = filter | T = transformer | |
| J = receptacle connector | | |
| ABBREVIATIONS | | |
| A = amperes | gnd = ground(ed) | ph = Phillips head |
| ac = alternating current | gra = gray | pk = peak |
| ad = anode | grn = green | p-p = peak-to-peak |
| Al = aluminum | H = henries | pt = point |
| AR = as required | Hg = mercury | PIV = peak inverse voltage |
| adj = adjust | hr = hour(s) | PNP = positive-negative-positive |
| Assy = assembly | Hz = hertz | PWV = peak working voltage |
| B = base | hdw = hardware | porc = porcelain |
| bp = bandpass | hex = hexagon, hexagonal | posn = position(s) |
| bfo = beat frequency oscillator | ID = inside diameter | pozi = pozidrive |
| blk = black | IF = intermediate frequency | ph brz = phosphor bronze |
| blu = blue | in. = inch, inches | rf = radio frequency |
| brn = brown | I/O = input/output | rdh = round head |
| brs = brass | int = internal | rmo = rack mount only |
| Btu = British thermal unit | incl = include(s) | rms = root-mean-square |
| bwc = backward wave oscillator | insul = insulation, insulated | RWV = reverse working voltage |
| Be Cu = beryllium copper | impgrg = impregnated | rect = rectifier |
| C = collector | incand = incandescent | r/min = revolutions per minute |
| cw = clockwise | k = kilo (10^3), kilohm | s = second |
| ccw = counterclockwise | lp = low pass | SB = slow-blow |
| cer = ceramic | m = milli (10^{-3}) | Se = selenium |
| cmo = cabinet mount only | M = mega (10^6), megohm | Si = silicon |
| com = common | My = Mylar | scr = silicon-controlled rectifier |
| crt = cathode-ray tube | mfr = manufacturer | sil = silver |
| CTL = capacitor-transistor logic | mom = momentary | sst = stainless steel |
| cath = cathode | mtg = mounting | stl = steel |
| cd pl = cadmium plate | misc = miscellaneous | spcl = special |
| Comp = composition | met ox = metal oxide | spdt = single-pole, double-throw |
| conn = connector | mintr = miniature | spst = single-pole, single-throw |
| compl = complete | n = nano (10^{-9}) | semicond = semiconductor |
| dc = direct current | nc = normally closed or no connection | Ta = tantalum |
| dr = drive | Ne = neon | td = time delay |
| DTL = diode-transistor logic | no. = number or normally open | Ti = titanium |
| depc = deposited carbon | np = nickel plated | tgl = toggle |
| dpdt = double-pole, double-throw | NPN = negative-positive-negative | thd = thread |
| dpst = double-pole, single-throw | NPO = negative positive zero (zero temperature coefficient) | tol = tolerance |
| E = emitter | NSR = not separately replaceable | TTL = transistor-transistor logic |
| ext = external | NRFR = not recommended for field replacement | term = terminal |
| encap = encapsulated | OD = outside diameter | U (μ) = micro (10^{-6}) |
| elctlt = electrolytic | OBD = order by description | V = volt(s) |
| F = farads | orn = orange | var = variable |
| FF = flip-flop | ovh = oval head | vio = violet |
| flh = flat head | oxd = oxide | VDCW = direct current working volts |
| flm = film | p = pico (10^{-12}) | W = watts |
| fxd = fixed | PC = printed circuit | ww = wirewound |
| filh = fillister head | | wht = white |
| G = giga (10^9) | | WIV = working inverse voltage |
| Ge = germanium | | yel = yellow |
| gl = glass | | |



SALES & SERVICE OFFICES

UNITED STATES

ALABAMA
8290 Whitesburg Dr., S.E.
P.O. Box 4207
Huntsville 35802
Tel: (205) 881-4591
TWX: 810-726-2204
Medical Only
228 W. Valley Ave.,
Room 302
Birmingham 35209
Tel: (205) 879-2081/2

ARIZONA
2336 E. Magnolia St.
Phoenix 85034
Tel: (602) 244-1361
TWX: 910-951-1331
2424 East Aragon Rd.
Tucson 85706
Tel: (602) 889-4661

***ARKANSAS**
Medical Service Only
Little Rock 72205
Tel: (501) 664-8773

CALIFORNIA
1430 East Orangethorpe Ave.
Fullerton 92631
Tel: (714) 870-1000
TWX: 910-592-1288
3939 Lankershim Boulevard
North Hollywood 91604
Tel: (213) 877-1282
TWX: 910-499-2170
6305 Arizona Place
Los Angeles 90045
Tel: (213) 649-2511
TWX: 910-328-6147
*Los Angeles
Tel: (213) 776-7500
3003 Scott Boulevard
Santa Clara 95050
Tel: (408) 249-7000
TWX: 910-338-0518
*Ridgecrest
Tel: (714) 446-6165
2220 Watt Ave.
Sacramento 95825
Tel: (916) 482-1463
TWX: 910-367-2092

9606 Aero Drive
P.O. Box 23333
San Diego 92123
Tel: (714) 279-3200
TWX: 910-335-2000
Calculators Only
601 California St.
San Francisco 94108
Tel: (415) 989-8470

COLORADO
5600 South Ulster Parkway
Englewood 80110
Tel: (303) 771-3455
TWX: 910-935-0705

CONNECTICUT
12 Lunar Drive
New Haven 06525
Tel: (203) 389-6551
TWX: 710-465-2029

FLORIDA
P.O. Box 24210
2808 W. Oakland Park Blvd.
FL. Lauderdale 33307
Tel: (305) 731-2020
TWX: 510-955-4099
*Jacksonville
Medical Service Only
Tel: (904) 725-6333
P.O. Box 13910
6177 Lake Ellenor Dr.
Orlando 32809
Tel: (305) 859-2900
TWX: 810-850-0113
21 East Wright St.
Suite 1
Pensacola 32501
Tel: (904) 434-3081

GEORGIA
P.O. Box 28234
450 Interstate North
Atlanta 30328
Tel: (404) 434-4000
TWX: 810-766-4890

HAWAII
2875 So. King Street
Honolulu 96814
Tel: (808) 955-4455

ILLINOIS
5500 Howard Street
Skokie 60076
Tel: (312) 677-0400
TWX: 910-223-3613
*St. Joseph
Tel: (217) 469-2133

INDIANA
7301 North Shadeland Ave.
Indianapolis 46250
Tel: (317) 842-1000
TWX: 810-260-1796

IOWA
1902 Broadway
Iowa City 52240
Tel: (319) 338-9466
Night: (319) 338-9467

***KANSAS**
Derby
Tel: (316) 267-3655

LOUISIANA
P.O. Box 840
3239 Williams Boulevard
Kenner 70062
Tel: (504) 721-6201
TWX: 810-955-5524

KENTUCKY
Medical/Calculator Only
8003 Troutwood Court
Louisville 40291
Tel: (502) 426-4341

MARYLAND
6707 Whitestone Road
Baltimore 21207
Tel: (301) 944-5400
TWX: 710-862-9157
4 Choke Cherry Road
Rockville 20850
Tel: (301) 948-6370
TWX: 710-828-9685
P.O. Box 1648
2 Choke Cherry Road
Rockville 20850
Tel: (301) 948-6370
TWX: 710-828-9684

MASSACHUSETTS
32 Hartwell Ave.
Lexington 02173
Tel: (617) 861-8960
TWX: 910-326-6904

MICHIGAN
23855 Research Drive
Farmington 48024
Tel: (313) 476-6400
TWX: 810-242-2900

MINNESOTA
2400 N. Prior Ave.
Roseville 55113
Tel: (612) 636-0700
TWX: 910-563-3734

MISSISSIPPI
*Jackson
Medical Service Only
Tel: (601) 982-9363

MISSOURI
11313 Colorado Ave.
Kansas City 64137
Tel: (816) 763-8000
TWX: 910-771-2087
148 Weldon Parkway
Maryland Heights 63043
Tel: (314) 567-1455
TWX: 910-764-0830

NEBRASKA
Medical Only
11902 Elm Street
Suite 4C
Omaha 68144
Tel: (402) 333-6017

NEW JERSEY
W. 120 Century Rd.
Paramus 07652
Tel: (201) 265-5000
TWX: 710-990-4951

NEW MEXICO
P.O. Box 11634
Station E
11300 Lomas Blvd., N.E.
Albuquerque 87123
Tel: (505) 292-1330
TWX: 910-989-1185

156 Wyatt Drive
Las Cruces 88001
Tel: (505) 526-2485
TWX: 910-983-0550

NEW YORK
6 Automation Lane
Computer Park
Albany 12205
Tel: (518) 458-1550
TWX: 710-441-8270
Calculators Only
1251 Avenue of the Americas
Floor 32 - Suite 3296
New York City 10020
Tel: (212) 265-5575
*New York City
Manhattan, Bronx
Contact Paramus, NJ Office
Tel: (201) 265-5000
Brooklyn, Queens, Richmond
Contact Woodbury, NY Office
Tel: (516) 921-0300
201 South Avenue
Poughkeepsie 12601
Tel: (914) 454-7330
TWX: 510-248-0012
39 Saginaw Drive
Rochester 14623
Tel: (716) 473-9500
TWX: 510-253-5981
5858 East Molloy Road
Syracuse 13211
Tel: (315) 455-2486
TWX: 710-541-0482
1 Crossways Park West
Woodbury 11797
Tel: (516) 921-0300
TWX: 510-221-2168
NORTH CAROLINA
P.O. Box 5186
1923 North Main Street
High Point 27262
Tel: (919) 885-8101
TWX: 510-926-1516

OHIO
16500 Sprague Road
Cleveland 44130
Tel: (216) 243-7300
Night: 243-7305
TWX: 810-423-9431

330 Progress Rd.
Dayton 45449
Tel: (513) 859-8202
TWX: 910-459-1925
1041 Kingsmill Parkway
Columbus 43229
Tel: (614) 436-1041

OKLAHOMA
P.O. Box 32008
Oklahoma City 73132
Tel: (405) 721-0200
TWX: 910-830-6862

OREGON
17890 SW Boones Ferry Road
Tualatin 97062
Tel: (503) 620-3350
TWX: 910-467-8714

PENNSYLVANIA
111 Zeta Drive
Pittsburgh 15238
Tel: (412) 782-0400
Night: 782-0401
TWX: 710-795-3124
1021 8th Avenue
King of Prussia Industrial Park
King of Prussia 19406
Tel: (215) 265-7000
TWX: 510-660-2670

SOUTH CAROLINA
6941-O N. Trenholm Road
Columbia 29260
Tel: (803) 782-6493

TENNESSEE
*Memphis
Medical Service Only
Tel: (901) 274-7472
*Nashville
Medical Service Only
Tel: (615) 244-5448

TEXAS
P.O. Box 1270
201 E. Arapahoe Rd.
Richardson 75080
Tel: (214) 231-6101
TWX: 910-867-4723

P.O. Box 27409
6300 Westpark Drive
Suite 100
Houston 77027
Tel: (713) 781-6000
TWX: 910-881-2645
205 Billy Mitchell Road
San Antonio 78226
Tel: (512) 434-8241
TWX: 910-871-1170

UTAH
2160 South 3720 West Street
Salt Lake City 84119
Tel: (801) 487-0715

VIRGINIA
Medical Only
P.O. Box 12778
No. 7 Koger Exec. Center
Suite 212
Norfolk 23502
Tel: (804) 497-1026/7
P.O. Box 9854
2914 Hungary Springs Road
Richmond 23238
Tel: (804) 285-3431
TWX: 710-956-0157

WASHINGTON
Bellevue Office Pk.
1203-114th SE
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2446

***WEST VIRGINIA**
Medical/Analytical Only
Charleston
Tel: (304) 345-1640

WISCONSIN
9004 West Lincoln Ave.
West Allis 53227
Tel: (414) 541-0550

FOR U.S. AREAS NOT LISTED:
Contact the regional office nearest you. Atlanta, Georgia, North Hollywood, California, Rockville, (4 Choke Cherry Rd.) Maryland, Skokie, Illinois. Their complete addresses are listed above.

*Service Only

CANADA

ALBERTA
Hewlett-Packard (Canada) Ltd.
11748 Kingsway Ave.
Edmonton T5G 0X5
Tel: (403) 452-3670
TWX: 610-831-2431
Hewlett-Packard (Canada) Ltd.
915-42 Avenue S.E. Suite 102
Calgary T2G 1Z1
Tel: (403) 287-1672

BRITISH COLUMBIA
Hewlett-Packard (Canada) Ltd.
837 E. Cordova Street
Vancouver V6A 3R2
Tel: (604) 254-0531
TWX: 610-822-5059

MANITOBA
Hewlett-Packard (Canada) Ltd.
513 Century St.
St. James
Winnipeg R3H 0L8
Tel: (204) 786-7581
TWX: 610-671-3531

NOVA SCOTIA
Hewlett-Packard (Canada) Ltd.
800 Windmill Road
Dartmouth B3B 1L1
Tel: (902) 469-7820

ONTARIO
Hewlett-Packard (Canada) Ltd.
1785 Woodward Dr.
Ottawa K2C 0P9
Tel: (613) 225-6530
TWX: 610-562-8966
Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
Mississauga L4V 1L9
Tel: (416) 298-9430
TWX: 610-492-4246

QUEBEC
Hewlett-Packard (Canada) Ltd.
275 Hymus Blvd.
Pointe Claire H9R 1G7
Tel: (514) 697-4232
TWX: 610-422-3022
TLX: 05-821521 HPCL

Hewlett-Packard (Canada) Ltd.
2376 Galvani Street
Ste-Foy G1M 4G4
Tel: (418) 688-8710

FOR CANADIAN AREAS NOT LISTED:
Contact Hewlett-Packard (Canada) Ltd. in Mississauga.

CENTRAL AND SOUTH AMERICA

ARGENTINA
Hewlett-Packard Argentina
S.A.C.e.I.
Lavalle 1171-3° Piso
Buenos Aires
Tel: 35-0436, 35-0627, 35-0341
Telex: 012-1009
Cable: HEWPACK ARG

BOLIVIA
Stambuk & Mark (Bolivia) Ltda.
Av. Mariscal, Santa Cruz 1342
La Paz
Tel: 40626, 53163, 52421
Telex: 3560014
Cable: BUKMAR

BRAZIL
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Frei Caneca, 1, 152-Bela Vista
01307-São Paulo-SP
Tel: 288-71-11, 287-81-20,
287-61-93
Telex: 309151/2/3
Cable: HEWPACK São Paulo

Hewlett-Packard Do Brasil
I.E.C. Ltda.
Praca Dom Feliciano, 78-8°
andar (Sala 806/8)
9000-Porto Alegre-RS
Tel: 25-84-70-DDD (0512)
Cable: HEWPACK Porto Alegre
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Siqueira Campos, 53, 4°
andar Copacabana
2000-Rio de Janeiro-GB
Tel: 257-80-94-DDD (021)
Telex: 2100 79 HEWPACK
Cable: HEWPACK
Rio de Janeiro

CHILE
Calcaín y Metcalfe Ltda.
Calle Lira 81, Oficina 5
Casilla 2118
Santiago, 1
Tel: 398613
Cable: CALMET

COLOMBIA
Instrumentación
Henrik A. Langebaek & Kier S.A.
Carrera 7 No. 48-59
Apartado Aéreo 6287
Bogotá, 1 D.E.
Tel: 45-78-06, 45-55-46
Cable: AARS Bogota
Telex: 44400INSTCO

COSTA RICA
Cienciafi Costarricense S.A.
Apartado 10159
San José
Tel: 21-86-13
Cable: GALGUR San José

GUATEMALA
IPESA
Avenida La Reforma 3-48,
Zona 9
Guatemala
Tel: 63627, 64786
Telex: 4192 TELTRU GU

MEXICO
Hewlett-Packard Mexicana,
S.A. de C.V.
Torres Adalid No. 21, 11° Piso
Col. del Valle
Mexico 12, D.F.
Tel: (905) 543-42-32
Telex: 017-74-507
Hewlett-Packard Mexicana,
S.A. de C.V.
Ave. Constitución No. 2184
Monterrey, N.L.
Tel: 48-71-32, 48-71-84

NICARAGUA
Roberto Terán G.
Apartado Postal 689
Edificio Terán
Managua
Tel: 3451, 3452
Cable: ROTERAN Managua

PANAMA
Electrónico Balboa, S.A.
P.O. Box 4929
Calle Samuel Lewis
Ciudad de Panama
Tel: 64-2700
Telex: 3431103 Curunda,
Canal Zone
Cable: ELECTRON Panama

PERU
Compañía Electro Médica S.A.
Ave. Enrique Canaval 312
San Isidro
Casilla 1030
Lima
Tel: 22-3900
Cable: ELMED Lima

PUERTO RICO
San Juan Electronics, Inc.
P.O. Box 5167
Ponce de León 154
Pda. 3-PTA de Tierra
San Juan 00906
Tel: (809) 725-3342, 722-3342
Cable: SATRONICS San Juan
Telex: SATRON 3450 332

URUGUAY
Pablo Ferrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel: 40-3102
Cable: RADIUM Montevideo

VENEZUELA
Hewlett-Packard de Venezuela
C.A.
Apartado 50933
Edificio Segre
Tercera Transversal
Los Ruices Norte
Caracas 107
Tel: 35-00-11
Telex: 21146 HEWPACK
Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT:
Hewlett-Packard Inter-Americas
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
TWX: 910-373-1260
Cable: HEWPACK Palo Alto
Telex: 034-8300, 034-8493

CERTIFICATION

Products, materials, parts, and services furnished on this order have been provided in accordance with all applicable Hewlett-Packard specifications. Actual inspection and test data pertaining to this order is on file and available for examination.

Hewlett-Packard's calibration measurements are traceable to the National Bureau of Standards to the extent allowed by the Bureau's calibration facilities.

The Hewlett-Packard Quality Program satisfies the requirements of MIL-Q-9858, MIL-I-45208, and MIL-C-45662.



MANUAL PART NO. 12880-90001
MICROFISCHE PART NO. 12880-90006

PRINTED IN U.S.A.